




**OMNTEC**  
Advanced Tank Monitoring & Leak Detection



1. Open the camera app
2. Focus the camera on the QR code by gently tapping the code
3. Follow the instructions on the screen to view PDF file

# OEL8000III-K | OEL8000III-X

## PROGRAMMING MANUAL



### PROTEUS® Series TANK GAUGING SYSTEM GenIV

Revision 1.4

Document No. DOC00008

OMNTEC® Mfg., Inc. has been certified  
by DQS Inc. to ISO 9001:2015

## TABLE OF CONTENTS

1.	Navigating To Setup.....	3
2.	System Units .....	4
3.	Printer Settings .....	5
4.	Shift Time Settings .....	6
5.	Misc. Settings.....	7
6.	Tank Parameters.....	9
7.	Tank Alarm Settings .....	11
8.	Tank Table (Strapping) .....	12
9.	Tank Drop and Other .....	13
10.	Tank Colors and Orientation.....	16
11.	Copy Tank Parameters.....	17
12.	BX-Sensor Control.....	18
13.	BX-Sensor Parameters .....	20
14.	Comm Ports .....	22
15.	Modbus.....	24
16.	Network Properties .....	25
17.	DataCheck™ Settings .....	27
18.	Interface Boards and Relays .....	28
19.	Clear Logs.....	35
20.	Backup System Parameters .....	35
21.	Restore System Parameters .....	36
22.	VLD – Leak System Settings .....	37
23.	VLD – Leak Tank Settings .....	38
24.	CITLD – Leak System Settings .....	40
25.	Line Leak Detection .....	41
26.	Print System Parameters .....	46
27.	Time/Date Format .....	47
28.	Software Update .....	47
29.	Email Account.....	48
30.	Email Setup.....	49

## 1. Navigating To Setup

### Home Screen:

The SETUP MENU is located via UTILITIES.

(See Figure 1.1)

**Note:** Figure 1.1 is the factory-default Home Screen.

To change the Home Screen:  
Go to Section 5 of this document;  
page 2 of MISCELLANEOUS  
SETTINGS.

(See Figure 5.2)




Figure 1.1

### Utilities Screen:

To enter SETUP, press the SETUP MENU icon.

(See Figure 1.2)




Figure 1.2

### Enter Password:

Enter the current Setup Menu password. The manufacturer's default password is **000000** (six zeros).

(See Figure 1.3)



Figure 1.3

### Setup Menu (Page 1):

Used to navigate corresponding system setup options. Press the down arrow, on the right, to access SETUP MENU (PAGE 2). (See Figure 1.4)




Figure 1.4

### Setup Menu (Page 2):

Used to navigate additional system setup options. You can press the up arrow (right side of screen), or back button (U-turn arrow, bottom right), to go back to SETUP MENU (PAGE 1). (See Figure 1.5)




Figure 1.5

## 2. System Units

### Set Units of Measurement:

Individually select units desired for volume, level, and temperature. All three can be set by selecting either US or METRIC option on the left side of this screen.

The SAVE button, on the right side of this screen, must be pressed to save any changes made. (See Figure 2.1)

**Note:** Any changes to SYSTEM UNITS will prompt the controller to reset itself.




Figure 2.1



### 3. Printer Settings

Offers the ability to input and edit PRINT LINE HEADERS, and features printer functions.  
(See Figure 3.1)

**Note:** The factory default is set for the local onboard printer (if installed). Network printing must be set up using the PROTEUS® web server page. Refer to [document 500185](#) (*Printing Via CUPS Interface*), available at [www.omntec.com](http://www.omntec.com).

02:55:29PM 10/12/2023 Status: **SETUP**

**PRINTER SETTINGS**

**PRINT LINE HEADERS**

PRINT HEADER LINE 1: OMNTEC Mfg., Inc.

PRINT HEADER LINE 2: 2420 Pond Rd.

PRINT HEADER LINE 3: Ronkonkoma, NY 11779

PRINT HEADER LINE 4: 1 (631) 981-2001  
(30 Characters per line)

**PRINTER FUNCTIONS**

Restart Printer Reset Printer To Factory Default

Default: Internal Printer  
Select/Program an external printer from the Proteus's web page(Setup->PRINTER SETUP)

SETUP  
NEXT PAGE

Figure 3.1

- Print Line Headers:** Typically, site-specific information that is printed on the system status report header and displayed on the web server's System Status Menu page. Examples of the information entered here are site name, site address, site phone number, manager's name, and other relevant site-specific details.
- Restart Printer:** Restarts the onboard printer to help resolve printer pause due to a printer error. You are prompted to choose YES or NO.
- Reset Printer To Factory Default:** Deletes all network printers associated with the PROTEUS controller. Activates the default onboard printer (if one is present).

## 4. Shift Time Settings

### Shift Time Settings:

Setup for generating daily shift reports.

(See Figure 4.1)

Jun 07, 2023 08:48:06 Status: **SETUP**

### SHIFT TIME SETTINGS

NUMBER OF SHIFTS:

AUTO PRINT:

SHIFT END TIMES

SHIFT 1  :

SHIFT 2  :

SHIFT 3  :

SHIFT 4  :

(TIME: 00:00 TO 23:59)

SETUP

NEXT PAGE

Figure 4.1

- a) **Number Of Shifts:** Number of shift reports generated daily.
- b) **Auto Print:** Will enable or disable an automatic printout at each shift's end time.
- c) **Shift End Times:** End times for the number of shifts that were selected. If multiple shifts are selected, the end time of the last shift is the open time of the next shift.

## 5. Misc. Settings

### Miscellaneous Settings:

Settings for remote horn and alarms, and available auto printouts. The SETUP MENU password can be changed here as well.

Press MISC. PAGE 2 (right side of screen), to advance to page 2 of MISCELLANEOUS SETTINGS for additional settings.  
(See Figure 5.1)

Figure 5.1

- a) **Remote Horn Timeout:** Amount of time the horn will sound before automatically silencing.
- b) **Remote Horn Timeout Enable:** Used to enable or disable the horn timeout.
- c) **Remote Alarm ACK Timeout:** Amount of time before re-sounding the horn after it is silenced.
- d) **Ullage Percentage:** The percentage of the tank's total capacity used to calculate the empty space in the tank. This is used to avoid overfilling the tank (e.g., if ULLAGE PERCENTAGE is set to 90%, the ullage will read 0 gallons when the volume reaches 90% of the tank).
- e) **Setup Password:** To change the SETUP MENU password, press the white field. A keypad will appear. Enter a new password. When finished, press the SAVE button.
- f) **Alarm Auto Printout:** Used to enable or disable an automatic printout of an Alarm report.
- g) **Drop Auto Printout:** Used to enable or disable the automatic printout of a Drop report.
- h) **Shift Auto Printout:** Used to enable or disable the automatic printout of a Shift report.
- i) **VLD Auto Printout:** Used to enable or disable the automatic printout of a VLD report.
- j) **Interstitial Auto Printout:** Used to enable or disable the automatic printout of an interstitial sensor weekly report.

### Miscellaneous Settings (page 2):

Additional settings to adjust the Home Screen and page change to delivery in progress.

(See Figure 5.2)

- a) **Home Screen:** Choose which page you would like to set as the Home Screen. Use the dropdown (▼) to choose from SYSTEM STATUS, 4-TANK INVENTORY, 1-TANK INVENTORY, or ZOOM INVENTORY.

(See Figure 5.3)




Figure 5.2




Figure 5.3

- b) **Home Screen Tank #:** If a 1-Tank or Zoom Inventory page is chosen, this will select which tank is shown.
- c) **Delivery Page Change:** Automatically wakes up the display to show a tank with delivery in progress.
- d) **Backlight Timeout:** This can be changed to dim the display between 1 and 255 minutes. It can also be set to zero which leaves the display always on. *Note: leaving the display always on will shorten the life of the display.*
- e) **Inventory Logging:** Saves data every specified minute (select from 1 to 255 minutes; input 0 to disable this feature). This feature keeps the last 30 days of data before auto-clearing out the oldest logs. These logs are accessible via the controller's web server, through the REPORTS icon.
- f) **Backlight Adjustment:** Adjusts the backlight brightness for all display screens. The SAVE button must be pressed to set this adjusted parameter.
- g) **Information Icon** (i in circle): This will display a scrollable screen and details what each parameter does within MISCELLANEOUS SETTINGS.

(See Figure 5.4).




Figure 5.4

## 6. Tank Parameters

### Setup - Tank Parameters:

Various parameters that are needed to obtain proper and accurate functionality.

(See Figure 6.1)

- a) **Tank Number:** Selects the tank whose parameters are being set up or adjusted.
- b) **Product Type:** Labels the contents of the tank (max of 40 characters).
- c) **Product Null:** Amount subtracted from the gauging probe product level measurement to match the actual product level measurement (enter product height from stick reading).
- d) **Water Null:** Amount subtracted from the gauging probe water level measurement to match the actual water level measurement (enter water height from stick reading).
- e) **Enable/Disable:** Enable or disable the corresponding tank.
- f) **Tank Capacity:** Total volume of the tank (obtained from the manufacturer's tank chart).
- g) **Tank Diameter:** Height of the tank (highest point on the manufacturer's tank chart).
- h) **Probe Length:** Overall probe length (in inches). Found in the CAT No. on the head of the probe, the last three numbers following **L** (see Figure 6.2; blue rectangle).
- i) **Wire Speed:** Factory-defined wire speed. Obtained from the probe label on the head of the probe following **WS:** (see Figure 6.2; pink rectangle).
- j) **Volume Correction:** Brings you to the Volume Correction page where you can choose from COEFFICIENT THERMAL EXPANSION, API GRAVITY, RELATIVE DENSITY or DENSITY. (See next page for additional Volume Correction details).
- k) **Probe Type:** Shows how many temperature thermistors are in the probe associated with that tank. This is obtained from the CAT No. on the head of the probe (see Figure 6.2; green square). **R1** or **T1**; enter 1. **R5**; enter 5. If using a "redhead" probe; enter 4.
- l) **Volume Offset:** Amount added to the volume reading for further calibration.

Figure 6.1

Enter corresponding values in each box. Press the NEXT PAGE icon to continue programming the alarm parameters on that same tank.

**Note:** Figure 6.2 (red square) represents the number of floats on that probe. **F1** = one float, **F2** = two floats.



Figure 6.2

**Volume Correction (cont. from 6i):**  
 After selecting volume correction,  
 you can select which correction  
 method you will use.  
 (See Figure 6.3).

Figure 6.3

Select the Correction Method button and set either the COEFFICIENT THERMAL EXPANSION, API GRAVITY, RELATIVE DENSITY, or DENSITY option fields (middle column). Use the data format shown (right column) to input to the Coeff., Gravity or Density field (top right column). Thermal coefficient of expansion x 10<sup>-5</sup> (obtained from thermal coefficient table (e.g., Gasoline = 70, Diesel = 45, etc.).

You may also remove the water volume from the temperature compensated measurement by pressing the check box (this will show as net volume) in the bottom left column.

## 7. Tank Alarm Settings

### Tank Alarms And Set Points:

The parameters used to control how the alarms will function.

(See Figure 7.1)

Jun 07, 2023 09:15:05 Status: **SETUP**

### TANK ALARMS AND SET POINTS

TANK NUMBER 01	LOW PRODUCT 15.00 %	PROBE HIGH TEMP 302.00 F
HIGH PRODUCT 90.00 %	DELIVERY NEEDED 0.00 %	PROBE LOW TEMP -40.00 F
OVERFILL 90.00 %	HIGH WATER 3.00 Inch	
HIGH WARNING 85.00 %	SUDDEN LOSS 50.00 Gal.	

Navigation buttons: SETUP, NEXT TANK, NEXT PAGE, and a back arrow.

Figure 7.1

- a) **Tank Number:** Selects the tank whose alarms and set points are being adjusted.
- b) **High Product:** Percentage of volume that will trigger a high-level alarm, typically 90% (max 95%).
- c) **Overfill:** Percentage of volume that will trigger an overfill alarm, set for the same percentage as High Product. Triggers during delivery in progress (value input of 101 will disable).
- d) **High Warning:** Percentage of volume that will trigger a high-warning level.
- e) **Low Product:** Percentage of volume that will trigger a low-level alarm (minimum of 1 percent; cannot be set to zero).
- f) **Delivery Needed:** Percentage of volume that will trigger a delivery-needed alarm (value input of 0 will disable this feature).
- g) **High Water:** The water level that will trigger a high-water alarm.
- h) **Sudden Loss:** The amount of decrease needed during a VLD test to trigger a sudden-loss alarm.
- i) **Probe Temp High:** Temperature needed to activate a probe high-temp alarm.
- j) **Probe Temp Low:** Temperature needed to activate a probe low-temp alarm.



## 8. Tank Table (Strapping)

### Tank Chart Points:

Used to create the incremental chart level points for each tank.  
(See Figure 8.1)

Jun 07, 2023 09:16:20 Status: **SETUP**

### TANK CHART POINTS

TANK NUMBER: 01

CHART INCREMENT: 1.000 Inch

TANK CAPACITY: 1600.00 Gal.

TANK DIAMETER: 16.00 Inch

LEVEL	VOLUME
1.000	100.00
2.000	200.00
3.000	300.00
4.000	400.00
5.000	500.00
6.000	600.00
7.000	700.00
8.000	800.00

Navigation: SETUP, NEXT TANK, NEXT PAGE, Back Arrow

Figure 8.1

- a) **Tank Number:** Selects the tank whose chart level points are being set up or adjusted.
- b) **Chart Increment:** Used to calculate how many chart levels are generated for the chart. Divide the tank diameter by the chart increment to get the number of chart levels. Enter the correct volume for each level given in the tank chart. It is recommended to input at least 20-increment chart levels for accuracy, based on that specific tank manufacturer's tank chart. Linear tanks can use 2-increment chart levels.

## 9. Tank Drop and Other

### Setup Tank Parameters:

Information needed to provide more accurate inventory and delivery data.

(See Figure 9.1)

- Tank Number:** Selects the tank whose parameters are being set up or adjusted.
- Drop Threshold:** The volume amount needed to initiate a delivery in progress.
- Drop Dwell Time:** Time delayed after a drop is completed before generating the drop report.
- Product Code:** User-defined number that identifies the tank's product for use with remote commands.

Jun 07, 2023 09:17:09 Status: **SETUP**

### SETUP - TANK PARAMETERS

TANK NUMBER 01	TANK TILT 0.00 Inch	ZERO PRODUCT NULL
DROP THRESHOLD 100.00 Gal.	TEMPERATURE THERMISTOR OFFSET	ZERO WATER NULL
DROP DWELL TIME 5 Min.		INCREMENT FACTOR 10
PRODUCT CODE 1	Do not change without Omntec Permission	

Enter a single ASCII character.

Navigation: SETUP, NEXT TANK, NEXT PAGE, Back Arrow

Figure 9.1

- Temperature Thermistors Offset:**  
Used to offset temperatures for the gauging probe. The number of TEMP OFFSETS is determined by the probe type.

#### Type R5:

Five-thermistor probe (five Temp Offsets).

(See Figure 9.2)

Jun 07, 2023 09:19:58 Status: **SETUP**

### PROBE TEMPERATURE OFFSETS

TANK#	T1 (L)	T2	T3	T4	T5 (H)	F
Tank 01:	73.4	73.6	73.8	73.9	73.9	F

TANK NUMBER 01	TEMP OFFSET 1 0.00	TEMP OFFSET 4 0.00
NOTE: TO DISABLE A TEMPERATURE THERMISTOR: SET THE 'TEMP OFFSET' EQUAL TO '900'. IT'S DATA WILL NOT BE USED IN THE SYSTEMS TEMP CALCULATION.	TEMP OFFSET 2 0.00	TEMP OFFSET 5 0.00
	TEMP OFFSET 3 0.00	AVERAGE TEMPERATURE 73.4 F

Navigation: SETUP, NEXT TANK, NEXT PAGE, Back Arrow

Figure 9.2

#### Type T1/R1:

One-thermistor probe (one Temp Offset).

(See Figure 9.3)

Jun 07, 2023 09:18:45 Status: **SETUP**

### PROBE TEMPERATURE OFFSETS

TANK#	T1 (L)	T2	T3	T4	T5 (H)	F
Tank 01:	73.4	73.6	73.8	73.9	73.9	F

TANK NUMBER 01	TEMP OFFSET 1 0.00	AVERAGE TEMPERATURE 73.4 F
NOTE: TO DISABLE A TEMPERATURE THERMISTOR: SET THE 'TEMP OFFSET' EQUAL TO '900'. IT'S DATA WILL NOT BE USED IN THE SYSTEMS TEMP CALCULATION.		

Navigation: SETUP, NEXT TANK, NEXT PAGE, Back Arrow

Figure 9.3

- f) **Zero Product Null:** Resets the product null to the factory-default value of 1. You are prompted to press YES or NO. (See Figure 9.4)




Figure 9.4

- g) **Zero Water Null:** Resets the water null to the factory-default value of 1.57. You are prompted to press YES or NO. (See Figure 9.5)




Figure 9.5

- h) **Increment Factor:** Requires a password. This is used to change the probe sensitivity. ***Only change after consulting with OMNTEC®.*** (See Figure 9.6)




Figure 9.6

- i) **Tank Tilt:** Number obtained by the tank tilt formula to further calibrate probe levels.  
(See Figure 9.7)




Figure 9.7

**P** = The center of the fill riser opening to the center of the probe riser opening.

**M** = The distance of the center of the probe riser opening to the center of the tank.

**D** = The difference in gross liquid level between the fill opening and the riser opening (fill – probe).

**Note:** Not required if the location of the MTG probe is in the center of the tank or if the tank is level.

## 10. Tank Colors and Orientation

### Set Tank Color + Orientation:

Used to control the (visual) display settings for each tank.

(See Figure 10.1)




Figure 10.1

- a) **Select Product Color:** Choose a color to visually distinguish the display contents of each tank, based on the API color code system.
- b) **Select Tank Profile:** Choose the visual tank orientation profile (HORIZONTAL, VERTICAL, or OIL WATER SEPARATOR).

**IMPORTANT:** The PROTEUS is now programmable for oil/water separator (OWS) applications. When choosing the OIL WATER SEPARATOR icon, the tank alarm points will change to HIGH-HIGH OIL, HIGH OIL, HIGH LIQUID, LOW LIQUID, and LOW WATER alarms. (See Figure 10.2).

If you have a PROTEUS OWS system, please refer to our PROTEUS Oil/Water Separator Programming & Installation supplement for additional programming and installation details ([document DI00014 DI00015 DI00018 DI00020 DI00026-7](#)) available at [www.omntec.com/support/documents](http://www.omntec.com/support/documents) (O & M Manuals tab).




Figure 10.2

## 11. Copy Tank Parameters

### Copy Tank Parameters:

Used to copy the full set of tank parameters from one tank to another tank.

(See Figure 11.1)

**Note:** You must still program unique parameters for each tank such as product type and probe wire speed where applicable.

Jun 07, 2023 09:59:17      Status: **SETUP**

**COPY TANK PARAMETERS**

COPY ALL TANK PARAMETERS AND TANK CHART FROM ONE TANKS MEMORY TO ANOTHER TANK.

When finished, go to the 'TANK PARAMETERS' page and change any parameters (like 'PRODUCT TYPE' or 'WIRE SPEED') that are unique to the second tank.

SELECT 1st TANK NUMBER    1    ➡    SELECT 2nd TANK NUMBER    2

**COPY PARAMETERS**

SETUP

Figure 11.1

## 12. BX-Sensor Control

### Sensor Control:

This page is used to delete or add BX-Sensors. When there are no sensors installed, the SENSOR NUMBER field will display “00”. (See Figure 12.1)

When replacing a sensor, it is recommended to **first** delete (physically and electronically) the old sensor from the system before wiring the new sensor, so when you add the new sensor it will take the same sensor assignment place of the old sensor. This is helpful when keeping relay events from being reprogrammed.

### Deleting/Replacing a Sensor:

- Turn off the PROTEUS and physically disconnect the (old) sensor from the ATG system.
- Turn on the unit and go to SETUP MENU.
- Go into SENSOR CONTROL and toggle to the sensor to delete from the programming. Press the DELETE SENSOR button. When prompted, answer YES.

(See Figure 12.2)

Jun 07, 2023 09:32:56 Status: **SETUP**

### SENSOR CONTROL

SENSOR NUMBER: 00 ENABLE/DISABLE: ---

SENSOR TYPE: --- SERIAL NUMBER: ---

PRESS TO DELETE THE CURRENT SENSOR DISPLAYED ABOVE

**DELETE SENSOR**

NOTE: PHYSICALLY REMOVE THE SENSOR FROM THE SYSTEM BEFORE DELETING

PRESS TO SEARCH FOR NEW SENSORS CONNECTED TO THE CONSOLE

**FIND SENSOR**

SETUP  
NEXT SENSOR  
NEXT PAGE  
←

Figure 12.1

### DELETE SENSOR

Are you sure you want to delete this sensor from the system?

Notes: Make sure to remove the physical sensor wiring. Use the FIND SENSOR button to re-install this sensor later if needed.

**YES** NO

Figure 12.2



### Adding a Sensor:

- a) Turn off the PROTEUS and connect the (new) sensor to the ATG system.
- b) Turn on the unit.
- c) From the SETUP MENU, go into SENSOR CONTROL and select the FIND SENSOR button. When prompted, answer YES.  
(See Figure 12.3)




Figure 12.3

This will start the FINDING SENSORS process. This allows the system to electronically install the new sensor. It may be necessary to repeat this step for systems with multiple new sensors.  
(See Figure 12.4)




Figure 12.4

The system confirms (or finds) the new sensor(s).

Pressing the NEXT PAGE button will bring you into BX-SENSOR PARAMETERS where you set the sensor's labels.  
(See Figure 12.5)




Figure 12.5

## 13. BX-Sensor Parameters

### Sensor Parameters:

These are the parameters used to define the sensor type, location, and labeling.

(See Figure 13.1)

Figure 13.1 shows the 'SENSOR PARAMETERS' setup screen. At the top, it displays the date and time 'Jun 07, 2023 09:41:31' and the status 'SETUP'. The screen is divided into two columns of input fields. The left column contains: 'SENSOR NUMBER' (01), 'SENSOR TYPE' (BX-PDS), 'LOCATION' (Need Label with a dropdown arrow), and 'LOCATION #' (0). The right column contains: 'ENABLE/DISABLE' (Enabled), 'SERIAL NUMBER' (200223838), 'TANK #' (0), and 'PRINT STATUS ON SHIFT REPORT' (Enabled). On the far right, there is a vertical sidebar with buttons: 'SETUP' (with a house icon), 'NEXT SENSOR', 'NEXT PAGE', and a back arrow.

Figure 13.1

- Sensor Number:** Sensor number assigned by the system; selects a sensor for setup.
- Sensor Type:** Sensor Type assigned by the system based upon serial number.
- Location:** Predefined and user-selectable location labels, via the dropdown (V) menu, to describe where the sensor is located. Choose OTHER to create a custom label not predefined in this list. (See Figure 13.2)

Figure 13.2 shows the same 'SENSOR PARAMETERS' setup screen as Figure 13.1, but with the 'LOCATION' dropdown menu open. The dropdown menu lists the following options: HiLevel, HiHiLevel, CautLevel, Reservoir, Brine, Other, Vault, Well, LowLevel, Refrig, and Freezer. The rest of the screen, including the input fields and the sidebar buttons, remains the same.

Figure 13.2

- Location #:** If more than one sensor is present in the same location and tank number then you may set a location number to differentiate between both sensors.
- Enable/Disable:** Shows if the selected sensor is enabled or disabled. A disabled sensor will not trip an alarm but will show as disabled, or inactive, in the sensor list.
- Serial Number:** Serial number that is factory-programmed into each sensor.
- Tank #:** The tank number assigned to this sensor for labeling purposes.
- Print Status On Shift Report:** Enables/Disables sensor status for a shift report.

i) **Temperature Sensor:**

The BX-TC-1 is designed to monitor temperatures ranging from -58°F to 302°F (-50°C to 150°C) with an accuracy of  $\pm 2^\circ\text{F}$ .

SENSOR PARAMETERS	
SENSOR NUMBER 02	ENABLE/DISABLE Enabled
SENSOR TYPE BX-TC1	SERIAL NUMBER 610082881
LOCATION Refrig	TANK # 0
LOCATION # 0	PRINT STATUS ON SHIFT REPORT Enabled
TEMP - HIGH 80.00 F	TEMP - LOW 33.00 F
TEMP OFFSET 0.00	ALARM DELAY 2

Figure 13.3

The BX-TC-1 has four additional programmable sensor parameters:

- TEMP-HIGH: High temperature alarm point.
- TEMP-LOW: Low temperature alarm point.
- TEMP OFFSET: Used to calibrate sensor to actual temperature reading.
- ALARM DELAY: Number of sensor test cycles verifying temperature before triggering an alarm.

(See Figure 13.3)

j) **Vapor Sensor:** The BX-VS is designed to monitor surface absorption of volatile organic products (e.g., gasoline, diesel, and motor fuels).

SENSOR PARAMETERS	
SENSOR NUMBER 03	ENABLE/DISABLE Enabled
SENSOR TYPE BX-VS	SERIAL NUMBER 400000001
LOCATION Vault	TANK # 0
LOCATION # 0	PRINT STATUS ON SHIFT REPORT Enabled
VAPOR CALIB 60	

Figure 13.4

The BX-VS has one additional programmable sensor parameter:

- VAPOR CALIB: Used to calibrate the vapor trigger point. Range value is 1 (less sensitive) to 255 (more sensitive), with 60 being the (factory-default) normal.
- Note:** Calibration of our BX-VS sensors is a trial-and-error process; set, test, and adjust (sometimes repeatedly) based on the specifics of the deployment environment and vapor being monitored in the application.

(See Figure 13.4)

## 14. Comm Ports

### Comm Port Settings:

Used to program the settings for onboard RS-232, or two Option Bus expansion boards, e.g.: RS-485.

(See Figure 14.1)

The screenshot shows the 'COMMUNICATIONS SETTINGS' screen. At the top, the time is 11:43AM 07/17/2023 and the status is 'SETUP'. The title 'COMMUNICATIONS SETTINGS' is in yellow. On the right, there is a 'SETUP' button with a house icon and a circular arrow button. The main area has two columns. The left column contains: 'Comm Type:' with a dropdown menu showing 'COM1'; 'Remote Security Code' section with 'Security Code:' set to '000000' and 'Enable/Disable:' set to 'Disable'. The right column contains: 'COM1/OptionBus1/OptionBus2' header; 'Baud Rate:' set to '9600'; 'Data Bits:' set to '8'; 'Parity:' set to 'NONE'; 'Stop Bits:' set to '1'; and 'Conn Type:' set to 'REMOTE'.

Figure 14.1

- a) **Comm Type:**  
Dropdown (▼) options available are:
- COM1 (RS232)
  - Option Bus 1
  - Option Bus 2
- (See Figure 14.2)
- b) **Remote Security Code:**  
Provides extra protection when using Ethernet Telnet ports.
- c) **Enable/Disable:**  
Enables or disables remote security code.

This screenshot is similar to Figure 14.1, but the 'Comm Type:' dropdown menu is open, showing three options: 'COM1' (highlighted in red), 'Option Bus 1', and 'Option Bus 2'. The other settings remain the same.

Figure 14.2

- d) **Baud Rate:** Selections available from the dropdown (▼) menu are 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 baud.
- (See Figure 14.3)

This screenshot shows the 'Baud Rate:' dropdown menu open, displaying a list of baud rates: 1200, 2400, 4800, 9600 (highlighted in red), 19200, 38400, 57600, and 115200. The 'Comm Type' dropdown is still open from the previous step, showing 'COM1', 'Option Bus 1', and 'Option Bus 2'.

Figure 14.3

- e) **Data Bits:** Factory set at 8.  
This cannot be changed.  
(See Figure 14.1)
- f) **Parity:** Selections available from the dropdown (▼) menu are NONE, ODD, and EVEN.  
(See Figure 14.4)

The screenshot shows the 'COMMUNICATIONS SETTINGS' screen. At the top, the status is 'SETUP' and the time is 11:49AM 07/17/2023. The 'Comm Type' is set to 'COM1'. The 'Baud Rate' is 9600. The 'Remote Security Code' dropdown menu is open, showing options: NONE (highlighted in red), EVEN, and ODD. The 'Security Code' is 000000. The 'Enable/Disable' button is set to 'Disable'. The 'Stop Bits' is 1. The 'Conn Type' is REMOTE. On the right side, there is a 'SETUP' button with a house icon and a circular arrow button.

Figure 14.4

- g) **Stop Bits:** Factory set at 1.  
This cannot be changed.
- h) **Conn Type:** For Com 1 (RS-232; communications only), the selections available from the dropdown (▼) menu are REMOTE (OMNTEC PC, Mini-Me, or industry-standard protocol) and MODBUS.  
(See Figure 14.5)

The screenshot shows the 'COMMUNICATIONS SETTINGS' screen. At the top, the status is 'SETUP' and the time is 11:57AM 07/17/2023. The 'Comm Type' is set to 'COM1'. The 'Baud Rate' is 9600. The 'Remote Security Code' dropdown menu is open, showing options: REMOTE (highlighted in red) and MODBUS. The 'Security Code' is 000000. The 'Enable/Disable' button is set to 'Disable'. The 'Stop Bits' is 1. The 'Conn Type' is REMOTE. On the right side, there is a 'SETUP' button with a house icon and a circular arrow button.

Figure 14.5

- i) Option Bus 1 and Option Bus 2 can be used for either RS-232 or RS-485. Other modules can be used in these slots. The usable selections from the dropdown (▼) menu are REMOTE, MODBUS, RD625, or RD7CTS (Mini-Me).

**Note:** RD625 (digital display) only operates on RS-485 communication and will *not* function with RS-232.  
(See Figure 14.6)

The screenshot shows the 'COMMUNICATIONS SETTINGS' screen. At the top, the status is 'SETUP' and the time is 11:59AM 07/17/2023. The 'Comm Type' is set to 'Option Bus 1'. The 'Baud Rate' is 9600. The 'Remote Security Code' dropdown menu is open, showing options: REMOTE, MODBUS, RD625 (highlighted in red), and RD7CTS. The 'Security Code' is 000000. The 'Enable/Disable' button is set to 'Disable'. The 'Stop Bits' is 1. The 'Conn Type' is RD625. On the right side, there is a 'SETUP' button with a house icon and a circular arrow button.

Figure 14.6

## 15. Modbus

### Modbus Settings:

Used to program the settings for Modbus.

(See Figure 15.1)

The screenshot shows the 'MODBUS SETTINGS' screen. At the top, the date and time are 'Jun 07, 2023 10:14:54' and the status is 'SETUP'. The title 'MODBUS SETTINGS' is in yellow. The screen contains four input fields: 'ENABLE CODE' with value 'EL444445', 'MODBUS ADDRESS' with value '2', 'REGISTER OFFSET' with value '0', and 'REVERSE MODE' with value 'Disabled'. Each field has a range or note in blue text: '(MODBUS Option) (Call Omntec Mfg) (For Enable code)' for the code, '(2 to 255)' for the address, '(0 = Default) (40001 = PLC)' for the offset, and '(Disabled: Low Reg / High Reg) (Enabled: High Reg / Low Reg)' for the reverse mode. A yellow 'PRINT MODBUS MAP' button is to the right of the offset field. A note at the bottom states: 'NOTE: MODBUS must also be selected in 'COMM PORTS' or in NETWORK PROPERTIES for the desired port. RS232 ports use MODBUS RTU mode. Ethernet ports use MODBUS TCP/IP mode.' On the right side, there is a vertical toolbar with a 'SETUP' button (house icon), three empty square buttons, and a 'Back' button (curved arrow icon).

Figure 15.1

- a) **Modbus Address:** Unique Modbus slave address.
- b) **Register Offset:** Holding register offset, typically set to 0 or 40001.
- c) **Enable Code:** A Modbus-enabled code is required from OMNTEC to run this optional feature.
- d) **Reverse Mode:** When enabled, reverses the high and low registers for certain PLCs or computer software that accepts a different Modbus format.
- e) **Print Modbus Map:** Prints the current register range for enabled probes and sensors.



## 16. Network Properties

### Network Protocol Properties:

Used to setup either a static or dynamic (DHCP) IP and other relevant networking properties. (See Figure 16.1)

Figure 16.1

- a) **Obtain IP Address Automatically:** Pressing the square box to the left of this adds or removes an “X” checkmark, which toggles between static or dynamic (DHCP) IP address functionality.
- b) **IP Address:** Static IP address assigned to the PROTEUS.
- c) **Subnet Mask:** Subnet Mask to match the existing network.
- d) **Default Gateway:** Default Gateway to match the existing network.
- e) **Preferred DNS:** Primary Domain Name Server address.
- f) **Alternate DNS:** Secondary Domain Name Server address.
- g) **MAC Address:** Each PROTEUS is programmed with a unique MAC address that cannot be changed by the user.
- h) **Telnet Port #:** The default telnet ports are factory set to 502 (MODBUS TCP), 4001, 8001, and 10001, and can be changed to suit network requirements.
- i) **Port Type:** Selections available from the dropdown (▼) menus are REMOTE, MODBUS RTU, and MODBUS TCP. (See Figure 16.2)
- j) **VPN Settings Icon:** Allows the ability of ENABLING or DISABLING the Virtual Private Network (VPN) feature.

Figure 16.2

The PROTEUS VPN is a secure, encrypted communication channel that is intended for use with OMNTEC Cloud-based services. In some cases, it may be used for OMNTEC tech support to remotely access the controller to assist in gathering data for troubleshooting. See Figures 16.3, 16.4, and 16.5 for more details on VPN Settings.



### VPN Settings Icon (cont'd):

By factory default, VPN is disabled. The TERMS OF SERVICE (ToS) are displayed. Choose the ENABLE radio button to enable the VPN service. Choosing to enable this VPN service means you understand and agree to the displayed TERMS OF SERVICE (ToS). (See Figure 16.3)

**Note: OMNTEC Manufacturing, Inc. is not responsible for any data loss or breach when the user chooses to enable VPN service.**

When prompted, click YES to confirm you want to enable the VPN connection. (See Figure 16.4)

The VPN STATUS will confirm that VPN has been established. RESTART VPN and STOP VPN will do just that. To prevent the VPN from running on the next power cycle, choose the DISABLE radio button, until you ENABLE it again. (See Figure 16.5)




Figure 16.3




Figure 16.4




Figure 16.5

## 17. DataCheck™

### Datacheck™ Settings:

This allows the user to program Datacheck™ wireless transmitter settings, if applicable to your specific system.

(See Figure 17.1)

Jun 07, 2023 10:18:13      Status: **SETUP**

**DATACHECK SETTINGS**

SYSTEM ID:  (1 to 255)  
This number is programmed into all the transmitters for this system.  
Only transmitters brordcasting this system ID will be used in this system.

INACTIVE ALARM TIME:  MIN. (1 to 255, Default: 30)  
This number is the time from the last transmission at which a transmitter will be considered timed out.

SETUP  
Home icon  
Back arrow

Figure 17.1

- a) **System ID:** This number value is programmed into all the transmitters for this system. Only transmitters broadcasting this system ID will be used in this unit (System ID values, 1 to 255).
- b) **Inactive Alarm Time:** This number value is the time from the last transmission at which the transmitter will time out (Inactive Alarm Time values, 1 to 255. The factory default is 30).

## 18. Interface Boards and Relays

### Interface Boards Relays:

Depending on which model you have, and its configuration, more boards may be displayed.

Press the MCU EVENTS RELAY / EMAIL icon in the top left corner to configure the onboard MCU relays. Press each red relay board to program either 8-channel or 4-channel relay boards (if applicable). (See Figure 18.1)




Figure 18.1

### Program Events:

Enter the appropriate device selection for event programming.

### Program Relay/Input Modes:

Enter the appropriate device selection for mode programming. This is used to select the mode of each relay (LIGHT, HORN, or RELAY), and input option.




Figure 18.2

### Fail-Safe Mode (XB-4IO and RB8):

This sets the correct relay fail-safe operation upon AC power loss. (See Figure 18.3)




Figure 18.3

### Program Events:

30 events that can be programmed for the onboard MCU relays. 100 events can be programmed for the XB-RB8 (PROTEUS X), XC-R8 (PROTEUS K), and XB-4IO boards (PROTEUS X). The event list may show empty or already programmed events.

To program an event, press on the event line you would like to program and navigate to the event programming page.  
(See Figure 18.4)

#### NOTE:

- The SAVE EVENT button must be pressed to save any entered or changed parameters.
- Programmed events can be disabled when the device is under repair to prevent the event from occurring and re-enabled when the problem is resolved. The event can also be deleted if it is no longer required.

(See Figure 18.5)

#### c) Select Event Type:

This sets the device type. Dropdown (▼) menu selections are TANK, SENSOR, or BOARD. You can toggle between devices of that type. Device information is displayed in the white box (lower left) for the selected device.  
(See Figure 18.6)




Figure 18.4




Figure 18.5




Figure 18.6

d) **Select Event:**

This selects the required alarm condition needed for the selected device. Various options are available from the Select Event dropdown (▼) menu.

- Tank Selections:  
(See Figure 18.7)




Figure 18.7

- Sensor Selections:  
(See Figure 18.8)




Figure 18.8

- Board Selections:  
(See Figure 18.9)




Figure 18.9

e) **Select Relay and/or Email Recipient:**

This will vary based upon the board selected. The checkboxes will determine which relays are enabled by the event, and which email recipient will receive the alarm notices (MCU board only).

- f) **Relay On:** Turns on relay at the programmed set point.  
g) **Relay Off:** Turns off relay at the programmed set point.

(See Figure 18.10)

Figure 18.10

**Program Relay/Input Modes (MCU):** (MCU uses Figure 18.12 on Ver. P001AW and earlier).

The Program Relay Modes/Input Parameters screen will open for the appropriate device.

- a) Use the CHANGE MODE R (#) button for the appropriate relay to toggle between LIGHT, HORN, RELAY, or DISABLED.  
b) Use the CHANGE MODE I/O (#) button for the appropriate input to access the Input Selection page.  
c) Features INDIVIDUAL RELAY FAILSAFE selections.

(See Figure 18.11)

Figure 18.11

**Note:** Used on Ver. P001AX and after.

**Program Relay/Input Modes (XB-4IO):**

The Program Relay Modes/Input Parameters screen will open for the appropriate device.

- a) Use the CHANGE MODE R (#) button for the appropriate relay to toggle between LIGHT, HORN, RELAY, or DISABLED.  
b) Use the CHANGE MODE I/O (#) button for the appropriate input to access the Input Selection page.

(See Figure 18.12)

Figure 18.12



### Local Acknowledge:

**Note:** Each selection will have specific settings that can be enabled/disabled.

- Any relay programmed for horn mode (on this board only; relates to specific slot number) will be acknowledged when the input is pulled low. This does not acknowledge the display board.
- Time/date and ON label can be logged or printed.

(See Figure 18.13)

### Relay Follower:

- Turns on the relay for the corresponding input that is pressed.
- On the MCU board, input 1 controls relay 1, input 2 controls relay 2.
- On the 4-I/O board; same as MCU board plus additional 2 inputs and relays.
- Time/date and ON/OFF label can be logged or printed.
- This can be inverted so that when the input is pressed, the relay will de-energize.
- This can show alarm on the display and email/text message when the input is pressed.

(See Figure 18.14)

Figure 18.14

### Input:

- This is used to check when an input is ON or OFF.
- Time/date and ON/OFF label can be logged or printed (alarm is not logged to system alarm log).
- This can be inverted so that when the input is released, it will then send messages/alarms.
- This can show an alarm on the display and email/text message when input is pressed.

(See Figure 18.15)

Figure 18.15



### System Acknowledge:

- The horn is acknowledged system-wide on all system boards. This includes the MCU, display, and relay boards.
- Time/date and ON label can be logged or printed.
- This can show an alarm on the display and email/text message when input is pressed.

(See Figure 18.16)

The screenshot shows a touchscreen interface for setting up an input. At the top, it displays the date and time 'Aug 23, 2023 09:50:47' and the status 'Status: SETUP'. Below this is the title 'Input Selections (For XB-4IO / MCU Inputs)' and a dropdown menu set to 'MCU # 1'. There are two input fields: 'ON LABEL' with the text 'SYSTEM ACKNOWLEDGE' and an empty 'OFF LABEL' field. A 'CHANGE MODE' button is next to the 'ON LABEL' field. To the right, there are two checkboxes: 'ENABLE' (checked) and 'LOG INPUT' (unchecked). Below these is a 'SEND TO PRINTER' button. At the bottom left is a 'CHANGE MODE I/O' button. At the bottom center is a yellow button labeled 'SAVE INPUT CHANGES (this input only)'. On the right side, there is a vertical bar with a 'SETUP' button (house icon), a 'NEXT INPUT' button (blue), and a circular arrow button.

Figure 18.16

### Acknowledge/Page Change/Test:

- A single input that is used for enclosure mode when accessing the touchscreen is not possible.
- Upon a current alarm, a single press will acknowledge the alarm on the panel.
- When current alarms are not present, a single press will cycle through tank pages and current alarm page.
- When the button is held for 5 seconds, a test to check relays (horn/lights) is performed.
- On (some) models that have UV protective tint, push button will clear screen and turn opaque again after the time delay has expired (programmed in Miscellaneous Settings).
- Normally open push button only.
- Used on MCU inputs only.

(See Figure 18.17)

The screenshot shows a similar touchscreen interface to Figure 18.16. It displays the date and time 'Aug 23, 2023 09:52:07' and the status 'Status: SETUP'. The title is 'Input Selections (For XB-4IO / MCU Inputs)' with a dropdown menu set to 'MCU # 1'. The 'ON LABEL' field contains the text 'ACKNOWLEDGE-PAGE-TEST' and the 'OFF LABEL' field is empty. A 'CHANGE MODE' button is next to the 'ON LABEL' field. To the right, there are two checkboxes: 'ENABLE' (checked) and 'LOG INPUT' (unchecked). Below these is a 'SEND TO PRINTER' button. At the bottom left is a 'CHANGE MODE I/O' button. At the bottom center is a yellow button labeled 'SAVE INPUT CHANGES (this input only)'. On the right side, there is a vertical bar with a 'SETUP' button (house icon), a 'NEXT INPUT' button (blue), and a circular arrow button.

Figure 18.17

### Inventory Run Time:

- Inventory data for the selected tank will be recorded when input is active and stops when deactivated.
- Time/Date and ON/OFF labels and tank inventory can be logged or printed.
- Email/text message when data is recorded.
- Input active/de-active state can be reversed.
- Inventory Run Time report mode to stop and start leak tests while the input is held down.

(See Figure 18.18)

Aug 23, 2023 09:52:54 Status: **SETUP**

**Input Selections (For XB-4IO / MCU Inputs) # 1**

ON LABEL: INVENTORY RUN TIME

OFF LABEL:

CHANGE MODE

Inventory run time

CHANGE MODE I/O

☒ ENABLE

☐ LOG INPUT

☐ FAILSAFE MODE

☐ SEND TO PRINTER

☐ EMAIL ON INPUT

TANK#: 0

SAVE INPUT CHANGES (this input only)

SETUP

NEXT INPUT

Back arrow

### Run Time:

- Will record when the input is active and then deactivated.
- Records time only, does not tie input to a particular tank.
- Time/Date and ON/OFF labels can be logged or printed.
- Email/text message when data is recorded.
- Input active/de-active state can be reversed.

(See Figure 18.19)

Aug 23, 2023 09:54:10 Status: **SETUP**

**Input Selections (For XB-4IO / MCU Inputs) # 1**

ON LABEL: RUN TIME

OFF LABEL:

CHANGE MODE

Run time

CHANGE MODE I/O

☒ ENABLE

☐ LOG INPUT

☐ FAILSAFE MODE

☐ SEND TO PRINTER

☐ EMAIL ON INPUT

SAVE INPUT CHANGES (this input only)

SETUP

NEXT INPUT

Back arrow

Figure 18.19

## 19. Clear Logs

### Data Logs Page:

From this menu it is possible to individually clear each log from the unit's memory. This is useful after the site is commissioned, to clear out test data.

(See Figure 19.1)

- a) **Clear Alarm Log:** Clears all alarms from log.
- b) **Clear Shift Log:** Clears all shifts.
- c) **Clear VLD Log:** Clears all VLD data from log.
- d) **Clear Delivery Log:** Clears all previous deliveries but keeps the latest delivery saved.
- e) **Clear CITLD Log:** Clears all CITLD data from log.




Figure 19.1

## 20. Backup System Parameters

### System Parameter Backup:

You are prompted to confirm the backup process; press YES.

(See Figure 20.1)




Figure 20.1

The backup process is displayed, and you are prompted to return to the Setup Menu when completed.

(See Figure 20.2)




Figure 20.2

## 21. Restore System Parameters

### System Parameter Restore:

You are prompted to confirm the restore process; press YES.

(See Figure 21.1)




Figure 21.1

The restore process is displayed, and the system will restart when completed.

(See Figure 21.2)




Figure 21.2

## 22. VLD – Leak System Settings

### Tank Volumetric Leak Detection:

This feature is used for setting a specific time interval for running a VLD test. It can automatically run every day, once a week, or once a month at a specific time of the day. (See Figure 22.1)

Jun 07, 2023 10:35:53 Status: **SETUP**

**TANK VOLUMETRIC LEAK DETECTION**

**TEST LEVEL** All tests run at the same level. (.1GPH, .2GPH, OR 1LPH)  
[.2GPH ▼]

**TEST TIME** VLD Test Time (.1, .2, Test Minimum 4 Hours)  
Set in hours (no minutes)  
[4]

**DWELL TIME** Settling time before the VLD test starts. (Minimum 30 minutes)  
[30]

**ENABLE/DISABLE** VLD tests will be active when enabled here. VLD tests must also be enabled for each tank in 'VLD TANK SETTINGS'.  
[Enabled]

SETUP  
NEXT PAGE  
↺

Figure 22.1

- Test Level:** Choose which type of VLD test you would like to run. Selectable dropdown (▼) options are .1GPH, .2GPH, or 1LPH. (See Figure 22.2)
- Test Time:** The total time the test will run with a minimum of four hours.
- Dwell Time:** Product must remain constant and still for a minimum of 30 minutes before running a test (no delivery or dispensing).
- Enable/Disable:** Enable the VLD test feature. You must also enable VLD test for each tank.

Jun 07, 2023 10:36:59 Status: **SETUP**

**TANK VOLUMETRIC LEAK DETECTION**

**TEST LEVEL** All tests run at the same level. (.1GPH, .2GPH, OR 1LPH)  
[.2GPH ▼]  
[.1GPH]  
[.2GPH]  
[1LPH]

**TEST TIME** VLD Test Time (.1, .2, Test Minimum 4 Hours)  
Set in hours (no minutes)  
[4]

**DWELL TIME** Settling time before the VLD test starts. (Minimum 30 minutes)  
[30]

**ENABLE/DISABLE** VLD tests will be active when enabled here. VLD tests must also be enabled for each tank in 'VLD TANK SETTINGS'.  
[Enabled]

SETUP  
NEXT PAGE  
↺

Figure 22.2

### IMPORTANT!

Remember that the VLD test time is (a minimum of) 4 hours, plus the dwell time (minimum 30 minutes), therefore the minimum time for running a VLD test is 4.5 hours. During this time, the product level must remain constant and still. If you have a delivery or dispense product before a VLD test, you must wait at least 4-8 hours (dependent on the tank size) before the start of the test.

## 23. VLD – Leak Tank Settings

### Tank Volumetric Leak Detection:

Additional VLD test settings. This page feature is used to control the desired testing frequency for each tank.

(See Figure 23.1)




Figure 23.1 shows the 'TANK VOLUMETRIC LEAK DETECTION' setup screen. The status is 'SETUP'. The screen displays the following fields and options:

- TANK NUMBER:** 01
- TEST START TIME:** 00 : 05 (0 TO 23:59)
- SET INTERVAL:** DISABLED (selected from a dropdown menu with options: MONTHLY, WEEKLY, DAILY, DISABLED)

On the right side, there is a 'SETUP' button with a house icon, a 'NEXT TANK' button, and a circular arrow icon.

Figure 23.1

- a) **Tank Number:** Assign which tanks need to run testing.
- b) **Test Start Time:** The time at which the VLD test should start.
- c) **Set Interval:** Selectable dropdown (▼) options are DAILY, WEEKLY, MONTHLY, or DISABLED.  
(See Figure 23.2)




Figure 23.2 shows the 'TANK VOLUMETRIC LEAK DETECTION' setup screen with the 'SET INTERVAL' dropdown menu open. The status is 'SETUP'. The screen displays the following fields and options:

- TANK NUMBER:** 01
- TEST START TIME:** 00 : 05 (0 TO 23:59)
- SET INTERVAL:** DAILY (selected from a dropdown menu with options: MONTHLY, WEEKLY, DAILY, DISABLED)

On the right side, there is a 'SETUP' button with a house icon, a 'NEXT TANK' button, and a circular arrow icon.

Figure 23.2

- d) When the SET INTERVAL is DAILY, Set Date and Set Day are not required.  
(See Figure 23.3)




Figure 23.3 shows the 'TANK VOLUMETRIC LEAK DETECTION' setup screen with the 'SET INTERVAL' set to 'DAILY'. The status is 'SETUP'. The screen displays the following fields and options:

- TANK NUMBER:** 01
- TEST START TIME:** 00 : 05 (0 TO 23:59)
- SET INTERVAL:** DAILY (selected from a dropdown menu with options: MONTHLY, WEEKLY, DAILY, DISABLED)

On the right side, there is a 'SETUP' button with a house icon, a 'NEXT TANK' button, and a circular arrow icon.

Figure 23.3

- e) When the SET INTERVAL is WEEKLY, Set Day selectable dropdown (▼) options are the days of the week.  
(See Figure 23.4)

The screenshot shows the 'TANK VOLUMETRIC LEAK DETECTION' setup screen. At the top, the date and time are 'Jun 21, 2023 12:48:23' and the status is 'SETUP'. The title 'TANK VOLUMETRIC LEAK DETECTION' is in yellow. On the left, there are two input fields: 'TANK NUMBER' with the value '01' and 'TEST START TIME' with the value '00 : 05' (with a note '(0 TO 23:59)'). In the center, the 'SET INTERVAL' is set to 'WEEKLY'. A dropdown menu is open for 'SET DAY', showing options: Sunday (highlighted in red), Monday, Tuesday, Wednesday, Thursday, Friday, and Saturday. To the right of the dropdown, the options 'MONTHLY, WEEKLY, DAILY, DISABLED' are listed. Below the dropdown, there is a label 'ENTER IF WEEKLY SET'. On the right side of the screen, there is a vertical bar with four buttons: 'SETUP' (with a house icon), 'NEXT TANK', a blank button, and a back button (with a curved arrow icon).

Figure 23.4

- f) When the SET INTERVAL is MONTHLY, Set Date is entered with the required date.  
(See Figure 23.5)

The screenshot shows the 'TANK VOLUMETRIC LEAK DETECTION' setup screen. At the top, the date and time are 'Jun 21, 2023 12:49:15' and the status is 'SETUP'. The title 'TANK VOLUMETRIC LEAK DETECTION' is in yellow. On the left, there are two input fields: 'TANK NUMBER' with the value '01' and 'TEST START TIME' with the value '00 : 05' (with a note '(0 TO 23:59)'). In the center, the 'SET INTERVAL' is set to 'MONTHLY' (with a dropdown arrow). Below it, the 'SET DATE' is entered as '15'. To the right of the date input, the options 'MONTHLY, WEEKLY, DAILY, DISABLED' are listed. Below the date input, there is a label 'ENTER IF MONTHLY SET'. On the right side of the screen, there is a vertical bar with four buttons: 'SETUP' (with a house icon), 'NEXT TANK', a blank button, and a back button (with a curved arrow icon).

Figure 23.5



## 24. CITLD – Leak System Settings

### Continuous In-Tank Leak Detection:

This page and function allows a leak test to run in a tank that is in continuous use. Requires 20-minute time intervals to determine if the tank has a leak and will generate a monthly report.

(See Figure 24.1)

The screenshot shows a web-based setup interface for CITLD. At the top, the date and time are 'Aug 23, 2023 14:01:18' and the status is 'SETUP'. The title is 'CONTINUOUS IN TANK LEAK DETECTION(CITLD)'. There are three main settings sections, each with a green header and a white input field:

- CITLD ENABLE CODE:** The input field contains 'EL555556'. To the right, it says '(OPTIONAL FEATURE) Contact Omntec for a CITLD enable code.'
- AUTO PRINT ENABLE:** The input field contains 'Disabled'. To the right, it says 'Enable the printout of the CITLD (current) leak state (Pass/No Results).'
- PRINT REPORT MONTHLY/WEEKLY:** The input field contains 'Weekly'. To the right, it says 'When enabled the CITLD leak state will printout monthly (21st) or weekly.'

On the right side of the screen, there is a vertical sidebar with a 'SETUP' button at the top, three empty square buttons in the middle, and a back arrow button at the bottom.

Figure 24.1

- a) **CITLD Enable Code:** A CITLD enabled code is required from OMNTEC to run this optional feature.
- b) **Auto Print Enable:** Enables the unit to print out the CITLD results automatically.
- c) **Print Report Monthly/Weekly:** Allows the user to change between printing a monthly or weekly report for CITLD.

## 25. Line Leak Detection

Choose between either the EMLLD (Electro-Mechanical) or ELLD (Pressure) radio buttons at the bottom of the screen to configure the required Line Leak Detection process. (See Figure 25.1)

Note: Each line has its own settings to configure. **Take note of the LINE# (in the upper right) when configuring.**

Figure 25.1

### EMLLD (Electro-Mechanical):

- a) **Line Description:** Name of the product, fuel, or type. CONFIRM THE CORRECT LINE# IS BEING PROGRAMMED (up to four lines with one HV board).
- b) **Line Enable:** (YES/NO choice).
  - YES: line is enabled (allowed to dispense).
  - NO: line is disabled (not allowed to dispense).
- c) **Gross Test (3 GPH):** Enabled or Disabled.
- d) **STP Halt On Fail:** (YES/NO choice).
  - YES: pump is inhibited from running if a test fails.
  - NO: system will log/alarm test failure, but the line can still dispense/re-test.
- e) **BX-EPS Sensor SN:** Enter the serial number of the Electronic Piston Sensor for the line.
- f) **STP Halt On S# Alarm:** (YES/NO choice).
  - YES: pump is inhibited from running if there is a problem with the sensor.
  - NO: system will only log/alarm sensor issue, but the line can still dispense.
- g) **Resiliency Volume:** Measured in milliliters at each site for each line. This is required for proper timing of test. Refer to the **PROTEUS X EMLLD Installation and Operation** manual (document number 550001 from <https://www.omntec.com/support/documents>).
- h) **Delay Time:** The amount of time (in seconds) the system waits to confirm the MLLD is fully reset before starting the repressure phase of a test. It is derived from Resiliency Volume; it cannot be configured by the user.
- i) **Repressure Time:** The amount of time (in seconds) the system allows for the MLLD to reach the full flow position during the repressure phase of a test. It is typically derived from Resiliency Volume; it can be set manually in certain situations.
- j) **Repressure Retries:** Enter the number of times the system should retry pressurizing the line during a test. Enter 0 (zero) if you do not want the system to retry if the first attempt to pressurize the line fails during a test.
- k) **Reset From STP Shutdown:** Following an STP Halt due to a failed test, use this button to reset the system to reenale dispensing and testing.

### EMLLD Page 2:

This page contains settings for lines with multiple pumps and/or a control valve. Use the drop-down menus to select the system relay that is associated with a given pump or the control valve. If a pump has been assigned a relay then it must also have a corresponding EPS sensor assigned.

The **DEFAULT** selection is only available for Pump 1. *The Installation and Operation* manual (document number 550001) identifies the default Pump 1 relay for each line.

The **Pump Control** setting is only used if the line is configured with multiple pumps. The available pump control modes are **STAGED**, **STAGED-ALTERNATING**, or **ALTERNATING** (and N/A). Refer to the *Installation and Operation* manual for a description of each of these modes. (See Figure 25.2)

The screenshot shows the 'LINE LEAK DETECTION' setup screen for Line # 1. The status is 'SETUP'. The line description is 'PLUS 87'. The screen is divided into two main sections: 'Relay Assignment' and 'Sensor Assignment'. In the 'Relay Assignment' section, Pump 1 is set to 'Default', Pump 2 is 'Not Used', Pump 3 is 'Not Used', Control Valve is 'Not Used', and Pump Control is 'N/A'. In the 'Sensor Assignment' section, BX EPS1 SENSOR SN is 600000013, BX EPS2 SENSOR SN is 600000001, and BX EPS3 SENSOR SN is 600000002. On the right side, there are buttons for 'SETUP' (with a house icon), 'PAGE 3', 'SAVE', and a back arrow.

Figure 25.2

### EMLLD Page 3:

LINE DISABLING setup. For each line, you can disable dispensing and testing for scheduled time periods. (See Figure 25.3)

The screenshot shows the 'SCHEDULED LINE SHUTDOWN TIMES' setup screen for Line # 1. The status is 'SETUP'. The line description is 'PLUS 87'. The screen displays a table for scheduling shutdowns. The table has columns for 'Start Time', 'End Time', and days of the week (M, T, W, T, F, S, S). There are three rows for scheduling, each with a 'Not Applied' button. On the right side, there are buttons for 'SETUP' (with a house icon), 'SAVE', and a back arrow.

Figure 25.3

Choosing the ELLD (Pressure) radio button at the bottom-center of the Line Leak Detection (page 1) screen will configure this function. (See Figure 25.4)

Note: ELLD has additional features vs EMLLD (see Figure 25.1). Like EMLLD, each line has its own settings to configure. Take note of the LINE# (in the upper right) when configuring.

Apr 18, 2025 14:26:39 Status: **SETUP**

**LINE LEAK DETECTION**

LINE DESCRIPTION: DIESEL 1 LINE# 2

LINE ENABLE: Yes PERIODIC TEST: Disabled

STP HALT ON FAIL: No

GROSS TEST: Enabled ANNUAL TEST: Disabled

STP HALT ON FAIL: No

BX IPS SENSOR SN: 700000101 DISPENSE MONITORING: Disabled

STP HALT ON S# ALM: No MIN. PRESSURE (PSI): 7.50

Reset From STP Shutdown: STP HALT ON FAIL: No

Clear Alarm - Reset STP

☐ EMLLD(Electro-Mechanical) ☒ ELLD(Pressure) ☐ LINE NOT USED

SETUP

NEXT LINE

PAGE 2

SAVE

Figure 25.4

#### PLLD (Pressure):

- Line Description:** Name of the product, fuel, or type. CONFIRM THE CORRECT LINE# IS BEING PROGRAMMED (up to four lines with one HV board).
- Line Enable:** (YES/NO choice).
  - YES: line is enabled (allowed to dispense).
  - NO: line is disabled (not allowed to dispense).
- Gross Test (3 GPH):** Enabled or Disabled.
- Periodic Test (.2 GPH):** Enabled or Disabled.
- Annual Test (.1 GPH):** Enabled or Disabled.
- STP Halt On Fail Options:** (YES/NO choice).
  - YES: pump is inhibited from running if the corresponding test fails.
  - NO: system will log/alarm test failure, but the line can still dispense/re-test.
- BX-IPS Sensor SN:** Enter the serial number of the Intelligent Pressure Sensor for the line.
- STP Halt On S# Alarm:** (YES/NO choice).
  - YES: pump is inhibited from running if there is a problem with the sensor.
  - NO: system will only log/alarm sensor issue, but the line can still dispense.

**Reset From STP Shutdown:** Following an STP Halt due to a failed test, use this button to reset the system to re-enable dispensing and testing.

### ELLD Page 2:

This page contains settings for lines with multiple pumps and/or a control valve. Use the drop-down menus to select the system relay that is associated with a given pump or the control valve.

(See Figure 25.5)

The **DEFAULT** selection is only available for Pump 1. *The Installation and Operation* manual (document number 550001) identifies the default Pump 1 relay for each line.

Apr 18, 2025 14:27:15 Status: **SETUP**

**LINE LEAK DETECTION**

LINE DESCRIPTION: DIESEL 1 LINE# 2

**Relay Assignment**

Pump 1: Default

Pump 2: Reselect Relay

Pump 3: Reselect Relay

Control Valve: Reselect Relay

**Sensor Assignment**

BX IPS SENSOR SN: 700000101

**Line Profiling**

Pump Control: N/A

Staging Pressure (PSI): 15.00

Start Line Profile

SETUP PAGE 3 SAVE

Figure 25.5

The **Pump Control** setting is only used if the line is configured with multiple pumps. The available pump control modes are **STAGED**, **STAGED-ALTERNATING**, or **ALTERNATING** (and N/A). Refer to the *Installation and Operation* manual for a description of each of these modes.

Press the START LINE PROFILE button to begin Line Profiling.

### LINE PROFILING:

(See Figure 25.6)

**CAL SENSOR TO ZERO:** You are prompted to zero calibrate the pressure sensor. Make sure the pressure on the line is zero before beginning this process.

**START LINE PROFILING:** You are prompted to start the line profiling.

**ABORT LINE PROFILING:** You are prompted to cancel the line profiling.

Apr 18, 2025 14:30:12 Status: **SETUP**

**LINE PROFILING**

**PROFILE RESULTS**

CAL Sensor To Zero

Start Line Profiling

Abort Line Profiling

Wed Feb 11 12:29:08 UTC 2025 Channel 3 Pressure Line Leak Status: Zero Calibration: 5.3 PSI Calibration: FAILED FAILED FAILED #!%&\$. Done.

Wed Feb 11 12:39:03 UTC 2025 Channel 3 Pressure Line Leak Status: Zero Calibration:

LINE: 2 ELLD PRESSURE (PSI): 0.0

SETUP PAGE 3 SAVE

Figure 25.6

### ELLD Page 3:

LINE DISABLING setup. For each line, you can disable dispensing and testing for scheduled time periods.  
(See Figure 25.7)

The screenshot shows the 'LINE LEAK DETECTION' setup screen for 'DIESEL 1' (LINE# 2). The status is 'SETUP'. The screen displays a table for 'SCHEDULED LINE SHUTDOWN TIMES' with columns for Start Time, End Time, and days of the week (M, T, W, T, F, S, S). There are three rows of time slots, each with a corresponding 'Apply Sched.' button. The first row shows times 20:00 to 07:00 with 'Applied' status. The second row shows times 22:00 to 06:00 with 'Applied' status. The third row shows times 00:00 to 00:00 with 'Not Applied' status. A 'SAVE' button is visible on the right side of the screen.

Start Time	End Time	M	T	W	T	F	S	S	Apply Sched.
20:00 (0 TO 23:59)	07:00 (0 TO 23:59)	X	X	X	X	X			Applied
22:00 (0 TO 23:59)	06:00 (0 TO 23:59)						X	X	Applied
00:00 (0 TO 23:59)	00:00 (0 TO 23:59)								Not Applied

Figure 25.7

To view the status of a line, along with leak test status, go to the main screen (SYSTEM STATUS MENU) and press the (green) COMPLIANCE button.  
(See Figure 25.8)

Press the LINE LEAK TEST button on the following page and a general view is displayed of the lines.

The screenshot shows the 'SYSTEM STATUS MENU' screen. The status is 'NORMAL'. The screen displays several buttons: INVENTORY, REPORTS, ALARMS, COMPLIANCE, SENSOR STATUS, UTILITIES, and a TEST button. A vertical sidebar on the right contains buttons for HOME, ALARM ACK, PRINT, and TEST.

Figure 25.8

The general four-line view of each line. To see a detailed view of a line, press on that desired quadrant.  
(See Figure 25.9)

The screenshot shows the 'LINE LEAK DETECTION' screen with a status of 'ALARM'. The screen displays a four-line view of the system. The top section shows 'LINE# 1- Regular 87' and 'LINE# 2- E 85'. The bottom section shows 'LINE# 3- 93' and 'LINE# 4'. Each line has a 'TEST' status, 'STP' (Stop) status, and 'STATE' (Status). The 'LINE# 2- E 85' line is highlighted with a red 'GROSS TEST FAILED' status. A 'MENU' button is visible on the right side of the screen.

LINE#	TEST	STP	STATE
LINE# 1- Regular 87	NONE	Energized	Dispensing- No Test
LINE# 2- E 85	3 GPH	Off	MLLD Resetting
LINE# 3- 93	3 GPH	Off	MLLD Resetting
LINE# 4	---	---	---

Figure 25.9

Detailed view of the line. The state of the line (LINE STATE) is visible along with TEST STATES and line setup. Sensor errors and setup errors are shown. Additionally, the state of MLLD is displayed.  
(See Figure 25.10)




Figure 25.10

## 26. Print System Parameters

### Print All System Parameters:

You are prompted to confirm the PRINT ALL SYSTEM PARAMETERS action; press YES. The system's parameters are sent to the printer and will return you to the Setup Menu when finished.  
(See Figure 26.1)




Figure 26.1



## 27. Time/Date Format

### Time/Date Format:

Provides eight time-and-date format configuration options. Select one to display the desired time-and-date format that appears in the upper left of the display screen. The SAVE button on the right side of the screen must be pressed to save any changes made on this screen.

(See Figure 27.1)




Figure 27.1

## 28. Software Update

### Software Update:

Provides a scrollable view of firmware history and firmware update results.

(See Figure 28.1)

- UPDATE FROM SD CARD:**  
Performs a firmware update from a microSD card installed into the unit's onboard microSD card reader when Internet access to the PROTEUS controller is not available.




Figure 28.1

**Note:** The maximum size capacity of the microSD card should not exceed 32 GB.

The microSD card must first contain the firmware upgrade, accessible from [proteusupdates.omntec.com](http://proteusupdates.omntec.com), prior to being at the site without Internet. See [document 500183 \(PROCEDURE 2\)](#) from [www.omntec.com](http://www.omntec.com) for more details on doing these steps.


- UPDATE FROM OMNTEC SITE (recommended method):** Performs a firmware update directly from the display panel to OMNTEC's website. Internet access to the PROTEUS is required.
- LOAD PREVIOUS RELEASE:** Reverts to the previous firmware version stored in the system's memory.
- OPTIONS:** Enables additional firmware options. **For OMNTEC use only.**

## 29. Email Account

### Email Properties:

Setup page for enrolling in automatic email updates.


(See Figure 29.1)



The screenshot shows the 'EMAIL PROPERTIES' setup page. At the top, the date and time are 'Jun 22, 2023 12:19:07' and the status is 'SETUP'. The page contains several input fields: 'USER NAME' (USER@EMAIL.COM), 'PASSWORD' (masked with asterisks), 'SENDER NAME' (EMAIL FROM LABEL), 'SENDER EMAIL ADDRESS' (USER@EMAIL.COM), and 'OUTGOING MAIL SERVER(SMTP)' (MAIL.EMAIL.COM). Below these fields are four controls: 'SERVER PORT#' (25), 'SERVER REQUIRES AUTHENTICATION' (Login), 'TLS ENABLE' (off), and 'STARTTLS' (off). On the right side, there is a 'SETUP' button with a house icon and a circular arrow icon.

Figure 29.1

- a) **User Name:** Login name used for sending email.
- b) **Password:** Password for the above User Name.
- c) **Sender Name:** Name of email originator.
- d) **Sender Email Address:** Address of the email originator. Appears on the email together with the controller's "EL" (serial) number.
- e) **Outgoing Mail Server (SMTP):** IP address of the mail server, or the mail server domain name.
- f) **(Mail) Server Port #:** Default is 25 and can be changed to match the site's mail server port.
- g) **Server Requires Authentication:**  
Selectable dropdown (▼) options are OFF, LOGIN, AUTO, or PLAIN.  
(See Figure 29.2)
- h) **TLS Enable:** Ensures that data transmitted between controller and the email server is encrypted and secure.
- i) **StartTLS:** Used as a protocol extension for communication by email.



This screenshot is identical to Figure 29.1, but with the 'SERVER REQUIRES AUTHENTICATION' dropdown menu open. The dropdown shows four options: 'Off', 'Login' (highlighted in red), 'Auto', and 'Plain'. The 'Login' option is selected.

Figure 29.2

## 30. Email Setup

### Email Properties – User Addresses And Events:

This will allow the user to send email and text message reports to inputted email addresses or mobile numbers, up to a maximum of eight address entries.

(See Figure 30.1)




Figure 30.1

- a) **Address (1 through 8):** This allows the user to input and send email and text message reports to specific email address or mobile number recipients.

(See Figure 30.1)

**Note: Individual alarm events can only be sent to address fields 1, 2, or 3. All Alarms Only events can be sent to address fields 1-8.**

(See numbering list 30.d and Figure 30.2)

- b) **Delivery (Drop) Reports:** If enabled, a Delivery/Drop Report is sent to an assigned email or mobile number (detailed previously in numbered list 30.a).
- c) **Current Status Report:** If enabled, the Current Status Report will be sent to the assigned email address or mobile number (detailed previously in numbering list 30.a) after every shift.
- d) **Alarms (All Alarms Only):** If enabled, a report will be sent to the assigned email address or mobile number every time there is an alarm (addresses 1-8, detailed previously in numbering list 30.a). Another option is to choose individual “alarm events” (addresses 1-3).
- e) **Input Events:** If enabled, a report is sent to the assigned email address or mobile number (detailed previously in numbering list 30.a) every time there is an input event.

**Note:** To set individual alarm events (address fields 1, 2, or 3 only), press SET ALARM EVENTS to the right.

(See Figure 30.2)




Figure 30.2