



## Robot Operational Manual Packet



This Page Was Left Intentionally Blank



WELLIH



## **WARNING**

Please carefully read Operational  
Manual prior to equipment operation.

# Table of Contents

<b>Preface</b> .....	<b>5</b>
<b>Guarantee</b> .....	<b>5</b>
<b>1.0 Controller Description</b> .....	<b>6</b>
1.1 Emergency Stop Button .....	7
1.2 Robot Enable Switch .....	7
1.3 Safety Switch .....	7
1.4 Run Button .....	8
1.5 Stop Button .....	8
1.6 Lock Switch .....	8
1.7 Indication Lights .....	8
1.8 Motor Enable Hotkey .....	9
<b>2.0 System Start &amp; Stop</b> .....	<b>10</b>
2.1 Start System .....	10
2.2 Shutdown System .....	11
<b>3.0 Emergency Stop &amp; Release</b> .....	<b>12</b>
3.1 Emergency Stop Operation Method .....	12
3.2 Emergency Stop Release Method .....	13
<b>4.0 Screen Description</b> .....	<b>12</b>
4.1 Home Page & Passwords .....	14
4.1A Robot User Levels of Access .....	15
4.2 Reset Button .....	15
4.3 Startpoint Button .....	16
4.4 Testrun Button .....	16
4.5 Autorun Button .....	16
<b>5.0 The Function Menu</b> .....	<b>17</b>
5.1 Teach .....	18
5.1A To Edit An Existing Program .....	19
5.1B Creating a New Program .....	19
5.1C Axis Motion .....	21
5.1D Vacuum Grip .....	22
5.1E Stack Motion .....	23
5.1F Wait Signal .....	25
5.1G IMM Signal .....	26
5.1H Label & Jump .....	27
5.1I Jump Example .....	28
5.2 Function Set .....	29
5.2A I/O Check Tab .....	29
5.2B Time Set .....	30
5.2C Limit Position .....	31
5.2D Special Set .....	32
5.3 System Set .....	33
5.4 Mould Set .....	34
5.5 Alarm List .....	35
5.6 Production Set .....	36
<b>6.0 Monitor</b> .....	<b>37</b>
<b>7.0 Manual</b> .....	<b>38</b>
7.1 Manual Axis Operation .....	39
7.2 Manual Vacuum & Grip Operation .....	39
7.3 Relieving Axis Overstroke Alarm .....	30
<b>5.0 Program</b> .....	<b>41</b>
<b>6.0 Modify</b> .....	<b>42</b>
<b>7.0 Robot Alarm Troubleshooting Guide</b> .....	<b>44</b>
<b>8.0 Electrical &amp; Pneumatic Schematics</b> .....	<b>49</b>
<b>Robot Preventative Maintenance Schedule</b> .....	<b>66</b>
<b>Contact Us</b> .....	<b>68</b>

## Preface

Dear Valued Customer,

At Absolute Robot Inc., we appreciate your business and look forward to helping you efficiently automate your success. The automated fabrication and design of this robot is suitable for heavy-type operations, designed for customers seeking to increase efficiency.

The purpose of this Operation User Manual is to thoroughly outline and describe the corresponding and necessary safety, installation, operation, and maintenance of your robot. As such, please read this manual carefully, before operating your robot to ensure the proper safety measures are being taken.

To ensure all safety measures are taken before, during, and after robot's operation, prior to installation, please check the robot and its respective components on the provided "Parts List" for any damage that may have incurred during transit. If there are any missing or damaged parts, please contact ARI customer service immediately. See the following "Guarantee" for further outlined details.

### **Absolute Robot Contact Information:**

**Phone:** +1 508-792-4305

**Fax:** +1 508-792-9646

**Email:** [service@absoluterobot.com](mailto:service@absoluterobot.com)

**Website:** [www.absoluterobot.com](http://www.absoluterobot.com)

## Guarantee

Prior to your robot arriving at your facility, it will have been thoroughly inspected and tested by our engineering team to ensure operational success.

Please visually check the robot's exterior for any possible damage, which may have been caused during transit and then carefully remove all packaging and robot parts. If you find damage that occurred during transit, please take the following listed actions:


- a. Notify the Transportation Company or your sales distributor immediately.
- b. File a "Damaged Goods" claim to the corresponding Transportation Company.
- c. Retain the damaged goods for inspection. **Do not** send the damage parts back **unless** directly instructed to do so.

## 1.0 Controller Description

Controller Description is outlined to describe and illustrate the robot's main Controller System, its respective buttons and its variety of automation-related necessary functions.

Pictured below is the robot's controller of "HMI" which houses the robot's controlling screen, buttons and components necessary for the Robot User to control and automate the robot's programmed and un-programmed actions. Below are the following components of the controller.

- Run Button
- Lock Switch
- Emergency Stop Button
- Motor Enable Hotkey
- Stop Button
- I/O Indication Lights



## 1.1 Emergency Stop Button

Press the E-Stop button if an emergency occurs at any point during operation to immediately cease all operations.



- I. If the “Emergency Switch” is pressed, it can cause a malfunction. DO NOT press the switch unless it is an extreme emergency
- II. After the emergency situation has been cleared, the equipment can only be restarted.
- III. Before restarting, make sure the area is safe and all personnel are clear of the working area.

**\*\*Failure to follow these instructions may cause injury\*\***

## 1.2 Robot Enable Switch

Pictured below is the “Robot Enable Switch” which is flipped on to enable robot operation. When the switch is flipped off, the robot forces all enable signals to the IMM. If the operator needs to move the IMM in manual or setup modes, the Robot Enable Switch must be in the off position.

**Robot Enable Switch**



**Note: The Robot Enable Switch may only be turned off when the robot’s vertical arm (Z-Axis) is green and it is at its 0.0 position.**

## 1.3 Safety Switch

Below is the Safety of “Dead Man Switch”. This switch is located on the back left-hand side of the robot’s HMI.

Lightly press the Safety Switch when operating the robot in Manual or Teach modes or when the below warning is displayed.

**Safety Switch**



**Press Safety Switch Screen**



## 1.4 Run Button

The Run Button is the green button located on the front of the robot's HMI .

The Run Button is used to initiate the “Autorun” and “Testrun” operating modes. In mode “Testrun” or “Autorun,” when the Controller’s screen system prompts the following:



Press down the green “Run Button”  and the robot will start the “Autorun” or “Testrun” mode.

## 1.5 Stop Button

The Stop Button is the red button located on the front of the robot's HMI .

The Stop Button can execute three (3) different functions:

1. During “Autorun” mode, the Stop Button will stop the robot’s automatic cycle.
2. The Stop Button clears robot alarms after the alarm has been acknowledged.
3. The Stop Button acts as a shortcut to the robot’s Main Screen.



## 1.6 Lock Switch

When the corresponding Controller Key is removed, the robot’s automations and/or functions **cannot** be revised by any parameters of the Controller, at which time the Controller is considered “Locked” wherein operations are protected with a password. Removal of the key brings the robot to Access Level “0” by default.

## 1.7 Indication Lamp

Figure 1.1E: Indication Lamp



As pictured above in Figure 1.1E, the LED signal lights represent whether an input or output is present. If the signal is present, the LED will illuminate.

### Robot Inputs

LMD: Safety Door  
LMO: Mold Opened  
LMC: Mold Closed

### Robot Outputs

ME: Enable Ejectors  
MC: Enable Mold Close  
MS: Enable Cycle

## 1.8 Motor Enable Hotkey




Pictured below, is the Motor Enable Screen. To turn on the robot's motors, select the Motor Enable Hotkey, then select the "Motor Enable" soft key. This will allow the servo drives to send power to their respective motors.

When enabling the robot's motors, verify that the global speed indicator is at its maximum position to enable a full range of operating speed.

To Exit the Enable Motor Screen select "Cancel"

**Figure 1.1F: Language Hotkey**



### **WARNING**

**Make sure work area is clear of all personnel and area is deemed safe prior to enabling the robot's motor power.**

## 2.0 System Start and Stop

This System Start and Stop Section attempts to outline and describe the starting and stopping of the automated system.



**To ensure proper safety precautions, make sure no personnel is within the stroke range when starting the robot. The robot user must follow these safety precautions:**

- 1. Do not start system when or if there is someone or something in designated work area.**
- 2. Do not start system when or if there are signs of faulty equipment.**

**Note: Failure to follow the three steps may lead to a production accident, resulting in serious injury.**

### 2.1 Start System

1. To power on your robot, make sure the main disconnect is closed or “ON”.
2. Select the green start button on the remote start/stop switch.
3. When the robot has finished initializing, the “Initialization Complete” prompt will display on the pendant screen select “Ack” for acknowledge.
4. Now select the key symbol located at the top of the robot pendant display and enter your designated level of access password.
5. Next, select the “FN” button and select “Enable Motor” to turn the robot’s servo motors on. When finished, select “Cancel”.
6. Next, we need to select “Reset” to reset the robot and bring it to its start position. When the robot has been successfully reset, four blue arrows will appear at the top of the robot pendant display .
7. After the robot has been reset, verify there is a green house at the top of the pendant display, indicating the robot is at its start point or home position.
8. You are now ready to upload your desired program and initiate an automatic cycle between the robot and the IMM.

## 2.2 Shutdown System

- a. Stop the Auto Cycle between the IMM & robot.
- b. Once the robot or IMM has stopped, select the stop key  on the robot pendant to exit the “Autorun” mode on the robot.
- c. If you intend to use your IMM without the robot, go into manual and traverse the robot outward so the robot is no longer above the mold area.
- d. Once the robot is in the desired location, select the “FN” key , then de-select “Enable Motor” to de-energize the axis motors.
- e. With the robot’s motor power off, the robot user may now power down the robot by pressing the remote start/stop switch. The main disconnect switch may remain in the “On” or “Closed” position when the robot is off.



Main Disconnect



Start/Stop Switch



If the main disconnect switch is in the “On” position, there is still live power on the line and load side of that main disconnect, even when the robot is off.

If the main disconnect switch is in the “Off” position, there is still live power on the line side of the main disconnect, even when robot is off.

## 3.0 Emergency Stop and Release

Section 1.3 Emergency Stop and Release attempts to outline and describe the necessary methodology of an emergency stop and emergency release. This function is an ‘Emergency State’ function and is **only** to be used in an apparent dangerous situation. If the machine or robot is running normally, do not use this function.



**If a dangerous situation is about to occur or has already occurred, quickly use/press the emergency stop switch to immediately stop the robot.**

**Failure to heed these instructions may lead to product failure or injury.**

### 3.1 Emergency Stop Operation Method

Section 1.3A Emergency Stop Operation Method outlines and describes the necessary methodology for an Emergency Operational Stop. This robot is equipped with an “Emergency Stop Button,” as pictured below. This button is to be pressed, in case of an emergency. The Emergency Stop button is located on the front of the HMI.




When the “Emergency Stop Button” is pressed, an alarm will sound. All the motors will power off and vacuum and gripper circuits will open.



- I. **If the “Emergency Stop button” is pressed, it can cause a malfunction. DO NOT press the switch unless it is an extreme emergency**
- II. **After the emergency situation has been cleared, the robot needs to be reset**
- III. **Before resetting the robot, make sure the area is safe and all personnel are clear of the working area.**

**\*\*Failure to follow these instructions may cause injury\*\***


## 3.2 Emergency Stop Release Method

1. Relieve the robot's Emergency Stop situation by turning the E-Stop button clockwise and pulling up.
2. Per ANSI regulations, when the robot's E-Stop is activated, the robot will force the user to reboot the robot. To reboot, turn the robot off, wait three seconds, and turn the robot on. When the robot is finished booting, sign into your designated level of user access, and enable the robot's servomotors by hitting the "FN" or "Lang" key .
3. You may now reset the robot.
4. Verify you are at your home position .
5. Once the robot is reset, disable the robot, and activate the IMM's automatic cycle. Once the IMM's clamp is closed, re-enable the robot and press "Autorun" . After the "Autorun" soft key has been pressed, select the green Run Button. Now your robot and IMM are in automatic cycle.

## 4.0 Screen Description


Section 1.4 Screen Description illustrates the robot software's variety of screen displays and their respective functions.

*Please note this screen is a touchscreen, simply touch the screen for a response.*



## 4.1 Home Page and Passwords

After the system robot's software finishes initializing, the robot's homepage will become present on the HMI's Touchscreen Display



## 4.1A Robot User Levels of Access:

Level 0: Default password – Robot user can reset, view program, and can start/stop auto-run.

Level 1: Robot user can operate in manual, teach program, and modify. (Password: 9999)

Level 2: Robot user can change the special set, production control, and subprogram design. (See Administrator for Password).

Level 3: Robot user can enter Advanced Set in the Function Set. (See Administrator for Password).

Level S: Same at level 3 but you can alter program software. Level “S” also allows for “jumping” over program lines in the teach menu. (See Administrator for Password).

## 4.2 Reset Button

Resetting your robot allows the robot to find its actual positions. Once it's positions are found, it will return to its 0.0 position or its Startpoint value in the “Mould Set” Tab in the Function Menu.

The robot will need to be reset for the following reasons:

- During robot start-up
- After an alarm has been cleared
- After your axis origin has been altered

To Reset Your robot, follow the instructions below:

1. Make sure your robot is powered on, the robot user is signed in  and the robot's motor power is enabled.
2. Select the reset button 
3. Your robot will now reset. Once the reset is complete, the robot will be at its Axis 0.0 or Startpoint position.



**Helpful Hint:** If the robot alarms and displays “Not in Safe Position”, this is an indication that one or several of the critical robot Axis’ (Z, C, or A) are not at their “0” position. This alarm is purposefully there to reduce the risk of a crash. To relieve this alarm, go into manual and manually return these Axis’ to their home positions. Once the critical Axis’ are home, you may now select “Reset” and your robot will continue with its reset.

#### 4.3 Startpoint Button



Before the robot can begin operation, the robot must be at its startpoint. The robot must also be at its startpoint in order to enter the Teach Menu. To bring the robot to its startpoint, select the "Go to Startpoint" softkey.

#### 4.4 Testrun Button



Testrun allows the Robot User to activate their robot program to operate at real-time production speeds without the cycling of the IMM. The Testrun function is useful because it allows the robot user to make changes in the "Modify" Tab then those changes can be illustrated in the Testrun function.

To activate the Testrun function:

- a. Verify the robot is at its startpoint.
- b. Select "Testrun"
- c. Hold the safety switch on the back of the HMI.
- d. Press down the "Run Button" to confirm Testrun activation.
- e. To exit the Testrun mode, select the "Stop Button".

**Note:** The "Testrun" mode cannot replace the "Autorun" mode.

#### 4.5 Autorun Button

Autorun allows the Robot User to activate the robot's automatic cycle in conjunction with the IMM.

To activate the Autorun function:

- a. With the robot standing by at its start point, verify that the program that is intended to be ran is present at the top of the robot's pendant display.
- b. **THE IMM MUST BE PUT INTO AUTO BEFORE THE ROBOT.**
- c. Before putting the IMM into Auto, be sure the enable output signals are present on the robot's HMI. If these signals are not present, cycle the "Robot Use" switch to refresh the robot's enable output signals.
- d. Now place the IMM in semi or automatic cycle.
- e. Once the IMM is in an Auto mode, select "Autorun".
- f. After "Autorun" has been selected, select the green "Run" key to confirm "Autorun" initiation.

## 5.0 The Function Menu

The Function Tab on the robot's Main Screen allows the Robot User to access the Function Menu. In the Function Menu, the Robot User can access various robot settings and create programs in the Teach Function.

From the Main Screen, press the "Function" Tab on the left-hand side of the screen. After selecting the "Function" Tab, the following display will appear as seen below.



Once the Function Tab has been selected, the following display will appear on the HMI:



## 5.1 Teach


Section 2.1 describes the proper way for the Robot User to create a new program using the Teach Function in the Function Menu.



### To Enter The “Teach Function”:

1. Select the “Teach” tab in the Function Menu.
2. After, a pop-up will appear and it will ask the Robot User if they would like to “create a new program?”; select “Ok” or “No”.
  - a. By selecting “No” the Robot User will be directed to the Teach Menu to edit the current program that is open on the Main Screen.
  - b. By selecting “Ok” the Robot User will be asked to input a name for their new program, then they will be directed to the Teach Menu.
3. After inputting your desired program name select “Ok”. The following Teach Menu will appear as displayed in Figure 2.3:

Figure 2.3: The Teach Menu




## 5.1A To Edit an Existing Program:

1. Press the respective “No” option appearing in the pop-up window.
2. Modify the parameters of the action instructed selected, by pressing “Modify” 
3. Delete the action instruction selected, by pressing “Delete” 
4. To move the Outlined Box Up or Down, select the “Previous”  and “Next” 


## 5.1B Creating A New Program:

1. Go to “Function”  , then “Teach” 
2. To Create a New Program, select “Ok”
3. Select “Axis Motion” on the right  , select desired axis to move. Hold the safety button, move the desired axis using the  or  . Save movement by selecting 
4. Hold the safety button then press  to move passed the 

**Note: Movements after this step will be the part removal sequence.**

5. Position robot in mold close to moveable platen, turn on vacuum circuits by selecting  Bring robot vacuum cups into part contact. In this position, the robot can now safely control the ejector/core functions. This option is utilized by selecting  and activating 
6. At this point, you can click on the previous Y-axis and Z-axis motions to adjust and align to the End of Arm Tool (EOAT) to the moveable platen. To adjust the previous steps, click on the appropriate axis motion. Use minor adjustments in the displayed menu. After adjustments are made, select “Save”



7. Next, Enable the ejectors back  . Move the robot out of the mold area, return the Z-axis to the zero position. Now the robot user is ready to traverse the X-Axis out over the part-drop area.

**Note: Movements after this step will be the part deposit sequence.**

8. Once the X-Axis is in the part-drop area, the X-Axis values will be displayed in **amber**. This indicates to the robot user that we are in a safe position to deposit the parts.

9. After the parts are deposited, bring all the Axis back to their 0.0 position and verify the last line in your program is “End” 

**Note: Movements after this step will be for testing the newly created robot program.**

10. Once your program has been created, exit the Teach Menu, your program will be saved automatically.
11. Now reenter the Teach Menu and step-through the entire program to verify the taught lines are being executed as intended.
12. Once the program step-through has been completed, put the robot into “Testrun” mode . Testrun will allow your robot to operate at its set real-time operating speed without IMM motion.
13. If changes need to be made to the program after monitoring the robot’s Testrun cycle. From the robot’s Main Screen, select “Modify”  and make your program adjustments accordingly.



#### **Helpful Hint:**

When creating a new program, it is easiest for the Robot User to place the part on the mold’s ejector pins. Then, select “Manual” on the Robot’s Main Screen and manually move the robot so it is in position to remove the part off the ejector pins while at this point. At this point, take note of the Y-Axis and Z-Axis values. These will be the points to program to when creating a new program in the Teach Interface.


## 5.1C Axis Motion

The Axis Motion Tab in the Teach Menu is where the robot user will input all the robot's axis motions into the robot's program.

When the Axis Motion Tab is selected, the following screen will appear on the HMI:



**To insert an axis motion into the program:**

- a. Select the Axis you would like to move from the drop-down menu  from the Axis Selection Bar 
- b. Hold Down the Safety Switch until the red pencil turns green.
- c. Now move the axis to its desired location.
- d. Once the robot is in its desired location, select "Save" 



### Helpful Hint:

When getting accustomed to creating programs, do not change the delay or speeds on any of the axis motions. Wait until after you have test-ran your program in the "Testrun" Function on the robot's main screen. Then, if there is a need to change a delay time or action speed, select the "Modify" tab on the main screen to make those changes. After the changes are complete, the Robot User can go back into "Testrun" to view the recent changes.

## 5.1D Vacuum Grip

The Vacuum Grip Tab in the Teach Menu is for adding Gripper, Vacuum, and Spare Outputs into your robot's program.


When the Vacuum Grip Tab is selected, the following screen will appear on the HMI.



## To insert a Gripper, Vacuum, or Spare Output into the program:

1. Select  to add a Gripper, Vacuum, or Spare Output. The following screen will appear on the HMI:



2. Click on the output you would like to add into your robot program.
3. Select “On”  to turn on the output.
4. Then select “Confirm” 
5. To have multiple outputs activate at once, select  again and follow the previous steps.
6. Once your desired outputs are “On”, select “Save” 

## 5.1E Stack Motion

The Stack Motion Tab in the Teach Menu is for adding part palletization stacks into your robot's program.


**Note: The Stack Motion Tab should be selected after the robot program has extracted the part for the mold's cavity and the Z-Axis is back at its 0.0 position.**

When the stack motion tab is selected, the following display will appear on the HMI.



### To Insert a Stack Motion into The Program:

1. Precondition: The Stack Motion Tab should be selected after the robot program has extracted the part for the mold's cavity and the Z-Axis is back at its 0.0 position and is **green**.
2. Select "Stack Motion"  then click on the "Stack Param" dropdown  and select 1-5 as desired. We will modify these parameters in the next step. Save the step after selecting the Stack Parameter you wish to use.



3. Select "Axis Motion" and move the X-Axis to the location of the first stack. Be sure the X-Axis values are **amber**, indicating the robot is in the part-drop area prior to starting your stack. Save the step, this step should be highlighted in green when it is saved into your program.
4. Select "Stack Motion"  again. This time, select "Modify" . Click the "Start Pos." under the X,Y, and Z Axis' then click on "OK." This will save the current X/Y/ Z Axis positions as the start of the stack
5. Next select the quantity of the parts you would like to stack in that Axis direction.
6. For product spacing, enter how far (mm) you would like to move that part in each Axis.
7. Select "Direction", and enter direction the parts will be stacking, either P- (Towards 0.0 position) or P+ (Away from 0.0 position).
8. Now select the "Back" button and "Save"  the step to complete the Stack Motion function.
9. The robot user can now program the robot deposit the parts and return to its start position to complete the program.

**Note: If you are depositing stacks on a conveyor that is interfaced with the robot, please update the “Production Set” Menu appropriately. The “Production Set” Menu is in the Function Menu.**

## 5.1F Wait Signal

The Wait Signal Tab in the Teach Menu is for adding various wait signals into your robot's program. The Wait Signal is inserted into a program to allow for the robot to "wait" until the selected IMM Signal or Spare Input Signal is present to continue with its program.

When the Wait Signal tab is selected, the following display will appear on the HMI.



There are 2 types of wait signals available; IMM Input Signals and Spare Input Signals.

IMM Input Signals	Spare Input Signals
<ul style="list-style-type: none"><li>- LMO Mold Open</li><li>- LMC Mold Close</li><li>- LMF Ejector Back</li><li>- LMR Ejector Forward</li><li>- LMT2 Core Pull Back</li><li>- LMG2 Core Set Forward</li><li>- Spare 12</li><li>- Spare 13</li><li>- Spare 14</li><li>- Spare 15</li><li>- Core Puller 5 Back</li><li>- Core Puller 5 Forward</li><li>- Core Puller 6 Back</li><li>- Core Puller 6 Forward</li><li>- LMDG Reject Part</li><li>- LMN Middle Mold Signal</li></ul>	<ul style="list-style-type: none"><li>- LP1 Spare 1</li><li>- Spare 2</li><li>- Spare 3</li><li>- Spare 4</li><li>- Spare 5</li><li>- Spare 6</li><li>- Spare 7</li><li>- Spare 8</li><li>- Check Grip &amp; Vacuum</li><li>- Z1 Down Standby</li><li>- Z2 Down Standby</li><li>- LV1 Vacuum Check</li><li>- LV2 Vacuum Check</li><li>- LV3 Vacuum Check</li><li>- LV4 Vacuum Check</li><li>- LG1 Gripper 1 Check</li></ul>

### To Insert a Wait Signal into The Program:

1. Select the desired IMM/Spare Input Wait Signal to add into your Program.



2. Select "Save"

## 5.1G IMM Signal

The IMM Signal Tab in the Teach Menu is for adding various IMM Enable signals into your robot's program. The IMM Signal is inserted into a program to allow for the robot to send an output or enable signal to the IMM. This function is important for enabling IMM ejectors forward and back, as well as core puller functions and Mold Close control.

When the IMM Signal tab is selected, the following display will appear on the HMI.



### To Insert an IMM Signal into The Program:

1. Select the desired IMM Enable Signal to add into your Program.
2. Select “Save”

## 5.1H Label & Jump


The Label Tab in the Teach Menu allows for the Robot User to reference different locations throughout the program. Labels are used in conjunction with the Jump command.

Note: It is necessary to be signed into Level "S" User Access to allow for the Robot User to use the Jump Up & Jump Down Arrows.

### To Insert Label & Jump Into Your Program:

1. Hold the safety button then press  to step through the program until you've reached the point you wish  to add a Label or Jump command. Or, if you are signed into User Level "S" you can use the Jump arrows to move your Selection Box to its proper location.
2. Select  to add a place marker or  to add in an "IF" statement.
3. The Label option (below) allows for Label 0 through 10000 to be placed anywhere in the program. Labels may be used to mark the beginning of a robot sequence for picking a part, placing a part, or anywhere during the program sequences.
4. Below is the Jump command menu. Jump command allows you to compare IO, overall Product Count or specific Counters that have been added to the robot program.
5. Using IO Port, select the desired IO. In the example, we are using IO 1 which correlates to LME1 IMM Emergency Stop. For a complete list of the IO ports, see Operator's Manual.
6. After that, select whether the signal should be on or off.
7. Then select what Label the robot should jump to. If the Label selected is not in the current program, the robot will respond with the selected "If Time Out" response.
8. Under the "If Time Out" dropdown, you can have the robot continue, alarm, exit automatic mode, etc. Select the desired reaction.

### Jump Function



## 5.1I Jump Example:

001 — Start —	010 Up,Z1:800.0->0.0,
002 Forward,Y1:0.0->200.0,	011 Traverse Out,X:0.0->1200.0,
003 Waiting LM0 Mold Opened,	012 # Pt.70=Tr,Jmp Lb2 Else Ctn
004 Down,Z1:0.0->800.0,	013 Label 1
005 VacuumGrip:SV1 Vacuum 1 output	014 Back,Y1:200.0->0.0,
006 Forward,Y1:0.0->250.0,	015 Axis,C:0.0->90.0,
007 LM.M:ME Enable ejector forward ON	016 Down,Z1:0.0->800.0,
008 Back,Y1:250.0->200.0	017 VacuumGrip:SV1 Vacuum 1 output
009 LM.M:MK Enable ejector back ON	018 # Pt.0=Fa1,Jmp Lb3 Else Ctn

9. Steps 001 through 011 is the robot sequence of removing parts from the mold and proceeding to the initial drop position.
10. Step 012 Jump Command – If INPUT 70 (Spare Input) is True (ON), Jump to Label 2. If the Signal is False (OFF), the robot will continue to Label 1.
11. Label 1 marks the beginning of robot sequence to drop parts in area 1.
12. Label 2 Marks the start of robot sequence for drop position 2.
13. Label 3 marks the start of robot sequence to return to the home position.

019 Label2
020 Traverse Out,X:1200.0->1400.0,
021 Forward,Y1:0.0->350.0,
022 Axis,C:90.0->90.0,
023 Up,Z1:800.0->800.0,
024 VacuumGrip:SV1 Vacuum 1 output
025 Label3
026 Up,Z1:800.0->0.0,
027 Axis,C:90.0->0.0,
028 Back,Y1:350.0->0.0,
029 Traverse In,X:1400.0->0.0,
030 — End —

## 5.2 Function Set

Function Set is where various program-related settings are located as well as your robot's software limit positons. To enter Special Set, Select Set Tab in the Function Menu



Once the Robot User selects the Special Set Tab, The following I/O page will appear:

### 5.2A I/O Check Tab

I/O Check	Time Set	Limit Pos	Special S
<input checked="" type="checkbox"/>	LV1 Vacuum 1 Check		
<input checked="" type="checkbox"/>	LV2 Vacuum 2 Check		
<input checked="" type="checkbox"/>	LV3 Vacuum 3 Check		
<input checked="" type="checkbox"/>	LV4 Vacuum 4 Check		
<input checked="" type="checkbox"/>	LG1 Gripper 1 Check		
<input checked="" type="checkbox"/>	LG2 Gripper 2 Check		
<input checked="" type="checkbox"/>	LG3 Gripper 3 Check		
<input checked="" type="checkbox"/>	LG4 Gripper 4 Check		
<input checked="" type="checkbox"/>	LG5 Gripper 5 Check		

Confirmation signal required for Autorun.

Confirmation signal not required for Autorun

## 5.2B TimeSet

IO Check	Time Set	Limit Position	Special Set	Go Start Point
1 Mould—Open	0.50 s	8 Time Servo Fa	1800 s	
2 CycleTimeOut	600.00 s	9 Screensaver W	9999 s	
3 ResetTimeOut	120.00 s			
4 Mould—Open	300.00 s			
5 Oil Pump Rem	15 day			
6 Screen Refresh	200 ms			
7 Step TimeOut	6.00 s			

*The Time Sets For Various Robot Inputs & Functions.*

**Note:**

- Mold-Open Delay:** This is the delay time from when the mold open signal becomes present to when robot continues with its program.
- Cycle Timeout:** When the cycle time is more than the set time, the system will stop and an alarm will sound.
- Reset Timeout:** If the robot resets more than the set time limit, the system will stop and an alarm will sound.
- Mold-Open Timeout:** The time limit of the mold-open in “Autorun,” if this action takes longer than the set time, the system will stop and alarm.
- Oil Pump Remind:** This is a set reminder to let the Robot User know the last time the robot’s axis was lubricated.
- Screen Refresh:** The refresh frequency time of the HMI display.
- Step Timeout:** The max amount of time the robot will wait for an action to complete in teach. If the action takes longer to complete than the set time, the system will stop and an alarm will sound.
- Servo dormancy:** If servo stops more than this set time, it will enter dormant state automatically.
- Screensaver Wait:** Wait time until screensaver becomes present on the HMI display.


## 5.2C Limit Position

X Min	0 mm	X Max	2000 mm	X Origin Are	200 mm	Positioning	1 mm
				1		2	
Y1 Min	0 mm	Y1 Max	830 mm	Place Begin	1500 mm	Down Stand	0 mm
Z1 Min	0 mm	Z1 Max	1300 mm	Place End	1970 mm		
				3		4	
XSafe Zone	0 mm	XSafe Zone	0 mm	XSafe Zone	0 mm	XSafe Zone	0 mm

- 1. X origin area:** Length of home position flag
- 2. Positioning accuracy:** When the current position is within 1mm to target position, the robot will be in place and start next action, if not the robot will alarm
- 3. Placed area:** It is the software limit of part-drop area
- 4. Down standby Distance:** The Z axis will move down this distance to wait Mold open. It must open the Down Standby function.

## 5.2D Special Set

The Special Set Menu allows the Robot User to change various robot function and robot program settings. The four most important settings the Robot User will need to know are outlined in green below.



*Special Set Settings*

- 1. Mold Close:**
  - a. **In Mold:** Mold will close automatically when the Z-Axis returns to 0.0
  - b. **Out Mold:** Mold will close automatically when the robot enters the part-drop area
  - c. **Manual:** The Robot User will need to insert the Mold Close Enable signal into the program for the mold to close.
- 2. Ejector:** It is the output signal “enable ejector”
  - a. **Enable:** The robot will control IMM ejector functions
  - b. **Disable:** The IMM will control the ejector functions
- 3. Core Puller:** It is the output signal “enable core function”
  - c. **Enable:** The robot will control IMM core functions
  - d. **Disable:** The IMM will control the core functions
- 4. IMI Function:** The In-Mold insert function, allow Z-Axis arm to move down with vacuum and grip signal.


## 5.3 System Set

The System Set tab in the Function Set Menu allows the robot user to change the robot's time and date display, calibrate the HMI touchscreen, turn the alarm on/off, and update robot's software.



Once the Robot User selects the Special Set Tab, the following page will appear.

**Figure 1.5G-1**




The Robot User may change date and time settings, and calibrate screens. All other possible functions should be executed with the help of ARI Service.

## 5.4 Mould Set

The Mould Set tab in the Function Menu allows the robot user to alter the robot's start positions. It also allows the Robot User to input a EOAT alteration position.

When the Mould Set tab is selected, the following display will appear on the HMI.




Having a startpoint other than 0.0 for any of the axis might be necessary depending on the type of mold installed in the IMM. For example, if the mold has a tall core stack on top of the mold, the Robot User would want to change the X-Axis startpoint so the robot does not collide with the core stack.

If the Robot User would like the robot to return to its startpoint (other than 0.0) the following option must be ENABLED




The Robot User may also input an EOAT alteration position. This allows the Robot User to move the robot to a dedicated position where he EOAT can be altered or changed.



## 5.5 Alarm List

The Alarm List tab in the Function Menu allows the Robot User to view and clear robot alarm messages. This robot's alarm list can save up to 128 alarm messages. The Robot User can only clear alarm messages if they are signed into level "S".



When the Alarm List Tab is selected, the following display will appear on the HMI.

Time	Code	Error Message	Unclear	Back
2015-08-24 13:23:41	59	59 Step action Timeout		
2015-04-07 15:53:52	59	59 Step action Timeout		
2015-04-07 15:46:11	59	59 Step action Timeout		

Below the table are three buttons: 'Clear' and 'Servo Err Record' on the right, and a large empty area at the bottom.

## 5.6 Production Set

The Production Set Tab allows the robot user to control the conveyor output signal when a conveyor is interfaced with the robot.

When the Production Set Tab is selected, the following display will appear on the HMI.



- 1. Product Output:** Input a value to control the amount of products being extracted. When the limit has been reached, the robot will alarm
- 2. Transfer Qty:** The conveyor will index once the transfer quantity value has been met. If you are stacking parts on a conveyor, it is important to make sure the transfer quantity matches the amount of parts in that particular stack.
- 3. Transfer Time:** This is how long the conveyor output will remain “On”.
- 4. Samplings:** If set as a given number, system will take out a sample to setting position every cycle.
- 5. Defectives:** If the amount of defective parts has reached the set point, the system will alarm and stop. You can set the placed position of defective parts. (Note: You should open the check of defective signal in Special Set.)
- 6. Tests:** In Autorun, the test cycle number and put the product to setting position.


To manually turn on the conveyor select and the conveyor will move until the transfer time has been met.

## 6.0 Monitor

The Monitor Tab is used for monitoring specific operational and automation signals.



When the Monitor Tab is selected, the following display will appear on the HMI.



Here the Robot User can view various I/O signals from the robot, IMM, and any spare or auxiliary interfaced equipment. Robot outputs are shaded in grey and robot inputs are shaded in pink.

When a signal becomes activated, the grey square next to the signal will turn green.

## 7.0 Manual

The Manual Tab allows the Robot User to manually move all the robot's axis, turn on/off vacuum and gripper circuits, turn on/off any spare output signals, and allows the Robot User to clear over-stroke alarms.



When the Manual Tab is selected, the following display will appear on the HMI:



**Prior to operation, please confirm nobody is in the robot work area**

***Failure to ensure these safety measures, may lead to production accident, and/or very serious injury. Please take notice.***

**Please refer to the following three (3) outlined steps taken to ensure proper technique:**

## 7.1 Manual Axis Operation:


1. Select the Axis you would like to move in the dropdown menu or click the axis coordinate on the top of the screen.



2. Set Distance by selecting the best option provided by the dropdown menu (pictured to the right) or by manual input. The axis can only move the distance cited, so be diligent to press the "move button" every time. The distance "0" is unlimited movement.



3. To set the speed at which the axis is running, look to the display screen to see an image like the one pictured to the right. The less number of red bars displayed = a slower running axis, while the more red bars displayed = a faster running axis.



## 7.2 Manual Vacuum & Grip Operation



1. Select the Vacuum or Gripper output button to turn on the designated vacuum/gripper circuit.
2. If an input is triggered, a green light will appear next the respective signal in the pink input box on the left side of the HMI display.

## 4.3 Relieving Axis Over-Stroke Alarms

An axis minimum/maximum alarm becomes present when the robot over-strokes one of its axis' limits. This alarm is generated when the robot axis' min/max sensors travel over their respective flags. This condition can occur when the robot is moved in manual prior to resetting the robot. This condition may also occur if your axis' soft limits are greater than the available stroke of that axis.

Please use the following procedure to clear your axis min/max alarm:


1. When the min/max alarm is present, select "Know" and hit the red "Stop" button to clear the alarm.
2. Once the alarm is cleared, please select the "FN" or "Lang" key to enable the robot's motors.
3. Once the motors re-enabled, select the "Manual" tab on the robot's main screen. Once in manual, select the "Open Enable Motor" tab. 
4. Once the "Open Enable Motor" tab has been selected, select the "Open Enable Motor" soft key. 
5. Once the soft key has been pressed, you will notice the axis value colors on the top of the HMI will go from yellow to grey/white.
6. Now while still in the Manual Function, select "Axis" and move your axis in the direction in which you need to move to relieve the alarm.
7. Once the axis has been moved, select the "Reset" key located at the bottom of the robot's main screen.
8. After resetting the robot, ensure the robot is at its home position and then resume normal robot operations.

## 5.0 Program

The Program Tab allows the robot user to open existing programs, copy, rename, and delete programs as well as upload and download programs to a USB thumb drive.



When the Program Tab is selected, the following display will appear on the HMI:



- Select where you would like to save or load your robot program
- Open the selected program to set as the current program
- Create a new program and label its corresponding name
- Save program selected as a different name (used to copy programs)
- Delete the Local program selected.



### Helpful Hint:


When creating a new program, it is easiest for the Robot User to select the "Teach Tab" instead of creating a new program in the "Program Tab".

## 6.0 Modify

Selecting the Modify Tab allows the Robot User to modify program lines of the current open program. The robot user can modify the program while the robot is stationary or in Autorun mode.



When the Modify Tab is selected, the following display will appear on the HMI:



### Modifying The Open Robot Program

1. Select the program line you would like to modify by selecting that particular program line.
2. The robot user now has the option to modify that program line.
3. To increase decrease delay times, select the Delay setting and input your desired delay time. Delay  s
4. To increase/decrease axis positions, select the position setting and modify the axis position by 1mm or .1mm at a time. -0.2mm -1.0mm X轴 : 0.0mm +1.0mm +0.2mm
5. To increase/decrease speeds of that program line, select the speed setting and adjust it accordingly. -0.2mm -1.0mm X轴 : 0.0mm +1.0mm +0.2mm
6. When the modifications are finished, select Save. Save

This Page Was Left Intentionally Blank

## 7.0 Robot Alarm Troubleshooting Guide

No.	Name	Detail	Failure Type	Cause	Corrective Action
0	X: Z-axis is not at origin	When the function of "Traverse In Mold" is Enabled, X axis can't move to out of Origin area	Operation error	When the function of "Traverse In Mold" is Enabled, X axis can't move to out of Origin area if Z axis is not at the Origin.	Move X Axis back to origin
1	X: Z-axis is not at origin and forbidding Traverse In Program	When the axis is not at the Origin, function of "Traverse In Mold" is Enabled, X axis can't move if Z axis is not at the Origin.	Operation error	When the function of "Traverse In Mold" is Enabled, X axis can't move if Z axis is not at the Origin.	Disable the traverse in Module or open the Traverse In Module
2	X: No mold opened signal	When in standby, and out of Mold, robot doesn't allow X axis to move if the Mold opened signal is not received.	No Mold opened signal	1. Contact the IMM service 2. Relay board LMD has poor contact 3. 16P cable contact: 26# poor contact 4. Main board can not receive the 5. No mold open signal from the IMM	1. Check with service engineer 2. Change board 3. Change board 4. Change the Main board cable 5. Check the IMM
3	Z: C axis Horizontal, Forbid fall down.	When C Action In Mold is disabled, the action is disabled	Operation error	When C Action In Mold is disabled, forbids the arm to fall down if action is disabled	please move the C to vertical 2. Set the C Action
4	Z: Safety Door not open, Forbid fall down.	When robot is in horizontal position and the safety door is open the robot z axis can not operate	No safety door signal	1. The relay on the IMM 2. Relay board LMD poor contact 3. 16 pin cable contact number 15 has a poor connection 4. Main board can not receive the 5. IMM safety door is not closed	1. Check relay replace if bad 2. Change the relay board. 3. Change 16 pin cable 4. Change Main board 5. Check the IMM
5	Z: X Axis position mistake, forbids fall down.	X axis not at origin	Operation error	The X axis is not at origin or placed area. This prevents Z axis from moving.	Move X Axis to origin or placed area at first, then try to move
6	Z: No mold open signal,Forbid fall down.	No mold open signal from the IMM	IMM error	1. Contact the IMM service 2. Relay board LMD has poor contact 3. 16 Pin cable contact number 20 has a poor connection 4. Main board can not receive the 5. No mold open signal from the IMM	1. Check with service engineer 2. Check the connection if its good then change board 3. Check the connection if its good then change board 4. Change the Main board cable 5. Check the IMM
7	Target position beyond the stroke	The robot over traveled	Operation error	The drop area is beyond the stroke of the robot	Reset the target position
8	The output of Vacuum and Gripper output is turned on, and there is no part found the robot will inhibit Z from falling		Operation error	The robot vacuum check or gripper check is on and the vacuum or gripper signal is activated but there is no part.	Check the output signal, if no signal check the part vs gripper/vacuum cups.
9	C Vertical: no mold open signal	When in Standby way you get a no mold open signal	No Mold opened signal	1. Contact the IMM service 2. Relay board LMD has poor contact 3. 16 Pin cable contact number 26 has a poor connection 4. Main board can not receive the 5. No mold open signal from the IMM	1. Check with service engineer 2. Check the connection if its good then change board 3. Check the connection if its good then change board 4. Change the Main board cable 5. Check the IMM
10	Controller test fail to communicate with the main board	The controller is not getting a signal from the CPU	No main board return signal	1. Communication fail between the controller and the main board 2. Main board is damaged 3. There is no 5V power to the main board	1. Check the communication line 2. Replace the main board 3. Check the fuses if OK then change the power supply if no power request
11-14	Vacuum X hasn't return signal.	Vacuum X has no signal from the vacuum cups	No return signal	1. Vacuum leak between the cups and the part. 2. Vacuum leak in air lines. 3. Part too heavy for the vacuum.	1. Check for vacuum leaks 2. Check the airlines for leaks. 3. May need to get larger vacuum cups.
15-19	Gripper X hasn't return signal.	Gripper X has no signal from the grippers	No return signal	1. Gripper did not grab the part. 2. Gripper signal has a loose connection.	1. Check the part and gripper 2. Check the signal of the gripper in the manual section of the teach pad.
20	Reserved	Reserved	Reserved	Reserved	Reserved
21	X Max limit	X exceeded the max limit position	Prompt message	X axis moved to the Max limit	Please move X axis within the limit

No.	Name	Detail	Failure Type	Cause	Corrective Action
22	A Max limit	A exceeded the max limit position	Prompt message	A axis moved to the Max limit	Please move A axis within the limit
23	B Max limit	B exceeded the max limit position	Prompt message	B axis moved to the Max limit	Please move B axis within the limit
24	C Max limit	C exceeded the max limit position	Prompt message	C axis moved to the Max limit	Please move C axis within the limit
25	Y1 Max limit	Y1 exceeded the max limit position	Prompt message	Y1 axis moved to the Max limit	Please move Y1 axis within the limit
26	Z1 Max limit	Z1 exceeded the max limit position	Prompt message	Z1 axis moved to the Max limit	Please move Z1 axis within the limit
27	Y2 Max limit	Y2 exceeded the max limit position	Prompt message	Y2 axis moved to the Max limit	Please move Y2 axis within the limit
28	Z2 Max limit	Z2 exceeded the max limit position	Prompt message	Z2 axis moved to the Max limit	Please move Z2 axis within the limit
29	X Min limit	X exceeded the min limit position	Prompt message	X axis moved to the Min limit	Please move X axis within the limit
30	A Min limit	A exceeded the min limit position	Prompt message	A axis moved to the Min limit	Please move the A axis within the limit
31	B Min limit	B exceeded the min limit position	Prompt message	B axis moved to the Min limit	Please move B axis within the limit
32	C Min limit	C exceeded the min limit position	Prompt message	C axis moved to the Min limit	Please move C axis within the limit
33	Y1 Min limit	Y1 exceeded the min limit position	Prompt message	Y1 axis moved to the Min limit	Please move Y1 axis within the limit
34	Z1 Min limit	Z1 exceeded the min limit position	Prompt message	Z1 axis moved to the Min limit	Please move Z1 axis within the limit
35	Y2 Min limit	Y2 exceeded the min limit position	Prompt message	Y2 axis moved to the Min limit	Please move Y2 axis within the limit
36	Z2 Min limit	Z2 exceeded the min limit position	Prompt message	Z2 axis moved to the Min limit	Please move Z2 axis within the limit
37	Reserved	Reserved	Reserved	Reserved	Reserved
38	Reserved	Reserved	Reserved	Reserved	Reserved
39	Reserved	Reserved	Reserved	Reserved	Reserved
40	Reserved	Reserved	Reserved	Reserved	Reserved
41	Robot Emergency Stop Button is Pressed	The estop on the pendant has been depressed	Prompt message	Check the emergency stop button	Please reposition Emergency Stop button
42	The emergency stop of IMM is Pressed	The estop on the IMM has been depressed	Prompt message	1. Check the emergency stop button on the IMM. 2. Check for 24 volt power on the relay	1. Please reposition the Emergency Stop button 2. Change the power supply or the relay
43	Wait timeout of mold-open signal	The robot did not receive the mold open signal	Prompt message	1. Contact the IMM service. 2. Relay board LMD has poor contact 3. 26 Pin cable contact number 20 has a poor connection 4. Main board can not receive the 5. No mold open signal from the IMM	1. Contact the IMM service 2. Check the connection if its good then change Board 3. Check the connection if its good then change board 4. Change the Main board cable 5. Check the IMM
44	no injection signal	This function is not used in the USA	Not used		
45	Discover the Reject products	The robot received a reject signal from the machine	Prompt message	Received defective part signal from the IMM	Check the settings on the IMM.
46	Try to start the motor without power-on	Motor not energized	Operation error	Turn on the drives	Turn on the drives
47	Axis position abnormal	The position of one of the axis is wrong	Machine Error	Axis position has a bad with signal	Please check the arm fault and reset robot
48	Pneu axis position abnormal	The pneumatic axis is in the wrong position	Machine Error	1. There is no signal from the pneumatic axis 2. The signal is not received on the 3. The robot axis is not correct	1. Check air supply 2. Check the sensor. 3. Put the axis in the correct position
49	Can't Reset because of no mold open signal.	Mold open signal missing from the IMM	No Mold open signal	1. Contact the IMM service 2. Relay board LMD has poor contact 3. 26 Pin cable contact number 20 has a poor connection 4. Main board can not receive the 5. No mold open signal from the IMM	1. Check with service engineer 2. Check the connection if its good then change Board 3. Check the connection if its good then change board 4. Change the Main board cable 5. Check the IMM
50	No robot Automatic Run signal	The machine does not have the automatic signal	No Automatic Run signal	1. IMM robot function not on 2. Contact the IMM service 3. Check the relay board LMD has a poor contact 4. 26 Pin cable contact number 20 has a poor connection signal	1. Enable robot use on the IMM 2. Contact the IMM service 3. Check the connection if its good then change Board 4. Check the connection if its good then change board 5. Change the Main board cable

No.	Name	Detail	Failure Type	Cause	Corrective Action
51	Z1 axis is not at the origin	Z1 axis is not at the origin position	Operation error	Z1 axis is out of position	In manual move the Z axis up then press the home position button
52	Y1 axis is not at the origin	Y1 axis is not at the origin position	Operation error	Y1 axis is out of position	Press the home position button
53	X axis is not at the standby position	X axis is not at the origin position	Operation error	X axis is out of position	Press the home position button
54	Z2 axis is not at the origin	Z2 axis is not at the origin position	Operation error	Z2 axis is out of position	In manual move the Z axis up then press the home position button
55	Y2 axis is not at the origin	Y2 axis is not at the origin position	Operation error	Y2 axis is out of position	Press the home position button
56	C axis is not at the standby position	C axis is not at the origin position	Operation error	C axis is out of position	Press the home position button
57	Reset timesut	While reinitializing the robot timer	Prompt message	Robot took too long to reset	Adjust the reset speed or time
58	Cycle timeout	Cycle time is longer than the timer settings	Prompt message	Cycle time is greater than the setpoint	Adjust the autostart speed and/or the timeout time
59	Step action Timeout	Step time is longer than the step timer settings	Prompt message	Step time is greater than the setpoint	Adjust the step run timeout time
60	The Safety Door open in Autostart	The IMM safety door was opened during the run cycle	Prompt message	The Safety Door open is opened on the IMM	Close the safety door on the IMM
61	Mold open signal interrupt	Finish open Mold but robot don't receive the mold open signal	Machine Error	IMM did not send the mold open signal	Check that the mold open reached its position on the IMM
62	Ejector back Timeout	IMM ejectors did not reach their back position	Prompt message	IMM fault ejectors did not retract in time	Check eject retract timer
63	Disable function of C action in mold	When C Action in Mold is disable, try to move C axis in Mold area	Operation error	C axis action is disabled	Enable C action in mold function
64	reserved	Reserved	Reserved	Reserved	Reserved
65	There is no standby signal and Z axis isn't at Origin	When down Standby is enable, Z axis can not move	Machine Error	The machine is not at its home position	Reset robot
66	Reserved	Reserved	Reserved	Reserved	Reserved
67	Robot pause,Please press the use/no use switch to enable robot.	The robot is in no use function	Operation error	When Use Switch is Off, try to reset robot	Toggle the Use Switch and reset robot
68	Robot must be pause at safety position and IMM safe	Arm is not in a safe position	Operation error	1. Try to turn off Use Switch 2. Z axis arm is down	Move arm to safety position and turn off the toggle switch Move the Z axis in manual to the 0 position
69	X axis Start position signal is abnormal	X axis is not in the proper start position	Operation error	Check the start position	Reset the robot or press return to home position
			Origin or placed position abnormal	1. Sensor position wrong 2. I/O board SR1H has poor contact 3. I/O board LR1H has poor contact 4. 25 Pin Cable poor contact	1. Rewire the sensor 2. Check for a poor connection. If still a problem replace the I/O board 3. Check for a poor connection. If still a problem replace the I/O board 4. Rewire or replace the 25-pin connector card
			Machine Error	Servo response is slow	Adjust the servo parameter
70	Pneumatic axis motion Overtime	A or C axes did not move in time	Prompt message	Pneumatic axis motion time is greater than STE time	1. Check the cylinder to make sure it moves freely 2. Increase the STE time
71	X axis product placed signal is abnormal	X axis product place signal is not correct	Signal abnormal	1. Sensor position is wrong 2. I/O board LP3 has poor contact 3. 25P Cable has poor contact	1. Adjust the sensor position 2. Check for a poor connection. If still a problem replace the I/O board 3. Rewire or replace the 25-pin connector card
			Machine Error	1. Servo response is slow	Adjust the servo parameter
72	X axis origin signal is abnormal	X axis origin signal is not correct	Signal abnormal	1. Sensor abnormal 2. I/O board LZ1 has poor contact 3. 25P Cable has a poor connection 4. Main board is not receiving the	1. Rewire the sensor 2. Check for a poor connection. If still a problem replace the I/O board 3. Change 25 pin cable 4. Change Main board

No.	Name	Detail	Failure Type	Cause	Corrective Action
73	Z axis origin signal is abnormal	Z axis origin signal is not correct	Signal abnormal	1. Sensor abnormal 2. I/O board EZ1 has poor contact 3. 2SP Cable has a poor connection 4. Main board is not receiving the signal	1. Rewire the sensor 2. Check for a poor connection. If still not working, change 26 pin cable 3. Change 26 pin cable 4. Change Main board
				Machine Error	Servo response time is slow Adjust the servo parameter
74	Product placed and origin signal exist together on Z axis	Product placed and x axis signal exist at the same time	Machine Error	1. The signal wiring is wrong 2. Product placed or origin sensor has a short circuit	Check the circuit
75	C axis horizontal signal interrupt	C axis did not receive the horizontal signal	Machine Error	1. Lost the air pressure 2. Part is too heavy for the C axis 3. C axis moves too slow 4. Main board can not receive the signal	Check circuit fault
76	C axis vertical signal interrupt	C axis did not receive the vertical signal	Machine Error	1. Lost the air pressure 2. Part is too heavy for the C axis 3. C axis moves too slow 4. Main board can not receive the signal	Check circuit fault
77	Stack Number shouldn't be Zero.	Stack value is set to 0	Operation error	1. The robot received the wrong add to stack signal 2. The wrong action occurred 3. Sensor and part did not touch correctly abnormal stack end	1. Check the robot stack settings 2. Check the robot for a fault 3. Adjust the sensor and the metal plate
78	Reset unfinished, please check the state of axes.	Reset abnormal	Machine Error	1. The robot did not finish the reset function 2. The reset function took too long 3. One of the axes are outside the limits	1. Check which axis did not finish the reset 2. Adjust the reset timer or increase the reset speeds 3. Adjust the offset values
79	Not teach stack end mark	Missing the stack end command	Operation error	The teach step is abnormal the stack end not reached.	Add the end mark in program
80	Not teach Check place product end mark	Missing the product end command	Operation error	The teach step is abnormal the product end mark not reached	Add the end mark in program
81	Teach check place product abnormally	The product drop area is not correct	Operation error	Check the drop area settings so they are within the drop area limits	Check the sampling and test settings for proper X axis settings
82	Teach position Not locate product place	The product place area is outside the limits	Operation error	Stack position did not locate product place value	Reprogram the product place value within the limits
83	Servo driver alarm	Servo drive has a fault	Operation error	Servo drive error	Check the servo drive code and call service
84	Communication test fail with servo, please Power on again	Controller sent the signal to servo, but it did not receive return signal	No servo return signal	1. Communication fault between the servo and the controller 2. Servo address is wrong 3. Servo delay time is not correct	1. Check the communication cable 2. Check the servo address 6C00 3. Check the servo delay time
85	not allow to down without middle—mold signal	Z not allowed to go down without the mid mold signal from the IMM	No middle mold signal given	1. Relay board not getting the signal 2. IMM not giving the signal 3. Main board is not receiving the signal 4. The position of the sensor signal is not correct	1. Rewire the sensor 2. Check the IMM to make sure the signal is activated 3. Change the main board 4. Adjust the position of the sensor
86	Not receive the mold closed signal	Don't receive the mold close signal from IMM	No Mold closed signal	1. Signal circuit fault 2. Check the IMM for mold close signal	1. Check circuit fault 2. Check the contact or IMM service
87	imm motion segments controlled by servo are	Servo drive has a fault	Prompt message	The signal for the servo is creating a fault	Check the circuit fault
88	Mold opened and mold closed signal exist together	System receive Mold opened and Mold closed signal at the same time	Machine Error	IMM signal is shorted out	Check wiring
89	non Defined Err Happen, please contact with The Server.	Unknow error occurred	Prompt message	Contact service robot has an unknown error	Call service

No.	Name	Detail	Failure Type	Cause	Corrective Action
90	X axis Not in Product Placed Area when Stand out of Program	X axis is not in the proper start position	Operation error	X axis Not In Product place area during standby	Standby must be at Product Placed Area
91	Limited Distance Set Wrong	The setting for the limits are not correct	Operation error	Check the limit position	Change the set of Software limits
92	Trying Dangerous Action or motor fault, Please Reset Robot	The action being performed is not safe	Machine Error	The action is not safe to perform	Reset the robot
93	IMM Sign Output TimeOut	Robot don't receive return signal from the IMM	No IMM output	Check the IMM signal	Contact the IMM service department
94	Low air pressure, please check the air supply.	Robot did not receive the signal for the air pressure	Air pressure under 0.6Mpa	1. Air line is too small 2. Air pressure is too low	1. Change the air line 2. Increase the air pressure
			Circuit fault	I/O board is not getting AIR Pressure signal	Turn on the air or Change the I/O board
			Sensor fault Main Board	1. Sensor Fault 2. Main board did not receive the signal	1. Clean Sensor circuit or Change Sensor 2. Change main board
95	Not allow to down When has Grip or Vacuum On.	Z axis is not allowed to move over mold when the vacuum or gripper is on	Operation error	The signal is on.	Turn off the vacuum and/or gripper signal prior to going into the mold
96	Motor position arrive limited data bit, please	Servo drive has a fault	Operation error	Contact service robot has an unknown error	Contact the Service department
97	Motor is not power on.	System did not receive the Motor power on signal	Prompt message	Voltage too low	Check power
98	Protective Door is opened	IMM door is not closed	Prompt message	Check the IMM door	Close the safety door on the IMM

## 8.0 Robot Electrical & Pneumatic Schematics

 <p>ARI American Robot Inc. 90 Gardner St, Woburn, MA, 01888 +1 781.272.4251 / +1 800.720.9648 <a href="http://www.americanrobot.com">www.americanrobot.com</a></p>	<p>Notes:</p>	<p>Electrical Schematics For 3-5 Axis Servo Well-Lih Cartesian Robots</p> <p>POWER SOURCE : AC 460V 60Hz 3P/PE</p> <p>Model Details: MaxA/B/C-FH+A+C EUROMAP 12</p>	<table border="1"><tr><td>Title:</td><td>Client Name:</td></tr><tr><td>Screen By:</td><td>Date:</td></tr><tr><td>Drawn By:</td><td>Date (Estimate)</td></tr><tr><td>Scale:</td><td>Sheet: 1/1</td></tr><tr><td>Owner:</td><td>Cover Page</td></tr><tr><td>Rev. #:</td><td>0.04</td></tr></table>	Title:	Client Name:	Screen By:	Date:	Drawn By:	Date (Estimate)	Scale:	Sheet: 1/1	Owner:	Cover Page	Rev. #:	0.04	<p>For Max Series A, AW, &amp; BW 3-Axis Servo Robots</p>
Title:	Client Name:															
Screen By:	Date:															
Drawn By:	Date (Estimate)															
Scale:	Sheet: 1/1															
Owner:	Cover Page															
Rev. #:	0.04															




**Absolute Robot Inc.**  
332 Gardner St. Worcester, MA 01655  
+1 508-792-4235 | E: +1 508-792-9646  
www.absoluterobot.com

104

Table

Chassis No:	Date:
Child No:	Date:
Grade:	Size:
Class:	
Prov.:	Code:

For Max Series A, AW, & BW  
3-Axis Servo Robots




**ARI**

Absolute Robot Inc.  
88 Gardner St., Waltham, MA 02451 • +1 888.792.4305 • [www.arirobotics.com](http://www.arirobotics.com)

Notes:

Title:  
Main Power Distribution Circuit

Drawn By:	Date:
Chkd By:	Date: 03/14/2017
Scale:	Not Specified
Drawn:	Sheet: 2 of 16
Rev:	004

For Max Series A, AW, & BW  
3-5 Axis Servo Robots

To X Driver

To Y1 Driver

To Z1 Driver

To A Driver  
(If equipped)To C Driver  
(If equipped)




Absolute Robotics Inc.  
31 Gardner St, Worcester, MA, 01610  
T: +1 508-752-4300 / F: +1 508-752-4646  
www.aborobot.com

Notes:

TR# 24VDC Distribution Circuit  
Drawn By: Date: 03/14/2017  
Ckt By: Date: 03/14/2017  
Scale: 1:15 Sheet: 3 of 16  
Dwg #: Rev #: 004

For Max Series A, AW, & BW  
3-5 Axis Servo Robots





Absolute Robot Inc.  
200 Worcester St, Worcester, MA 01610  
(+1 state 782-4348) (+1 888-762-8649)  
[www.absoluterobot.com](http://www.absoluterobot.com)


10

Title

Sheet 4 of 16

For Max Series A, AW, & BW  
3-Axis Servo Robots

ASDA1




# ARI

Absolute Robot Inc.  
82 Gardner St, Worcester, MA, 01655  
+1 508 852 4213 / +1 508 792 9644  
www.abetterservobox.com

**ARI**

Absolute Robot Inc.  
87 Quinlan St, Worcester, MA 01610  
+1 508-752-4231 / +1 508-752-8049  
www.absoluterobot.com

Note:



For Max Series A, AW, & BW  
3-5 Axis Servo Robots



**Auslaut Röhrl Kos**  
Gardner St. Worcester, MA, 01610  
508-792-4505 / F: +1 508-792-9548  
[www.3051ststreet.com](http://www.3051ststreet.com)

三

Title: Autumn Drive Visiting Diagram

Sheet: 7 of 16

For Max Series A, AW, & BW  
3-Axis Servo Robots

The diagram illustrates the ASDA4 block, showing its Top View, Bottom View, and a detailed connection section.

**Top View:** Shows the front panel with various connectors and indicators. The connectors include:
 

- DL3/PX002, DL2/PX002, DL1/PX002 (Digital Inputs)
- H24/PX003, 24E/PX003 (Analogue Inputs)
- 24VDC (Power Input)
- PILOT (Pilot Output)
- PILOT C (Pilot Output)
- PILOT D (Pilot Output)
- PILOT E (Pilot Output)
- PILOT F (Pilot Output)
- PILOT G (Pilot Output)
- PILOT H (Pilot Output)
- PILOT I (Pilot Output)
- PILOT J (Pilot Output)
- PILOT K (Pilot Output)
- PILOT L (Pilot Output)
- PILOT M (Pilot Output)
- PILOT N (Pilot Output)
- PILOT O (Pilot Output)
- PILOT P (Pilot Output)
- PILOT Q (Pilot Output)
- PILOT R (Pilot Output)
- PILOT S (Pilot Output)
- PILOT T (Pilot Output)
- PILOT U (Pilot Output)
- PILOT V (Pilot Output)
- PILOT W (Pilot Output)
- PILOT X (Pilot Output)
- PILOT Y (Pilot Output)
- PILOT Z (Pilot Output)

**Bottom View:** Shows the rear panel with various connectors and indicators. The connectors include:
 

- PILOT (Pilot Output)
- PILOT C (Pilot Output)
- PILOT D (Pilot Output)
- PILOT E (Pilot Output)
- PILOT F (Pilot Output)
- PILOT G (Pilot Output)
- PILOT H (Pilot Output)
- PILOT I (Pilot Output)
- PILOT J (Pilot Output)
- PILOT K (Pilot Output)
- PILOT L (Pilot Output)
- PILOT M (Pilot Output)
- PILOT N (Pilot Output)
- PILOT O (Pilot Output)
- PILOT P (Pilot Output)
- PILOT Q (Pilot Output)
- PILOT R (Pilot Output)
- PILOT S (Pilot Output)
- PILOT T (Pilot Output)
- PILOT U (Pilot Output)
- PILOT V (Pilot Output)
- PILOT W (Pilot Output)
- PILOT X (Pilot Output)
- PILOT Y (Pilot Output)
- PILOT Z (Pilot Output)

**Connection Section:** A detailed view showing the internal connections between the Top View and Bottom View. It includes:
 

- PILOT (Pilot Output) connected to PILOT C (Pilot Output)
- PILOT C (Pilot Output) connected to PILOT D (Pilot Output)
- PILOT D (Pilot Output) connected to PILOT E (Pilot Output)
- PILOT E (Pilot Output) connected to PILOT F (Pilot Output)
- PILOT F (Pilot Output) connected to PILOT G (Pilot Output)
- PILOT G (Pilot Output) connected to PILOT H (Pilot Output)
- PILOT H (Pilot Output) connected to PILOT I (Pilot Output)
- PILOT I (Pilot Output) connected to PILOT J (Pilot Output)
- PILOT J (Pilot Output) connected to PILOT K (Pilot Output)
- PILOT K (Pilot Output) connected to PILOT L (Pilot Output)
- PILOT L (Pilot Output) connected to PILOT M (Pilot Output)
- PILOT M (Pilot Output) connected to PILOT N (Pilot Output)
- PILOT N (Pilot Output) connected to PILOT O (Pilot Output)
- PILOT O (Pilot Output) connected to PILOT P (Pilot Output)
- PILOT P (Pilot Output) connected to PILOT Q (Pilot Output)
- PILOT Q (Pilot Output) connected to PILOT R (Pilot Output)
- PILOT R (Pilot Output) connected to PILOT S (Pilot Output)
- PILOT S (Pilot Output) connected to PILOT T (Pilot Output)
- PILOT T (Pilot Output) connected to PILOT U (Pilot Output)
- PILOT U (Pilot Output) connected to PILOT V (Pilot Output)
- PILOT V (Pilot Output) connected to PILOT W (Pilot Output)
- PILOT W (Pilot Output) connected to PILOT X (Pilot Output)
- PILOT X (Pilot Output) connected to PILOT Y (Pilot Output)
- PILOT Y (Pilot Output) connected to PILOT Z (Pilot Output)

ASDA4


# ARI

Absolute Robot Inc.  
10 Gardner St. Worcester, MA. 01610  
(508) 754-4210 / FAX: (508) 754-4200  
www.absoluterobot.com

Notes:

Title: C. Axis Drive Wiring Diagram  
Drawn By: Date: 03/14/2017  
Check By: File: Blank rev: 1  
Scale: MTS Design: 8 of 16  
Design: Rev: 004  
Sheet: 8 of 16

For Max Series A, AW, & BW  
3-5 Axis Servo Robots





**Associate Robot Inv.**  
1000 River St., Worcester, MA 01652  
(508) 753-4105 / FAX: (508) 752-3644  
www.associaterobot.com

102




Table	Subject Name (Using Diagram)
Drawn By:	Date:
Child Name:	Date: 05/05/2017
Scorer:	Score: 10/10
Design #:	Sheet: 9 of 16
Play #:	304

For Max Series A, AW, & BW  
3-Axis Servo Robots



Absolute Robot Inc.  
12 Gardner St, Worcester, MA 01610  
T: +1 508-752-4285 / F: +1 508-864-6646  
www.roboteamrobotics.com

Pin	Name	Pin Value	Actual Value
P1	Power	0	0
P2	WORK	0	0
P3	+5V	0	0
P4	DHIGH	0	0
P5	DMODE	0	0
P6	IOGND	0	0
P7	SG	0	0
P8	PE	0	0
P9	VGA	0	0
P10	24V	0	0
P11	0V	0	0
P12	1N24/PX003	0	0
P13	1P24B/PX003	0	0
P14	1N24/PX003	0	0
P15	1P24B/PX003	0	0
P16	1N24/PX003	0	0
P17	1P24B/PX003	0	0
P18	1N24/PX003	0	0
P19	1P24B/PX003	0	0
P20	1N24/PX003	0	0
P21	1P24B/PX003	0	0
P22	1N24/PX003	0	0
P23	1P24B/PX003	0	0
P24	1N24/PX003	0	0
P25	1P24B/PX003	0	0
P26	1N24/PX003	0	0
P27	1P24B/PX003	0	0
P28	1N24/PX003	0	0
P29	1P24B/PX003	0	0
P30	1N24/PX003	0	0
P31	1P24B/PX003	0	0
P32	1N24/PX003	0	0
P33	1P24B/PX003	0	0
P34	1N24/PX003	0	0
P35	1P24B/PX003	0	0
P36	1N24/PX003	0	0
P37	1P24B/PX003	0	0
P38	1N24/PX003	0	0
P39	1P24B/PX003	0	0
P40	1N24/PX003	0	0
P41	1P24B/PX003	0	0
P42	1N24/PX003	0	0
P43	1P24B/PX003	0	0
P44	1N24/PX003	0	0
P45	1P24B/PX003	0	0
P46	1N24/PX003	0	0
P47	1P24B/PX003	0	0
P48	1N24/PX003	0	0
P49	1P24B/PX003	0	0
P50	1N24/PX003	0	0
P51	1P24B/PX003	0	0
P52	1N24/PX003	0	0
P53	1P24B/PX003	0	0
P54	1N24/PX003	0	0
P55	1P24B/PX003	0	0
P56	1N24/PX003	0	0
P57	1P24B/PX003	0	0
P58	1N24/PX003	0	0
P59	1P24B/PX003	0	0
P60	1N24/PX003	0	0
P61	1P24B/PX003	0	0
P62	1N24/PX003	0	0
P63	1P24B/PX003	0	0
P64	1N24/PX003	0	0
P65	1P24B/PX003	0	0
P66	1N24/PX003	0	0
P67	1P24B/PX003	0	0
P68	1N24/PX003	0	0
P69	1P24B/PX003	0	0
P70	1N24/PX003	0	0
P71	1P24B/PX003	0	0
P72	1N24/PX003	0	0
P73	1P24B/PX003	0	0
P74	1N24/PX003	0	0
P75	1P24B/PX003	0	0
P76	1N24/PX003	0	0
P77	1P24B/PX003	0	0
P78	1N24/PX003	0	0
P79	1P24B/PX003	0	0
P80	1N24/PX003	0	0
P81	1P24B/PX003	0	0
P82	1N24/PX003	0	0
P83	1P24B/PX003	0	0
P84	1N24/PX003	0	0
P85	1P24B/PX003	0	0
P86	1N24/PX003	0	0
P87	1P24B/PX003	0	0
P88	1N24/PX003	0	0
P89	1P24B/PX003	0	0
P90	1N24/PX003	0	0
P91	1P24B/PX003	0	0
P92	1N24/PX003	0	0
P93	1P24B/PX003	0	0
P94	1N24/PX003	0	0
P95	1P24B/PX003	0	0
P96	1N24/PX003	0	0
P97	1P24B/PX003	0	0
P98	1N24/PX003	0	0
P99	1P24B/PX003	0	0
P100	1N24/PX003	0	0
P101	1P24B/PX003	0	0
P102	1N24/PX003	0	0
P103	1P24B/PX003	0	0
P104	1N24/PX003	0	0
P105	1P24B/PX003	0	0
P106	1N24/PX003	0	0
P107	1P24B/PX003	0	0
P108	1N24/PX003	0	0
P109	1P24B/PX003	0	0
P110	1N24/PX003	0	0
P111	1P24B/PX003	0	0
P112	1N24/PX003	0	0
P113	1P24B/PX003	0	0
P114	1N24/PX003	0	0
P115	1P24B/PX003	0	0
P116	1N24/PX003	0	0
P117	1P24B/PX003	0	0
P118	1N24/PX003	0	0
P119	1P24B/PX003	0	0
P120	1N24/PX003	0	0
P121	1P24B/PX003	0	0
P122	1N24/PX003	0	0
P123	1P24B/PX003	0	0
P124	1N24/PX003	0	0
P125	1P24B/PX003	0	0
P126	1N24/PX003	0	0
P127	1P24B/PX003	0	0
P128	1N24/PX003	0	0
P129	1P24B/PX003	0	0
P130	1N24/PX003	0	0
P131	1P24B/PX003	0	0
P132	1N24/PX003	0	0
P133	1P24B/PX003	0	0
P134	1N24/PX003	0	0
P135	1P24B/PX003	0	0
P136	1N24/PX003	0	0
P137	1P24B/PX003	0	0
P138	1N24/PX003	0	0
P139	1P24B/PX003	0	0
P140	1N24/PX003	0	0
P141	1P24B/PX003	0	0
P142	1N24/PX003	0	0
P143	1P24B/PX003	0	0
P144	1N24/PX003	0	0
P145	1P24B/PX003	0	0
P146	1N24/PX003	0	0
P147	1P24B/PX003	0	0
P148	1N24/PX003	0	0
P149	1P24B/PX003	0	0
P150	1N24/PX003	0	0
P151	1P24B/PX003	0	0
P152	1N24/PX003	0	0
P153	1P24B/PX003	0	0
P154	1N24/PX003	0	0
P155	1P24B/PX003	0	0
P156	1N24/PX003	0	0
P157	1P24B/PX003	0	0
P158	1N24/PX003	0	0
P159	1P24B/PX003	0	0
P160	1N24/PX003	0	0
P161	1P24B/PX003	0	0
P162	1N24/PX003	0	0
P163	1P24B/PX003	0	0
P164	1N24/PX003	0	0
P165	1P24B/PX003	0	0
P166	1N24/PX003	0	0
P167	1P24B/PX003	0	0
P168	1N24/PX003	0	0
P169	1P24B/PX003	0	0
P170	1N24/PX003	0	0
P171	1P24B/PX003	0	0
P172	1N24/PX003	0	0
P173	1P24B/PX003	0	0
P174	1N24/PX003	0	0
P175	1P24B/PX003	0	0
P176	1N24/PX003	0	0
P177	1P24B/PX003	0	0
P178	1N24/PX003	0	0
P179	1P24B/PX003	0	0
P180	1N24/PX003	0	0
P181	1P24B/PX003	0	0
P182	1N24/PX003	0	0
P183	1P24B/PX003	0	0
P184	1N24/PX003	0	0
P185	1P24B/PX003	0	0
P186	1N24/PX003	0	0
P187	1P24B/PX003	0	0
P188	1N24/PX003	0	0
P189	1P24B/PX003	0	0
P190	1N24/PX003	0	0
P191	1P24B/PX003	0	0
P192	1N24/PX003	0	0
P193	1P24B/PX003	0	0
P194	1N24/PX003	0	0
P195	1P24B/PX003	0	0
P196	1N24/PX003	0	0
P197	1P24B/PX003	0	0
P198	1N24/PX003	0	0
P199	1P24B/PX003	0	0
P200	1N24/PX003	0	0
P201	1P24B/PX003	0	0
P202	1N24/PX003	0	0
P203	1P24B/PX003	0	0
P204	1N24/PX003	0	0
P205	1P24B/PX003	0	0
P206	1N24/PX003	0	0
P207	1P24B/PX003	0	0
P208	1N24/PX003	0	0
P209	1P24B/PX003	0	0
P210	1N24/PX003	0	0
P211	1P24B/PX003	0	0
P212	1N24/PX003	0	0
P213	1P24B/PX003	0	0
P214	1N24/PX003	0	0
P215	1P24B/PX003	0	0
P216	1N24/PX003	0	0
P217	1P24B/PX003	0	0
P218	1N24/PX003	0	0
P219	1P24B/PX003	0	0
P220	1N24/PX003	0	0
P221	1P24B/PX003	0	0
P222	1N24/PX003	0	0
P223	1P24B/PX003	0	0
P224	1N24/PX003	0	0
P225	1P24B/PX003	0	0
P226	1N24/PX003	0	0
P227	1P24B/PX003	0	0
P228	1N24/PX003	0	0
P229	1P24B/PX003	0	0
P230	1N24/PX003	0	0
P231	1P24B/PX003	0	0
P232	1N24/PX003	0	0
P233	1P24B/PX003	0	0
P234	1N24/PX003	0	0
P235	1P24B/PX003	0	0
P236	1N24/PX003	0	0
P237	1P24B/PX003	0	0
P238	1N24/PX003	0	0
P239	1P24B/PX003	0	0
P240	1N24/PX003	0	0
P241	1P24B/PX003	0	0
P242	1N24/PX003	0	0
P243	1P24B/PX003	0	0
P244	1N24/PX003	0	0
P245	1P24B/PX003	0	0
P246	1N24/PX003	0	0
P247	1P24B/PX003	0	0
P248	1N24/PX003	0	0
P249	1P24B/PX003	0	0
P250	1N24/PX003	0	0
P251	1P24B/PX003	0	0
P252	1N24/PX003	0	0
P253	1P24B/PX003	0	0
P254	1N24/PX003	0	0
P255	1P24B/PX003	0	0
P256	1N24/PX003	0	0
P257	1P24B/PX003	0	0
P258	1N24/PX003	0	0
P259	1P24B/PX003	0	0
P260	1N24/PX003	0	0
P261	1P24B/PX003	0	0
P262	1N24/PX003	0	0
P263	1P24B/PX003	0	0
P264	1N24/PX003	0	0
P265	1P24B/PX003	0	0
P266	1N24/PX003	0	0
P267	1P24B/PX003	0	0
P268	1N24/PX003	0	0
P269	1P24B/PX003	0	0
P270	1N24/PX003	0	0
P271	1P24B/PX003	0	0
P272	1N24/PX003	0	0
P273	1P24B/PX003	0	0
P274	1N24/PX003	0	0
P275	1P24B/PX003	0	0
P276	1N24/PX003	0	0
P277	1P24B/PX003	0	0
P278	1N24/PX003	0	0
P279	1P24B/PX003	0	0
P280	1N24/PX003	0	0
P281	1P24B/PX003	0	0
P282	1N24/PX003	0	0
P283	1P24B/PX003	0	0
P284	1N24/PX003	0	0
P285	1P24B/PX003	0	0
P286	1N24/PX003	0	0
P287	1P24B/PX003	0	0
P288	1N24/PX003	0	0
P289	1P24B/PX003	0	0
P290	1N24/PX003	0	0
P291			




**Armature Robot Inc.**  
92 Gardner St, Worcester, MA, 01650  
T: +1 508 752-4500 | F: +1 508 752-0646  
www.armaturerobotics.com

Notes:

## HCB1

EXT I/O /PX008



N24 p. 003

003 p. 003



Title:	Extended I/O Module	
Drawn By:	Date: 01/14/2017	Date:
Check By:	Sheet: N75	Sheet: 11 of 16
Scale:	0.00	Rev. #: 004

For Max Series A, AW, & BW  
3-6 Axis Servo Robots




Absolute Robot Inc.  
33 Gardner St, Worcester, MA 01650  
+1 508-752-4365 / +1 508-752-9348  
www.acerobotics.com

Part#:


Title:	Half-Round Pendant
Drawn By:	Date:
Checked By:	Date: 07/14/2017
Scale:	1:15
Design:	Sheet: 12 of 16
Rev. #:	004

For Max Series A, AW, & BW  
3-5 Axis Servo Robots



HMI/Pendant

## Euromap 12 robot/IMM Interface



**Autodesk Robot Inc.**  
32 Caspian St, Worcester, MA, 01655  
T: +1 508-792-4034 / F: +1 508-792-9846  
[www.autodeskrobot.com](http://www.autodeskrobot.com)

None

Title: E-12 Robot/IMM Interface  
Drawing By: Date: 06/14/2017  
Cust By: Cust. ID: 1010  
Scale: 1/100 Sheet: 1 of 16  
Dwg #: Dwg. #: 0001  
Rev #: Rev. #: 0001

For Max Series A, AW, & BW  
3-5 Axis Servo Robots



Absolute Robot Inc.  
92 Gardner St. Worcester, MA, 01619  
T: +1 508-752-4605 / F: +1 508-752-8844  
www.acerobotics.com





Notes:

Title:  
External Control Cabinet

Drawn By:	Date:
Created By:	Date: 02/14/2017
Scale:	1/16
Doc #:	Sheet: 14 of 16
Rev #:	USA

For Max Series A, AW, & BW  
3-5 Axis Servo Robots

Location On Robot Cabinet




201/PW006

CNV-A

GSB

200/PW008



XP3

O1

O2

O3

O4

O5

O6

O7

O8

O9

O10

O11

O12

O13

O14

O15

O16

O17

O18

O19

O20

O21

O22

O23

O24

O25

O26

O27

O28

O29

O30

O31

O32

O33

O34

O35

O36

O37

O38

O39

O40

O41

O42

O43

O44

O45

O46

O47

O48

O49

O50

O51

O52

O53

O54

O55

O56

O57

O58

O59

O60

O61

O62

O63

O64

O65

O66

O67

O68

O69

O70

O71

O72

O73

O74

O75

O76

O77

O78

O79

O80

O81

O82

O83

O84

O85

O86

O87

O88

O89

O90

O91

O92

O93

O94

O95

O96

O97

O98

O99

O100

O101

O102

O103

O104

O105

O106

O107

O108

O109

O110

O111

O112

O113

O114

O115

O116

O117

O118

O119

O120

O121

O122

O123

O124

O125

O126

O127

O128

O129

O130

O131

O132

O133

O134

O135

O136

O137

O138

O139

O140

O141

O142

O143

O144

O145

O146

O147

O148

O149

O150

O151

O152

O153

O154

O155

O156

O157

O158

O159

O160

O161

O162

O163

O164

O165

O166

O167

O168

O169

O170

O171

O172

O173

O174

O175

O176

O177

O178

O179

O180

O181

O182

O183

O184

O185

O186

O187

O188

O189

O190

O191

O192

O193

O194

O195

O196

O197

O198

O199

O200

O201

O202

O203

O204

O205

O206

O207

O208

O209

O210

O211

O212

O213

O214

O215

O216

O217

O218

O219

O220

O221

O222

O223

O224

O225

O226

O227

O228

O229

O230

O231

O232

O233

O234

O235

O236

O237

O238

O239

O240

O241

O242

O243

O244

O245

O246

O247

O248

O249

O250

O251

O252

O253

O254

O255

O256

O257

O258

O259

O260

O261

O262

O263

O264

O265

O266

O267

O268

O269

O270

O271

O272

O273

O274

O275

O276

O277

O278

O279

O280

O281

O282

O283

O284

O285

O286


O287

O288

O289

O290

O291



TM  
Pneumatic Valve Control Wiring


Drawn By:	Date:
Chkd By:	Date: 03/04/2017
Scale:	5x5
Drawn:	Sheet: 15 of 16
Rev. E:	03/1

For Max Series A, AW, & BW  
3-5 Axis Servo Robots

# ARI

Asaplite Robot Inc.  
62 Gardner St. Worcester, MA 01645  
+1 508-792-4365 / F: +1 508-792-8646  
www.asapliterobot.com

Notes:



No.	Name	Model
①	Exhaust Valve	WHS40-03
②	Pressure Regulator	AMAO-03006-R-R
③	Air Pressure Confirmation Valve	CV99H051
④	Shifter	SM200-02
⑤	1-Way Valve (No. 1 or 2)	VALG-L14-4857-A1 -G18-1P3
⑥	2-Way Valve (A & C Axis)	VALG-L14-4857-T -G18-1P3
⑦	vacuum Pump	298.300F-038-H-MCB
⑧	Vacuum Generator	S86-15-03-52A
⑨	A/C-Axis Air Cylinder(s)	SP701B-4C1
⑩	Air Manifold	WHS3412-300-W1 -Model#10-1P

Title: Pneumatic Line Schematic

Drawn By: Date:

Checked By: Date: 05/14/2017

Scale: 1/16 Size: in

Drawn #: Sheet: 16 of 16

Rev #: 004

For Max Series A, AW, & BW  
3-Axis Servo Robots



## ROBOT MAINTENANCE AND SERVICE INTERVALS

INSPECTION ITEMS	DESCRIPTION OF INSPECTION & RECOMMENDED ACTION	RECOMMENDED INTERVALS FOR INSPECTION			
		DAILY	MONTHLY	6 MONTHS	1 YEAR
END OF ARM TOOLING	CHECK CONNECTIONS AND COMPONENT OPERATION, CLEAN & REPLACE DEFECTIVE COMPONENTS AS NEEDED	<input checked="" type="checkbox"/>			
ROBOT AIR FILTER	CHECK & REPLACE AS NEEDED FOR PROPER AIR FLOW IN ROBOT CABINET	<input checked="" type="checkbox"/>			
ROBOT PENDANT	CHECK FOR PHYSICAL DEFECTS, LOOSE CONNECTIONS & PROPER OPERATION, REPLACE AS NEEDED	<input checked="" type="checkbox"/>			
ROBOT PNEUMATIC CIRCUIT	CHECK FOR LEAKAGE, REPLACE AS NEEDED	<input checked="" type="checkbox"/>			
HARDWARE-NUTS & BOLTS	CHECK FOR LOOSE OR BROKEN CONNECTIONS, TIGHTEN & REPLACE AS NEEDED	<input checked="" type="checkbox"/>			
ROBOT CONTROLLER FAN	CHECK FAN FOR NOISE & OPERATION, VERIFY GOOD AIR FLOW IS PRESENT, SEE FILTER PROCESS IF AIR FLOW IS WEAK. REPLACE IF LOW OUTPUT IS DETERMINED & FILTERS ARE CLEAN		<input checked="" type="checkbox"/>		
AXIAL BEARINGS & ROLLERS	CHECK FOR PHYSICAL DEFECTS (GALLING, SCORING, METAL FLAKES OR WEAR SPOTS) & PROPER MOVEMENT (NO ELLIPTICAL ECCENTRIC MOTIONS) CHECK FOR EXCESS NOISE, VIBRATION & PROPER LUBRICATION IS PRESENT. CLEAN & LUBRICATE AS NEEDED. REPLACE ANY WORN COMPONENTS AS NEEDED		<input checked="" type="checkbox"/>		
LINEAR BEARINGS & RAILS	CHECK FOR PHYSICAL DEFECTS (METAL CHIPS, BURS, SCORING OR WEAR SPOTS) AND PROPER MOVEMENTS (NO PLAY IN LATERAL MOTIONS) CHECK FOR EXCESS NOISE, VIBRATION & PROPER LUBRICATION IS PRESENT. CLEAN & LUBRICATE AS NEEDED, REPLACE ANY WORN COMPONENTS AS NEEDED		<input checked="" type="checkbox"/>		
GEAR & RACK COMPONENTS *C SERIES ROBOTS	CHECK FOR PHYSICAL DEFECTS (METAL CHIPS, WORN GEAR TEETH OR EXCESSIVE WEAR) & PROPER MOVEMENTS (NO PLAY IN LATERAL MOTIONS), CHECK FOR EXCESS NOISE, VIBRATION & PROPER LUBRICATION IS PRESENT. CLEAN & LUBRICATE AS NEEDED, REPLACE ANY WORN COMPONENTS AS NEEDED		<input checked="" type="checkbox"/>		
ROBOT CONTROLLER CABINET	CHECK FOR LOOSE CONNECTIONS OR TERMINALS, TIGHTEN ALL CONNECTIONS & CLEAN CABINET OF DEBRIS		<input checked="" type="checkbox"/>		
DRIVE BELTS	CHECK BELTS FOR WEAR, DEFECTS, ALIGNMENT & TENSION, ADJUST TO SPECS PER ROBOT. REPLACE AS NEEDED		<input checked="" type="checkbox"/>		
HOSES & DRAG CHAIN ASSY	CHECK FOR LEAKS, WEAR AREAS, BULGES & DEBRIS. REPLACE AS NEEDED			<input checked="" type="checkbox"/>	
PNEUMATIC CYLINDERS	CHECK FOR AIR LEAKAGE, WORN SEALS, LUBRICANT SEEPAGE & OPERATION. REPLACE AS NEEDED.			<input checked="" type="checkbox"/>	
ELECTRICAL COMPONENTS	CHECK ALL ELECTRICAL COMPONENTS, RELAYS & ELECTRIC CABLES FOR LOOSE CONNECTIONS, OPERATION & DEFECTS. REPLACE AS NEEDED				<input checked="" type="checkbox"/>
LUBRICATION SYSTEM	CHECK FOR PROPER OPERATION & REFILL LUBRICANT FEED SYSTEM				<input checked="" type="checkbox"/>

PLEASE CONTACT ARI SERVICE FOR TROUBLESHOOTING  
AND REPAIR ASSISTANCE

## Thank you

Dear Valued Customer,

At Absolute Robot, we sincerely appreciate your business and we look forward to fulfilling your future automating needs.

Sincerely,

The Entire ARI Team



# Contact Us



## Absolute Robot Inc.

Absolute Robot has a dedicated team of individuals who will work to solve your automation needs. Whether you have a question about one of our series of robots or would like to find out how we can help with your unique injection molding process, please send us an email or give us a call, one of our team members will be able to answer all your questions.



### Contact Information

#### Main Office

**Headquarters**  
92 Gardner Street  
Worcester, MA 01610  
Phone: (508) 792-4305  
[service@absoluterobot.com](mailto:service@absoluterobot.com)



**Facebook:** @AbsoluteRobot



**Twitter:** @Absolute\_Robot



**Linked In:** @Absolute Robot Inc.