




Process

MIG (GMAW)

TIG (GTAW)

STICK (SMAW)

250D Double Pulse Synergic Multi-MIG Welding System



Operators' Manual

IMPORTANT: Read this Owner's Manual Completely before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. Contact your distributor if you do not fully understand this manual.

CONTENT

§1 Safety.....	1
§1.1 Symbols Explanation	1
§1.2 Machine Operating warnings!	1
§1.3 EMC device classification	7
§1.4 EMC measure	7
§1.5 Warning label	7
§2 Overview.....	8
§2.1 Features	8
§2.2 Brief Introduction	9
§2.3 Technical Data	10
§2.4 Duty Cycle and Over-heat	10
§2.5 Working Principle.....	11
§2.6 Volt-Ampere Characteristic.....	11
§3 Machine Layout & Descriptions	12
§3.2 Machine Layout	14
§3.1 Machine Front & Back	12
§3.1.1 Wire Feed Cabinet	13
§3.2 Control Panel of Welding Machine	14
§3.2.1 MMA control panel.....	15
§3.2.2 Lift TIG control panel	16
§3.2.3 MIG (Dual) Pulse control panel	18
§3.2.4 MIG Synergic control panel	20
§3.2.5 MIG Manual control panel	21
§3.2.6 System Setting control panel	Error! Bookmark not defined.
§3.2.7 JOB Program control panel.....	26
§4 Installation & Operation	27
§4.1 Installation & Operation for MMA/Stick Electrode Welding	27
§4.1.1 Set-Up Installation	27
§4.1.2 MMA/Stick Electrode Welding	28
§4.1.3 MMA Welding Fundamentals	29
§4.2 Installation & Operation for TIG Welding	31
§4.2.1 Set-Up for TIG Welding	31
§4.2.2 DC TIG Welding	33
§4.2.3 TIG Welding Fusion Technique	34
§4.2.4 Tungsten Electrodes.....	35
§4.2.5 Tungsten Preparation	38
§4.2.6 TIG Torch Switch Controls.....	40

§4.3 Installation & Operation for MIG Welding	41
§4.3.1 Set up installation for MIG Welding (Gas shielded wire).....	41
§4.3.2 Wire Feed Roller Selection	43
§4.3.3 Wire Installation and Set-Up Guide	44
§4.3.4 Set up for MIG Welding- Aluminum or Silicone Bronze Wire	46
§4.3.5 MIG Torch Liner Installation.....	47
§4.3.6 MIG Torch Liner Types and Information	48
§4.3.7 Torch & Wire Feed Set-Up for Aluminum Wire.....	50
§4.3.8 Set-Up Installation for Spool Gun.....	50
§4.3.9 Set-Up Installation for Push/Pull MIG Gun.....	52
§4.3.10 MIG Welding	54
§4.4 Welding Parameters	61
§4.5 Operation Environment	63
§4.6 Operation Notices.....	63
§5 Torch & Machine Parts List.....	64
§5.1 MIG Torches SL15 (Gun #1, #2 & #3)	64
§5.1.1 MIG Torch #1 / SL15 with RED Handle for Silicone Bronze Wire	64
§5.1.2 MIG Torch #2 / SL26 with BLUE Handle for Aluminum Wire	65
§5.1.3 MIG Torch #3 / SL25 with GREEN Handle for Steel Wire.....	66
§5.2 TIG Torch SR17-12-9P	67
§5.3 Machine Parts List	68
§6 Maintenance & Troubleshooting	70
§6.1 Maintenance.....	70
§6.2 Troubleshooting.....	70
§6.2.1 MIG Welding - Trouble Shooting	73
§6.2.2 MIG Wire Feed - Trouble Shooting	74
§6.2.3 DC TIG Welding - Trouble Shooting.....	76
§6.2.4 MMA Welding - Trouble Shooting.....	78
§6.3 List of Error Codes	79
§6.4 Electrical Schematic Drawing	80

§1 Safety

Welding and cutting equipment can be dangerous to both the operator and people in or near the surrounding working area, if the equipment is not correctly operated. Equipment must only be used under the strict and comprehensive observance of all relevant safety regulations. Read and understand this instruction manual carefully before the installation and operation of this equipment.

§1.1 Symbols Explanation



- The above symbols mean warning!

Notice! Running parts, getting an electric shock or making contacts with thermal parts will cause damage to your body and others. The underline message is as follows:

Welding is a safe operation after taking several necessary protection measures!

§1.2 Machine Operating warnings!

- The following symbols and words explanations are for some damages to your body or others, which could happen during the welding operation. While seeing these symbols, please remind yourself and others to be careful.
- Only people who are trained professionally can install, debug, operate, maintain and repair the welding equipment covered with this Operator's Manual!
- During the welding operation, non-concerned people should NOT be around, especially children!
- After shutting off the machine power, please maintain and examine the equipment according to §7 because of the DC voltage existing in the electrolytic capacitors at the output of the power supply!

**ELECTRIC SHOCK CAN KILL.**

Touching live electrical parts can cause fatal shocks or severe burns. The electrode & work circuit is electrically live whenever the output is on. The input power circuit and internal machine circuits are also live when power is on. In MIG welding, the wire, drive rollers, wire feed housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is dangerous.

- Never touch live electrical parts.
- Wear dry, hole-free gloves and clothes to insulate your body.
- Be sure to install the equipment correctly and ground the work or metal to be welded to a good electrical (earth) ground according to the operation manual.
- The electrode and work (or ground) circuits are electrically “hot” when the machine is ON. Do not touch these “hot” parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically “hot”.
- Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- Be Careful when using the equipment in small places, falling-off and wet circumstance.
- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.
- Never simultaneously touch electrically “hot” parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above the floor level, use a safety belt to protect yourself from a fall should you get an electric shock!



FUMES AND GASES CAN BE DANGEROUS.

Smoke and gas generated whilst welding or cutting can be harmful to people's health. Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Do not breathe the smoke and gas generated whilst welding or cutting, keep your head out of the fumes. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below the Threshold Limit Values using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.

- Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.

- Shielded gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.

- Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet and follow your employer's safety practices.



ARC RAYS: Harmful to people's eyes and skin.

Arc rays from the welding process produce intense visible and invisible ultraviolet and infrared rays that can burn eyes and skin.

- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding.

- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your coworkers from the arc rays.

**SELF-PROTECTION**

- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from rollers, gears, fans and all other moving parts when starting, operating or repairing equipment.
- Do not put your hands near the cooling fan.

**WELDING SPARKS can cause fire or explosion.**

Welding on closed containers, such as tanks, drums, or pipes, can cause them to explode. Flying sparks from the welding arc, hot work piece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding

- Remove fire hazards material from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situation.
- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been “cleaned”.
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff less trousers, high shoes and a cap over your hair. Wear earplugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the

possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.



Gas Cylinders.

Shielding gas cylinders contain gas under high pressure. Because gas cylinders are normally part of the welding process, be sure to treat them carefully. CYLINDERS can explode if damaged.

- Protect gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames sparks, and arcs.
- Ensure cylinders are held secure with chains and upright to prevent tipping or falling over.
- Never allow the welding electrode or earth clamp to touch the gas cylinder, do not drape welding cables over the cylinder.
- Open the cylinder valve slowly and turn your face away from the cylinder outlet valve and gas regulator.
- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - At a safe distance from arc welding operations and any other source of sparks or flame.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.



Gas build up.

The buildup of gas can cause a toxic environment, deplete the oxygen content in the air resulting in death or injury. Many gases used in welding are invisible and odorless.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



Electric and Magnetic Fields.

Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). The discussion on the effect of EMF is ongoing in the entire world. Up to now, no material evidences show that EMF may have effects on health. However, the research on the effect of EMF is still ongoing. Before any conclusion, we should minimize exposure to EMF if possible.

In order to minimize EMF, we should use the following procedures:

- Route the electrode and work cables together – Secure them with tape when possible.
- All cables should be put away and far from the operator.
- Never coil the power cable around your body.
- Make sure welding machine and power cable to be far away from the operator as far as possible according to the actual circumstance.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- People with pacemakers should be away from the welding area.



Noise can damage hearing.

Noise from some processes or equipment can damage hearing. You must protect your ears from loud noise to prevent permanent loss of hearing.

- To protect your hearing from loud noise, wear protective ear plugs and/or ear muffs. Protect others in the workplace.
- Noise levels should be measured to be sure the decibels do not exceed safe levels.



Hot parts.

Items being welded generate and hold high heat and can cause severe burns. Do not touch hot parts with bare hands. Allow a cooling period before working on the welding gun. Use insulated welding gloves and clothing to handle hot parts and prevent burns.

§1.3 EMC device classification



Radiation Class A Device.

- Only can be used in the industrial area
- If it is used in other area, it may cause connection and radiation problems of circuit.

Radiation Class B device.

- It can meet the radiation requirements of residential area and industrial area. It also can be used in residential area which power is supplied by public low voltage circuit.

EMC device can be classified by power nameplate or technical data.

H&S Autoshot welding machines belong to Class A.

§1.4 EMC measure



In the special situation, the specified welding area may be affected. The standard of radiation limit value has been complied according to the domestic and international standards; however, the ambient devices' electromagnetism situation and anti-interference ability must be confirmed for each installation.


§1.5 Warning label

The welder includes a warning label. **Do not remove, destroy or cover this label.** These warnings are intended to avoid incorrect device operations that could result in serious personal injury or property damage.

§2 Overview

§2.1 Features

- Easy viewing 7" LCD screen.
- New PWM technology and IGBT inverter technology for high efficiency operation.
- Three dedicated wire feed systems for high productivity and no cross contamination.
- Dual cylinder supports and shield gas lines with four gas solenoid valves.
- Three 4-roll, gear drive wire feeders with 8" (200mm) and 12" (300mm) spool holders.
- Three euro-connect outputs for steel, aluminum, silicone bronze and spool gun torches.
- Spool gun connection (Allows controlled feeding of smallest diameter wire for thin panels).
- TIG torch, with thumb control, connection (Offers operator control and quick mode change)
- MMA stick electrode connection with hot-start and arc-force adjustment.
- CSA / UL Certified & IP21S rating for environmental/safety protection
- **MIG functions:** Single-Pulse Synergic, Dual-Pulse Synergic and Manual operation.
 - Synergic programs for aluminum, mild steel, stainless steel and silicone bronze.
 - JOB mode (Save and call 10 job records)
 - 2T/4T/S4T & Spot Weld welding mode
 - Function parameter adjustment
- **DC TIG functions:**
 - Lift Arc ignition (No high frequency)
 - 2T/ 4T Trigger Control
 - Adjustable Up/Down slope
 - Adjustable pre and post gas
- **MMA functions:** (Stick electrode)
 - Hot start (improves electrode starting)
 - Adjustable Arc Force



§2.2 Brief Introduction

The 250D DOUBLE PULSE SYNERGIC series of welding machines is an inverter-based MIG/MMA/TIG Welding machine with Synergic Programs and Dual pulse functions. The MIG function allows you to weld with Gas Shielded wire applications giving excellent, professional welding results. Easy step-less adjustment of voltage and wire feed coupled with integrated digital meters allows easy setting of welding parameters. Synergic setting of welding machines features MIG welding with Synergic welding programs designed for ease of use with your selected gas mixture. The operator selects the gas mixture and wire diameter they are using then simply start welding. Once this is done the operator can make fine adjustments to the voltage for even greater control of the weld pool. The added Lift-Arc DC TIG capability delivers perfect arc ignition every time and a remarkably smooth stable arc produces high quality TIG welds. TIG functionality includes adjustable up/down slope & pre/post gas control. The stick welding (MMA) capability delivers easy electrode welding with high quality results, including cast Iron, stainless and low hydrogen with hot-start and arc-force adjustment. An additional feature is the spool gun function that allows the simple connection of Spool Gun for the use of thin or softer wires that don't have the column strength to feed through MIG torches, such as some aluminum and silicone bronze wires. In the JOB mode, 100 different JOB records can be stored and recalled, improve the quality of welding process.

The 250D-DPS series of arc welding machine is an industrial quality machine that is suitable for all positions welding for various plates made of stainless steel, carbon steel, alloyed steel etc. Applications applied to automotive, petrochemical, architecture, industrial and common steel fabrication.

The 250D-DPS series of welding machines has built-in automatic protection functions to protect the machines from over-voltage, over-current and over-heat. If any one of the above problems happens, the alarm lamp on the front panel will illuminate and output current will be shut off automatically to protect machine and operator.

§2.3 Technical Data


Models Parameters	250D DOUBLE PULSE SYNERGIC (DPS)		
Input Voltage (V)	208-240±5% 1-Phase		
Frequency (Hz)	50/60		
	MIG	TIG	MMA
Input Current (A)	24.8	27	38.9
Input Power (KW)	8.0	6.2	8.9
Welding Current	15~250	10~250	
Welding Voltage	14.8~26.5	10.4~20	20.4~30
No-load Voltage	83	93	93
Duty cycle (40°C)	30% 250A 60% 180A 100% 140A		
Protection class	IP21S		
Circuit breaker	32A		
Dimensions (mm)	40" x 28.875 x 36.625 (1020*605*930)		
Weight (Kg)	144 Lbs. (65.4)		
Power Factor	0.99		

Note: The above parameters are subject to change.

§2.4 Duty Cycle and Over-heat


The letter “X” stands for Duty Cycle, which is defined as the portion of the time a welding machine can weld at maximum rated output current within a 10-minute cycle.

If the welding machine is operated beyond the rated duty-cycle, the IGBT sensor will send a signal to the welding machine controller switching welding current OFF and over-heat alarm. The machine should not be operated for 10~15 minutes to allow cool down. When operating the machine again, the welding output current should be reduced to match the duty cycle.




§2.5 Working Principle

The working principle of 250D DPS series welding machine is shown as the following figure. Single-phase 208-240VAC is rectified into DC, then is converted to medium frequency AC (about 20KHz) by inverter device (IGBT), after reducing voltage by medium transformer (the main transformer) and rectifying by medium frequency rectifier (fast recovery diodes) and fine-tuned by inductance filtering. The circuit utilizes current feedback control technology to insure current output stability when MMA or TIG and adopt to voltage feedback control technology to insure voltage output stability when operating in MIG mode.




§2.6 Volt-Ampere Characteristic

DPS series of welding machines have an excellent volt-ampere characteristic as shown in the following figure. The relation between the rated loading voltage (U_2) and welding current (I_2) is defined as follows: $U_2=14+0.05I_2$ (V).




§3 Machine Layout & Descriptions

§3.1 Front & Rear Panel Layout




1. **MIG Torch Connectors:** Three dedicated MIG guns for steel, aluminum & silicone bronze.
2. **Main Power Switch:** Controls ON/OFF power to the inverter from front panel.
3. **Control Socket:** Provides TIG torch or spool gun control power and functions.
4. **Positive (+) Output Socket:** Positive output power to TIG or MMA cables.
5. **Negative (-) Output Socket:** Negative output power to Earth, TIG or MMA cables
6. **TIG Torch Gas Fitting:** Internally threaded brass fitting for TIG gas hose connection.
7. **Input Power Cord:** UV/IR power cable with NEMA 6-50P input plug.
8. **MIX Gas Input Fitting:** Internally threaded brass fitting for gas hose from regulator.
9. **ARGON Gas Input Fitting:** Internally threaded brass fitting for gas hose from regulator.
10. **Circuit Breaker (50A):** LINE circuit breaker to protect machine from electrical shorts.

§3.1.1 Wire Feed Cabinet Layout




- 11. Spool Holder:** Supports 8" & 10" spools with locking pin and adjustable drag tension nut.
- 12. Wire Feed Drives:** 4-roll wire feeders for constant feeding speeds for all wire diameters.
- 13. Wire Feed Tension Knobs:** Allows for accurate adjustment of drive rolls tension.
- 14. Wire Feed Tension Arms:** Hardened ball bearing roller provides accuracy and long-life.
- 15. Wire Feed Inlet Guide:** Assures wire from spool feeds freely into drive rolls.
- 16. Wire Drive Rollers:** Hardened steel V or U groove rolls provide positive wire contact.

§3.2 Control Panel of Welding Machine



1. **LCD Screen:** Displays welding voltage, current wire speed and all other parameters.
2. **Menu:** Press to select welding mode, synergic programs, parameters, settings and jobs.
3. **Gas:** Press to confirm and/or purge correct shield gas flow to correct torch.
4. **L-Select:** Confirms "set" of LEFT knob selection displayed on screen.
5. **L-Knob:** Rotate to adjust current and wire feed speed as displayed on screen.
6. **Save:** Push to "save" all settings for a selected job.
7. **Gun Change:** Toggles between MIG Gun #1, Gun #2, Gun #3 as displayed on screen.
8. **R-Knob:** Rotate to select parameter values as displayed on screen.
9. **R-Select:** Confirms "set" of RIGHT knob selection displayed on screen.
10. **Feed:** Press to manually confirm wire feeding from selected torch and feed drive.
11. **Enter:** Takes user to welding screen (ready to weld) and displays voltage, current, wire feed speed and other parameters that the machine has been set to provide during welding.

3.2.1 MMA Control Panel



1. **Menu:** Press to select STICK (MMA) mode. Press ENTER for ready-to-weld.
2. **L-Knob:** Rotate to adjust output welding current for electrode in use.
3. **Parameter Select:** Press ENTER **2-times** to display Hot Start and Arc Force.
4. **L-Knob:** Rotate to display and select Hot Start or Arc Force
5. **R-Knob:** Rotate to set 0~10 for Hot Start or Arc Force. Press R-Select after setting.
6. **Enter:** Press to return to ready-to-weld and begin welding operation.


Hot Start

Hot start provides extra “ignition” power when the weld starts to counteract the high resistance of the electrode and workpiece as contact is made. Setting range: 0~10.

Arc Force

An MMA welding power source is designed to produce constant output current (CC). Arc Force control boosts the welding power if it senses the welding voltage is getting too low. The higher the arc force adjustment, the higher the minimum voltage that the power source will allow. This effect will also cause the welding current to increase. This is useful for electrode types that have a higher operating voltage requirement or joint types that require a short arc length.

§3.2.2 Lift TIG Control Panel



1. **Menu:** Press to select TIG LIFT mode. Press ENTER for ready-to-weld.
2. **L-Knob:** Rotate to adjust welding output current as required by application.
3. **Parameter Select:** Press ENTER **2-times** to display TIG LIFT parameters
4. **L-Knob:** Rotate to select parameter of trigger, down slope or post flow.
5. **R-Knob:** Rotate to set selected parameter as displayed on right-hand side of screen.
7. **Enter:** Press to return to ready-to-weld and begin welding operation.



LIFT TIG Parameter Interface:




1. **Trigger mode:** Rotate R-Knob to 2T or 4T.
2. **Down slope time:** Rotate R-Knob to 0~10s.
3. **Post flow time:** Rotate R-Knob to 0~10s.

(Press ENTER to return to ready-to-weld and begin welding operation.)

Trigger Mode Select:



§3.2.3 MIG Pulse or Dual Pulse Control Panel



1. **Mode:** Press to MENU 1-time to display PULSE or DUAL PULSE mode.
2. **L-Knob:** Rotate to desired mode and press SELECT-L.
3. **Mig Gun Select:** Press GUN CHANGE to #1 Silicone Bronze, #2: Aluminum or #3 Steel.
4. **Program Select:** Press MENU **2-times** to display pulse synergic programs with wire diameter.
5. **L-Knob:** Rotate to select desired program. Press SELECT-L to confirm program desired.
6. **Parameter Select:** Press MENU **3-times** to display MIG PULSE parameters. SEE BELOW
7. **L-Knob:** Rotate to select desired MIG PULSE parameter for adjustment.
8. **R-Knob:** Rotate to set MIG PULSE parameter. Press SELECT-R to confirm setting.
9. **Settings:** Press MENU **4-times** to adjust machine settings. Press Enter for ready-to-weld.
10. **Job Saved:** Press MENU **5-times** to save job. See section 3.2.6 for complete details.
11. **Ready-to-Weld:** Press ENTER to begin MIG PULSE or MIG DUAL PULSE welding.
12. **L & R Knobs:** Rotate L-Knob to adjust output AMPS or rotate R-Knob to adjust output VOLTS.

MIG (Dual) Pulse Functional Parameters:



1. **Plate thickness:** Rotate R-Knob to set material thickness to be welded.
2. **Arc length:** Rotate R-Knob to set arc length (+10 to -10). Press R-SELECT to set.
3. **Inductance:** Rotate R-Knob to set inductance (0~10). Press R-SELECT to set.
4. **Trigger:** Rotate R-Knob to set 2T/4T/S4T/ Spot Weld. Press R-SELECT to set.
5. **Burn back:** Rotate R-Knob to set burn back (0~10s). Press R-SELECT to set.
6. **Pre flow:** Rotate R-Knob to set gas pre-flow (0~10s). Press R-SELECT to set.
7. **Post flow:** Rotate R-Knob to set gas post-flow (0~10s). Press R-SELECT to set.
8. **Slow Feed:** Rotate R-Knob to set slow feed (0~10). Press R-SELECT to set.
9. **Push Pull:** Rotate R-Knob to select push-pull torch On or Off. Press R-SELECT to set.

Double Pulse Only: Delta pulse current, Pulse frequency, Pulse duty, Base current arc length


Arc Length

If arc length is decreased, the arc cone becomes narrow and more focused resulting in a weld bead that is narrow with slightly decreased penetration. Conversely, if arc length is increased, the arc is wider resulting in weld bead that is wider and flatter with slightly increased penetration. Wire speed must be constant (preset synergic) for arc length adjustment to have the desired effect on the weld.

Inductance/ Wave Form

Inductance slows the rate of current rise. A high inductance setting (+10) provides more penetration. A low inductance setting (-10) provides a narrow bead, less penetration and less blow-through.

S4T Trigger Mode: (Only functional in Double-Pulse)




Pulse Frequency (T):

Set pulse frequency, as shown in Figure regulating the value of time T, ripple pattern of density regulation. Higher Hz produces many short ripples with slightly lower penetration.


Pulse Duty (T1 & T2):

Set strong pulse time T1 (peak) for penetration and low-frequency cycle T2 ratio (cooling), namely the regulation of the proportion of the ripple pattern on weld puddle surface and resulting depth in groove.



§3.2.4 MIG SYNERGIC Control Panel

The operator simply selects a program by the material type, wire type & diameter and shielding gas for the application. Once the material thickness is set, the optimal voltage and wire feed setting for the material will be automatically set. Once set by machine, operator may adjust as required.



1. **Mode:** Press MENU to display MIG DUAL PULSE, PULSE, SYNERGIC & MANUAL modes.
2. **L-KNOB:** Rotate to select MIG SYNERGIC welding mode for the application.
3. **SELECT-L:** Press SELECT-L to confirm MIG SYNERGIC welding mode.
4. **Mig Gun Select:** Press GUN CHANGE to #1 Silicone Bronze, #2: Aluminum or #3 Steel.
5. **Program Select:** Press MENU **2-times** to display synergic programs with wire diameter.
6. **L-Knob:** Rotate to select desired program. Press SELECT-L to confirm program desired.
7. **Parameter Select:** Press MENU **3-times** to display MIG SYNERGIC parameters. SEE BELOW
8. **L-Knob:** Rotate to select desired MIG SYNERGIC parameter for adjustment.
9. **R-Knob:** Rotate to set MIG SYNERGIC parameter. Press SELECT-R to confirm setting.
10. **Settings:** Press MENU **4-times** to adjust machine settings. Press Enter for ready-to-weld.
11. **Job Saved:** Press MENU **5-times** to save job. See section 3.2.6 for complete details.
12. **Ready-to-Weld:** Press ENTER to begin MIG SYNERGIC welding.
13. **L & R Knobs:** Rotate L-Knob to adjust output AMPS or rotate R-Knob to adjust output VOLTS.

MIG SYNERGIC Functional Parameters:



1. **Plate thickness:** Rotate R-Knob to set material thickness to be welded.
2. **Arc length:** Rotate R-Knob to set arc length (+10 to -10). Press R-SELECT to set.
3. **Inductance:** Rotate R-Knob to set inductance (0~10). Press R-SELECT to set.
4. **Trigger:** Rotate R-Knob to set 2T/4T/ Spot Weld. Press R-SELECT to set.
5. **Burn back:** Rotate R-Knob to set burn back (0~10s). Press R-SELECT to set.
6. **Pre flow:** Rotate R-Knob to set gas pre-flow (0~10s). Press R-SELECT to set.
7. **Post flow:** Rotate R-Knob to set gas post-flow (0~10s). Press R-SELECT to set.
8. **Slow Feed:** Rotate R-Knob to set slow feed (0~10). Press R-SELECT to set.
9. **Push Pull:** Rotate R-Knob to select push-pull torch On or Off. Press R-SELECT to set.

Burn back

Burn back control sets the length of welding wire that can burn back towards the contact tip when trigger is released. Current is reduced over time after trigger is released to keep wire from puddle.

Slow feed


This function is used to regulate the speed of wire feeding when trigger is pressed. Slow starting assists development of puddle with small diameter or “soft” wire. Range: 0~10s.

§3.2.5 MIG Manual Control Panel



1. **Mode:** Press MENU **1-time** to display welding modes.
2. **L-Knob:** Rotate to MIG MANUAL welding mode.
3. **Select-L:** Press SELECT-L to confirm MIG MANUAL. Press ENTER to set.
4. **Mig Gun Select:** Press GUN CHANGE to #1 Silicone Bronze, #2: Aluminum or #3 Steel.
5. **Parameter Select:** Press MENU **2-times** to display MIG MANUAL parameters. SEE BELOW
6. **L-Knob:** Rotate to select desired MIG MANUAL parameter for adjustment.
7. **R-Knob:** Rotate to set MIG MANUAL parameter. Press SELECT-R to confirm setting.
8. **Settings:** Press MENU **3-times** to adjust machine settings. Press Enter for ready-to-weld.
9. **Job Saved:** Press MENU **4-times** to save job. See section 3.2.6 for complete details.
10. **Ready-to-Weld:** Press ENTER to begin MIG PULSE or MIG DUAL PULSE welding.
11. **L & R Knobs:** Rotate L-Knob to adjust output AMPS or rotate R-Knob to adjust output VOLTS.

MIG Manual Functional Parameters:



1. **Inductance:** Rotate R-Knob to set inductance (0~10). Press R-SELECT to set.
2. **Trigger:** Rotate R-Knob to set 2T/4T/Spot Weld. Press R-SELECT to set.
3. **Burn back:** Rotate R-Knob to set burn back (0~10s). Press R-SELECT to set.
4. **Pre flow:** Rotate R-Knob to set gas pre-flow (0~10s). Press R-SELECT to set.
5. **Post flow:** Rotate R-Knob to set gas post-flow (0~10s). Press R-SELECT to set.
6. **Slow Feed:** Rotate R-Knob to set slow feed (0~10). Press R-SELECT to set.
7. **Push Pull:** Rotate R-Knob to select push-pull torch On or Off. Press R-SELECT to set.
8. **Spool Gun:** Rotate R-Knob to select spool gun On or Off. Press R-SELECT to set.

NOTE: Spool gun will only work in MIG MANUAL and must be in Gun #1.


Burn back

Burn back control sets the length of welding wire that can burn back towards the contact tip when trigger is released. Current is reduced over time after trigger is released to keep wire from puddle.

Slow feed

This function is used to regulate the speed of wire feeding when trigger is pressed. Slow starting assists development of puddle with small diameter or “soft” wire. Range: 0~10s.

Spot Weld Trigger Mode:



§3.2.6 System Setting Control Panel



1. **Menu:** Press MENU **3 or 4 times** to display SETTING screen icon
2. **L-Knob:** Rotate to desired SETTING of Units, Brightness or Factory Reset
3. **R-Knob:** Rotate to change SETTING as listed on RH side of display.
4. **R-Select:** Push to confirm new SETING.
5. **Enter:** Push to display Ready-To-Weld screen

§3.2.7 JOB Program Control Panel

The machine can save 10 jobs per gun (Gun 1, 2 & 3) and has no pre-saved JOB programs.

NOTE: In the JOB menu screen, the only JOBS displayed will be for the Gun # that is selected.



Save a JOB:

Operator must select a gun, select welding mode and set all parameters for the JOB application:

1. **Enter:** Press ENTER to display the Ready-To-Weld screen.
2. **Save:** Press SAVE button and display will change to JOB screen, pasting the job settings into the next open JOB # spot on the list. It is saved at this point, no further action required.

Load a JOB: (Previously saved)

1. **Menu:** Press MENU until JOB screen is displayed.
2. **Gun Select:** Confirm you have selected the correct gun. If not, press GUN CHANGE.
3. **L-Knob:** Rotate it to select JOB desired to run. (Note #9 & #10 are on page 2)
4. **R-Knob:** Rotate it to LOADING position and press R-SELECT button to load..
5. **Enter:** Press ENTER to go to Ready-To-Weld screen

Delete a JOB: (Previously saved)

1. **Menu:** Press MENU until JOB screen is displayed.
2. **Gun Select:** Confirm you have selected the correct gun. If not, press GUN CHANGE.
3. **L-Knob:** Rotate it to select JOB to delete. (Note #9 & #10 are on page 2)
4. **R-Knob:** Rotate it to LOADING position and press R-SELECT button to load.
5. **Enter:** Press ENTER to go to Ready-To-Weld screen

§4 Installation & Operation


§4.1 Operation for Stick (MMA) Electrode Welding

§4.1.1 Set-Up for MMA / Stick Welding

Two sockets are available on this welding machine, One Positive (+) and one Negative (-) polarity, to connect Electrode Holder and Earth Clamp cables. Various electrodes require different polarity for optimum results. Refer to the electrode data sheet for the correct polarity.

DCEP: Electrode connected to Positive (+) output socket.


DCEN: Electrode connected to Negative (-) output socket.



- (1) Power source on. Press MENU, rotate L-Knob to MMA welding mode. Press ENTER.
- (2) Press MENU **2-times** and using L-Knob, set Hot Start or Arc Force. Press ENTER.
- (3) Set the welding current with L-Knob relevant to the electrode type and size being used as recommended by the electrode manufacturer.
- (4) Place the electrode into the electrode holder and clamp tight.
- (5) Strike the electrode against the work piece and hold steady to maintain the arc.


§4.1.2 MMA / Stick Electrode Welding

One of the most common types of arc welding is manual metal arc welding (MMA) or stick welding. An electric current is used to strike an arc between the base material and a consumable electrode rod or 'stick'. The electrode rod is made of a material that is compatible with the base material being welded and is covered with a flux that releases a gaseous vapor that serve as a shielding gas and providing a layer of slag, both of which protect the weld area from atmospheric contamination. The electrode core itself acts as filler material the residue from the flux that forms slag covering over the weld metal must be chipped away after welding.



MMA/Stick Electrode

- The arc is initiated by momentarily touching the electrode to the base metal.
- The melted electrode metal is transferred across the arc into the molten pool and becomes weld metal.
- The deposit is covered and protected by slag from the electrode flux coating.



Flux Properties

- producing a protective gas around the weld area
- providing fluxing elements and deoxidizer
- creating a protective slag coating over the weld
- establishing arc characteristics
- adding alloying elements

Stick electrodes serve many purposes in addition to filler metal to the molten pool. These additional functions are provided mainly by the various electrode coverings.

§4.1.3 MMA Welding Fundamentals

Electrode Selection

As a general rule, the selection of an electrode is straight forward, in that it is only a matter of selecting an electrode of similar composition to the parent metal. However, for some metals there is a choice of several electrodes, each of which has particular properties to suit specific classes of work. It is recommended to consult your welding supplier.

Average Thickness of Material	Max. Recommended Electrode Diameter
1.0~2.0 mm	2.5 mm
2.0~5.0 mm	3.2 mm
5.0~8.0 mm	4.0 mm
>8.0 mm	5.0 mm

The size of the electrode generally depends on the thickness of the section being welded, and the thicker the section the larger the electrode required. The maximum size of electrodes that may be used for various thicknesses based on a general purpose type 6013 electrode.

Welding Current (Amperage)

Correct current selection for a particular job is an important factor in arc welding. With the current set too low, difficulty is experienced in striking and maintaining a stable arc. The electrode tends to stick to the work, penetration is poor and beads with a distinct rounded profile will be deposited. Too high current is accompanied by overheating of the electrode resulting undercut and burning through of the base metal and producing excessive spatter.

Electrode Size ø mm	Current Range (Amps)
2.5 mm	60~95
3.2 mm	100~130
4.0 mm	130~165
5.0 mm	165~260

Normal current for a particular job may be considered as the maximum, which can be used without burning through the work, over-heating the electrode or producing a rough spattered surface. The table shows current ranges recommended for a general purpose electrode type 6013.

Arc Length

To strike the arc, the electrode should be gently scraped on the work until the arc is established. There is a simple rule for the proper arc length; it should be the shortest arc that gives a good surface to the weld. An arc too long reduces penetration, produces spatter and gives a rough surface finish to the weld. An excessively short arc will cause sticking of the electrode and result in poor quality welds. General rule of thumb for down hand welding is to have an arc length no greater than the diameter of the core wire.

Electrode Angle

The angle that the electrode makes with the work is important to ensure a smooth, even transfer of metal. When welding in down hand, fillet, horizontal or overhead the angle of the electrode is generally between 5 and 15 degrees towards the direction of travel. When vertical up welding, the angle of the electrode should be between 80 and 90 degrees to the work piece.

Travel Speed


The electrode should be moved along in the direction of the joint being welded at a speed that will give the size of run required. At the same time, the electrode is fed downwards to keep the correct arc length at all times. Excessive travel speeds lead to poor fusion, lack of penetration etc, while too slow a rate of travel will frequently lead to arc instability, slag inclusions and poor mechanical properties.

Material and Joint Preparation

The material to be welded should be clean and free of any moisture, paint, oil, grease, mill scale, rust or any other material that will hinder the arc and contaminate the weld material. Joint preparation will depend on the method used include sawing, punching, shearing, machining, flame cutting and others. In all cases edges should be clean and free of any contaminates. The type of joint will be determined by the chosen application.

§4.2 Installation & Operation for TIG Welding

§4.2.1 Set-Up for TIG Welding




- (1) Plug the earth cable into the positive (+) socket and twist to lock in place.
- (2) Plug the TIG torch into the negative (-) socket and twist to lock in place.
- (3) Connect TIG torch gas hose to outlet gas connector on the front of the machine.
- (4) Connect TIG torch control cable to 9-pin socket on the front of the machine.
- (5) Connect gas regulator to the gas cylinder and the gas hose to the gas regulator.
- (6) Connect gas hose to the machine inlet gas connector located on the rear panel.
- (7) Connect the power cable of welding machine to the electrical outlet.
- (8) Carefully open the valve of the gas cylinder, set the required gas flow rate.
- (9) Select TIG function on the front panel by pressing MENU button.
- (10) Set parameters for trigger, down-slope and post gas. Press ENTER to weld.



(11) Assemble front end parts of the TIG torch, fitting a sharpened tungsten suitable for the material to be welded.



(12) Lay the outside edge of the cup on work piece with the tungsten 1~2mm from the work piece.



(13) With a small movement rotate the gas cup forward so that the tungsten electrode touches the work piece.



(14) Now rotate the gas cup in the reverse direction to lift the tungsten electrode from the work piece to create the arc. (Lift Arc)


(15) Weld the material by placing the filler rod into the arc.

(16) Control weld current with foot pedal to maintain desired weld puddle.

(16) Release the trigger or foot pedal to stop the welding.

IMPORTANT! – It is recommended that you check for gas leaks prior to operation and that the operator close the cylinder valve when the machine is not in use.



§4.2.2 DC TIG Welding



The power source provides what is known as DC (direct current) in which the main electrical component, known as electrons, flow in only one direction from the negative terminal (-) to the positive terminal (+). In DC electrical circuit there is an electrical principle at work that provides 70% of the energy (heat) is always on the positive side. This is important because it determines what terminal to connect the TIG torch.

WARNING: If tungsten electrode glows RED hot & melts away, confirm correct polarity.

DC TIG welding is a process in which an arc is struck between a TUNGSTEN electrode and the metal work piece. The weld area is shielded by an inert gas flow to prevent contamination of the tungsten, molten pool and weld area. When the TIG arc is struck the inert gas is ionized and superheated changing its' molecular structure which converts it into a plasma stream. This plasma stream that flows between the tungsten and the work piece is the TIG arc and can be as hot as 34,000°F (19,000°C). It is a very pure and concentrated arc which provides the controlled melting of most metals into a weld pool. TIG welding offers the user the greatest amount of flexibility to weld the widest range of materials, thicknesses and profiles. DC TIG welding is also the cleanest weld with no sparks or spatter for all types of alloy steel.




The intensity of the arc is proportional to the current that flows from the tungsten. The welder regulates the welding current to adjust the power of the arc. Typically, thin material requires a less powerful arc with less heat to melt the material so less current (amps) is required, thicker material


requires a more powerful arc with more heat so more current (amps) are necessary to melt the material. As current increases, the required diameter of the tungsten electrode will increase.

LIFT ARC IGNITION for TIG Welding


Lift Arc is a form of arc ignition where the machine has voltage on the electrode of only a few volts, with a current limit of one or two amps (well below the limit that causes metal to transfer and contamination of the weld or electrode). When the machine detects that the tungsten has left the surface and a spark is present, within microseconds, it increases power, converting the spark to a full arc. It is a simple, lower cost alternative to potentially harmful high-frequency ignition.




Lay the nozzle on the job without the tungsten touching the work.



Rock the torch sideways so that the tungsten touches the work & hold momentarily.




Rock the torch back in the opposite direction, the arc will ignite as the tungsten lifts off.






Lift the torch to maintain the arc.

§4.2.3 TIG Welding Fusion Technique




Manual TIG welding is often considered the most difficult of all the welding processes. Because the welder must maintain a short arc length, great care and skill are required to prevent contact between the electrode and the workpiece. Similar to Oxygen/Acetylene torch welding, TIG welding normally requires two hands and in most instances requires the welder to manually


feed a filler wire into the weld pool with one hand while manipulating the welding torch in the other. However, some welds combining thin materials can be accomplished without filler metal like edge, corner, and butt joints. This is known as Fusion welding where the edges of the metal pieces are melted together using only the heat and arc force.



TIG Welding with Filler Wire Technique



It is necessary in many situations with TIG welding to add a filler wire into the weld pool to build up weld reinforcement and create a strong weld. Once the arc is started the torch tungsten is held in place until a weld pool is created, a circular movement of the tungsten will assist in creating a weld pool of the desired size. Once the weld pool is established tilt the torch at about a 75° angle and move smoothly and evenly along the joint. The filler metal is introduced to the leading edge of the weld pool. The filler wire is usually held at about a 15° angle and fed into the leading edge of the molten pool, the arc will melt the filler wire into the weld pool as the torch is moved forward. A “dabbing” technique can be used to control the amount of filler wire added. The wire is fed into the molten pool and retracted in a repeating sequence as the torch is moved slowly and evenly forward. It is important during the welding to keep the molten end of the filler wire inside the gas shield as this protects the end of the wire from being oxidized and contaminating the weld pool.



§4.2.4 Tungsten Electrodes

Tungsten is a rare metallic element used for manufacturing TIG welding electrodes. The TIG process relies on tungsten's hardness and high-temperature resistance to carry the welding current to the arc. Tungsten has the highest melting point of any metal, 3,410 degrees Celsius. Tungsten electrodes are a consumable and come in a variety of sizes, they are made from pure tungsten or an alloy of tungsten and other rare earth elements. Choosing the correct tungsten depends on the material being welded, amps required and whether you are using AC or DC welding current. Tungsten electrodes are color-coded at the end for easy identification.

Thoriated (RED)

Thoriated tungsten electrodes (AWS classification EWTh-2) contain a minimum of 97.30 percent tungsten and 1.70 to 2.20 percent thorium and are called 2% thoriated. They are the most commonly used DC electrodes today and are preferred for their longevity, ease of use and higher amperage performance. Thorium however is a low-level radioactive hazard and many users have switched to other alternatives (See Ceriated). Regarding the radioactivity, thorium is an alpha emitter but when it is enclosed in a tungsten matrix the risks are negligible. Thoriated tungsten should not get in contact with open cuts or wounds. The more significant danger to welder can occur when thorium oxide gets into the lungs. This can happen from the exposure to vapors during welding or from ingestion of material/dust in the grinding of the tungsten. Follow the manufacturer's warnings, instructions, and the Material Safety Data Sheet (MSDS).

Pure (Green)

Pure tungsten electrodes (AWS classification EWP/WP) contain a minimum of 99.5% percent tungsten. Pure Tungsten Electrodes provide conductivity similar to Zirconiated electrodes. Pure Tungsten Electrodes work well on AC constant current power sources, such as transformer, for aluminum and magnesium alloys in low to medium temperature applications. They can be used DC electrode negative with a pointed end, or balled for use with AC power sources, they tend to split at higher amperages and should be used for non-critical welds only.

Ceriated (Orange)

Ceriated tungsten electrodes (AWS classification EWCe-2) contain a minimum of 97.30 percent tungsten and 1.80 to 2.20 percent cerium and are referred to as 2% ceriated. Ceriated tungsten performs best in DC welding at low current settings. They have excellent arc starts at low amperages and become popular in such applications as orbital tube welding, thin sheet metal work. They are best used to weld carbon steel, stainless steel, nickel alloys, and titanium, and in some cases, can replace 2% Thoriated electrodes. Ceriated tungsten is best suited for lower amperages should last longer than Thoriated at low power. Higher amperage applications are best left to Thoriated or Lanthanated tungsten.

Lanthanated (Gold)



Lanthanated tungsten electrodes (AWS classification EWLa-1.5) contain a minimum of 97.80 percent tungsten and 1.30 percent to 1.70 percent lanthanum and are known as 1.5% lanthanated. These electrodes have excellent arc starting, a low burn off rate, good arc stability, and excellent re-ignition characteristics. Lanthanated tungsten also share the conductivity and high amperage characteristics of 2% Thoriated tungsten. Lanthanated tungsten electrodes are ideal if you want to optimize your welding capabilities. They work well on AC or DC electrode negative with a pointed end, or they can be balled for use with AC sine wave power sources. Lanthanated tungsten maintains a sharpened point well, which is an advantage for welding steel and stainless steel on DC or AC from square wave power sources.

Zirconiated (White)



Zirconiated tungsten electrodes (AWS classification EWZr-1) contain a minimum of 99.10 percent tungsten and 0.15 to 0.40 percent zirconium oxide. Most commonly used for AC welding, Zirconiated tungsten produces a very stable arc and is resistant to tungsten spitting. It is ideal for AC welding because it retains a balled tip and has a high resistance to contamination. Its current-carrying capacity is equal to or greater than that of thoriated tungsten. Zirconiated tungsten is not recommended for DC welding.

Tungsten Electrodes Rating for Welding Currents

Tungsten Diameter mm	DC Current Amps Torch Negative 2% Thoriated	AC Current Amps Un-Balanced Wave 0.8% Zirconiated	AC Current Amps Balanced Wave 0.8% Zirconiated
1.0mm	15~80	15~80	20~60
1.6mm	70~150	70~150	60~120
2.4mm	150~250	140~235	100~180
3.2mm	250~400	225~325	160~250
4.0mm	400~500	300~400	200~320

§4.2.5 Tungsten Preparation

Always use **DIAMOND** wheels when grinding and cutting. While tungsten is a very hard material, the surface of a diamond wheel is harder, and this makes for smooth grinding. Grinding without diamond wheels, such as Aluminum oxide wheels, can lead to jagged edges, imperfections, or poor surface finishes not visible to the eye that will contribute to weld inconsistency and weld defects.

Always ensure to grind the tungsten in a longitudinal direction on the grinding wheel. Tungsten electrodes are manufactured with the molecular structure of the grain running lengthwise and thus grinding crosswise is “grinding against the grain”. If electrodes are ground crosswise, the electrons have to jump across the grinding marks and the arc can start before the tip and wander. Grinding longitudinally with the grain, the electrons flow steadily and easily to the end of the tungsten tip. The arc starts straight and remains narrow, concentrated and stable.



Electrode Shape & Angle

The shape of the tungsten electrode tip is an important process variable in precision arc welding. A good selection of tip/flat size will balance the need for several advantages. The bigger the flat, the more likely arc wander will occur and the more difficult it will be to arc start. However, increasing the flat to the maximum level that still allows arc start and eliminates arc wander will improve the weld penetration and increase the electrode life. The included angle determines weld bead shape and size. Generally, as the included angle increases, penetration increases and bead width decreases.

Some welders still grind electrodes to a sharp point, which makes arc starting easier. However, they risk decreased welding performance from melting at the tip.



Electrode Included Angle/Taper - DC Welding

Tungsten electrodes for DC welding should be ground longitudinally and concentrically with diamond wheels to a specific included angle in conjunction with the tip/flat preparation. Different angles produce different arc shapes and offer different weld penetration capabilities.

Blunter electrodes with larger included angle provide:

- Last Longer
- Have better weld penetration
- Have a narrower arc shape
- Can handle more amperage without eroding.





Sharper electrodes with smaller included angle provide:

- Offer less arc weld
- Have a wider arc
- Have a more consistent arc

Tungsten Diameter	Diameter at the Tip - mm	Constant Included Angle - Degrees	Current Range Amps	Current Range Pulsed Amps
1.0mm	0.250	20	5~30	5~60
1.6mm	0.500	25	8~50	5~100
1.6mm	0.800	30	10~70	10~140
2.4mm	0.800	35	12~90	12~180
2.4mm	1.100	45	15~150	15~250
3.2mm	1.100	60	20~200	20~300
3.2mm	1.500	90	25~250	25~350

§4.2.6 TIG Torch Switch Controls




Remote Control Socket


9-Pin Socket	Function
1	Spool / Push-Pull gun motor (-) Not connected
2	Trigger switch N/O
3	Trigger switch N/O
4	Spool / Push-Pull gun motor (+) Not connected
5	10k ohm (maximum) connection to 10k ohm remote control potentiometer.
6	0K ohm (minimum) connection to 10k ohm remote control potentiometer.
7	Wiper arm connection to 10k ohm spool gun potentiometer. Not Connected
8	Wiper arm connection to 10k ohm TIG remote control potentiometer.
9	Not connected

§4.3 Installation & Operation for MIG Welding

§4.3.1 Set up installation for MIG Welding





- (1) Insert the earth clamp cable plug into the Negative (-) socket and twist to tighten.
- (2) Insert correct the MIG welding gun plug into one of three euro-connect sockets on the front panel and tighten locking nuts securely.
- (3) Connect the gas regulator to the gas cylinder and connect the gas hose to the regulator.
- (4) Connect the gas hose to gas connector on the rear panel.
- (5) Open the gas cylinder valve and set regulator flow rate. **Check for Leaks!**
- (6) Connect the power cord of welding machine with the outlet on electrical box.




- (7) Place wire onto spool holder - (spool retaining nut is left hand thread) feed wire through the inlet guide tube on to the drive roller.


- (8) Carefully feed the wire over the drive roller into the outlet guide tube, feed through about ½" (15mm) into the torch receptacle.



- (9) Check that the drive roller size is compatible with the wire diameter, replace the roller if necessary. (SEE Section 4.3.2 for more information)
- (10) Align the wire into the groove of the drive roller and close the top roller tension arms making sure the wire is in the groove of the bottom drive roller, lock the tension arms into place with pressure knobs and tighten by turning clockwise.



Tension arms



Tension Adjusting Knob -

Turn to 1.5 position and check for wire slip at end of torch neck. Increase tension until no slip.

Too much tension will result in bird-nesting of wire, In this case, reduce tension on rolls

- (11) Remove the gas nozzle and contact tip from the torch neck.
- (12) Press and hold the manual wire button to feed the wire through to the torch neck, release the manual wire key when the wire exits the torch neck.

WARNING: Be sure to keep torch neck away from your eyes, face or hands as the wire feeds through the power cable and exits the swan neck!

- (13) Fit the correct sized contact tip and feed the wire through it, screw the contact tip into the tip holder of the torch neck, tighten tip with wrench and nip extension to 1/8" (3-5mm).
- (14) Replace shield gas nozzle to the torch head.
- (15) Connect earth clamp to material to be welded.
- (16) Turn power switch to ON position.
- (17) Ready-To-Weld.

§4.3.2 Wire Feed Roller Selection

The importance of smooth consistent wire feeding during MIG welding cannot be emphasized enough. Simply put the smoother the wire feed then the better the weld.


Feed rollers or drive rollers are used to feed the wire mechanically through the length of the welding gun cable. Feed rollers are designed to be used for certain types of welding wire and they have different types of grooves machined in them to accommodate the different types of wire. The wire is held in the groove by the top roller of the wire drive unit and is referred to as the pressure roller, pressure is applied by a tension arm that can be adjusted to increase or decrease the pressure as required. The type of wire will determine how much pressure can be applied and what type of drive roller is best suited to obtain optimum wire feed.

Solid Hard Wire - Steel, Stainless Steel requires a drive roller with a “V” shape groove for optimum grip and drive capability. Solid wires can have more tension applied to the wire from the top pressure roller that holds the wire in the groove and the “V” shape groove is more suited for this. Solid wires are more forgiving to feed due to their higher cross-sectional column strength, they are stiffer and don’t deflect so easily.

Soft Wire - Such as Aluminum, require a “U” shape groove. Aluminum wire has a lot less column strength, can bend easily and is therefore more difficult to feed. Soft wires can easily buckle at the wire feeder where the wire is fed into inlet guide tube of the torch. The U-shaped roller offers more surface area grip and traction to help feed the softer wire. Softer wires also require less tension from the top pressure roller to avoid deforming the shape of the wire which can cause it to catch in the contact tip.

Flux Core/ Gasless Wire - These wires are made up of a thin metal sheath that has flux and metal compounds layered onto the surface and then rolled into a cylinder to form the finished wire. The wire cannot take too much pressure from the top roller as it can be crushed and deformed if too much pressure is applied. A knurled-V drive roller has been developed and it has small serrations in the groove, the serrations grip the wire and assist to drive it without too much pressure from the top roller. The downside to the knurled wire feed roller on flux cored wire is it

will slowly over time bit by bit eat away at the surface of the welding wire, and these small pieces will eventually go down into the liner. This will cause clogging in the liner and added friction that will lead to welding wire feed problems. The U groove roll can also be used for flux core wire without the wire particles coming off the wire surface. However, it is considered that the knurled roller will give a more positive feed of flux core wire without any deformation of the wire shape.



§4.3.3 Wire Installation and Set-Up Guide

The importance of smooth consistent wire feeding during MIG welding cannot be emphasized enough. The correct installation of the wire spool and the wire into the wire feed unit is critical to achieving an even and consistent wire feed. A high percentage of faults with MIG welders emanate from poor set up of the wire into the wire feeder.


The guide below will assist in the correct setup of your wire feeder.



(1) Remove the spool retaining nut. Note the tension spring adjuster and spool locating pin.




(2) If you need install 200mm wire spool, please install the spool spacer firstly. If install 300mm wire spool, please ignore this step.




(3) Fit the wire spool onto the spool holder fitting the locating pin into the location hole on the spool. Replace the retaining nut.




(4) Snip the wire carefully, be sure to hold wire to prevent the spool uncoiling. Carefully feed the wire into the inlet guide tube of the wire feed unit.



(5) Feed the wire through the drive rollers and into the outlet guide tube of the wire.



(6) Lock down the top pressure roller and tighten using the tension adjustment knob.




(7) Check that the wire passes through the center of the outlet guide tube without touching the sides. Loosen the locking screw and then loosen the outlet guide tube retaining nut too make adjustment if required. Carefully retighten the locking nut and screw to hold the new position.




WARNING: Must wear gloves

(8) A simple check for the correct drive tension is to “bow” the feeding wire. Hold it about 4” (100mm) from your hand and let it run into your hand, it should coil round in your hand without stopping and slipping at the drive rollers, increase the tension if it slips.



(9) The weight and speed of the wire spool turning creates an inertia that can cause the spool to run on and the wire loop over the side of the spool and tangle. If this happens increase the pressure on the tension spring inside the spool holder assembly using the tension adjustment nut. ***Remove spool holder nut to expose.***

§4.3.4 Set up for MIG Welding- Aluminum or Silicone Bronze Wire



- (1) Repeat all steps as listed in 4.3.1.
- (2) Fit the correct size U-groove drive roller for soft wires.
- (3) Change shield gas to 100% Argon.

§4.3.5 MIG Torch Liner Installation




(1) Remove MIG torch front end parts.



(2) Remove the liner retaining nut.



(3) Carefully pull out and completely remove.




(4) Carefully unravel the new liner.



(5) Carefully feed in the new liner down the torch lead all the way to exit the torch neck.




(6) Fit the liner retaining nut and screw only 1/2 way down.



(7) Snip the liner off 1/8" (3mm) past the end of the torch neck. **(Remove any burrs with file)**



(8) Replace the front-end parts and tighten tip & tip holder with wrench.



§4.3.6 MIG Torch Liner Types and Information

MIG Torch Liners

The liner is both one of the simplest and most important components of a MIG gun. Its sole purpose is to guide the welding wire from the wire feeder, through the gun cable and up to the contact tip.

Steel Liners

Most MIG gun liners are made from coiled steel wire also known as piano wire, which provides the liner with good rigidity and flexibility and allows it to guide the welding wire smoothly through the welding cable as it bends and flex during operational use. Steel liners are primarily used for feeding of solid steel wires, other wires such as Aluminum, Silicon Bronze, Etc. will perform better using a Teflon or Polyamide line. The internal diameter of the liner is important and relative to the wire diameter being used. The correct inside diameter and will assist in smooth feeding and prevention of the wire kinking and bird-nesting at the drive rollers. Also bending the cable too tightly during welding increases the friction between the liner and the welding wire making it more difficult to push the wire through the liner resulting in poor wire feeding, premature liner wear and bird-nesting. Dust, grime and metal particles can accumulate inside the liner over time and cause friction and blockages, it is recommended to periodically blow out the liner with compressed air. Small diameter welding wires, 0.6mm through 1.0mm have relatively low columnar strength, and if matched with an oversized liner, can cause the wire to wander or drift within the liner. This in turn leads to poor wire feeding and premature liner failure due to excessive wear. By contrast, larger diameter welding wires, 1.2mm through 2.4mm have much higher columnar strength but it is important to make sure the liner has enough internal diameter clearance. Most manufacturers will produce liners sized to match wire diameters and length of welding torch cable and most are color coded to suit.

Steel Liners

Blue - 0.6mm~0.8mm	
Red - 0.9mm~1.2mm	
Yellow - 1.6mm	
Green - 2.0mm~2.4mm	

Teflon and Polyamide (PA) Liners

Teflon liners are well suited for feeding soft wires with poor column strength like aluminum wires. The interiors of these liners are smooth and provide stable feeding, especially on small diameter welding wire. Teflon can be good for higher heat applications that utilize water-cooled torches and brass neck liners. Teflon has good abrasion resistance characteristics and can be used with a variety of wire types such as silicon bronze, stainless steel as well as aluminum. A note of caution to carefully inspect the end of the welding wire prior to feeding it down the liner. Sharp edges and burrs can score the inside of the liner and lead to blockages and accelerated wear. Polyamide Liners (PA) are made of carbon infused nylon and are ideal for softer aluminum, copper alloy welding wires and push pull torch applications. These liners are generally fitted with a floating collet to allow the liner to be inserted all the way to the feed rollers.

Teflon Liners

Blue - 0.6mm~0.8mm	
Red - 0.9mm~1.2mm	
Yellow - 1.6mm	
Black - 1.0mm~1.6mm	

PA Liner

Copper Neck Liners

For high heat applications, copper wound jumper or neck liner on the end of the liner at the neck end will increase the working temperature of the liner as well as improve the electrical conductivity of the welding power transfer to the wire. It is recommended for all Aluminum and Silicone Bronze welding applications.

Copper Neck Liner



§4.3.7 Torch & Wire Feed Set-Up for Aluminum Wire

The same method is used for Teflon and/or Polyamide Liners (PA).

§4.3.8 Set-Up Installation for Spool Gun


- (1) Insert the earth cable plug into the negative (-) socket and twist to tighten.
- (2) Plug the Spool Gun into the **#1 euro-connect socket** on the front panel and tighten.

IMPORTANT: When connecting the torch be sure to tighten the adaptor nut completely tight. A loose connection can result in arcing between the gun and machine connector and that causes serious damage to both the torch and machine connections.


- (3) Connect the Spool Gun control cable to the 9-pin receptacle on the front panel.
- (4) Connect the gas regulator to the gas cylinder and connect the gas hose to the regulator.
- (5) Connect the gas hose to gas connector on the rear panel.
- (6) Open the gas cylinder valve, set regulator flow rate. **Check for Leaks!**
- (7) Connect the power cord of welding machine with the outlet on electrical box.
- (8) Select Spool Gun welding mode by selecting the spool gun ON parameter.
- (9) Adjust current, voltage and other parameters by L/R knobs and L/R Select buttons.



- (10) Remove the spool cover by pressing button and lifting off the cover.



- (11) Place a spool of wire inside the spool holder on post.





(12) Feed the wire through the drive rolls and into the inlet guide tube. Tighten the wire tension swing arm.



(13) Pull the trigger to drive the wire down the neck until it exits the contact tip.

(14) Press the GAS button to purge all air from the spool gun power cable.

226 Spool Gun Control Plug



Remote Control Plug


9-Pin Socket	Function
1	Spool gun motor (-)
2	Not connected
3	Not connected
4	Spool gun motor (+)
5	10k ohm (maximum) connection to 10k ohm remote control potentiometer.
6	0k ohm (minimum) connection to 10k ohm remote control potentiometer.
7	Wiper arm connection to 10k ohm remote control potentiometer.
8	Not connected
9	Not connected

§4.3.9 Set-Up Installation for Push/Pull MIG Gun

- (1) Insert the earth cable plug into the negative (-) socket and twist to tighten.
- (2) Insert the push/pull MIG gun plug into the **#1 euro-connect socket** and tighten.



IMPORTANT: When connecting the torch be sure to tighten the adaptor nut completely tight. A loose connection can result in arcing between the gun and machine connector and that causes serious damage to both the torch and machine connections.

- (3) Connect the Push/Pull MIG Gun control cable to the 9-pin receptacle on the front panel.
- (4) Connect the gas regulator to the gas cylinder and connect the gas hose to the regulator.
- (5) Connect the gas hose to gas connector on the rear panel.
- (6) Open the gas cylinder valve, set regulator flow rate. **Check for Leaks!**
- (7) Connect the power cord of welding machine with the outlet on electrical box.




- (8) Place wire onto spool holder - (spool retaining nut is left hand thread) feed wire through the inlet guide tube on to the drive roller.


- (9) Carefully feed the wire over the drive roller into the outlet guide tube, feed through about ½" (15mm) into the torch receptacle.



(10) Align the wire into the groove of the drive roller and close the top roller tension arms making sure the wire is in the groove of the bottom drive roller, lock the tension arms into place with pressure knobs and tighten by turning clockwise.



Tension arms




Tension Adjusting Knob -


Turn to 1.5 position and check for wire slip at end of torch neck. Increase tension until no slip.

Too much tension will result in bird-nesting of wire, In this case, reduce tension on rolls

(11) Press the welding mode key to select desired welding mode. Press the menu button until parameters are shown. Use L-Knob to highlight push/pull and use R-Knob to turn ON. And adjust welding current, voltage and other parameters by keys and knobs, such as trigger mode, Pre flow, Post flow, Burn back, Slow feed time.



(12) Press and hold the manual wire button to feed the wire through to Pull MIG gun.



(13) Change the wire tension swing arm to adjust the drive roller tightness.

(14) Pull trigger to feed wire through neck and contact tip.

(15) Replace gas nozzle.


(16) Push GAS button to purge all air from push/pull power cable.

§4.3.10 MIG Welding


Definition of MIG Welding

MIG (metal inert gas) welding also known as GMAW (gas metal arc welding) or MAG (metal active gas welding), is a semi-automatic or automatic arc welding process in which a continuous and consumable wire electrode and a shielding gas are fed through a welding gun. A constant voltage, direct current power source is most commonly used with MIG welding. There are four primary methods of metal transfer in MIG welding, called short circuit (also known as dip transfer) globular transfer, spray transfer and pulsed-spray, each of which has distinct properties and corresponding advantages and limitations.


Short Circuit Transfer - Short circuit transfer is the most common used method whereby the wire electrode is fed continuously down the welding torch through to and exiting the contact tip. The wire touches the work piece and causes a short circuit the wire heats up and begins to form a molten bead, the bead separates from the end of the wire and forms a droplet that is transferred into the weld pool. This process is repeated about 100 times per second, making the arc appear constant to the human eye.




The wire touches the work creating a short circuit. Because there is no space between the wire and the base metal there is no arc.




The wire cannot support all the current flow so resistance builds up and the wire begins to melt.




The current flow creates a magnetic field that begins to pinch the melting wire forming it into droplet.



The pinch causes the forming droplet to separate and falls towards the now



An arc is created at the separation of the droplet and the heat and force of the arc flattens-out the droplet into



The wire feed speed overcomes the heat of the arc and the wire again approaches the work to short circuit and repeat

Basic MIG Welding


Good weld quality and weld profile depends on gun angle, direction of travel, electrode extension (stick out), travel speed, thickness of base metal, wire feed speed and arc voltage. To follow are some basic guides to assist with your setup.

Gun Position - Travel Direction, Work Angle: Gun position or technique usually refers to how the wire is directed at the base metal, the angle and travel direction chosen. Travel speed and work angle will determine the characteristic of the weld bead profile and degree of weld penetration.


Push Technique - The wire is located at the leading edge of the weld pool and pushed towards the un-melted work surface. This technique offers a better view of the weld joint and direction of the wire into the weld joint. Push technique directs the heat away from the weld puddle allowing faster travel speeds providing a flatter weld profile with light penetration - useful for welding thin materials. The welds are wider and flatter allowing for minimal clean-up and grinding time.

Perpendicular Technique - The wire is fed directly into the weld, this technique is used primarily for automated situations or when conditions make it necessary. The weld profile is generally taller and a deeper penetration is achieved.


Drag Technique - The gun and wire are dragged away from the weld bead. The arc and heat is concentrated on the weld pool, the base metal receives more heat, deeper melting, more penetration and the weld profile is higher with more build up.



Flat even weld profile
light penetration




Narrower weld profile
even penetration



Narrow higher weld
profile more penetration


Travel Angle - Travel angle is the right to left angle relative to the direction of welding. A travel angle of 5° ~ 15° is ideal and produces a good level of control over the weld pool. A travel angle greater than 20° will give an unstable arc condition with poor weld metal transfer, less penetration, high levels of spatter, poor gas shield and poor quality finished weld.

Angle 5° ~ 15°




Good level of control
over the weld pool,
even flat weld.

Not enough angle




Less control over the weld
pool more spatter.

Angle more than 20°




Poor control, unstable
arc, less penetration, lots
of spatter.

Angle to Work - The work angle is the forward back angle of the gun relative to the work piece. The correct work angle provides good bead shape, prevents undercut, uneven penetration, poor gas shield and poor quality finished weld.




Stick Out - Stick out is the length of the un-melted wire protruding from the end of the contact tip. A constant even stick out of 5~10mm will produce a stable arc, and an even current flow providing good penetration and even fusion. Too short stick out will cause an unstable weld pool, produce spatter and over heat the contact tip. Too long stick out will cause an unstable arc, lack of penetration, lack of fusion and increase spatter.




Travel Speed - Travel speed is the rate that the gun is moved along the weld joint and is usually measured in inches per minute (IPM). Travel speeds can vary depending on conditions and the welder's skill and is limited to the welder's ability to control the weld pool. Push technique allows faster travel speeds than drag technique. Travel speed needs to match the amperage and will decrease as the material thickness and amperage increase.


Too Fast Travel Speed - A too fast travel speed produces too little heat per mm of travel resulting in less penetration and reduced weld fusion, the weld bead solidifies very quickly trapping gases inside the weld metal causing porosity. Undercutting of the base metal can also occur and an unfilled groove in the base metal is created when the travel speed is too fast to allow molten metal to flow into the weld crater created by the arc heat.



Too Slow Travel Speed - A too slow travel speed produces a large weld with lack of penetration and fusion. The energy from the arc dwells on top of the weld pool rather than penetrating the base metal. This produces a wider weld bead with more deposited weld metal per mm than is required resulting in a weld deposit of poor quality.




Correct Travel Speed - The correct travel speed keeps the arc at the leading edge of the weld pool allowing the base metal to melt sufficiently to create good penetration, fusion and wetting out of the weld pool producing a weld deposit of good quality.



Gas selection - The purpose of the gas in the MIG process is to protect / shield the wire, the arc and the molten weld metal from the atmosphere. Most metals when heated to a molten state will react with the air in the atmosphere, without the protection of the shielding gas the weld produced would contain defects like porosity, lack of fusion and slag inclusions.

The correct gas flow is also very important in protecting the welding zone from the atmosphere.

Use the correct shielding gas. CO₂ is good for steel and offers good penetration, the weld profile is narrower and slightly more raised than the weld profile obtained from Argon/CO₂ mixed gas. Argon CO₂ (Argon 80% & CO₂ 20%) mix gas offers better weld ability for thin metals and has a wider range of setting tolerance on the machine.



Argon gas at 100% mixture is good for aluminum and silicone bronze applications. It offers good penetration and weld control. CO₂ is not recommended for these metal alloys.

Wire types and sizes - Use the correct wire type for the base metal being welded. Use stainless steel wire for stainless steel, aluminum for aluminum and steel wires for steel.

Use a smaller diameter wire for thin base metals. For thicker materials use a larger wire diameter and larger machine, check the recommended welding capability of your machine. As a guide refer to the “Welding Wire Thickness Chart” below.


WELDING WIRE DIAMETER CHART					
MATERIAL THICKNESS	RECOMMENDED WIRE DIAMETERS				
	0.8	0.9	1.0	1.2	1.6
0.8mm					
0.9mm					
1.0mm					
1.2mm					
1.6mm					
2.0mm					
2.5mm					
3.0mm					
4.0mm					
5.0mm					
6.0mm					
8.0mm					
10mm					
14mm					
18mm					
22mm					
For material thickness of 5.0mm and greater, multi-pass runs or a beveled joint design may be required depending on the amperage capability of your machine.					

Welding MIG Manual Settings Chart


VOLTAGE & WIRE SPEED SETTINGS FOR MANUAL MIG										
MATERIAL & WIRE TYPE	SHIELD GAS & FLOW	WIRE SIZE	1/2" (12.7mm)	3/8" (9.5mm)	1/4" (6.4mm)	3/16" (4.8mm)	1/8" (3.2mm)	1/16" (1.6mm)	1/32" (0.8mm)	1/64" (0.4mm)
STEEL ER70S-6	80% Ar/20% CO2 25cfh	0.023"(0.6mm)				20.0/480	18.4/350	18.1/240	17.0/188	15.8/125
		0.030"(0.8mm)		24.3/500	21.0/397	19.0/291	17.9/248	17.4/200	16.3/114	15.9/94
		0.035"(0.9mm)	29.5/511	26.0/472	21.0/374	18.3/263	17.4/228	16.5/188	15.8/118	14.9/86
		0.047"(1.2mm)	29.5/314	28.0/299	20.0/224	17.4/192	17.1/188	16.5/165	15.5/94	15.0/59
STAINLESS ER316	98% Ar/2% CO2 25cfh	0.030"(0.8mm)					21.0/669	17.7/354	16.1/224	14.1/86
		0.035"(0.9mm)				22.8/570	18.4/362	16.7/267	13.8/102	
		0.047"(1.2mm)			22.5/374	18.7/267	17.0/177	15.7/122	14.6/74	
ALUMINUM AISI5 ER4043	100% Ar 25cfh	0.030"(0.8mm)			24.5/618	22.6/542	20.5/468	17.5/448	16.7/267	14.3/118
		0.035"(0.9mm)		23.5/700	23.0/531	21.5/448	19.3/381	18.2/299	15.6/153	15.3/118
		0.047"(1.2mm)	24.0/476	23.5/433	23.0/374	21.4/303	19.6/251	17.1/114	15.9/59	15.6/43
ALUMINUM AlMg5 ER5356	100% Ar 25cfh	0.030"(0.8mm)					17.8/791	17.4/716	15.9/531	14.6/334
		0.035"(0.9mm)		17.8/704	17.6/649	17.1/566	16.2/511	15.9/484	14.9/377	13.4/248
		0.047"(1.2mm)	20.0/570	18.7/511	17.5/464	16.8/393	16.3/366	15.2/275	14.5/224	13.3/161
Al99.5	100% Ar 25cfh	0.047"(1.2mm)				23.5/334	21.8/259	19.9/173	17.4/78	16.2/55
SILICONE BRONZE CuSi3	100% Ar 25cfh	0.030"(0.8mm)					12.3/562	11.7/366	11.5/271	10.5/165
		0.035"(0.9mm)					14.0/366	13.4/322	12.9/236	11.8/129
		0.047"(1.2mm)			19.8/417	16.3/322	13.8/244	18.2/208	12.8/177	11.5/86

§4.4 Welding Parameters



Process reference for CO₂ butt welding of low carbon steel solid welding wire

	Material thickness (MM)	Root gap G(MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Gas-flow rate (L/MIN)
Butt-joint 	0.8	0	0.8	60-70	16-16.5	50-60	10
	1.0	0	0.8	75-85	17-17.5	50-60	10-15
	1.2	0	0.8	80-90	17-18	50-60	10-15
	2.0	0-0.5	1.0/1.2	110-120	19-19.5	45-50	10-15
	3.2	0-1.5	1.2	130-150	20-23	30-40	10-20
	4.5	0-1.5	1.2	150-180	21-23	30-35	10-20
	6	0	1.2	270-300	27-30	60-70	10-20
	6	1.2-1.5	1.2	230-260	24-26	40-50	15-20


Process reference for CO₂ corner welding of low carbon steel solid welding wire

Corner joint 	Material thickness (MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Gas-flow rate (L/MIN)
	1.0	0.8	70-80	17-18	50-60	10-15
	1.2	1.0	85-90	18-19	50-60	10-15
	1.6	1.0/1.2	100-110	18-19.5	50-60	10-15
	1.6	1.2	120-130	19-20	40-50	10-20
	2.0	1.0/1.2	115-125	19.5-20	50-60	10-15
	3.2	1.0/1.2	150-170	21-22	45-50	15-20
	3.2	1.2	200-250	24-26	45-60	10-20
	4.5	1.0/1.2	180-200	23-24	40-45	15-20
	4.5	1.2	200-250	24-26	40-50	15-20
	6	1.2	220-250	25-27	35-45	15-20
	6	1.2	270-300	28-31	60-70	15-20
	8	1.2	270-300	28-31	60-70	15-20
	8	1.2	260-300	26-32	25-35	15-20
	8	1.6	300-330	25-26	30-35	15-20
	12	1.2	260-300	26-32	25-35	15-20

Low carbon steel, stainless steel pulse MAG welding process reference

Welding position	Material thickness (MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Nozzle and workpiece spacing (MM)	Gas-flow rate (L/MIN)
Butt-joint 	1.6	1.0	80-100	19-21	40-50	12-15	10-15
	2.0	1.0	90-100	19-21	40-50	13-16	13-15
	3.2	1.2	150-170	22-25	40-50	14-17	15-17
	4.5	1.2	150-180	24-26	30-40	14-17	15-17
	6.0	1.2	270-300	28-31	60-70	17-22	18-22
Corner joint 	1.6	1.0	90-130	21-25	40-50	13-16	10-15
	2.0	1.0	100-150	22-26	35-45	13-16	13-15
	3.2	1.2	160-200	23-26	40-50	13-17	13-15
	4.5	1.2	200-240	24-28	45-55	15-20	15-17
	6.0	1.2	270-300	28-31	60-70	18-22	18-22

Welding process of aluminum alloy pulse MIG

Welding position	Material thickness (MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Nozzle and workpiece spacing(MM)	Gas-flow rate (L/MIN)
 Butt-joint	1.5	1.0	60~80	16~18	60~80	12~15	15~20
	2.0	1.0	70~80	17~18	40~50	15	15~20
	3.0	1.2	80~100	17~20	40~50	14~17	15~20
	4.0	1.2	90~120	18~21	40~50	14~17	15~20
	6.0	1.2	150~180	20~23	40~50	17~22	18~22
	4.0	1.2	160~210	22~25	60~90	15~20	19~20
	4.0	1.6	170~200	20~21	60~90	15~20	19~20
	6.0	1.2	200~230	24~27	40~50	17~22	20~24
	6.0	1.6	200~240	21~23	40~50	17~22	20~24
	8.0	1.6	240~270	24~27	45~55	17~22	20~24
	12.0	1.6	270~330	27~35	55~60	17~22	20~24
	16.0	1.6	330~400	27~35	55~60	17~22	20~24
 Corner joint	1.5	1.0	60~80	16~18	60~80	13~16	15~20
	2.0	1.0	100~150	22~26	35~45	13~16	15~20
	3.0	1.2	100~120	19~21	40~60	13~17	15~20
	4.0	1.2	120~150	20~22	50~70	15~20	15~20
	6.0	1.2	150~180	20~23	50~70	18~22	18~22
	4.0	1.2	180~210	21~24	35~50	18~22	16~18
	4.0	1.6	180~210	18~20	35~45	18~22	18~22
	6.0	1.2	220~250	24~25	50~60	18~22	16~24
	6.0	1.6	220~240	20~24	37~50	18~22	16~24
	8.0	1.6	250~300	25~26	60~65	18~22	16~24
	12.0	1.6	300~400	26~28	65~75	18~22	16~24

§4.5 Operation Environment

- ▲ Operation temperature range: 14~104°F (-10 ~ 40°C)
- ▲ Air relative humidity is below 90% and Height above sea level ≤1000 M.
- ▲ Preferable site the machine some angles above the floor level does not exceed 15°.
- ▲ Protect the machine against high moisture, water and against direct sunshine.
- ▲ Take care that there is sufficient ventilation during welding. There must be at least 1-1/2" (38cm) free distance between the machine and wall.

§4.6 Operation Notices


- ▲ Read Section §1 carefully before starting to use this equipment.

§5 Torch Consumable Parts List

§5.1 MIG Torches #1, #2 & #3

§5.1.1 MIG Torch #1 / SL15 with RED Handle for Silicone Bronze Wire


NU-TEC NM15 & SL15 MIG GUN PARTS LIST



10	140N0008 140N0059 140N0177	CONTACT TIP .023" CONTACT TIP .030" CONTACT TIP .035"	121	160N0065 160N0587	POWER CABLE 10' POWER CABLE 12'
40	145N0075	NOZZLE 1/2" (STANDARD)	135	175N0022	TERMINAL TRIGGER
41	145N0123	NOZZLE 3/8"	136	175N0004	TERMINAL EURO
42	145N0041	NOZZLE 5/8"	160	400N2099	CABLE SUPPORT SPRING
43	145N0168	NOZZLE SPOT-WELD	161	180N0046	CABLE SUPPORT SWIVEL
54	185N0005	TRIGGER NM STYLE	162	501N0045	CABLE SUPPORT BODY
55	185N0006	TRIGGER SL STYLE	164	501N0014	EURO CABLE NUT
56	002N0058	NOZZLE SPRING #15	170	501N0003	CENTRAL ADAPTOR A/C
57	002N0078	GAS DIFFUSER/TIP HOLDER #15	176	501N0082	LINER POSITION NUT
58	002N0050	HEAD INSULATOR #15	180	124N0015	STEEL LINER .023"-.035"
59	002N0009	SWAN NECK #15	186	126N9001 126N9002	TEFLON LINER .023"-.035" TEFLON W/COPPER .023"-.035"
62	001N0009	BRASS NUT JAM			
64	002N0064	SWAN NECK BUSHING #15			
66	400N0044	TORCH BODY			
70	180N0103	HANDLE NM-STYLE BLUE			
71	180N0040	HANDLE SWIVEL BLUE			

§5.1.2 MIG Torch #2 / SL26 with BLUE Handle for Aluminum Wire


Nu-Tec NM26 MIG Gun Parts



10	140N0051 140N0169 140N0379 140N0516	CONTACT TIP .030" CONTACT TIP .035" CONTACT TIP .045" CONTACT TIP .052"	121	160N0251 160N0254	POWER CABLE 10' POWER CABLE 12'
20	142N0012	TIP HOLDER #26	135	175N0022	TERMINAL TRIGGER
30	018N0004	GAS DIFFUSOR #26	136	175N0004	TERMINAL EURO
40	145N0085	NOZZLE 5/8" (STANDARD)	160	400N2099	CABLE SUPPORT SPRING
41	145N0132	NOZZLE 9/16"	161	180N0047	CABLE SUPPORT SWIVEL SPRING
42	145N0139	NOZZLE 1/2"	162	501N0045	CABLE SUPPORT BODY
43	145N0051	NOZZLE 3/4"	164	501N0014	EURO CABLE NUT
50	018N0001	SWAN NECK #26	170	501N0003	CENTRAL ADAPTOR A/C
53	180N0048	HANDLE SWIVEL BLUE	176	501N0082	LINER POSITION NUT
54	180N0047	HANDLE SWIVEL SPRING	180	124N0015 124N9003	STEEL LINER .023"- .035" STEEL LINER .045"- .052"
55	185N0005	TRIGGER	186	126N9002 126N9005	TEFLON LINER .023"- .035" TEFLON LINER .045"- .052"
62	001N0009	BRASS JAM NUT			
66	400N0044	TORCH BODY			

§5.1.3 MIG Torch #3 / SL25 with GREEN Handle for Steel Wire

NU-TEC NM25 & SL25 MIG GUN PARTS




10	140N0005 140N0051 140N0169 140N0379	CONTACT TIP .023" CONTACT TIP .030" CONTACT TIP .035" CONTACT TIP .045"	121	160N0128 160N0141	POWER CABLE 10' POWER CABLE 12'
40	145N0076 145N0124 145N0042 145N0169	NOZZLE 1/2" (STANDARD) NOZZLE 3/8" NOZZLE 5/8" NOZZLE SPOT WELD	135	175N0022	TERMINAL TRIGGER
54	185N0005	TRIGGER NM-STYLE	136	175N0004	TERMINAL EURO
55	185N0006	TRIGGER SL-STYLE	160	400N2099	CABLE SUPPORT SPRING
56	142N0001	TIP HOLDER #25	161	180N0047	CABLE SUPPORT SWIVEL SPRING
57	003N0013	NOZZLE SPRING #25	162	501N0045	CABLE SUPPORT BODY
59	004N0012	SWAN NECK #25	164	501N0014	EURO CABLE NUT
62	001N0009	BRASS JAM NUT	170	501N0003	CENTRAL ADAPTOR A/C
66	400N0044	TORCH BODY	176	501N0082	LINER POSITION NUT
70	180N0103 180N0048	HANDLE NM-STYLE HANDLE SWIVEL BLUE	180	124N0015 124N9003	STEEL LINER .023"-.035" STEEL LINER .045"-.052"
			186	126N9001 126N9002 126N9004 126N9005	TEFLON LINER .023"-.035" TEFLON W/COPPER .023"-.035" TEFLON LINER .045"-.052" TEFLON W/COPPER .045"-.062"

§5.2 TIG Torch


TIG Torch SR17 with Thumb-Wheel Control & Trigger in Handle

Nu-Tec SR17 TIG Torch Parts



2	57Y02-2	BACK CAP - MEDIUM	11	45V29	GAS LENS .020"
3	57Y04	BACK CAP - SHORT		45V24	GAS LENS .040"
4	18CG	CUP GASKET		45V25	GAS LENS 1/16"
5	SR17	TORCH HEAD		45V26	GAS LENS 3/32"
6	10N21	COLLET .020"			
	10N22	COLLET .040"	12	54N18	AL NOZZLE #4
	10N23	COLLET 1/16"		54N17	AL NOZZLE #5
	10N24	COLLET 3/32"		54N16	AL NOZZLE #6
				54N15	AL NOZZLE #7
8	10N29	COLLET BODY .020"		54N14	AL NOZZLE #8
	10N30	COLLET BODY .040"	13	100P10	HANDLE TIG W/ 10K POT.
	10N31	COLLET BODY 1/16"	14	105Z55	HANDLE TIG SMOOTH
	10N32	COLLET BODY 3/32"			
9	10N50	ALUMINA CUP #4	15	57Y01R	POWER CABLE 1PC 12.5'
	10N49	ALUMINA CUP #5		57Y03R	POWER CABLE 1PC 25'
	10N48	ALUMINA CUP #6			
	10N47	ALUMINA CUP #7	16	57Y01-2	POWER CABLE 2PC 12.5'
	10N46	ALUMINA CUP #8		57Y03-2	POWER CABLE 2PC 25'
	10N45	ALUMINA CUP #10			
	10N45	ALUMINA CUP #12			

§5.3 Machine Parts List



250D DOUBLE PULSE SYNERGIC (DPS)					
Item	Part No.	Description	Item	Part No.	Description
1	521.2563	MIG Torch holder	37	521.2527	Wheel caster 5" - front (2)
2	521.2567	Torch cable supports	38	521.2576	Wheel caster mount plate
3	521.2566	Torch support mount plate	39	521.2571	Chassis
4	521.2522	Lifting lug M8 (4)	40	521.2509	Four roll wire feeder #3 RH
5	521.2516	Rubber tool pad	41	521.2577	Base plate for wire feeder
6	521.2550	Cabinet - Top cover	42	521.2572	Bulkhead (Bottom)
7	707.0164	Gas hose quick-connect	43	521.2579	Spool holder mount plate(3)
8	521.2574	Solenoid mounting plate	44	521.2580	Spool holder cover plate
9	521.2523	Solenoid gas valve (4)	45	521.2578	Cylinder plate mount
10	521.2512	PCB MIG pulse feeder drive	46	521.2555	Cylinder plate
11	521.2551	Cabinet - LH panel (upper)	47	521.2561	Rear axel
12	521.2529	PCB Pulse exchange board	48	521.2562	Rear wheel 10' (2)
13	521.2570	Bulkhead (Center)	49	000N0010	Cable grommet
14	521.2533	PCB Push/Pull torch exch.	50	521.2513	Wire spool holder
15	521.2583	Back cover LCD plate	51	521.2531	PCB Dbl-pulse control (LCD)
16	521.2517	Latch wire feeder door (6)	52	521.2541	Inductor
17	521.2518	Handle (2)	53	521.2514	Relay torch output (4)

MAINTENANCE & TROUBLESHOOTING

18	521.2507	Sealing plate 7" display	54	521.2542	Hall sensor
19	521.2508	PCB Display board 7" LCD	55	521.2553	Cabinet LH panel (bottom)
20	521.2532	PCB Digital torch exchange	56	521.2573	Bulkhead (Top)
21	521.2510	Four roll wire feeder #1 LH	57	521.2528	PCB MIG pulse power board
22	521.2552	Cabinet- Strip (Upper)	58	521.2581	Transformer mount plate
23	521.2511	Knob M250	59	521.2515	Transformer (Control)
24	521.2520	Power switch 2-position	60	521.2543	MUR block
25	521.0011	Torch socket 9-pin	61	521.2524	Cooling Fan 24VDC
26	511N0030	1/2" dinse 50-70 socket	62	521.2544	PFC inductor
27	521.2526	Gas panel fitting 5/8-18RHT	63	521.2582	Inductor mount plate
28	521.2564	Cabinet - Front panel 250D	64	521.2532	Main IGBT inverter block
29	521.2519	Hinge wire feeder door (6)	65	521.2545	Circuit breaker bracket
30	521.2556	cabinet strip (Bottom)	66	521.5246	Circuit breaker
31	521.2510	Four roll wire feeder #2 LH	67	521.2525	Cooling fan cover
32	521.2575	Flange euro connector (3)	68	521.2565	Cabinet - Back panel
33	501N0167	Euro socket MIG gun (3)	69	521.2559	Cylinder holder bracket (2)
34	501N0167-1	Euro socket mount bar (3)	70	001N0250	Cylinder chain (4)
35	129N0250	Wire guide tube (3)	71	707.0173	Strain relief - Large
36	501N0086	Hose barb 6mm	72	521.2560	Cabinet RH side panel
250D DOUBLE PULSE SYNERGIC COMPONENTS					
31a	521.2537	Drive Roll V .040" - .045 (2)	31b	ER70S6-030	Steel wire .030" (.8mm) 11#
21a	521.2538	Drive Roll U .030" - .035 (2)	21b	ERCuSi-030	CuSi wire .030" (.8mm) 11#
40a	521.2539	Drive Roll U .040" - .045 (2)	40b	ER5356-047	ER5356 .047" (1.2mm) 3#
250D DOUBLE PULSE SYNERGIC ACCESSORIES					
	521.2535	Drive Roll V .023" - .035 (2)		140N0059	Contact tip .030" #15 MIG
	521.2536	Drive Roll V .030" - .040 (2)		140N0051	Contact tip .030" #25 MIG
	SL15-10SB	Red #15 MIG 10' (ERCuSi)		141N0010	Contact tip .047" A #26 MIG
	SL25-10G	Green #25 MIG 10' (Steel)		145N0075	Gas nozzle 1/2" #15 MIG
	SL26-10A	Blue #26 MIG 10' (Alum.)		145N0076	Gas nozzle 1/2" #25 MIG
	SR17-12-P9K	SR17 TIG Torch 12.5' w/pot		145N0085	Gas nozzle 5/8" #26 MIG
	721.0004	Gas regulator 2-gauge (2)		142N0001	Tip holder #25 MIG gun
	520.0009	Gas hose 5/8-18RHT (2)		142N0007	Tip holder #26 MIG gun
	AK-2	TIG torch kit WP17		018N0004	Gas insulator #26 MIG gun

Tech Service: 704-935-5242

§6 Maintenance & Troubleshooting

§6.1 Maintenance

The operator must understand the maintenance procedure of inverter welding machine and perform simple examinations, cleanings and inspections. It is best to protect the machine from contamination environment and not leave unit ON when not in use to lengthen service life of electronic inverter power supply. Inverter machines have IGBT transistors that are cooled by aluminum heat sinks. When the power supply is ON, the cooling fans may bring dirt & dust into the machine covering the heat sinks and reducing cooling capacity over time. All inverter machines will experience longer life if heat sinks are blow clean with dry shop air monthly.

- **Warning: For safety while maintaining the machine, please shut off the main input power and wait for 5 minutes, until capacitors voltage drops to safe voltage 36V!**

Date	Maintenance items
Daily examination	Observe that the knobs and switches in the front and at the back of arc welding machine are flexible and put correctly in place. If any knob has not been put correctly in place, please correct. If you can't correct or fix the knob, please replace immediately. If any switch is not flexible or it can't be put correctly in place, please replace immediately! Please get in touch with maintenance service department if there are no accessories. After turn-on power, watch/listen if the arc-welding machine has shaking, whistle calling or peculiar smell. If there is one of the above problems, find out the reason and clear it. If you can't find out the reason, please contact your local service repair station or distributor/Agent. Observe that the display value of LED is intact. If the display number is not intact, please replace the damaged LED. If it still doesn't work, please maintain or replace the display PCB. Observe that the min./max.Values on LED agree with the set value. If there is any difference and it has affected the normal welding results, please adjust it. Check whether the fan is damaged and whether it is normal to rotate or control. If the fan is damaged, please change immediately. If the fan does not rotate but it starts when blades are rotated in direction of fan, the start capacity should be replaced. Observe whether the fast connector is loose or overheated. If the arc-welding machine has the above problems, it should be fastened or changed. Observe whether the current output cable is damaged. If it is damaged, it should

	be insulated or changed.
Monthly examination	Use “dry” compressed air to clean the inside of arc welding machine. Especially for clearing dust on aluminium heat-sinks, inductors, IGBT modules, fast recover diodes, PCB’s, etc. Check the screws and bolts in the machine. If any are loose, please tighten. Check all torches, earth clamp and hose connections to insure they are securely in place. Loose connections can cause major failures.
Quarter-yearly examination	Check whether the actual current accords with the displaying value. If they did not accord, they should be regulated. The actual welding current value can be measured by and adjusted by plier-type ampere meter.
Yearly examination	Measure the insulating impedance among the main circuit, PCB and case, if it below 1MΩ, insulation is thought to be damaged and needs to be changed to strengthen insulation.

NOTE: General maintenance will increase the performance and life of the welding machine.

§6.2 Troubleshooting

- Before the welding machines are dispatched from the factory, they have already been tested and calibrated accurately. **Do not change settings on the equipment!**
- Maintenance procedures must be followed carefully. If any wire becomes frayed, cut or is misplaced, it maybe potential danger to user! Never wrap cables around body or extremities.
- Only professional maintenance staff that is authorized by manufacturer should service the machine!
- If there is any problem and there is no authorized professional maintenance personal on site, please contact local agent or the distributor!
- **Be sure to switch OFF the main power and disconnect the power cord from outlet!**
- **Before doing any repair work on the welding machine, wait 5 minutes after disconnecting from power for capacitor voltage to decrease!**

MIG Welder - Trouble Shooting

The following chart addresses some of the common POWER SUPPLY problems that may occur while operating this machine. In all cases of equipment malfunction, the manufacturer’s recommendations should be strictly adhered to and followed.

MIG Welder - Trouble Shooting

NO.	Troubles		Reasons	Solution
1	Turn ON power but the power light is not illuminated.		Switch damaged	Change it
			Fuse damaged	Change it
			Power cord damaged	Change it
2	After welding machine is over-heat, the fan doesn't work		Fan damaged	Change it
			The cable is loose	Screw the cable tight
3	Press the gun switch, no output shielded gas	No output gas when test gas	No gas in the gas cylinder	Change it
			Gas hose leaks gas	Change it
			Electromagnetic valve damaged	Change it
		Output gas when test gas	Control switch damaged	Repair the switch
			Control circuit damaged	Check the PCB
4	Wire-feeder doesn't work	Wire reel doesn't work	Motor damaged	Check and change it
			Control circuit damaged	Check the PCB
		Wire reel works	The idler roll is loose or weld wire skids	Adjust tension screws
			The drive roll doesn't fit with the diameter of weld wire	Change the roll
			Wire reel damaged	Change it
			Wire feed pipe is jammed	Repair or change it
			Tip is jammed because of splash	Repair or change it
5	No striking arc and no output voltage		Output cable is connected incorrectly or loosen	Screw it down or change it
			Control circuit damaged	Check the circuit
6	Welding stops, and alarm light is on		Machine has self-protection	Check over-voltage, over-current, over-temperature, lower-voltage and over-temperature, and solve it
7	Welding current is run away and can be not controlled		The potentiometer damaged	Check or change it
			The control circuit damaged	Check the circuit
8	The crater current can be not adjusted		The PCB damaged	Check it
9	No post-gas		The PCB damaged	Check it

§6.2.1 MIG Welding - Trouble Shooting

The following chart addresses some of the common problems of MIG welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly adhered to and followed.

NO.	Trouble	Possible Reason	Suggested Remedy
1	Excessive Spatter	Wire feed speed set too high	Select lower wire feed speed
		Voltage too high	Select a lower voltage setting
		Wrong polarity set	select the correct polarity for the wire being used - see machine setup guide
		Stick out too long	Bring the torch closer to the work
		Contaminated base metal	Remove materials like paint, grease, oil and dirt, including mill scale from base metal
		Contaminated MIG wire	Use clean, dry, rust free wire. Do not lubricate the wire with oil, grease etc.
		Inadequate gas flow or too much gas flow	Check the gas is connected, check hoses, gas valve and torch are not restricted. Set gas flow between 20~40 CFH (6~12 l/min) flow rate. Check hoses and fittings for leaks. Protect the welding zone from wind and drafts
2	Porosity - small cavities or holes resulting from gas pockets in weld metal.	Wrong gas	Check that the correct gas is being used
		Inadequate gas flow or too much gas flow	Check the gas is connected, check hoses, gas valve and torch are not restricted. Set gas flow between 20~40 CFh (6~12 l/min) flow rate. Check hoses and fittings for leaks. Protect the welding zone from wind and drafts
		Moisture on the base metal	Remove all moisture from base metal before welding
		Contaminated base metal	Remove materials like paint, grease, oil and dirt, including mill scale from base metal
		Contaminated MIG wire	Use clean, dry, rust free wire. Do not lubricate the wire.
		Gas nozzle clogged with spatter, worn or out of shape	Clean or replace the gas nozzle
		Missing or damaged gas diffuser	Replace the gas diffuser
		MIG torch euro connect O-ring missing or damaged	Check and replace the O-ring
3	Wire stubbing during welding	Holding the torch too far away	Bring the torch closer to the work and maintain stick out of 5~10mm

MAINTENANCE & TROUBLESHOOTING

		Welding voltage set too low	Increase the voltage
		Wire Speed set too high	Decrease the wire feed speed
4	Lack of Fusion – failure of weld metal to fuse completely.	Contaminated base metal	Remove materials like paint, grease, oil, dirt, including mill scale from base metal
		Not enough heat input	Select a higher voltage range and/or adjust the wire speed to suit
		Improper welding technique	Keep the arc at the leading edge of the weld pool. Gun angle to work should be between 5 & 15°. Direct the arc at the weld joint. Adjust work angle or widen groove to access bottom during welding. Momentarily hold arc on side walls if using weaving technique.
5	Excessive Penetration – weld metal melting through base metal	Too much heat	Select a lower voltage range and/or adjust the wire speed to suit Increase travel speed
6	Lack of Penetration – shallow fusion between weld metal and base metal	Poor in incorrect joint preparation	Material too thick. Joint preparation and design needs to allow access to bottom of groove while maintaining proper welding wire extension and arc characteristics. Keep the arc at the leading edge of the weld pool and maintain the gun angle at 5 & 15° keeping the stick out between 5~10mm
		Not enough heat input	Select a higher voltage range and/or adjust the wire speed to suit reduce travel speed.
		Contaminated base metal	Remove materials like paint, grease, oil and dirt, including mill scale from base metal

§6.2.2 MIG Wire Feed - Trouble Shooting

The following chart addresses some of the common WIRE FEED problems during MIG welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly adhered to and followed.

NO.	Trouble	Possible Reason	Suggested Remedy
1	No wire feed	Wrong mode selected	Check that the TIG/MMA/MIG selector switch set to MIG position
		Wrong torch selector switch	Check that the Wire Feeder/ Spool Gun selector switch is set to Wire Feeder position for MIG welding and Spool Gun when using the Spool gun
2	Inconsistent/ interrupted wire feed	Adjusting wrong dial	Be sure to adjust the wire feed and voltage dials for MIG welding. The amperage dial is for MMA and TIG welding mode
		Wrong polarity selected	Select the correct polarity for the wire being used. (see machine setup guide)
		Incorrect wire speed setting	Adjust the wire feed speed
		Voltage setting incorrect	Adjust the voltage setting
		MIG torch lead too long	Small diameter wires and soft wires like aluminum don't feed well through long torch leads - replace the torch with a lesser length torch
		MIG torch lead kinked or too sharp angle being held	Remove the kink, reduce the angle or bend
		Contact tip worn, wrong size, wrong type	Replace the tip with correct size and type
		Liner worn or clogged (the most common causes of bad feeding)	Try to clear the liner by blowing out with compressed air as a temporary cure, it is recommended to replace the liner
		Wrong size liner	Install the correct size liner
		Blocked or worn inlet guide tube	Clear or replace the inlet guide tube
		Wire misaligned in drive roller groove	Locate the wire into the groove of the drive roller
		Incorrect drive roller size	Fit the correct size drive roller eg; 0.8mm wire requires 0.8mm roller.
		Wrong type of drive roller selected	Fit the correct type roller (e.g. knurled rollers needed for flux cored wires)
		Worn drive rollers	Replace the drive rollers
		Drive roller pressure too high	Can flatten the wire electrode causing it to lodge in the contact tip - reduce the drive roller pressure
		Too much tension on wire spool hub	Reduce the spool hub brake tension
		Wire crossed over on the spool or tangled	Remove the spool untangle the wire or replace the wire
		Contaminated MIG wire	Use clean, dry, rust free wire. Do not lubricate the wire.

§6.2.3 DC TIG Welding - Trouble Shooting

The following chart addresses some of the common problems of DC TIG welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly adhered to and followed.

NO.	Trouble	Possible Reason	Suggested Remedy
1	Tungsten burning away quickly	Incorrect Gas or No Gas	Use pure Argon. Check cylinder has gas, connected, turned on and torch valve is open
		Inadequate gas flow	Check the gas is connected, check hoses, gas valve and torch are not restricted.
		Back cap not fitted correctly	Make sure the torch back cap is fitted so that the O-ring is inside the torch body
		Torch connected to DC+	Connect the torch to the DC- output terminal
		Incorrect tungsten being used	Check and change the tungsten type if necessary
		Tungsten being oxidized after weld is finished	Keep shielding gas flowing 10~15 seconds after arc stoppage. 1 second for each 10amps of welding current.
2	Contaminated tungsten	Touching tungsten into the weld pool	Keep tungsten from contacting weld puddle. Raise the torch so that the tungsten is off the work piece 2~5mm
		Touching the filler wire to the tungsten	Keep the filler wire from touching the tungsten during welding, feed the filler wire into the leading edge of the weld pool in front of the tungsten
3	Porosity - poor weld appearance and color	Wrong gas/ poor gas flow/ gas leak	Gas is connected, valve ON, check hoses, gas valve and torch are not restricted. Set the gas flow between 20~40 CFH (6~12 l/min). Check hoses and fittings for leaks.
		Contaminated base metal	Remove moisture and materials like paint, grease, oil and dirt from base metal
		Contaminated filler wire	Remove all grease, oil or moisture from filler metal
		Incorrect filler wire	Check the filler wire and change if necessary
4	Yellowish residue/ smoke on the	Incorrect Gas	Use pure Argon gas
		Inadequate gas flow	Set the gas flow between 20~40 CFH

	alumina nozzle & discolored tungsten		(10~20 l/min) flow rate
		Alumina gas nozzle too small	Increase the size of the alumina gas nozzle
5	Unstable Arc during DC welding	Torch connected to DC+	Connect the torch to the DC- output terminal
		Contaminated base metal	Remove materials like paint, grease, oil, and dirt, including mill scale from base metal.
		Tungsten is contaminated	Remove 10mm of contaminated tungsten and re grind the tungsten
		Arc length too long	Lower torch so that the tungsten is off of the work piece 2~5mm
6	Arc wanders during DC welding	Poor gas flow	Check and set the gas flow between 20~40 CFH flow rate
		Incorrect arc length	Lower torch so that the tungsten is off the work piece 2~5mm
		Tungsten incorrect or in poor condition	Check that correct type of tungsten is being used. Remove 10mm from the weld end of the tungsten and sharpen rod.
		Poorly prepared tungsten	Grind marks should run lengthwise with tungsten, not circular. Use proper grinding method and wheel.
		Contaminated base metal or filler wire	Remove contaminating materials like paint, grease, oil and dirt, including mill scale from base metal. Remove all grease and oil from filler metal
7	Arc difficult to start or will not start DC welding	Incorrect machine set up	Check machine set up is correct
		No gas, incorrect gas flow	Check the gas is connected and cylinder valve open, check hoses, gas valve and torch are not restricted. Set the gas flow between 20~40 CFH flow rate
		Incorrect tungsten size or type	Check and change the size and or the tungsten if required
		Loose connection	Check all connectors and tighten
		Earth clamp not connected to work	Connect the earth clamp directly to the work piece wherever possible

§6.2.4 MMA Welding - Trouble Shooting

The following chart addresses some of the common problems of MMA welding. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly followed.

MAINTENANCE & TROUBLESHOOTING

NO.	Trouble	Possible Reason	Suggested Remedy
1	No arc	Incomplete welding circuit	Check earth lead is connected. Check all cable connections
		Wrong mode selected	Check the MMA selector switch is selected
		No power supply	Check that the machine is switched ON and has a power
2	Porosity – small cavities or holes resulting from gas pockets in weld metal	Arc length too long	Shorten the arc length
		Work piece dirty, contaminated or moisture	Remove moisture and materials like paint, grease, oil and dirt, including mill scale from metal
		Damp electrodes	Use only dry electrodes
3	Excessive Spatter	Amperage too high	Decrease the amperage or choose a larger electrode
		Arc length too long	Shorten the arc length
4	Weld sits on top, lack of fusion	Insufficient heat input	Increase the amperage or choose a larger electrode
		Work piece dirty, contaminated or moisture	Remove moisture and materials like paint, grease, oil and dirt, including mill scale from metal
		Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
5	Lack of penetration	Insufficient heat input	Increase the amperage or choose a larger electrode
		Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
		Poor joint preparation	Check the joint design and fit up, make sure the material is not too thick for wire size.
6	Excessive penetration - burn through	Excessive heat input	Reduce the amperage or use a smaller electrode
		Incorrect travel speed	Try increasing the weld travel speed
7	Uneven weld appearance	Unsteady hand, wavering hand	Use two hands where possible to steady up, practice your technique
8	Distortion – movement of base metal	Excessive heat input	Reduce the amperage or use a smaller electrode
		Poor welding technique	Use the correct welding technique or seek assistance for the correct technique
9	Electrode “melts”	Incorrect polarity	Change the polarity, check the electrode manufacturer specification

§6.3 List of Error Codes

Error Type	Error code	Description	Lamp status
Thermal relay	E01	Over-heating (1st thermal relay)	Yellow lamp (thermal protection) always on
	E02	Over-heating (2nd thermal relay)	Yellow lamp (thermal protection) always on
	E03	Over-heating (3rd thermal relay)	Yellow lamp (thermal protection) always on
	E04	Over-heating (4th thermal relay)	Yellow lamp (thermal protection) always on
	E09	Over-heating (Program default)	Yellow lamp (thermal protection) always on
Welding machine	E10	Phase loss	Yellow lamp (thermal protection) always on
	E11	N/A	Yellow lamp (lack water) always on
	E12	No gas	Red lamp always on
	E13	Under voltage	Yellow lamp (thermal protection) always on
	E14	Over voltage	Yellow lamp (thermal protection) always on
	E15	Over current	Yellow lamp (thermal protection) always on
	E16	Wire feeder over load	
Switch	E20	Button fault on operating panel when switch on the machine	Yellow lamp (thermal protection) always on
	E21	Other faults on operating panel when switch on the machine	Yellow lamp (thermal protection) always on
	E22	Torch fault when switch on the machine	Yellow lamp (thermal protection) always on
	E23	Torch fault during normal working process	Yellow lamp (thermal protection) always on
Accessory	E30	Cutting torch disconnection	Red lamp blink
	E31	N/A	Yellow lamp (lack water) always on
Communication	E40	Connection problem between wire feeder and power source	
	E41	Communication error	

§6.4 Electrical Schematic Drawing

