



777 Aviation Dr  
Camarillo, Ca 93010  
USA

March 5<sup>th</sup>, 2026  
Revision E

# Maintenance Support Document

## ETM1000 -T53 /T55- ICA

### Instructions for Continued Airworthiness;

Installation of an AKV, Inc Exceedence and Trend Monitoring System P/N ETM1000 in the Bell UH-1, 204, 205, 210, Eagle Single Bell 212S with T53 Engine and Bell 214 with the T55 engine

STC Number: SR02413LA

S/N \_\_\_\_\_




**PROPRIETARY. ALL RIGHTS RESERVED.** NO PORTION OF THIS DOCUMENT MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING BY PHOTOCOPYING, RECORDING OR USE OF ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM WITHOUT EXPRESS WRITTEN PERMISSION OF AKV, Inc.

©2012 AKV, Inc




**REVISIONS INTRODUCTION**

The latest revision of this document is indicated by the highest revision letter as listed below in the Revision History and List of Effective Pages. Changes to the current revision will be indicated within the document by change bars. (Reference Section 1.) The entire document will be reprinted to reflect the current revision level.

**REVISION HISTORY**

Instructions for Continued Airworthiness; AKV Inc Exceedence and Trend Monitoring System ETM1000			ETM1000-T53/T55-ICA
Rev.	Date	Revision Description	Approval
NC	March 11 <sup>th</sup> , 2015	Initial Release	PREPARED J. Gunn
			CHECKED J. Gunn
			APPROVED 
A	January 29 <sup>th</sup> , 2016	Added applicable data for the addition of the Bell 214	PREPARED J. Gunn
			CHECKED J. Gunn
			APPROVED 
B	July 24 <sup>th</sup> , 2017	Added applicable drawings for the addition of the Bell Eagle Single 212S T53 conversion	PREPARED J. Gunn
		Added airspeed switch pitot/static test connection note to Pg 22	CHECKED J. Gunn
			APPROVED 

Continued

Instructions for Continued Airworthiness; AKV Inc Exceedence and Trend Monitoring System ETM1000			ETM1000-T53/T55-ICA
Rev.	Date	Revision Description	Approval
C	September 22 <sup>nd</sup> , 2018	<ul style="list-style-type: none"> <li>- Added cycle counting option with remote display or 3<sup>rd</sup> party Flightcell DZMx.</li> <li>- Updated App. A data. Changed to refer to the User Manual</li> <li>- Adjusted Appendix list due to App. A change</li> <li>- Updated App. D Drawings to include change for remote display and Flightcell DZMx interface</li> <li>- Various changes throughout</li> <li>- Changed this ICA to reflect B214 applicability with the T55</li> </ul>	PREPARED J. Gunn
			CHECKED J. Gunn
			APPROVED 
D	November 5 <sup>th</sup> , 2026	- Added new AA battery holder in place of coin cell and updated Appendix D drawings	PREPARED J. Gunn
			CHECKED J. Gunn
			APPROVED 
E	March 5 <sup>th</sup> , 2026	- Updated Appendix D drawings to MDL Rev R	PREPARED J. Gunn
			CHECKED J. Gunn
			APPROVED 

## LIST OF EFFECTIVE PAGES

All pages are revised when any page is changed so that all pages maintain the same revision level.

<b>PAGE</b>	<b>REVISION</b>	<b>DATE</b>
All	NC	March 11 <sup>th</sup> , 2015
ALL	A	January 29 <sup>th</sup> , 2016
3, 22 & 27- 58	B	July 24 <sup>th</sup> , 2017
ALL	C	September 22 <sup>nd</sup> , 2018
10 and Appendix D	D	November 5 <sup>th</sup> , 2020
Appendix D	E	March 5 <sup>th</sup> , 2026

## TABLE OF CONTENTS

<b>1. INTRODUCTION .....</b>	<b>1</b>
1.1 Service Difficulties.....	1
1.2 Warnings, Cautions, and Notes.....	1
1.3 Language .....	1
1.4 References.....	1
1.5 Revision to ICA .....	1
1.6 Abbreviations and Definitions .....	2
<b>2. AIRWORTHINESS LIMITATIONS .....</b>	<b>2</b>
<b>3. DESCRIPTION .....</b>	<b>2</b>
3.1 ETM1000 Configurations .....	2
3.2 ETM1000 Basic Operation.....	4
<b>4. MAINTENANCE INSTRUCTIONS .....</b>	<b>5</b>
4.1 Routine Cleaning & Maintenance .....	5
4.2 Tools .....	5
4.3 Overhaul .....	5
4.4 Component Retirement/Retirement Life .....	5
<b>5. REQUIRED INSPECTIONS .....</b>	<b>8</b>
5.1 Daily Coherence ccheck for cycle counter option.....	8
5.2 Annual Inspection .....	8
5.3 Special Inspection.....	9
<b>6. REMOVING AND REPLACING PARTS .....</b>	<b>14</b>
6.1 To Remove the ETM1000.....	14
6.2 To Replace the Airspeed Switch.....	14
6.3 To Replace the Pushbutton Switches.....	14
6.4 To Replace the Cycle Counter Remote Display .....	14
<b>7. TROUBLESHOOTING .....</b>	<b>15</b>
<b>8. WEIGHT AND BALANCE CHANGES .....</b>	<b>17</b>

<b>APPENDIX A</b> (Configuring the ETM1000) .....	<b>18</b>
<b>APPENDIX B</b> (Airspeed Switch Installation Instructions) .....	<b>18</b>
<b>APPENDIX C</b> (Pushbutton Indicator Removal/Installation Instructions) .....	<b>20</b>
<b>APPENDIX D</b> (Wiring Diagram) .....	<b>23</b>

## 1. INTRODUCTION

This AKV, Inc maintenance support document provides instructions for the continued airworthiness of the AKV Exceedence and Trend Monitoring System ETM1000. The basis for this document is 14 CFR 29.1529 and Appendix A to Part 29.

### 1.1 Service Difficulties

Technical Assistance can be provided by:

AKV, Inc.  
777 Aviation Dr.  
Camarillo, CA 93010  
Tel 805-437-1739  
Fax 805 437-1783  
Email: [sales@akvinc.com](mailto:sales@akvinc.com)  
Web: [www.akvinc.com](http://www.akvinc.com)

### 1.2 Warnings, Cautions, and Notes

#### WARNING

**FAILURE TO FOLLOW INSTRUCTIONS GIVEN IN A WARNING MAY  
RESULT IN PERSONAL INJURY OR DEATH.**

#### CAUTION

*FAILURE TO FOLLOW INSTRUCTIONS GIVEN IN A CAUTION MAY  
RESULT IN DAMAGE TO THE HELICOPTER*

#### Note

A note includes supplemental data about the procedure, practice, condition, etc., for the maintenance task you are about to perform.

### 1.3 Language

This manual is written to the Simplified English (SE) specification. This International Aerospace Maintenance Language Specification is important to maintenance personnel whose first language is not English.

### 1.4 References

The use of parentheses throughout this document is for denoting or depicting a reference to other sections, items, details, etc., the intent of which is to further identify or clarify existing information.

### 1.5 Revision to ICA

Revisions to this document and the documents listed within it are distributed to the operators who have this modification installed on the subject aircraft, either in electronic or paper format. **Contact AKV for available revision changes.**

## 1.6 Abbreviations and Definitions

A&P	Airframe & Powerplant Mechanic
CFR	Code of Federal Regulations
RFM	Rotorcraft Flight Manual
RFMS	Rotorcraft Flight Manual Supplement
FAR	Federal Aviation Regulations

## 2. AIRWORTHINESS LIMITATIONS

This section is FAA approved and specifies the inspections, and other maintenance, which are required under 14 CFR 43.16 and 91.403, unless an alternative program has been FAA approved. There are “No airworthiness limitations associated with this type design change”.

## 3. DESCRIPTION

### 3.1 ETM1000 Configurations


The ETM1000 is available in two configurations, a -1 or -2 configuration. In either configuration the ETM1000 enclosure is mounted on the pilot side below the instrument panel. It is electrically spliced to the existing signal generators for Tq, MGT, N1, N2 and Nr behind the instrument panel and at the rear of each indicator. The system receives airspeed indication in the form of a calibrated 80kt airspeed switch connected via a “tee” fitting in the pitot line and mounted in the forward section of the instrument panel area. It provides a signal to the ETM1000 that the A/C is operating 80Kt or greater and is utilized for Tq exceedence criteria. An OAT probe is mounted on the belly and the ETM1000 LRU has a pressure altitude (PA) sensor built-in. The OAT and PA sensor are used for the Delta Ng and power check recording.

**As a -1 configuration**, two (2) instrument panel mounted pushbutton / indicators (annunciators) and audio side-tone are provided for overall status and alert indication to the pilot. A flip guard is installed on the P-PWR/CHK (left side switch) to prevent inadvertent operation. The “P” in the P-PWR/CHK and P-MUTE white nomenclature indicates the pushbutton feature.

**NOTE:** Cycle counting is available as an option on the -1 configuration via the AKV remote display or displayed on the 3rd party Flightcell DZMx. **The LRU must be Rev P** or greater to allow for using the cycle AKV remote display and **software v72.0 or greater** must be installed for the cycle counting option.

**As a -2 configuration**, there are no pushbutton / indicators or audio side-tone supplied. **NOTE:** The cycle counting / remote display or Flightcell DZMx interface options are not available with the -2 configuration.

The system date and time is backed up with an externally mounted battery for easy access which is **replaced annually**. A Single power source via a 2 amp circuit breaker supplies power to the ETM1000.



**Figure 1 - Installed view of the ETM1000 LRU**

ETM1000  
ENCLOSURE LRU  
& MOUNTING  
TRAY

-1 CONFIGURATION  
ONLY. TYPICAL  
PUSHBUTTON /  
INDICATOR  
LOCATION



**Figure 2 - Installed view of the ETM1000 pushbutton / annunciator**

(OPTIONAL) CYCLE  
COUNTING  
REMOTE DISPLAY  
LOCATION



**Figure 3 - Installed view of the (optional) cycle counting remote display**



**Figure 4** –(Optional) Flightcell DZMx with cycle counting display

### 3.2 ETM1000 Operation

The ETM1000 is designed to continuously monitor and record all engine and drive train parameters at 1Hz (1/sec). For values in excess of the airframe and engine operating limitations during an exceedance, it is recorded at 5hz (5/sec). The 1Hz data referred to as a Run Log (RL) is used during post flight for graphing normal flight operations. Exceedence data is also graphed.

**As a -1 configuration** system health and exceedence status indication via white caution and blue warning indicators is provided to the pilot via two (2) pushbutton / annunciators mounted on the instrument panel. An audible side tone for the pilot's headset is also provided for caution and warning indication. Audible muting and a power check recording feature is provided as part of the pushbuttons. In the -1 configuration only, the optional cycle count is available.

**NOTE:** When using the optional cycle counting feature with either the AKV remote display or Flightcell DZMx then refer to the **ETM1000 Bell MediumT53 or Bell 214 T55 Cycle Counting Operating Specification** document.

**As a -2 configuration** there is no pilot interface and the ETM1000 system is essentially a black box recorder.

All data is written to a removable 2GB SD Card. Exceedances are backed up in the ETM1000 flash memory in case the SD card is missing.

**NOTE:** For additional information, refer to the **ETM1000 User Manual**.

## **4. MAINTENANCE INSTRUCTIONS**

### **4.1 Routine Cleaning & Maintenance**

Routine Cleaning & Maintenance of the ETM1000 Routine maintenance may be required as the result of an inspection. Re-tighten loose fasteners to the standard torque values shown in Table 1 and Table 2. Perform routine cleaning to remove contaminants from the ETM1000. Remove grease, fungus, and ground-in dirt from equipment and mounting brackets using a clean, soft cloth dampened with mild soap and warm water; avoid damaging the coating.

### **4.2 Tools**

The following tools will be necessary to maintain the AKV ETM1000 Installation:

- A Laptop PC utilizing Windows XP or later operating system
- RS-232 cable as supplied with the ETM1000 kit
- USB adaptor as supplied with the ETM1000 kit
- Pitot test set (user supplied)

### **4.3 Overhaul**

There are no component overhaul requirements for this type design change. Under normal operating conditions, the ETM1000 will not require component overhaul. All parts and assemblies are designed to be replaced "On Condition". Any maintenance needed to the ETM1000 or its installation beyond that described in this document requires that the components be removed and returned to AKV, Inc. The decision to return damaged components may be a subjective one and should be made by a qualified A & P Mechanic.

### **4.4 Component Retirement/Retirement Life**

The ETM1000 has been designed with components that have a virtually unlimited life span. However, it is anticipated that some components may require replacement at some time during the service life of the helicopter. The decision to replace these parts is a subjective one and should be made by the operator or an A & P Mechanic.

Bolts -- Steel Tension		Bolts -- Steel Tension		Bolts -- Aluminum								
AN 3 – AN 20		MS 20004 – MS 20024		AN 3DD – AN 20DD								
AN 42 – AN 49		NAS 144 – NAS 158		AN 173DD – AN 186DD								
AN 73 – AN 81		NAS 583 – NAS 590		AN 509DD								
AN 173 – AN 186		NAS 144 – NAS 158		AN 525D								
MS 20033 – MS 20046		NAS 144624 – NAS 644		MS 27039D								
MS 20073		NAS 1303 – NAS 1320		MS 24694DD								
MS 20074		NAS 172		-----								
AN 509 NK9		NAS 174		-----								
MS 24694		NAS 517		-----								
AN 525 NK525		-----		-----								
MS 27030		-----		-----								
		<b>Steel Shear Bolt</b>										
		NAS 464										
Nuts		Nuts		Nuts								
Steel Tension	Steel Shear	Steel Tension	Steel Shear	Aluminum Tension	Aluminum Shear							
AN 310	AN 320	AN 310	AN 320	AN 365D	AN320D							
AN 315	AN 364	AN 315	AN 364	AN 310D	AN 364D							
AN 363	NAS 1022	AN 363	NAS 1022	NAS 1021D	NAS 1022D							
AN 365	MS 17826	AN 365	MS 17826	-----	-----							
NAS 1021	MA 20364	MS 17825	MS 20364	-----	-----							
MS 17825	-----	MS 20365	-----	-----	-----							
MS 21045	-----	MS 21045	-----	-----	-----							
MS 20365	-----	NAS 1021	-----	-----	-----							
MS 20500	-----	NAS 679	-----	-----	-----							
NAS 679	-----	NAS 1291	-----	-----	-----							
FINE THREAD SERIES <sup>1</sup>												
Nut-Bolt Size	Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.	
	Min.	Max	Min.	Max	Min.	Max	Min.	Max	Min.	Max	Min.	Max
8 - 36	12	15	7	9	-----	-----	-----	-----	5	10	3	6
10 - 32	20	25	12	15	25	30	15	20	10	15	5	10
1/4 - 28	50	70	30	40	80	100	50	60	30	45	15	30
5/16 - 24	100	140	60	85	120	145	70	90	40	65	25	40
3/8 - 24	160	190	95	110	200	250	120	150	75	110	45	70
7/16 - 20	450	550	270	300	520	630	300	400	180	280	110	170
1/2 - 20	480	690	290	410	770	950	450	550	280	410	160	260
9/16 - 18	800	1000	480	600	1100	1300	650	800	380	580	230	360
5/8 - 18	1100	1300	660	780	1250	1550	750	950	550	670	270	420
3/4 - 16	2300	2500	1300	1500	2650	3200	1600	1900	950	1250	5560	880
7/8 - 14	2500	3000	1500	1800	3550	4350	2100	2600	1250	1900	750	1200
1 - 14	3700	4500	2200	3300	4500	5500	2700	3300	1600	2400	950	1500
1 1/8 - 12	5000	7000	3000	4200	6000	7300	3600	4400	2100	3200	1250	2000
1 1/4 - 12	9000	11000	5400	6600	11000	13400	6600	8000	3900	5600	2300	3650

**Table 1: Recommended torque values for nut-bolt combinations: Fine Thread Series**

<sup>1</sup> Torque values without lubrication

Bolts -- Steel Tension		Bolts -- Steel Tension		Bolts -- Aluminum								
AN 3 – AN 20		MS 20004 – MS 20024		AN 3DD – AN 20DD								
AN 42 – AN 49		NAS 144 – NAS 158		AN 173DD – AN 186DD								
AN 73 – AN 81		NAS 583 – NAS 590		AN 509DD								
AN 173 – AN 186		NAS 144 – NAS 158		AN 525D								
MS 20033 – MS 20046		NAS 144624 – NAS 644		MS 27039D								
MS 20073		NAS 1303 – NAS 1320		MS 24694DD								
MS 20074		NAS 172		-----								
AN 509 NK9		NAS 174		-----								
MS 24694		NAS 517		-----								
AN 525 NK525		-----		-----								
MS 27030		-----		-----								
		<b>Steel Shear Bolt</b>										
		NAS 464										
Nuts		Nuts		Nuts								
Steel Tension	Steel Shear	Steel Tension	Steel Shear	Aluminum Tension	Aluminum Shear							
AN 310	AN 320	AN 310	AN 320	AN 365D	AN320D							
AN 315	AN 364	AN 315	AN 364	AN 310D	AN 364D							
AN 363	NAS 1022	AN 363	NAS 1022	NAS 1021D	NAS 1022D							
AN 365	MS 17826	AN 365	MS 17826	-----	-----							
NAS 1021	MA 20364	MS 17825	MS 20364	-----	-----							
MS 17825	-----	MS 20365	-----	-----	-----							
MS 21045	-----	MS 21045	-----	-----	-----							
MS 20365	-----	NAS 1021	-----	-----	-----							
MS 20500	-----	NAS 679	-----	-----	-----							
NAS 679	-----	NAS 1291	-----	-----	-----							
COARSE THREAD SERIES <sup>2</sup>												
Nut-Bolt Size	Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.		Torque Limits In-lbs.	
	Min.	Max	Min.	Max	Min.	Max	Min.	Max	Min.	Max	Min.	Max
8 - 32	12	15	7	9	-----	-----	-----	-----	-----	-----	-----	-----
10 - 24	20	25	12	15	-----	-----	-----	-----	-----	-----	-----	-----
1/4 - 20	40	50	25	30	-----	-----	-----	-----	-----	-----	-----	-----
5/16 - 18	80	90	48	55	-----	-----	-----	-----	-----	-----	-----	-----
3/8 - 16	160	185	95	110	-----	-----	-----	-----	-----	-----	-----	-----
7/16 - 14	235	255	140	155	-----	-----	-----	-----	-----	-----	-----	-----
1/2 - 13	400	480	240	290	-----	-----	-----	-----	-----	-----	-----	-----
9/16 - 12	500	700	300	420	-----	-----	-----	-----	-----	-----	-----	-----
5/8 - 11	700	900	420	540	-----	-----	-----	-----	-----	-----	-----	-----
3/4 - 10	1150	1600	700	950	-----	-----	-----	-----	-----	-----	-----	-----
7/8 - 9	2200	3000	1300	1800	-----	-----	-----	-----	-----	-----	-----	-----
1 - 8	3700	5000	2200	3000	-----	-----	-----	-----	-----	-----	-----	-----
1 1/8 - 8	5500	6500	3300	4000	-----	-----	-----	-----	-----	-----	-----	-----
1 1/4 - 8	6500	8000	4000	5000	-----	-----	-----	-----	-----	-----	-----	-----

**Table 2: Recommended torque values for nut-bolt combinations: Coarse Thread Series**

<sup>2</sup> Torque values without lubrication

## 5. REQUIRED INSPECTIONS

### 5.1 Cycle Counting Daily Coherence Check (Installed as an option)

The following procedure applies to either use of the AKV remote display or 3<sup>rd</sup> party Flightcell DZMx display and provides an approved method for conforming with the SAFRAN “coherence check” as specified in the SAFRAN maintenance manual or with reference to SAFRAN / Turbomeca General Service Letter No. 2283/04 5th issue. It will provide a means to determine that the cycle counting function is recording cycles within your normal mission range.

**Procedure:** To understand your normal mission range, determine what the total manual count was for the last 10 flights. Add all 10 flights together and then divide by 10. The result is the average consumed cycles to which your normal range is determined by adding +/- 10%. Perform this function separately for Ng and Np.

After the last flight of the day, compare the recorded cycles from the cycle counter display with your normal mission range values. This method will insure that there is no significant discrepancy which would be evident with either a digital display of zero “flt” cycles or “flt” cycles that are in excess of what is the normal mission range. In the event that either of these situations is observed, then perform the Annual Inspection of the cycle counter as described below.

### 5.2 Annual Inspection

This section contains the time limit intervals and requirements for the scheduled and conditional inspections for the ETM1000 Installation. The inspection items are determined through experience, tests, and the judgment of mechanics and engineers. Every calendar and daily inspection is a visual and thorough inspection to determine the airworthiness of the ETM1000. Qualified persons must perform the inspections in accordance with standard aircraft practices and the applicable maintenance manuals.

An Annual inspection using this **ETM1000-ICA** document (Instructions for Continued Airworthiness), is required. When using **ETM1000-ICA** to perform the required inspections, use the “Inspection Task Description” forms below to record the appropriate data.

Any reference data needed to perform this inspection, other than this document, will be listed in the “Data Reference” column of the inspection forms.

The inspection task to be completed is described in the “Inspection Task Description” column of the inspection form.

When each task is satisfactorily completed, the mechanic performing the inspection task signs the “Mechanic” column for that task.

If the inspection task fails the inspection, the reason for the failure must be determined and remedial action taken before the “Mechanic” block can be signed off. Remedial action may involve cleaning, verifying correct operation, adjusting the tightness of fasteners and hardware, sending the assembly to the manufacturer for overhaul or replacement, etc. Once the appropriate remedial action has been taken and the inspection task has been satisfactorily performed, the mechanic may sign off the “Mechanic” block.

Once all tasks are signed off in the “Mechanic” Column, the inspection form may be signed off at the top of the form and the inspection has then been completed.



### **5.3 Special Inspection**

In the event of a hard landing, perform the “Annual Inspection” tasks prior to returning the aircraft to service.

Helicopter S/N: \_\_\_\_\_ Registration: \_\_\_\_\_  
 Facility: \_\_\_\_\_ W/O.: \_\_\_\_\_  
 A/F Total time: \_\_\_\_\_ Rin: \_\_\_\_\_  
 Engine Total time: \_\_\_\_\_ Cycle: \_\_\_\_\_  
 Date started: \_\_\_\_\_ Date completed: \_\_\_\_\_  
 Signature: \_\_\_\_\_ License number: \_\_\_\_\_

**Annual Inspection**

Data Reference	Inspection Task Description	Mechanic
ETM1000 User Manual v7.0 or later	<p><b>Replacement of the Lithium Backup AA battery for Rev Q and later LRU's</b></p> <p>The new 3.6V AA Lithium “button top” style battery should be replaced bi-annually in order to provide continued retention of the date / time clock. The 3.6V AA Lithium battery is a standard industry lithium battery that can be purchased from AKV, Inc.</p> <p><b>Caution:</b> Do not use a standard AA battery which has insufficient voltage of 1.5V</p> <p>With the A/C battery switch “OFF”, remove the LRU from the tray and then the battery holder cap by twisting counter clockwise. After the new battery has been installed, make sure the cap installaed and is <b>fully tightened</b>.</p> <p>You will now need to reset the date and time. Locate and connect the supplied RS232 cable to the “config” port just below the J1 connector. Connect the cable to a PC running Microsoft XP, 2000, Vista or Windows 7 or 10 using the 9 pin serial port. If a 9 pin serial port is not available then use the supplied USB / Serial adapter.</p> <div data-bbox="354 1388 1266 1808" data-label="Image"> <p>Front</p> <p>Replace with a new battery making sure the “+” side of the battery is down.</p> <p>Battery holder located on the bottom</p> </div>	

Data Reference	Inspection Task Description	Mechanic
ETM1000 User Manual v7.0 or later	<p><b>Operational Check</b></p> <p>The PC you will use must have been set up for communication via “HyperTerminal” prior to using the following procedure.</p> <p>Perform the following steps to verify proper operation of the ETM1000.</p> <ol style="list-style-type: none"> <li>Use a PC running Windows XP, 2000, Vista or Windows 7/8 and connect to the “Config” port using the AKV supplied RS232 9-pin serial cable. Use the AKV supplied USB/Serial adaptor if your PC does not have a 9 pin serial port available.</li> </ol> <p><b><u>If you have a -2 configuration without the pushbutton / indicators and audio side-tone, go to step 7</u></b></p> <ol style="list-style-type: none"> <li>If the indicators are known to be activated from within the configuration settings of HyperTerminal, turn the A/C battery switch “ON” and observe that the annunciator lights are illuminated as follows during system BIT self-check:           <div style="display: flex; justify-content: center; gap: 20px; margin: 10px 0;">   </div> </li> <li><b>NOTE:</b> If the <b>WARNING</b> light stays illuminated then there has been a prior exceedence that has not been acknowledge and cleared by maintenance. Remove the SD card to confirm what has been exceeded, verify corrective action then reset the light.</li> <li>If the <b>SD</b> light stays illuminated then check the SD card is inserted. If it is flashing then the SD card nearly full and data must be removed. If the SD card is bad then replace it.</li> <li>If the <b>ERR</b> light stays illuminated then there is a faulty connection with one of the signals to the ETM1000. Use HyperTerminal to determine which signal is faulty.  <b>* Ref. Appendix D for the Wiring Diagrams.</b></li> <li>If the audio is known to be activated from within the configuration settings of Hyperterminal and with the headset on your head, check that the audio side tone is heard by cycling the ETM circuit breaker. If it is weak or load, adjust the audio control head unit for a comforatbel level. It is not adjustable within the ETM1000.</li> <li>Check the cooling fan on the rear of the ETM1000 enclosure below the instrument panel for positive airflow by placing your hand next to the fan.</li> <li>Check the fan bearings are not noisy and the fan is clean and provides airflow by placing your hand over the rear of the ETM1000 enclosure.</li> <li>On your PC, locate and run the Windows native program called “HyperTerminal”</li> </ol>	

Data Reference	Inspection Task Description	Mechanic
ETM1000 User Manual v7.0 or later	<ol style="list-style-type: none"> <li>10. Check that the Date and Time are correct. If not, then enter “S” for settings, enter your password and change the appropriate field as required.</li> <li>11. Check that the Collective Time, Engine Run Time and Engine Starts are correct, If not then enter “S” for settings, enter the password and change the appropriate field as required.</li> <li>12. Check that the OAT value in “HyperTerminal” is with 5 deg C of the A/C OAT probe. Keep in mind that the ETM1000 OAT probe is mounted on the belly of the A/C and could be receiving additional heat form the ground when compared to the A/C OAT probe mounted above the canopy.</li> </ol> <p><b>NOTE:</b> If the cycle counting option is installed, then include the <b>cycle counting functional check</b> described on the next page along with item 13, 14 &amp; 15 below.</p> <ol style="list-style-type: none"> <li>13. Start the A/C and run at ground idle.</li> <li>14. Check that the engine parameters for Tq, MGT, N1, N2 and Nr values in “HyperTerminal” correspond with the indicators on the instrument panel.</li> </ol> <p><b>NOTE:</b> During startup it is normal to sometimes see the <b>ERR</b> light flash on for 1-2 secs. This can vary between different A/C.</p> <ol style="list-style-type: none"> <li>15. Run the A/C at flight speed and again, check the engine parameters for accuracy.</li> <li>16. Return to ground idle and shutdown the engine.</li> <li>17. Set the altimeter to 29.92 and verify the Pressure Altitude in “HyperTerminal” is within approximately 300ft.</li> <li>18. Connect a pitot test set to the A/C pitot tube and while monitoring “HyperTerminal” check that the “Air speed Switch” goes from “0” (OFF) to a “1” (ON) when the test set is adjusted to 80Kt or greater.            Tolerances - Activation +0 / -5 MPH and Deactivation -2 / -6 MPH            * <b>Ref. Appendix D for the Wiring Diagrams.</b></li> </ol> <p><b>Coninued next page</b></p>	

Data Reference	Inspection Task Description	Mechanic
ETM1000 Bell MediumT53 Or Bell 214 T55 Cycle Counting Operating Specification	<p><b>Cycle Counting Functional Check (installed as an option)</b></p> <p><b>NOTE:</b> Cycle counting is available as an option only on the -1 configuration via the AKV remote display or displayed on the 3rd party Flightcell DZMx as shown in Fig. 3 &amp; 4 above. In either case, the ETM1000 is the source for the cycle counting data. When using the AKV remote display the ETM1000 <b>LRU must be Rev P</b> or greater.</p> <p>1. Perform a ground run of the A/C and observe the first data screen for the N1 and N2 speeds. These values are compared to the instrument panel indicators and should be within +/- 0.5%.</p> <p><b>Note:</b> Per the engine manufacturer requirements, ground runs of the A/C require cycle penalties to be recorded.</p> <p>2. Perform a normal departure, cruise and landing. Note the max N1 to the nearest 1% during takeoff and the min N1 speed during power reduction as well as the amount of 10% speed excursions / operations (&gt;10% speed increase). After shutdown, compare your estimated cycle count using the T53 Cycle Counter Operations Specification document examples starting on Pg 10.</p> <p>Make sure there is no significant discrepancy between the estimated values and recorded values shown on the cycle counter. If a discrepancy exists, refer to the troubleshooting sect. 7 or contact AKV for further assistance. In place of the ETM1000 cycle counter system which includes the ETM1000 LRU and possibly the remote display (if bad), continue operating the A/C using the T53 “manual cycle counting” procedure during removal and repair of the cycle counter.</p> <p>After the ETM1000 LRU / remote display is repaired, repeat this “Annual Inspection” procedure to verify correct operation. Use the ETM1000 programming interface to update the cycle counting function with any new totals.</p> <p><b>END OF PROCEDURE</b></p>	

## 6. REMOVING PARTS

Removal instructions for the AKV ETM1000 and cycle counter remote display are listed below.

### 6.1 To Remove the ETM1000 LRU

**Note:** The ETM1000 Enclosure is secured to the mounting plate with four (4) ball studs that allow for a quick-release.

- a) Disconnect the airframe P1 electrical connector from the J1 ETM1000 enclosure electrical connector
- b) Place your hands on the front and rear of the enclosure
- c) Pull the enclosure directly towards you and away from the mounting bracket

### 6.2 To Remove the Airspeed Switch

See Appendix B for the Airspeed Switch Installation Instructions.

### 6.3 To Remove the Pushbutton Switches

See Appendix C for the Pushbutton Indicator Removal / Installation Instructions.

### 6.4 To Remove the (optional ) Cycle Counting Remote Display

- d) Disconnect the airframe electrical connector from the cycle counter enclosure
- e) Remove the 2 mounting screws holding the cycle counter to the bracket
- f) Install a plastic bag over the airframe connector and secure with zip ties.

**NOTE:** To Remove the 3rd Party Flightcell DZMx, refer to the OEM Flightcell DZMx manual

## 7. TROUBLESHOOTING

The troubleshooting table provides the mechanic with guidance for diagnosing malfunctions and the recommended course of action to remedy the fault. Additional help can be found in the Inspection Task (operational task) starting on Pg. 10 or by contacting AKV. See Page 1 for support contact information.

### ETM1000

Fault	Probable Cause	Action
No power to unit when aircraft battery power applied	1. Check Circuit breaker 2. Check J1 Connector	1. Reset the Circuit breaker 2. Turn off aircraft battery power and check connector with reference to Appendix D Drawings
Minimal or no airflow from cooling fan.	Cooling fan inoperative.	Check for obstruction and with the power off, check that the fan moves freely and is clean of dust.
Loss of date and time clock indicated by flashing ERR and confirmation with Hyperterminal connected	1. Battery hold tab loose 2. Battery is weak. Min 2.9V	1. Return LRU to AKV 2. Replace battery with a new one

### Cycle Counting (installed as an option)

Fault	Probable Cause	Action
No power to the remote display when aircraft battery power applied	1. Check ETM1000 Circuit breaker 2. Check J1 Connector	1. Reset the Circuit breaker 2. Turn off aircraft battery power and check connector with reference to Appendix D Drawings
High Ng and or Np cycles	Engine Signal Generator(s) noisy	Verify electrical connector at Signal Generator is clean and secure. <b>** <u>Perform signal quality check below.</u></b>
Blinking cursor in the top left corner of the remote display or no display at all	Electro-static discharge has damaged the LCD	Confirm that a ground bonding strap from the enclosure to airframe ground is present, secure and has < 3 milliohm resistance. <b>Remote Display will need to be returned to AKV for repair.</b> See Sect. 6 - Remove Parts

**NOTE:** If the above actions do not resolve the issue, contact AKV for additional assistance or to arrange for the unit to be returned for repair.


### Signal quality check

1. Connect an oscilloscope to the ETM1000 airframe wire harness at the wiring splice point for Ng or Np behind the indicators for whichever signal is of concern.

Refer to attached Appendix D drawings ETMUH1-003 for N1/Ng and N2/Np connections


2. Ground run the A/C at idle and observe the quality of the sine-wave signal is as shown in Fig 1.
3. Whilst observing the oscilloscope, slowly increase the FCL to the flight position and observe that the sine-wave remains as shown in Fig 1 thru the speed change.

**NOTE:** A bad sine-wave signal will look similar to figure 2. If this is observed, clean the signal generator connector and/or replace the signal generator and perform the test again to confirm the quality of the signal is displayed like Fig 1.



CLEAN

Fig. 1 (good)



NOISE

Fig. 2 (bad)

## 8. WEIGHT AND BALANCE CHANGES

In the event the ETM1000 has to be removed for maintenance, use the following table to adjust the aircraft weight and balance data.

Component	Weight
ETM1000 Enclosure P/N ETMUH1-006	1.25lbs 0.57 kg
Mounting tray P/N 96396-1	0.9 lbs 0.41 kg
(Optional) Cycle Counter Remote Display P/N ETMRD-004	0.25 Lbs 0.12 kg
(Optional) Cycle Counter Remote Display Bracket P/N UH1-ETMRD-002	0.75 Lbs 0.34 kg

## Appendix A

### A. CONFIGURING THE ETM1000

For Instructions on configuring the ETM1000 and optional cycle counting, refer to the ETM1000 User Manual v7.0 or later

## Appendix B

### B. AIRSPPEED SWITCH INSTRUCTIONS

#### **Intended Use:**

The intended use of the airspeed switch is to provide an airspeed signal at = > 80 Knots for torque exceedence criteria.

#### **System Description:**

This airspeed switch utilizes the existing Pitot system to provide the needed pressures for switch actuation. A ground leg is connected through the airspeed switch and will supply a ground connection for the ETM when the airspeed is = > 80 Knots.

**Note:** This installation will have negligible effect on aircraft weight and balance.

**WARNING:** When performing pitot/static systems certification you must connect the vent nipple on the AS9300-603-A switch to the static source on the test box to prevent damage to the switch diaphragm. The vent nipple bleed hole must be sealed to prevent leakage during testing. Do not connect vent nipple to the ships static system except during testing. Do not remove sealant compound from around switch terminals or pressure nipple bleed hole. Removal will cause leakage when performing a pitot system check.

#### **CHECKOUT PROCEDURES:**

##### **Required Equipment:**

- Pitot test set.

##### **Test:**

- 1) Test the Pitot system in accordance with the aircraft manufacturer's instructions. If the manufacturer has *not issued instructions for testing Pitot systems, utilize the procedures contained in AC 43.13-1A or later* approved revision.
- 2) Apply power to the aircraft and observe that the circuit protective device (circuit breaker or fuse) does not "trip" or "blow". Repair wiring if necessary for proper circuit protective device operation.
- 3) After the Pitot system has been successfully leak tested, adjust Pitot test set to indicate zero knots.
- 4) Observe that the Airspeed is "OFF" via the laptop PC running "HyperTerminal". If the Airspeed is "ON," check for the proper airspeed switch electrical connections. Incorrect switch connections will cause the ETM to not function correctly when determining a torque exceedence in flight.
- 5) Adjust the airspeed to equal 80 Knots or greater and observe that the Airspeed is "ON". If the Airspeed does not turn "ON", check connections on airspeed switch or repair wiring as necessary.

**NOTE:** Tolerances are Activation +0 / -5 MPH and Deactivation -2 / -6 MPH


- 6) Disconnect the Pitot test equipment from the aircraft.
- 7) Make the appropriate entries in the aircraft log book indicating a Pitot system test, and the airspeed switch installation have been completed.

## Appendix C


### C. Pushbutton Indicator Removal/Installation Instructions

- 1) Examine the two sides of the switch cap to ensure the extraction slots are completely visible.

**Note:** To release the switch cap from the actuated position, simply push in the switch cap and allow the cap to return to the released position.



- 2) Extract the switch cap by using the Cap Extractor Tool (Part Number: 17-150) or by applying finger pressure on two sides of the switch cap then pull the switch cap from the switch body.



- 3) Remove switch cap from the switch body by gently removing the cap pins from the metallic retainer.



- 4) Remove the mounting sleeve by sliding the sleeve over the switch body from the back.

**Note:** The optional spacer can also be removed by sliding it from the back of the switch body.





- 5) Insert the back of the switch body into the panel cutout and slide it through the panel from the front. Ensure the switch body label "TOP" is up.




- 6) From behind the mounting panel, replace the mounting sleeve onto the switch body and slide it up to the back of the mounting panel.



- 7) From the front and inside of the switch body, tighten the two screws until the Integral Mounting Hardware pulls the mounting sleeve tight up against the mounting panel. Typical torque is 18 inch ounces.



- 8) Replace the switch cap in the switch body by inserting the cap pins into the metallic retainer and push the cap into the switch body.



## Appendix D

### D. WIRING DIAGRAMS

This chart is a list of all MDL Rev R in order of appearance.


Drawing Number	Rev	Initial Release	Drawing Description
ETMUH1-001 Sht 1	E	11/5/20	SYSTEM COMPONENTS – TOP ASSEMBLY
ETMUH1-001 Sht 2	C	11/5/20	SYSTEM COMPONENTS – FOR -1 CONFIGURATION
ETMUH1-001 Sht 3	C	11/5/20	SYSTEM COMPONENTS – FOR -2 CONFIGURATION
ETMUH1-001 Sht 4	B	7/24/17	SYSTEM COMPONENTS – CABLE ROUTING
ETMUH1-002 Sht 1	C	11/5/20	MECHANICAL INSTALLATION – LRU MOUNTING LOCATION
ETMUH1-002 Sht 2	B	7/24/17	MECHANICAL INSTALLATION – AIRSPEED SWITCH
ETMUH1-002 Sht 3	B	7/24/17	MECHANICAL INSTALLATION – AIRSPEED SWITCH
ETMUH1-002 Sht 4	B	7/24/17	MECHANICAL INSTALLATION – AIRSPEED SWITCH
ETMUH1-002 Sht 5	B	7/24/17	MECHANICAL INSTALLATION – PUSHBUTTON MOUNTING
ETMUH1-002 Sht 6	C	11/5/20	MECHANICAL INSTALLATION – OAT MOUNTING
ETMUH1-002 Sht 7	C	7/24/17	MECHANICAL INSTALLATION – TQ SIGNAL CONDITIONER MOUNTING
ETMUH1-003 Sht 1	B	7/24/17	AIRFRAME WIRING INSTALLATION – POWER
ETMUH1-003 Sht 2	C	7/1/20	AIRFRAME WIRING INSTALLATION – THERMOCOUPLE MGT/EGT
ETMUH1-003 Sht 3	C	1/1/25	AIRFRAME WIRING INSTALLATION – TQ
ETMUH1-003 Sht 4	C	1/1/25	AIRFRAME WIRING INSTALLATION – N1
ETMUH1-003 Sht 5	C	1/1/25	AIRFRAME WIRING INSTALLATION – N2
ETMUH1-003 Sht 6	C	1/1/25	AIRFRAME WIRING INSTALLATION – NR
ETMUH1-003 Sht 7	B	7/24/17	AIRFRAME WIRING INSTALLATION – AIRSPEED SWITCH
ETMUH1-003 Sht 8	B	7/24/17	AIRFRAME WIRING INSTALLATION – COLLECTIVE INTERFACE
ETMUH1-003 Sht 9	B	7/24/17	AIRFRAME WIRING INSTALLATION – AUDIO INTERFACE
ETMUH1-003 Sht 10	C	1/1/25	AIRFRAME WIRING INSTALLATION – OAT

Cont'd next page

Cont'd

ETMUH1-003 Sht 11	B	7/24/17	AIRFRAME WIRING INSTALLATION – PUSHBUTTON / ANNUNCIATOR CONNECTION
ETMUH1-003 Sht 12	NC	1/1/25	AIRFRAME WIRING INSTALLATION – LOAD CELL
ETMUH1-004 Sht 1	D	1/1/25	- 1 WIRE HARNESS
ETMUH1-004 Sht 2	D	1/1/25	- 2 WIRE HARNESS
ETMUH1-005 Sht 3	E	1/1/25	WIRE HARNESS – J1 CONNECTOR PIN OUT
ETMUH1-010 Sht 1	C	3/6/18	CONFIGURATION PORT – RS232 PIN OUT
ETMUH1-011 Sht 1	D	1/1/25	DATA PORT – RS232 PIN OUT
UH1-ETMRD-003 Sht 1	A	4/3/20	REMOTE DISPLAY INSTALLATION
UH1-ETMRD-003 Sht 2	NC	3/6/18	REMOTE DISPLAY INSTALLATION
UH1-ETMRD-003 Sht 3	NC	3/6/18	REMOTE DISPLAY INSTALLATION
ETMRD-003 Sht 1	A	3/5/26	REMOTE DISPLAY WIRING
ETMRD-003 Sht 1	NC	3/5/26	REMOTE DISPLAY WIRING

**ETMUH1-001 SHT 1 – TOP ASSEMBLY**



**TOP ASSEMBLY**

BELL UH-1, 204, 205, 210 WITH THE T53 ENGINE INSTALLED. LRU SOFTWARE IS v71.0 OR GREATER

EAGLE SINGLE WITH T53 ENGINE INSTALLED. LRU SOFTWARE IS v71.0 OR GREATER.

BELL 214 WITH THE T55 ENGINE INSTALLED. LRU SOFTWARE IS v71.0 OR GREATER.

SEE BELOW

**NOTES:**

1. POWER 28VDC 750mA CONSUMPTION.
2. WEIGHT INCLUDES LRU, MOUNTING TRAY AND AIRFRAME WIRE HARNESS
  - BELL UH-1, 204, 205 & 210 WITH THE TO SIGNAL CONDITIONER, THE SYSTEM WEIGHT IS 5lb
  - BELL 214 & EAGLE SINGLE WITHOUT THE TO SIGNAL CONDITIONER, THE SYSTEM WEIGHT IS 4lb
3. SEE ETM1000-MDL FOR COMPLETE DRAWING LIST.
4. THE RS232 CONFIGURATION "CONFIG" PORT IS USED FOR GROUND SUPPORT EQUIPMENT PURPOSES. SEE DWG ETMUH1-010.
5. THE RS232 "DATA" PORT IS A PROVISIONAL PORT FOR 3RD PARTY APPROVED SATELLITE TRACKING SYSTEMS. SEE DWG ETMUH1-011.

TO ACCEPT THE CYCLE COUNTING REMOTE DISPLAY, THE FOLLOWING CONFIGURATION IS REQUIRED:  
 1. ETM1000 LRU MUST BE REV P OR GREATER  
 2. ETM1000 INSTALLED SOFTWARE MUST BE v72.0 OR GREATER.  
 REF. DOCUMENT "ETM1000 CONFIGURATION AND GRAPH / TRENDING USER MANUAL v7.0" AND SECT. 5.0 TO CONFIRM INSTALLED SOFTWARE VERSION AND OPERATION.

REVISIONS				
REV	DESCRIPTION	PREPARED	DATE	APPROVED
NC	INITIAL RELEASE	JG	3/11/15	
A	ADDED B214	JG	1/29/16	
B	CORRECTED NOTE 2 WEIGHT	JG	6/9/16	
C	ADDED EAGLE SINGLE	JG	7/24/17	
D	ADDED NEW NOTE FOR REMOTE DISPLAY REV P REQUIREMENT FOR THE REMOTE DISPLAY OPTION	JG	3/6/18	
E	REMOVED COIN CELL BATTERY	JG	11/5/20	

AKV Inc  
 P/N ETMUH1-006  
 part of kit P/N ETM1000  
 Make: Bell  
 Model: UH-1, 204, 205, 210, 214  
 & Eagle Single  
 S/N XXX Rev \_\_\_ FAA/PMA

QTY	QTY	ITEM	DESCRIPTION	PART NUMBER	VENDOR/MFOR
1	1	2	AVIONICS MOUNTING TRAY	96396-1	SHEETMETAL ENGINEERING
1	1	1	EXCEEDENCE & TREND MONITOR ETM1000 LRU	ETM350-006	AKV, INC

PROPRIETARY NOTICE		MATERIAL SPECIFICATIONS		DATE	
THIS DRAWING AND ALL INFORMATION CONTAINED HEREIN ARE THE SOLE PROPERTY OF AKV, INC. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF AKV, INC.		MATERIAL SPECIFICATIONS		DATE	
UNLESS NOTED OTHERWISE, ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED.		MATERIAL SPECIFICATIONS		DATE	
DIMENSIONS ARE TO BE TAKEN TO THE CENTER OF THE HOLE UNLESS OTHERWISE SPECIFIED.		MATERIAL SPECIFICATIONS		DATE	
DIMENSIONS ARE TO BE TAKEN TO THE CENTER OF THE HOLE UNLESS OTHERWISE SPECIFIED.		MATERIAL SPECIFICATIONS		DATE	

PARTS LIST		TITLE	
1	1	AVIONICS MOUNTING TRAY	96396-1
1	1	EXCEEDENCE & TREND MONITOR ETM1000 LRU	ETM350-006


  

MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	

MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	
MATERIAL SPECIFICATIONS		DATE	

**ETMUH1-001 SHT 2 - -1 CONFIGURATION**










### ETMUH1-002 SHT 2 – AIRSPEED SWITCH



REV	DESCRIPTION	PREPARED	DATE	APPROVED
NC	INITIAL RELEASE	JG	3/11/15	
A	ADDED B214	JG	1/29/16	
B	ADDED EAGLE SINGLE	JG	7/24/17	

**NOTES:**

1. FLOW RESISTOR END OF ADDED PITOT LINE CONNECTED TO AIRSPEED SWITCH

⚠ SEE DOCUMENT ETMUH1-100 FOR AIRSPEED LEAK TEST AND CALIBRATION.

**AIRSPEED SWITCH INSTALLATION**


BELL UH-1, 204, 205 & 210 WITH THE T53 ENGINE  
 EAGLE SINGLE WITH T53 ENGINE  
 BELL 214 WITH T55 ENGINE

**PROPRIETARY NOTICE**  
 THIS DRAWING AND ALL INFORMATION CONTAINED HEREIN ARE THE SOLE PROPERTY OF AKV, INC. AND ARE NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT THE WRITTEN PERMISSION OF AKV, INC.


REV	DATE	BY	APP
1	3/11/15	JG	
2	7/24/17	JG	

QTY	ITEM	DESCRIPTION	PART NUMBER	VENDOR/MFR
1		AIRSPEED SWITCH		
1		FLOW RESTRICTOR		
1		PITOT TUBE		

**ETMUH1-002 SHT 3 – AIRSPEED SWITCH**



**ETMUH1-002 SHT 4 – AIRSPEED SWITCH**



**ETMUH1-002 SHT 5 – PUSHBUTTON / INDICATOR MOUNTING**

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321

DCBA

87654321


DCBA

87654321


DCBA




### ETMUH1-002 SHT 7 – TQ SIGNAL CONDITIONER MOUNTING



**ETMUH1-003 SHT 1 – POWER**



**ETMUH1-003 SHT 2 – THERMOCOUPLE**




- NOTES:
1. SPLICE ETM THERMOCOUPLE WIRE APPROX 2" FROM REAR OF GAUGE.
  2. TRIM SUPPLIED WIRE HARNESS LENGTH IF NECESSARY TO SUIT INSTALLATION.
  3. PUT THE SENSOR AND INDICATOR WIRES IN THE SAME SIDE OF THE SPLICE.


THERMOCOUPLE INTERFACE CONNECTION

BELL UH-1, 204, 205 & 210 WITH THE T53 ENGINE  
 EAGLE SINGLE 212S WITH THE T53 ENGINE  
 BELL 214 WITH THE T55 ENGINE


**ETMUH1-003 SHT 3 – TORQUE**




### ETMUH1-003 SHT 4 – N1 GAS GENERATOR




**ETMUH1-003 SHT 5 – N2 POWER TURBINE**




### ETMUH1-003 SHT 6 – NR ROTOR




**ETMUH1-003 SHT 7 – AIRSPEED SWITCH**




**ETMUH1-003 SHT 8 – COLLECTIVE INTERFACE**



**ETMUH1-003 SHT 9 – AUDIO INTERFACE**



### ETMUH1-003 SHT 10 – OAT



REVISIONS				
REV	DESCRIPTION	PREPARED	DATE	APPROVED
NC	INITIAL RELEASE	JG	3/11/15	
A	ADDED B214	JG	1/29/16	
B	ADDED EAGLE SINGLE	JG	7/24/17	
C	CHANGED ITEM 3 TO STRAIGHT	JG	1/1/25	

NOTES:

1. REF DWG ETMUH1-002 SHT 6 FOR OAT MOUNTING DETAIL.
2. TRIM SUPPLIED WIRE LENGTH IF NECESSARY TO SUIT INSTALLATION.
3. FOR OAT CONNECTOR USE ASTRO TOOL CRIMPER P/N M22520/1-01 AND TURRET P/N M22520/1-02
4. FOR OAT CONNECTOR USE WIRE INSERT/EXTRACTION TOOL P/N M81969/1-02 (RED/WHITE)
5. STRIP INSULATION 1.5" FROM OAT END.

OAT INTERFACE CONNECTION

BELL UH-1, 204, 205 & 210 WITH THE T53 ENGINE  
 EAGLE SINGLE 212S WITH THE T53 ENGINE  
 BELL 214 WITH THE T55 ENGINE

QTY	ITEM	DESCRIPTION	PART NUMBER	VENDOR/AFOR
1	3	STRAIGHT BACKSHELL	M85048/S25BW	QPL
3	2	SOCKET PIN	M39029/S-115	QPL
1	1	PLUG	M83723/95W803H	QPL

PARTS LIST		DATE	BY
PROPOSED	J. CLUN	3/11/15	
PREPARED	J. CLUN	1/1/25	


<b>AKV Inc.</b> 777 AVIATION DR. CAMARILLO, CA.	
TITLE: AIRFRAME WIRING INSTALLATION	
DWG NO: ETMUH1-003	REV: c
SCALE:	SHEET 10 OF 12

<b>PROPRIETARY NOTICE</b> THIS DRAWING AND ALL CONTENTS HEREON ARE THE PROPERTY OF AKV, INC. AND ARE NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF AKV, INC.		REV. CODE PER PAR 5023 15-000000-0000 15-000000-0000 15-000000-0000 15-000000-0000	DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED
SHEET NO. 11 PART ASSEMBLY	UH-1 USED ON	15-000000-0000 REV. 001	DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE SPECIFIED






# ETMUH1-004 Sht 1 - - 1 WIRE HARNESS




### ETMUH1-004 Sht 2 - -2 WIRE HARNESS





**ETMUH1-010 SHT 1 – CONFIGURATION PORT**





**UH1-ETMRD-003 Sht 1 REMOTE DISPLAY INSTALLATION**

8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---

**BELL UH-1 MOUNTING BRACKET INSTALLATION**  
PILOT (RIGHT) SIDE

**BELL 205 / 212S MOUNTING BRACKET INSTALLATION**  
PILOT (RIGHT) SIDE

**REMOTE DISPLAY INSTALLATION**  
PILOT (RIGHT) SIDE

**NOTES:**

- ROUTE DISPLAY CABLE CONNECTOR THRU HOLE IN BRACKET.
- ROUTE / SECURE WIRING PER AC43.13-1B CHG 1, CHAPT. 11 SECT 8 PARA 11-105 THRU 11-121.
- FOR PREPARING THE GROUND STRAP BONDING SURFACE TO THE AIRFRAME, REF THE BELL STANDARD PRACTICES MANUAL "GENERAL ELECTRICAL BONDING" GUIDELINES
- ETM1000 LRU MUST BE REV P OR GREATER TO ACCEPT REMOTE DISPLAY INTERFACE
- THE 212S BRACKET WILL NOT FIT DUE TO CLEARANCE LIMITS WHEN THE OEM 212 COLLECTIVE HEAD IS USED. NOT SUPPLIED UNLESS REQUESTED

QTY	ITEM	DESCRIPTION	PART NUMBER	VENDOR/MFR
8	1/4" Oval Braided Wire Silver	2142 SV005		AKV / EDWO
2	#10 Ring Terminal	7113K241		AKV / McMaster Carr
4	10-32 Nut	95307A400 or MS21042L3		McMaster Carr / OPL
10	#10 Washer	95017A540 or AN680C10		McMaster Carr / OPL
5	Screw 10-32 x 0.5" Lg	95880A518 or MS35207-283		McMaster Carr / OPL
1	3	ENGINE CYCLE COUNTER OR REMOTE DISPLAY	UH1TS3CC OR ETMRD-004	AKV
1	2	BELL 205 / 212 MOUNTING BRACKET	UH1-ETMRD-002	AKV
1	1	BELL UH-1 MOUNTING BRACKET	UH1-ETMRD-001	AKV

**PROPRIETARY NOTICE**

THIS DRAWING AND ALL INFORMATION CONTAINED HEREIN ARE UNCLASSIFIED EXCEPT WHERE SHOWN OTHERWISE AND ARE THE PROPERTY OF AKV, INC. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT PERMISSION IN WRITING FROM AKV, INC.

UNLESS NOTED OTHERWISE, THIS DRAWING IS THE PROPERTY OF AKV, INC. UNLESS NOTED OTHERWISE, THIS DRAWING IS THE PROPERTY OF AKV, INC.

UNLESS NOTED OTHERWISE, THIS DRAWING IS THE PROPERTY OF AKV, INC.

**REVISIONS**

REV	DESCRIPTION	PREPARED	DATE	APPROVED
NC	INITIAL RELEASE	JG	3/8/18	
A	CORRECTED BRACKET TO MODEL	JG	4/3/20	

**AKV Inc.**  
 777 AVIATION DR. CAMARILLO, CA.


**TITLE**  
 BELL MEDIUM REMOTE DISPLAY INSTALLATION

**SIZE** DWG NO: D | UH1-ETMRD-003 | REV A

**SCALE** 1 OF 3

**UH1-ETMRD-003 Sht 2 REMOTE DISPLAY INSTALLATION**

2	DWG NO	UH1-ETMRD-003	SHT	2	REV	NC
REVISIONS						
REV	DESCRIPTION	PREPARED	DATE	APPROVED		
NC	INITIAL RELEASE	JG	3/6/18			




- NOTES:
1. ROUTE DISPLAY CABLE CONNECTOR THRU HOLE IN BRACKET.
  2. ROUTE / SECURE WIRING PER AC43.13-1B CHG 1. CHAPT. 11 SECT 8 PARA 11-105 THRU 11-121.

REMOTE DISPLAY INSTALLATION  
 BELL MEDIUM

A/R	QTY	DESCRIPTION	PART NUMBER	VENDOR/MFR
5	1	3/64" U-Channel Trim	8500K71	McMaster Carr / QPL
4	1	3/8" LOOP CLAMP	3225T23	McMaster Carr / QPL
3	3	10-32 Nut	95307A400 or MS21042L3	McMaster Carr / QPL
2	2	#10 Washer	96017A640 or AN960C10	McMaster Carr / QPL
1	1	Screw 10-32 x 0.5" Lg	96980A516 or MS35207-263	McMaster Carr / QPL

<p>PROPRIETARY NOTICE</p> <p>THIS DRAWING MAY CONTAIN SPECIFICATIONS AND/OR DATA, TECHNICAL MATERIAL, PROPRIETARY DESIGN AND INFORMATION THAT ARE THE SOLE PROPERTY OF AKV, INC. ANY REPRODUCTION, COPIES, TO BE HELD AND TREATED AS ITS RECEIPT ON A CONFIDENTIAL BASIS, AND IS NOT TO BE SHOWN, REPRODUCED OR DISCLOSED TO ANY UNAUTHORIZED ORGANIZATION OR PERSON WITHOUT PERMISSION.</p>		<p>UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES</p> <p>DECIMALS: 1/16, 1/8, 3/16, 1/2, 5/8, 3/4, 7/8, 1</p> <p>FRACTIONS: 1/2, 3/4, 1/2, 3/8, 1/4</p> <p>DO NOT SCALE DRAWINGS</p>	<p>DATE: 3/8/18</p> <p>DESIGNED BY: J. CLUNN</p> <p>DATE: 3/8/18</p>	<p>AKV Inc.</p> <p>777 AVIATION DR. CAMARILLO, CA.</p>
<p>UNLESS NOTED OTHERWISE THIS DRAWING IS UNCLASSIFIED</p> <p>DATE: 03/08/18</p> <p>BY: JG</p>	<p>REV: 1</p> <p>DATE: 03/08/18</p> <p>BY: JG</p>	<p>REV: 1</p> <p>DATE: 03/08/18</p> <p>BY: JG</p>	<p>REV: 1</p> <p>DATE: 03/08/18</p> <p>BY: JG</p>	<p>REV: 1</p> <p>DATE: 03/08/18</p> <p>BY: JG</p>

**ETMRD-003 Sht 3 REMOTE DISPLAY INSTALLATION**



2	DWG NO	UH1-ETMRD-003	SHT	3	REV	NC	1
REVISIONS							
REV	DESCRIPTION	PREPARED	DATE	APPROVED			
NC	INITIAL RELEASE	JG	3/6/18				

- NOTES:
1. ROUTE DISPLAY CABLE CONNECTOR THRU HOLE IN BRACKET.
  2. ROUTE / SECURE WIRING PER AC43.13-1B CHG 1. CHAPT. 11 SECT 8 PARA 11-105 THRU 11-121.
- ⚠ ETM1000 LRU MUST BE REV P OR GREATER TO ACCEPT REMOTE DISPLAY INTERFACE

REMOTE DISPLAY INSTALLATION  
 BELL MEDIUM

PROPRIETARY NOTICE THIS DRAWING MAY CONTAIN SPECIFICATIONS AND/OR DATA, TECHNICAL MATERIAL, PROPRIETARY DESIGN AND INFORMATION THAT ARE THE SOLE PROPERTY OF AKV INCORPORATED. THIS DRAWING IS TO BE USED ONLY FOR THE PURPOSES SPECIFIED HEREIN AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT PERMISSION IN WRITING FROM AKV INCORPORATED.		DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	PREPARED 3/9/18	PARTS LIST
DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	CHECKED 3/9/18	TITLE BELL MEDIUM REMOTE DISPLAY INSTALLATION	
DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	SHEET NO UH1-ETMRD-003	
DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	REV NC	
DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	DIMENSIONS ARE IN INCHES DECIMALS ARE 1/16" 1/32" 1/64" 1/8" 1/4" 3/8" 1/2" 5/8" 3/4" 7/8" 1"	SHEET 3 OF 3	

**ETMRD-003 Sht 1 REMOTE DISPLAY WIRING**

