

Multi-group mode By RS485:

do not need LV-HUB

Connect power cable first:

- 1) each pair of cable hold max 100A constant current. Connect enough pairs of cable based on calculation of system current.
- 2) Suitable protection breaker between battery system and inverter is



required.


- 3) Make sure all dip switch of master batteries are R0XX, then turn ON batteries.
R: is the baud rate of RS485 needed, all master batteries shall be the same.
- 4) After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.

The interruption of each RS485 command shall at least $\geq 1s$.

Multiple Battery Groups RS485 Communication Cable Connection


Max 6 groups

- 1) The A/CAN of 1st group/master battery connects to inverter or EMS(pin: 7A, 8B, **DO NOT connect other pins**)
- 2) The B connect to A of next group; the B/RS485 of last group master battery is empty.




Definition of RJ45 Port Pin

| | A/CAN | B/RS485 |
|------|---|------------------------|
| Pin1 | Shall be NULL. If not, may influence BMS function. | |
| Pin2 | | |
| Pin3 | | |
| Pin4 | CAN-H | CAN-H (single group) |
| Pin5 | CAH-L | CAN-L (single group) |
| Pin6 | CAN-GND | CAN-GND (single group) |
| Pin7 | 485A | 485A(recommended) |
| Pin8 | 485B | 485B(recommended) |



RJ45 Port



RJ45 Plug



PYLONTECH



Rechargeable Li-ion Battery

US3000C Operation Manual

UL version










Information Version: V1.0


5PMPA08-00221

This manual introduces US3000C from Pylontech. Please read this manual before you to install the battery and follow the instruction carefully during the installation process. Any confusion, please contact Pylontech immediately for advice and clarification.

| | |
|--|-----------|
| 1. Symbols in label, manual and product | 1 |
| 2. Safety / Sécurité | 2 |
| 3. Introduction | 9 |
| 3.1 Features | 9 |
| 3.2 Specifications | 11 |
| 3.3 Equipment interface instruction | 13 |
| 4. Safe handling of lithium batteries guide | 17 |
| 4.1 Schematic diagram of solution | 17 |
| 4.2 Danger label | 17 |
| 4.3 Tools | 18 |
| 4.4 Safety gear | 18 |
| 5. Installation and operation | 19 |
| 5.1 Package items | 19 |
| 5.2 Installation location | 21 |
| 5.3 Grounding | 22 |
| 5.4 Put into cabinet or racks | 23 |
| 5.5 Put into bracket | 25 |
| 5.6 Suitable breaker | 28 |
| 5.7 Power on | 29 |
| 5.8 Power off | 30 |
| 5.9 Multi-group mode | 31 |
| 6. Trouble shooting. | 33 |
| 7. Emergency Situations | 36 |
| 8. Remarks | 37 |

1. Symbols in label, manual and product

| | |
|---|--|
|  | Do not reverse connection the positive and negative. N'inversez pas la connexion positive et négative. |
|  | Do not place near open flame. Ne pas placer près d'une flamme nue. |
|  | Do not place at the children and pet touchable area. Ne placez pas l'appareil dans la zone de contact des enfants et des animaux domestiques. |
|  | Warning electric shock. Avertissement de choc électrique. |
|  | Warning Fire. Do not place near flammable material Avertissement d'incendie. Ne placez pas à proximité de matériaux inflammables. |
|  | Read the product and operation manual before operating the battery system! Lisez le produit et le manuel d'utilisation avant d'utiliser le système de batterie! |
|  | Grounding. Système de mise à la terre. |
|  | Recycle label. |
|  | The certificate label for EMC. |

| | |
|---|---|
|  | Label for Waste Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU) |
|  | The certificate label for Safety by TÜV Rheinland. |
|  | The certificate label for Safety by CSA |

2. Safety / Sécurité

The US3000C is operated by authorized person only. Read all safety instructions carefully prior to any work and observe them at all times when working on with the system.

US3000C opéré uniquement par le personnel autorisé. Lisez attentivement toutes les instructions de sécurité avant tout travail et respectez-les à tout moment lorsque vous travaillez avec le système

Incorrect operation or work may cause:

- 1) Injury or death to the operator or a third party
- 2) Damage to the system hardware and other properties belonging to the operator or a third party.

Une opération ou un travail incorrect peut causer:

- 1) *blessure ou mort à l'opérateur ou à un tiers;*
- 2) *Dommage au matériel du système et à d'autres propriétés appartenant à l'opérateur ou à un tiers.*

Qualified personnel must have the following skills:

- 1) Training in the installation and commissioning of the electrical system, as



well as the dealing with hazards






- 2) Knowledge of the manual and other related documents
- 3) knowledge of the local regulations and directives.

Le personnel qualifié doit avoir les compétences suivantes:

- 1) *Formation en matière d'installation et de mise en service du système électrique, et de gestion des risques;*
- 2) *Connaissance du manuel et d'autres documents concerné;*
- 3) *Connaissance des réglementations et directives locales.*

Symbol /Symbole

| | | |
|--|----------------------------------|--|
|  | <p>Danger Danger</p> | <p>Lethal voltage! <i>Tension mortelle!</i></p> <p>Battery strings will produce high voltage DC power and can cause a lethal voltage and an electric shock.</p> <p><i>La batterie produira un courant continu à haute tension et peuvent provoquer une tension mortelle et un choc électrique.</i></p> <p>Only qualified person can perform the wiring of the battery strings.</p> <p><i>Seule le personnel qualifié peut effectuer le câblage de la batterie.</i></p> |
|  | <p>Warning Avertissement</p> | <p>Risk of battery system damage or personal injury <i>Risque d'endommagement du système de batterie ou de blessure corporelle</i></p> <p>DO not pull out the connectors while the system is working!</p> <p><i>NE PAS debrancher les connecteurs lorsque le système fonctionne!</i></p> <p>De-energize from all multiple power sources and verify that there is no voltage.</p> <p><i>Mettez hors tension toutes les sources d'alimentation et vérifiez qu'il n'y a pas de tension.</i></p> |

| | | |
|--|--|---|
|  | Caution <i>Attention</i> | Risk of battery system failure or life cycle reduces. <i>Risque de défaillance ou de réduction de durée de vie du système de batterie.</i> |
|  | Read the product and operation manual before operating the battery system! <i>Lisez le manuel du produit avant d'utiliser le système de batterie!</i> | |
|  Li-ion |   | |

| | |
|---|---------------|
|  | Danger |
|---|---------------|

Batteries deliver electric power, resulting in burns or a fire hazard when they are short circuited, or wrongly installed.

Les piles fournissent de l'énergie électrique, ce qui entraîne des brûlures ou un risque d'incendie lorsqu'elles sont court-circuitées ou mal installées.

Lethal voltages are present in the battery terminals and cables. Severe injuries or death may occur if the cables and terminals are touched.

Des tensions mortelles sont présentes dans les bornes et les câbles de la batterie. Des blessures graves, voire mortelles, peuvent survenir si les câbles et les bornes sont touchés

Do not connect battery with PV solar wiring directly

Ne pas connecter directement la batterie avec le câblage solaire PV

It is prohibited to connect the battery and AC power directly

Il est interdit de connecter directement la batterie avec l'alimentation CA

In case of fire, only dry powder fire extinguisher can be used, liquid fire extinguishers are prohibited

En cas d'incendie, seul un extincteur à poudre sèche peut être utilisé, les

extincteurs à liquide sont interdits



Warning

Do not open or deform the battery module; It is prohibited to disassemble the battery (QC tab removed or damaged)

Ne pas ouvrir ou déformer le module de batterie; Il est interdit de démonter la batterie (langette QC retirée ou endommagée)

For battery installation, the installer shall refer to NFPA70 standard for operation.

Lors du montage extérieur de la batterie, le montage doit être réalisé conformément à la Norme NFPA70

Do not expose cable outside

Ne pas exposer le câble à l'extérieur

Any foreign object is prohibited to insert into any part of battery.

Il est interdit d'insérer aucun objet étranger dans aucune partie de la batterie

Do not expose battery to flammable or harsh chemicals or vapors; Keep the battery away from water and fire.

Ne pas exposer la batterie à des produits chimiques inflammables ou agressifs ou vapeurs ; Gardez la batterie loin de l'eau et du feu.

The embedded BMS in the battery is designed for 48VDC, please DO NOT connect battery in series



Caution

Improper settings or maintenance can permanently damage the battery.
Incorrect inverter parameters will lead to the premature aging of battery

Le réglage ou la maintenance incorrecte peuvent endommager en permanence la batterie. Les paramètres de l'inverseur incorrects entraîneront un vieillissement prématuré de la batterie.

Battery needs to be recharged within 12 hours, after fully discharged

La batterie doit être rechargée dans les 12 heures, après avoir été complètement déchargée

Do not use cleaning solvents to clean battery

Ne pas utiliser des solvants de nettoyage pour nettoyer la batterie

Do not paint any part of battery, include any internal or external components

Ne pas peindre aucune partie de la batterie, y compris les composants internes ou externes

Please contact the supplier within 24 hours if there is something abnormal.

The warranty claims are excluded for direct or indirect damage due to items above.

After unpacking, please check product and packing list first, if product is damaged or lack of parts, please contact with the local retailer

Please ensure the electrical parameters of battery system are compatible to related equipment, such as charger, inverter or load.

Make sure the settings on inverter are correct for US3000C.

If possible, check the communication between battery system and inverter is working normally



Caution before connecting

Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode

Avant l'installation, assurez-vous de couper l'alimentation du réseau et assurez-vous que la batterie est éteinte

Wiring must be correct, do not mistake the positive and negative cables, and ensure no short circuit with the external device

Le câblage doit être correct, ne pas confondre les câbles positif et négatif, et éviter tout court-circuit avec l'appareil externe

Battery system must be well grounding and the resistance must be less than 0.1Ω

Le système de batterie doit être bien mis à la terre et la résistance doit être inférieure à 0.1Ω



Caution in using

If the battery system needs to be moved or repaired, the power must be cut off and the battery is completely shut down

Si la batterie doit être déplacée ou réparée, l'alimentation doit être coupée et la batterie doit être complètement arrêtée

It is prohibited to connect the battery with different type of battery

Il est interdit de connecter la batterie à une batterie de différent type

Please do not open, repair or disassemble the battery except staffs from Pylontech or authorized by Pylontech. We do not undertake any consequences or related responsibility which because of violation of safety operation or violating of design, production and equipment safety standards

Veillez ne pas ouvrir, réparer ou démonter la batterie, à l'exception du personnel de Pylontech ou autorisé par Pylontech. Nous n'assumons aucune conséquence ou responsabilité connexe qui, en raison d'une violation des opérations de sécurité ou d'une violation des normes de conception, de production et de sécurité de l'équipement.

3. Introduction

US3000C lithium iron phosphate battery is the new energy storage products developed and produced by Pylontech, it can be used to provide reliable power for various types of equipment and systems.

US3000C has built-in BMS battery management system, which can manage and monitor cells information including voltage, current and temperature.

3.1 Features

- 1) NEW: Build-in soft-start function able to reduce current strike when inverter need to start from battery.
- 2) NEW: Dual active protection on BMS level.
- 3) NEW: Automatic address setting when connect in multi-group.
- 4) NEW: Support wake up by 5~12V signal from RJ45 port.
- 5) NEW: Support upgrade battery module from upper controller via CAN or RS485 communication.
- 6) NEW: Enable 95% depth of discharge, available for the inverter which completely follow Pylontech latest protocol to operate.
- 7) The module is non-toxic, non-polluting and environmentally friendly
- 8) Cathode material is made from LiFePO_4 with safety performance and long cycle life
- 9) Battery management system (BMS) has protection functions including over-discharge, over-charge, over-current and high/low temperature
- 10) The system can automatically manage charge and discharge state and balance voltage of each cell
- 11) Flexible configuration, multiple battery modules can be in parallel for expanding capacity and power
- 12) Adopted self-cooling mode rapidly reduced system entire noise
- 13) The module has less self-discharge, up to 6 months without charging it on shelf, no memory effect, excellent performance of shallow charge and

discharge

- 14) Small size and light weight, standard of 19-inch embedded designed module is comfortable for installation and maintenance
- 15) Compatible with the US2000C, US3000, and US2000.

*Mixture using master battery priority:


US3000C>US2000C>US3000>US2000

For same type of module always use the latest production unit as master.

*Mixture using battery deployment option:

| | |
|---|-------------------------------|
| Master battery (1 st) | US3000C/US2000C |
| Slave 2 nd ~8 th | US3000C/US2000C/US3000/US2000 |
| Slave 9 th ~16 th | US3000C/US2000C |

3.2 Specifications




| Basic Parameters | US3000C |
|-----------------------|-------------|
| Nominal Voltage (V) | 48 |
| Nominal Capacity (Wh) | 3552 |
| Usable Capacity (Wh) | 3374.4 |
| Dimension (mm) | 442*420*132 |
| Weight (Kg) | 32 |
| Discharge Voltage (V) | 44.5 ~ 53.5 |
| Charge Voltage (V) | 52.5 ~ 53.5 |

| | |
|---|---|
| Recommend Charge/Discharge Current (A) | 37 |
| Max. Charge/Discharge Current (A) | 74-89@60sec |
| Peak Charge/Discharge Current (A) | 90~200@15sec |
| Communication | RS485, CAN |
| Depth of discharge (%) | 95 |
| Configuration (max. in 1 battery group) | 16pcs |
| Working Temperature (°C) | 0°C~50°C Charge |
| | -10°C~50°C Discharge |
| Shelf Temperature (°C) | -20~60 |
| Short current/duration time | <4000A/2ms |
| Cooling type | Natural |
| Protective class | I |
| IP rating of enclosure | IP20 |
| Humidity (% RH) | 5 ~ 95(No Condensation) |
| Altitude(m) | <4000 |
| Certification | TÜV / CE / UN38.3/UL |
| Design life (year) | 15+(25°C/77°F) |
| Cycle Life (cycle)* | >8,000 25°C |
| Reference to standards | IEC62619, IEC63056, IEC62040, IEC62477-1, UL1973, UL1642, UL9540A, VDE2510-50, IEC61000-6-2, IEC61000-6-3, UN38.3 |

* Cycle Life is defined based on specific operation conditions, for more details please check with Pylontech service team.

3.3 Equipment interface instruction



Power Switch

ON: ready to turn on.

OFF: power off. For storage or shipping.

Start

Turn on: press more than 0.5s to start the battery module

Turn off: press more than 0.5s to turn off the battery.

RUN

Green LED lighting to show the battery running status

Alarm

Red LED flashing to show the battery has alarm; lighting to show the battery is under protection.

SOC

6 green LEDs to show the battery's current capacity.

ADD Switch




Dip1: RS485 baud rate: 1: 9600; 0: 115200. After change, please restart battery.

Dip2: CAN terminal resistance on BMS side. 1: NONE. 0: connected. After change, no restart required. **In single group mode, please keep dip2 at 0 position.** For multi-groups, please refer to [5.9].

Dip3~4, reversed.

Based on design of BMS, the dip switch is deployed physically reversely.

For instance:

| Dip1 | Dip2 | Dip3 | Dip4 | The corresponding position of switch | Status |
|------|------|------|------|---|--|
| 0 | 0 | 0 | 0 |  | RS485:115200 CAN terminal resistance: connected |
| 1 | 0 | 0 | 0 |  | RS485:9600 CAN terminal resistance: connected |
| 0 | 1 | 0 | 0 |  | RS485: 115200 CAN terminal resistance: NONE |

Console

For manufacturer or professional engineer to debug or service.

| | |
|---|---------------------|
| Pin3 | 232-TX |
| Pin4* | +5~+12V for wake up |
| Pin5* | GND for wake up |
| Pin6 | 232-RX |
| Pin8 | 232-GND |
| *Wake up signal shall $\geq 0.5\text{Sec}$, current between 5~15mA. After send wake up signal, the voltage shall disappear for normal operation. | |

Contact

| | | |
|------|---|---|
| Pin1 | Input, passive signal. On: turn off battery. Off: normal. | |
| Pin2 | | |
| Pin3 | Output1. On: stop charge. | + |
| Pin4 | | - |
| Pin5 | Output2. On: stop discharge. | + |
| Pin6 | | - |
| Pin7 | Output3. On: BMS error. | + |

| | | |
|------|--|---|
| Pin8 | | - |
|------|--|---|

Output request signal voltage $\leq 25V$

CAN

500 Kbps. 120 Ω recommended. For connection to LV-HUB, inverter, or upper battery.

RS485


9600 or 115200 bps. 120 Ω recommended. For connection to inverter, or slave battery.

Link Port 0, 1

for communication between multiple parallel batteries.

Definitions of RJ45 Port Pin

| | A/CAN | B/RS485 |
|------|--|------------------------|
| Pin1 | These pins shall be NULL. If not, may influence communication between BMS and inverter. | |
| Pin2 | | |
| Pin3 | | |
| Pin4 | CAN-H | CAN-H (single group) |
| Pin5 | CAH-L | CAN-L (single group) |
| Pin6 | CAN-GND | CAN-GND (single group) |
| Pin7 | NA | 485A |
| Pin8 | NA | 485B |




RJ45 Port



RJ45 Plug

Power Terminals

Power cable terminals: there are two pair of terminals with same function, one connects to equipment, the other one paralleling to other battery module for capacity expanding.



















Caution

Must keep pressing the “Lock Button” while pulling out the power plug.

Vous devez continuer à appuyer sur le « Bouton de verrouillage » tout en retirant la fiche d'alimentation.

LED Status Indicators


| Condition | RUN | ALR | 1 | 2 | 3 | 4 | 5 | 6 |
|---|--|---|---|---|---|---|---|---|
| Power off | - | - | - | - | - | - | - | - |
| Power on |  |  |  |  |  |  |  |  |
| Idle/Normal |  | - | - | - | - | - | - | - |
| Charge |  | - | Show soc; highest LED flash on: 0.5s; off 0.5s | | | | | |
| Discharge |  | | Show soc | | | | | |
| Alarm | ALR:  ; Other LEDs are same as above. | | | | | | | |
| System error/Protect | - |  | - | - | - | - | - | |
|  | ON | | | | | | | |
|  | flash, on: 0.3s; off: 3.7s | | | | | | | |
|  | flash, on:0.5s; off: 1.5s | | | | | | | |

BMS basic function


| Protection and alarm | Management and monitor |
|--------------------------------|--------------------------------|
| Charge/Discharge End | Cells Balance |
| Charge Over Voltage | Intelligent Charge Model |
| Discharge Under Voltage | Charge/Discharge Current Limit |
| Charge/Discharge Over Current | Capacity Retention Calculate |
| High/Low Temperature(cell/BMS) | Administrator Monitor |
| Short Circuit | Operation Record |
| | Power Cable Reverse |
| | Soft start of inverter |

4. Safe handling of lithium batteries guide









4.1 Schematic diagram of solution



4.2 Danger label



DANGER
DANGER LOW DC VOLTAGE INSIDE
FAIBLE TENSION DE COURANT CONTINU À L'INTÉRIEUR
DANGER ARC FLASH & SHOCK HAZARD
DANGER D'ARC ÉLECTRIQUE ET DE RISQUE D'ÉLECTROCUTION



- * Do not disconnect, disassemble or repair by yourself.
Ne pas débrancher, démonter ou réparer soi-même.
- * Do not drop, deform, impact, cut or spearing with a sharp object.
Ne pas échapper, déformer, frapper, couper ou transpercer avec un objet pointu.
- * Do not place near open flame or incinerate.
Ne pas placer près des flammes nues ou incinérer.
- * Do not sit or put heavy things on battery.
Ne pas s'asseoir ou mettre des objets lourds sur la batterie
- * Keep away from moisture or liquid.
Tenir loin de l'humidité ou de tout liquide.
- * Keep out of reach of children, animals or insects.
Garder hors de la portée des enfants, des animaux ou des insectes.
- * Maximum voltage / Tension maximale : 54 V
- * In case of fire, only dry powder fire extinguisher can be used, liquid fire extinguishers are prohibited.
En cas d'incendie, seul un extincteur à poudre sèche peut être utilisé, les extincteurs à liquide sont interdits

4.3 Tools



Wire cutter



Crimping modular plier



Screwdriver

NOTE

Use properly insulated tools to prevent accidental electric shock or short circuits. If insulated tools are not available, cover the entire exposed metal surfaces of the available tools, except their tips, with electrical tape.

4.4 Safety gear

It is recommended to wear the following safety gear when dealing with the battery pack



Insulated gloves



Safety goggles



Safety shoes

5. Installation and operation

5.1 Package items


Unpacking and check the Packing List

1) For battery module package:


- Battery Module



- Two 4AWG power cables and one RJ45 communication cable



- 10AWG grounding cable




2) For External cable kits:

NOTE

Power and communication cables to connect to inverter belongs to an **External Cable Kit**, **NOT include in battery carton box**. They are in another **extra small cable box**. If there is anything missed please contact dealer.

Two power cables (4 AWG, peak current capacity **120A**, constant **100A**) and communication cable for each energy storage system



For the external cables, the length shall less than 3 meters.

| SN of RJ45cable | Mark | Pin | |
|-----------------|--|------------------------------------|---|
| WI0SCAN30RJ1 | With blue mark: Battery-Inverter | Pin1~3: NULL Pin4~8: pin to pin | For connection to inverter |
| WI0SCAN35RJ3 | With silver mark: Battery-Battery | Pin1~8: pin to pin | For parallel connection between master batteries |

5.2 Installation location

Make sure that the installation location meets the following conditions:

- 1) The area is completely waterproof
- 2) The floor is flat and level.
- 3) There are no flammable or explosive materials.
- 4) The ambient temperature is within the range from 0°C to 50°C.
- 5) The temperature and humidity are maintained at a constant level.
- 6) There is minimal dust and dirt in the area.
- 7) The distance from heat source is more than 2 meters.
- 8) The distance from air outlet of inverter is more than 0.5 meters.
- 9) The installation areas shall avoid of direct sunlight.
- 10) There are no mandatory ventilation requirements for battery module, but please avoid of installation in confined area. The aeration shall avoid of high salinity, humidity or temperature.



Caution

If the ambient temperature is outside the operating range, the battery pack stops operating to protect itself. The optimal temperature range for the battery pack to operate is 0°C to 50°C. Frequent exposure to harsh temperatures may deteriorate the performance and life of the battery pack.


Si la température ambiante est hors de la plage de température de service, la batterie cesse de fonctionner pour se protéger.

La plage de température optimale pour la batterie est de 0°C à 50°C. Une exposition fréquente à des températures rigoureuses peut détériorer la performance et la durée de vie de la batterie

5.3 Grounding

Grounding cables shall be 10AWG or higher yellow-green cables. After connection, the resistance from battery grounding point to Ground connection point of room or installed place shall smaller than 0.1Ω.

- 1) based on metal directly touch between the module's surface and rack's surface. If using painted rack the corresponding place shall remove the painting.
- 2) install a grounding cable to the grounding point of the modules.



Warning

Grounding is necessary.

La mise à la terre est nécessaire.


5.4 Put into cabinet or racks

Put battery modules into cabinet and connect the cables:




- 1) Put the battery into the cabinet
- 2) Drive the 4 pcs screws
- 3) Connect the cables between battery modules

4) Connect the cables to inverter



5.5 Put into bracket



1) Dismantle the 2 holders of battery.

1. Dismantle the 2 tabs on the battery.




2) Put the battery into 2 pcs of bracket.

2. Set the battery into 2 pcs **Bracket** from front and back.



3) Use 4 location holes, stack the batteries together. And connect the 4 locker together.





4) Maximum 4 in stack.



NOTE

All the installation and operation must follow local electric standard.

L'installation et l'opération doivent respecter les normes électriques locales.

After installation, do not forget to register online for full warranty:

<http://www.pylontech.com.cn/service/support>



Warning

The power cables' current capacity is 120A max. If the battery string's design current over 100A, it must configure 2 pare external power cables to extend current capacity

La capacité de courant des câbles d'alimentation est de 120 A. Si le courant de conception de la chaîne de batterie est supérieur à 100 A, il est nécessaire d'utiliser au moins 2 paires de câbles d'alimentation externes pour étendre la capacité de courant.

Follow local electric safety and installation policy, a suitable manual disconnecting device (breaker, etc.) between battery system and inverter could be required.

Respectez la politique locale de sécurité électrique et d'installation, un dispositif de déconnexion manuel approprié (disjoncteur, etc.) entre le système de batterie et l'onduleur peut être nécessaire.

5.6 Suitable breaker


- 1) The rated voltage shall $\geq 60V$ DC. Do **NOT** use AC breaker.
- 2) The type of breaker shall be type C (recommended) or type D.
- 3) The rated current shall match with system design:
shall consider the DC current on inverter side.
the number of power cable: for instance, if only one pair of 4awg cable, the rated current of breaker shall be 125A or smaller.
- 4) The Icu required:
the short circuit current for calculation of each module is 2500A. for instance:

| | Icu of breaker |
|-------------|------------------|
| 1~4 modules | Must $\geq 10kA$ |
| 5~8 modules | Must $\geq 20kA$ |


5.7 Power on

Double check all the power cable and communication cable.

- 1) Switch on all the battery modules:



- 2) The one with **empty Link Port 0** is the **Master Battery Module**, others are slaves (1 master battery configure with maximum 15 slave batteries):



- 3) Press the **red SW button** of **master battery** to power on, all the battery LED light will be on one by one from the Master battery:



Note:

- 1) After the battery module powered on, the soft-start function takes **3sec** to active. After soft-starts battery ready to output high power.
- 2) During capacity expansion or replacement, when parallel different SOC/voltage of module together, please maintain the system in idle for ≥ 15 mins or till the SOC LEDs becomes similar (≤ 1 dot difference) before normal operation.

5.8 Power off

- 1) Turn external power source off.
- 2) Press red SW switch of master battery. Then all batteries will off.
- 3) Switch Power switch OFF.

5.9 Multi-group mode

By RS485: DO NOT need LV-HUB.

Connect power cable first:

- 1) each pair of cable hold max 100A constant current. Connect enough pairs of cable based on calculation of system current.
- 2) Suitable protection breaker between battery system and inverter is required.




- 3) Make sure all dip switch of master batteries are **R0XX**, then turn ON batteries.
R: is the baud rate of RS485 needed, all master batteries shall be the same.
- 4) After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.

The interruption of each RS485 command shall at least $\geq 1s$.

Multiple Battery Groups RS485 Communication Cable Connection

Max 6 groups


- 1) The A/CAN of 1st group/master battery connects to inverter or EMS(pin: 7A, 8B, DO NOT connect other pins)
- 2) The B connect to A of next group; the B/RS485 of last group master battery is empty.



By CAN:

Connect power cable first:

- 1) each pair of cable hold max 100A constant current. Connect enough pairs of cable based on calculation of system current.
- 2) Suitable protection breaker between battery system and inverter is required.
- 3) connect power cable of LV-HUB




- 4) Make sure all dipswitch is X0XX, then turn ON batteries.
- 5) After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.
- 6) Change the dip switch of **master battery in group1** to X1XX. Then connect communication cable between LV-HUB and master battery in group 1.
- 7) Then turn ON LV-HUB.

Detailed information please refer to manual of LV-HUB.

Multiple Battery Groups CAN Communication Cable Connection

Each Communication HUB connects maximum 6 battery piles.



Each battery pile can configure maximum 16pcs US2000C/US3000C.

6. Trouble shooting.

- Communication related problem

Unable to communicate with inverter on compatible list.

Possible conditions:

- 1) RS485: baud rate. Check the dip switch1, set to correct one, and restart. All master battery shall be the same.
- 2) CAN: terminal resistance. Check the dip switch2, set to 0 and retry.
- 3) CAN: pin. Try connect the CAN-H, L, GND only and do not connect other pins to inverter.

- Functional related problem

- 1) Whether the battery can be turned on or not
- 2) If battery is turned on, check the red light is off, flashing or lighting
- 3) If the red light is off, check whether the battery can be charged/discharged or not.

Possible conditions:

- 1) Battery cannot turn on, switch ON and press the red SW the lights are all no lighting or flashing.
- a) Capacity too low, or module over discharged.

solution: use a charge or inverter to provide 48-53.5V voltage. If battery can start, then keep charge the module and use monitor tools to check the battery log.

If battery terminal voltage is $\leq 45\text{Vdc}$, please use $\leq 0.05\text{C}$ to slowly charge the module to avoid affect to SOH.

If battery terminal voltage is $> 45\text{Vdc}$, it can use $\leq 0.5\text{C}$ to charge.

If battery cannot start, turn off battery and repair.

- 2) The battery can turn on, but red light is lighting, and cannot charge or discharge. If the red light is lighting, that means system is abnormal, please

check values as following

- b) Temperature: Above 60°C or under -10°C, the battery could not work.
Solution: to move battery to the normal operating temperature range between 0°C and 50°C
 - c) Current: If current exceeds 90A, battery protection will turn on.
Solution: Check whether current is too large or not, if it is, change the settings on power supply side.
 - d) High Voltage: If charging voltage above 54V, battery protection will turn on.
Solution: Check whether voltage is too high or not, if it is, to change the settings on power supply side. And discharge the module.
 - e) Low Voltage: When the battery discharges to 44.5V or less, battery protection will turn on.
Solution: Charge the battery till the red light turns off.
 - f) Cell voltage high. The module voltage is lower than 54V, SOC LED does not all on. When discharge the module protection disappear.
Solution: keep charge the module by 53-54V or keep the system cycle. The BMS can balance the cell during cycling.
- 3) Unable to charge and discharge with red LED on. The temperature is 0~50 degree. Use charger to charge, not possible. Use load to discharge, not possible.
- g) Under permanent protection. The single cell voltage has been higher than 4.2 or lower than 1.5 or temperature higher than 80 degrees. Solution: Switch off the module and contact your local distributor for repair.
- 4) Unable to charge and discharge without red LED on. The temperature is 0~50 degree. Use charger to charge, not possible. Use load to discharge, not possible.
- h) Fuse broken.
Solution: Switch off the module and contact your local distributor for repair.
- 5) Buzzer rings and **all LED flash**
- a) High voltage protection.

Cell voltage higher than 4V or module voltage higher than 55.5V.

Solution: **Battery system requires properly established communication with inverter and correctly settings on inverter to run safely.** Check the setting of the inverter or charger, the charge voltage shall be 53.2~52.5Vdc; Check the communication between battery system and inverter whether established or not; Check the ADD switch on battery module whether is set correctly or not;

Under this condition, the BMS remains functional without damage. Just leave the module switched OFF and wait for the battery voltage drop down naturally(15mins) then restart. If then no alarm comes out, this means the module is ready for work

6) Buzzer rings and **ALM solid red**

b) Reverse connection of cables.

Solution: Power off all battery and inverters. Disconnect breaker. Check the cable connection and disconnect all power cables. Check the power port damaged or not. Then try turn on the single module, without any cable connected. If no alarm, then it is reverse connection of cables. Switch off the module and contact your local distributor.

c) MOSFAIL.

Solution: Power off all battery and inverters. Disconnect breaker. Check the cable connection and disconnect all power cables. Check the power port damaged or not. Check the setting of inverter or charger, check the communication between inverter and battery system.

Try turn on the single module, without any cable connected. If still buzzer rings. Then switch off the module and contact your local distributor.

7) After switch On, the module turns on directly

d) BMS failure.

Solution : Switch off the module and contact your local distributor.

Excluding the points above, if the faulty still cannot be located, turn off battery and contact your local distributor.

7. Emergency Situations

1) Leaking Batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

- a) Inhalation: Evacuate the contaminated area and seek medical attention.
- b) Contact with eyes: Rinse eyes with flowing water for 15 minutes and seek medical attention.
- c) Contact with skin: Wash the affected area thoroughly with soap and water and seek medical attention.

Ingestion: Induce vomiting and seek medical attention.

2) Fire

NO WATER! Only dry powder fire or carbon dioxide extinguisher can be used; if possible, move the battery pack to a safe area before it catches fire.

3) Wet Batteries

If the battery pack is wet or submerged in water, do not let people access it, and then contact Pylontech or an authorized dealer for technical support. Cut off all power switch on inverter side.

4) Damaged Batteries

Damaged batteries are dangerous and must be handled with the utmost care. They are not fit for use and may pose a danger to people or property. If the battery pack seems to be damaged, pack it in its original container, and then return it to Pylontech or an authorized dealer.



Danger


Damaged batteries may leak electrolyte or produce flammable gas.

Les batteries endommagées peuvent laisser fuir l'électrolyte ou produire un gaz inflammable.

8. Remarks

Recycle and disposal

In case a battery (normal condition or damaged) needs disposal or needs recycling, it shall follow the local recycling regulation (i.e. Regulation (EC) N° 1013/2006 among European Union) to process, and using the best available techniques to achieve a relevant recycling efficiency.



Li-ion 

Storage, Maintenance and Expansion

- 1) It is required to charge the battery at least once every 12 months, for this charge maintenance make sure the SOC is charged to higher than 90%
- 2) Every year after installation. The connection of power connector, grounding point, power cable and screw are suggested to be checked. Make sure there is no loose, no broken, no corrosion at connection point. Check the installation environment such as dust, water, insect etc. make sure it is suitable for IP20 battery system.
- 3) If the battery is stored for long time, it is required to charge them every six months, and the SOC should be higher than 90%.
- 4) A new battery module can be added onto an existing system at any time. Please make sure the new battery is acting as the master. The new module,

due to a higher SOH may have a difference on SOC with existing system, but it will not affect the parallel connection system performance.



PYLONTECH

Pylon Technologies Co., Ltd.

5/F, No.71-72, Lane 887, ZuChongzhi Road, China (Shanghai) Pilot Free Trade Zone, Pudong, Shanghai 201203, China

T+86-21-51317699 | **F** +86-21-51317698

E service@pylontech.com.cn

W www.pylontech.com.cn



PYLONTECH



Rechargeable Li-ion Battery

US3000C Operation Manual










Information Version: V1.0




5PMPA08-00222

This manual introduces US3000C from Pylontech. Please read this manual before you to install the battery and follow the instruction carefully during the installation process. Any confusion, please contact Pylontech immediately for advice and clarification.

| | |
|--|-----------|
| 1. Symbols in label, manual and product | 1 |
| 2. Safety Precautions | 2 |
| 2.1 Before Connecting | 3 |
| 2.2 In Using | 3 |
| 3. Introduction | 4 |
| 3.1 Features | 4 |
| 3.2 Specification | 6 |
| 3.3 Equipment interface instruction | 8 |
| Definition of RJ45 Port Pin | 10 |
| 4. Safe handling of lithium batteries guide | 12 |
| 4.1 Schematic diagram of solution | 12 |
| 4.2 Danger label | 12 |
| 4.3 Tools | 13 |
| 4.4 Safety gear | 13 |
| 5. Installation and operation | 14 |
| 5.1 Package items | 14 |
| 5.2 Installation location | 16 |
| 5.3 Grounding | 17 |
| 5.4 Put into cabinet or racks | 18 |
| 5.5 Put into bracket | 20 |
| 5.6 Suitable breaker | 23 |
| 5.7 Power on | 23 |
| 5.8 Power off | 25 |
| 5.9 Multi-group mode | 26 |
| 6. Trouble shooting | 28 |
| 7. Emergency Situations | 31 |
| 8. Remarks | 32 |

1. Symbols in label, manual and product

| | |
|---|--|
|  | Caution! Warning! Reminding. Safety related information. Risk of battery system failure or life cycle reduces. |
|  | Do not reverse connection the positive and negative. |
|  | Do not place near open flame |
|  | Do not place at the children and pet touchable area. |
|  | Warning electric shock. |
|  | Warning Fire. Do not place near flammable material |
|  | Read the product and operation manual before operating the battery system! |
|  | Grounding. |
|  | Recycle label. |

| | |
|---|---|
|  | The certificate label for EMC. |
|  | Label for Waste Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU) |
|  | The certificate label for Safety by TÜV Rheinland. |

2. Safety Precautions



Reminding

- 1) It is important and necessary to read the user manual carefully (in the accessories) before installing or using battery. Failure to do so or to follow any of the instructions or warnings in this document can result in electrical shock, serious injury, or death, or can damage battery, potentially rendering it inoperable
- 2) If the battery is stored for long time, it is required to charge them every six months, and the SOC should be no less than 90%
- 3) Battery needs to be recharged within 12 hours, after fully discharged
- 4) Do not install the product in outdoor environment, or an environment out of the operation temperature or humidity range listed in manual.
- 5) Do not expose cable outside
- 6) Do not connect power terminal reversely.
- 7) All the battery terminals must be disconnected for maintenance
- 8) Please contact the supplier within 24 hours if there is something abnormal.
- 9) Do not use cleaning solvents to clean battery
- 10) Do not expose battery to flammable or harsh chemicals or vapors
- 11) Do not paint any part of battery, include any internal or external components

- 12) Do not connect battery with PV solar wiring directly
- 13) The warranty claims are excluded for direct or indirect damage due to items above.
- 14) Any foreign object is prohibited to insert into any part of battery



Warning

2.1 Before Connecting

- 1) After unpacking, please check product and packing list first, if product is damaged or lack of parts, please contact with the local retailer
- 2) Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode
- 3) Wiring must be correct, do not mistake the positive and negative cables, and ensure no short circuit with the external device
- 4) It is prohibited to connect the battery and AC power directly
- 5) The embedded BMS in the battery is designed for 48VDC, please DO NOT connect battery in series
- 6) Battery must connect to ground and the resistance must be less than 0.1Ω
- 7) Please ensured the electrical parameters of battery system are compatible to related equipment
- 8) Keep the battery away from water and fire.

2.2 In Using

- 1) If the battery system needs to be moved or repaired, the power must be cut off and the battery is completely shutdown
- 2) It is prohibited to connect the battery with different type of battery.
- 3) It is prohibited to connect batteries with faulty or incompatible inverter
- 4) It is prohibited to disassemble the battery (QC tab removed or damaged);
- 5) In case of fire, only dry powder fire extinguisher can be used, liquid fire

extinguishers are prohibited

- 6) Please do not open, repair or disassemble the battery except staffs from Pylontech or authorized by Pylontech. We do not undertake any consequences or related responsibility which because of violation of safety operation or violating of design, production and equipment safety standards.

3. Introduction

US3000C lithium iron phosphate battery is the new energy storage products developed and produced by Pylontech, it can be used to provide reliable power for various types of equipment and systems.

US3000C has built-in BMS battery management system, which can manage and monitor cells information including voltage, current and temperature.

3.1 Features

- 1) NEW: Build-in soft-start function able to reduce current strike when inverter need to start from battery.
- 2) NEW: Dual active protection on BMS level.
- 3) NEW: Automatic address setting when connect in multi-group.
- 4) NEW: Support wake up by 5~12V signal from RJ45 port.
- 5) NEW: Support upgrade battery module from upper controller via CAN or RS485 communication.
- 6) NEW: Enable 95% depth of discharge, available for the inverter which completely follow Pylontech latest protocol to operate.
- 7) The module is non-toxic, non-pollution and environmentally friendly
- 8) Cathode material is made from LiFePO₄ with safety performance and long cycle life
- 9) Battery management system (BMS) has protection functions including over-discharge, over-charge, over-current and high/low temperature
- 10) The system can automatically manage charge and discharge state and

balance voltage of each cell

- 11) Flexible configuration, multiple battery modules can be in parallel for expanding capacity and power
- 12) Adopted self-cooling mode rapidly reduced system entire noise
- 13) The module has less self-discharge, up to 6 months without charging it on shelf, no memory effect, excellent performance of shallow charge and discharge
- 14) Small size and light weight, standard of 19-inch embedded designed module is comfortable for installation and maintenance
- 15) Compatible with the US2000C, US3000, and US2000.

*Mixture using master battery priority:


US3000C>US2000C>US3000>US2000

For same type of module always use the latest production unit as master.

*Mixture using battery deployment option:

| | |
|---|-------------------------------|
| Master battery (1 st) | US3000C/US2000C |
| Slave 2 nd ~8 th | US3000C/US2000C/US3000/US2000 |
| Slave 9 th ~16 th | US3000C/US2000C |

3.2 Specifications




| Basic Parameters | US3000C |
|-----------------------|-------------|
| Nominal Voltage (V) | 48 |
| Nominal Capacity (Wh) | 3552 |
| Usable Capacity (Wh) | 3374.4 |
| Dimension (mm) | 442*420*132 |
| Weight (Kg) | 32 |
| Discharge Voltage (V) | 44.5 ~ 53.5 |
| Charge Voltage (V) | 52.5 ~ 53.5 |

| | |
|---|--|
| Recommend Charge/Discharge Current (A) | 37 |
| Max. Charge/Discharge Current (A) | 74-89@60sec |
| Peak Charge/Discharge Current (A) | 90~200@15sec |
| Communication | RS485, CAN |
| Depth of discharge (%) | 95 |
| Configuration (max. in 1 battery group) | 16pcs |
| Working Temperature (°C) | 0~50 Charge |
| | -10~50Discharge |
| Shelf Temperature (°C) | -20~60 |
| Short current/duration time | <4000A/2ms |
| Cooling type | Natural |
| Protective class | I |
| IP rating of enclosure | IP20 |
| Humidity (% RH) | 5 ~ 95 (No Condensation) |
| Altitude(m) | <4000 |
| Certifications | TÜV / CE / UN38.3/UL |
| Design life (year) | 15+ (25°C/77°F) |
| Cycle Life (cycle)* | >8,000 25°C |
| Reference to standards | IEC62619, IEC63056, IEC62040, IEC62477-1, UL1973,U1642,UL9540A, VDE2510-50, IEC61000-6-2, IEC61000-6-3, UN38.3 |

* Cycle Life is defined based on specific operation conditions, for more details please check with Pylontech service team.

3.3 Equipment interface instruction



Power Switch

ON: ready to turn on.

OFF: power off. For storage or shipping.

Start

Turn on: press more than 0.5s to start the battery module

Turn off: press more than 0.5s to turn off the battery.

RUN

Green LED lighting to show the battery running status

Alarm

Red LED flashing to show the battery has alarm; lighting to show the battery is under protection.

SOC

6 green LEDs to show the battery's current capacity.

ADD Switch




Dip1: RS485 baud rate: 1: 9600; 0: 115200. After change, please restart battery.

Dip2: CAN terminal resistance on BMS side. 1: NONE. 0: connected. After change, no restart required. **In single group mode, please keep dip2 at 0 position.** For multi-groups, please refer to [5.9].

Dip3~4, reversed.

Based on design of BMS, the dip switch is deployed physically reversely.

For instance:

| Dip1 | Dip2 | Dip3 | Dip4 | The corresponding position of switch | Status |
|------|------|------|------|---|---|
| 0 | 0 | 0 | 0 |  | RS485:115200 CAN terminal resistance: connected |
| 1 | 0 | 0 | 0 |  | RS485:9600 CAN terminal resistance: connected |
| 0 | 1 | 0 | 0 |  | RS485: 115200 CAN terminal resistance: NONE |

Console

For manufacturer or professional engineer to debug or service.

| | |
|---|---------------------|
| Pin3 | 232-TX |
| Pin4* | +5~+12V for wake up |
| Pin5* | GND for wake up |
| Pin6 | 232-RX |
| Pin8 | 232-GND |
| *Wake up signal shall $\geq 0.5\text{Sec}$, current between 5~15mA. After send wake up signal, the voltage shall disappear for normal operation. | |

Contact

| | | |
|------|---|---|
| Pin1 | Input, passive signal. On: turn off battery. Off: normal. | |
| Pin2 | | |
| Pin3 | Output1. On: stop charge. | + |
| Pin4 | | - |
| Pin5 | Output2. On: stop discharge. | + |
| Pin6 | | - |
| Pin7 | Output3. On: BMS error. | + |
| Pin8 | | - |

Output request signal voltage $\leq 25V$

CAN

500 Kbps. 120 Ω . For connection to LV-HUB, inverter, or upper battery.

RS485


9600 or 115200 bps. 120 Ω . For connection to inverter, or slave battery.

Link Port 0, 1

for communication between multiple parallel batteries.

Definition of RJ45 Port Pin

| | A/CAN | B/RS485 |
|------|--|------------------------|
| Pin1 | These pins shall be NULL. If not, may influence communication between BMS and inverter. | |
| Pin2 | | |
| Pin3 | | |
| Pin4 | CAN-H | CAN-H (single group) |
| Pin5 | CAH-L | CAN-L (single group) |
| Pin6 | CAN-GND | CAN-GND (single group) |
| Pin7 | 485A | 485A |
| Pin8 | 485B | 485B |



RJ45 Port




RJ45 Plug


















Power Terminals

Power cable terminals: there are two pair of terminals with same function, one connects to equipment, the other one paralleling to other battery module for capacity expanding.

For power cables uses water-proofed connectors. must keep pressing this Lock Button while pulling out the power plug.



LED Status Indicators


| Condition | RUN | ALR | 1 | 2 | 3 | 4 | 5 | 6 |
|---|--|---|---|---|---|---|---|---|
| Power off | - | - | - | - | - | - | - | - |
| Power on |  |  |  |  |  |  |  |  |
| Idle/Normal |  | - | - | - | - | - | - | - |
| Charge |  | - | Show soc; highest LED flash on: 0.5s; off 0.5s | | | | | |
| Discharge |  | | Show soc | | | | | |
| Alarm | ALR:  ; Other LEDs are same as above. | | | | | | | |
| System error/Protect | - |  | - | - | - | - | - | |
|  /  | ON | | | | | | | |
|  | flash, on: 0.3s; off: 3.7s | | | | | | | |
|  | flash, on:0.5s; off: 1.5s | | | | | | | |

BMS basic function


| Protection and alarm | Management and monitor |
|--------------------------------|--------------------------------|
| Charge/Discharge End | Cells Balance |
| Charge Over Voltage | Intelligent Charge Model |
| Discharge Under Voltage | Charge/Discharge Current Limit |
| Charge/Discharge Over Current | Capacity Retention Calculate |
| High/Low Temperature(cell/BMS) | Administrator Monitor |
| Short Circuit | Operation Record |
| | Power Cable Reverse |
| | Soft start of inverter |









4. Safe handling of lithium batteries guide

4.1 Schematic diagram of solution



4.2 Danger label

**DANGER**
DANGER LOW DC VOLTAGE INSIDE
DANGER ARC FLASH & SHOCK HAZARD



- * Do not disconnect or disassemble by non-professional personnel.
- * Do not drop, deform, impact, cut or spearing with a sharp object.
- * Do not place at a children or pet touchable area.
- * Do not place near open flame or flammable material.
- * Do not cover or wrap the product case.
- * Do not sit or put heavy things on battery.
- * Do not touch the leaking liquid.
- * Avoid of direct sunlight.
- * Avoid of moisture or liquid.
- * The product Ingress Protection (IP) class is IP20.
- * Make sure the grounding connection set correctly before operation.
- * Follow the product manual to make wiring connection.
- * If leaking, fire, wet or damaged, switch off the breaker on DC side and stay away from battery.
- * Contact your supplier within 24 hours if anything failure happens.

4.3 Tools



Wire cutter



Crimping modular plier



Screwdriver

NOTE

Use properly insulated tools to prevent accidental electric shock or short circuits. If insulated tools are not available, cover the entire exposed metal surfaces of the available tools, except their tips, with electrical tape.

4.4 Safety gear

It is recommended to wear the following safety gear when dealing with the battery pack



Insulated gloves



Safety goggles



Safety shoes

5. Installation and operation

5.1 Package items


Unpacking and check the Packing List

1) For battery module package:

- Battery Module



- Two 4AWG power cables and one RJ45 communication cable



- 10AWG grounding cable




2) For External cable kits:

NOTE

Power and communication cables to connect to inverter belongs to an **External Cable Kit, NOT include in battery carton box**. They are in another **extra small cable box**. If there is anything missed please contact dealer.

Two power cables (4 AWG, peak current capacity **120A**, constant **100A**) and communication cable for each energy storage system



For the external cables, the length shall less than 3 meters.

| SN of RJ45cable | Mark | Pin | |
|-----------------|--|------------------------------------|---|
| WI0SCAN30RJ1 | With blue mark: Battery-Inverter | Pin1~3: NULL Pin4~8: pin to pin | For connection to inverter |
| WI0SCAN35RJ3 | With silver mark: Battery-Battery | Pin1~8: pin to pin | For parallel connection between master batteries |

5.2 Installation location

Make sure that the installation location meets the following conditions:

- 1) The area is completely waterproof
- 2) The floor is flat and level.
- 3) There are no flammable or explosive materials.
- 4) The ambient temperature is within the range from 0°C to 50°C.
- 5) The temperature and humidity are maintained at a constant level.
- 6) There is minimal dust and dirt in the area.
- 7) The distance from heat source is more than 2 meters.
- 8) The distance from air outlet of inverter is more than 0.5 meters.
- 9) The installation areas shall avoid of direct sunlight.
- 10) There are no mandatory ventilation requirements for battery module, but please avoid of installation in confined area. The aeration shall avoid of high salinity, humidity or temperature.




Caution

If the ambient temperature is out of the operating range, the battery stops operating to protect itself. The optimal temperature range for the battery pack to operate is 10°C to 40°C. Frequent exposure to harsh temperatures may deteriorate the performance and life of the battery.

5.3 Grounding

Grounding cables shall be 10AWG or higher yellow-green cables. After connection, the resistance from battery grounding point to Ground connection point of room or installed place shall smaller than 0.1 Ω .

- 1) based on metal directly touch between the module's surface and rack's surface. If using painted rack, the corresponding place shall remove the painting.
- 2) install a grounding cable to the grounding point of the modules.




5.4 Put into cabinet or racks


Put battery modules into cabinet and connect the cables:



- 1) Put the battery into the cabinet
- 2) Drive the 4 pcs screws
- 3) Connect the cables between battery modules
- 4) Connect the cables to inverter



5.5 Put into bracket




1) Dismantle the 2 holders of battery.

1. Dismantle the 2 tabs on the battery.




2) Put the battery into 2 pcs of bracket.

2. Set the battery into 2 pcs **Bracket** from front and back.



3) Use 4 location holes, stack the batteries together. And connect the 4 locker together.





4) Maximum 4 in stack.



NOTE

After installation, do not forget to register online for full warranty:

<http://www.pylontech.com.cn/service/support>



Caution

- 1) Follow local electric safety and installation policies, a suitable breaker between battery system and inverter could be required.
- 2) All the installation and operation must follow local electric standards.

5.6 Suitable breaker


- 1) The rated voltage shall $\geq 60V$ DC. Do **NOT** use AC breaker.
- 2) The type of breaker shall be type C (recommended) or type D.
- 3) The rated current shall match with system design:
shall consider the DC current on inverter side.
the number of power cable: for instance, if only one pair of 4awg cable, the rated current of breaker shall be 125A or smaller.
- 4) The Icu required:
the short circuit current for calculation of each module is 2500A. for instance:

| | Icu of breaker |
|-------------|------------------|
| 1~4 modules | Must $\geq 10kA$ |
| 5~8 modules | Must $\geq 20kA$ |


5.7 Power on

Double check all the power cable and communication cable.

- 1) Switch on all the battery modules:



- 2) The one with **empty Link Port 0** is the **Master Battery** Module, others are slaves (1 master battery configure with maximum 15 slave batteries):



- 3) Press the **red SW button** of **master battery** to power on, all the battery LED light will be on one by one from the Master battery:



Note:

- 1) After the battery module powered on, the soft-start function takes **3sec** to active. After soft-starts battery ready to output high power.
- 2) During capacity expansion or replacement, when parallel different SOC/voltage of module together, please maintain the system in idle for ≥ 15 mins or till the SOC LEDs becomes similar (≤ 1 dot difference) before normal operation.

5.8 Power off

- 1) Turn external power source off.
- 2) Press red SW switch of master battery. Then all batteries will off.
- 3) Switch Power switch OFF.

5.9 Multi-group mode

By RS485: DO NOT need LV-HUB.

Connect power cable first:

- 1) each pair of cable hold max 100A constant current. Connect enough pairs of cable based on calculation of system current.
- 2) Suitable protection breaker between battery system and inverter is required.




- 3) Make sure all dip switch of master batteries are **R0XX**, then turn ON batteries.
R: is the baud rate of RS485 needed, all master batteries shall be the same.
- 4) After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.

The interruption of each RS485 command shall at least $\geq 1s$.

Multiple Battery Groups RS485 Communication Cable Connection

Max 6 groups


- 1) The A/CAN of 1st group/master battery connects to inverter or EMS(pin: 7A, 8B, **DO NOT connect other pins**)
- 2) The B connect to A of next group; the B/RS485 of last group master battery is empty.



By CAN:

Connect power cable first:

- 1) each pair of cable hold max 100A constant current. Connect enough pairs of cable based on calculation of system current.
- 2) Suitable protection breaker between battery system and inverter is required.
- 3) connect power cable of LV-HUB



- 4) Make sure all dipswitch is X0XX, then turn ON batteries.
- 5) After all batteries running and buzzer of master battery in group1 rings 3 times. Means all groups are online.
- 6) Change the dip switch of **master battery in group1** to X1XX. Then connect communication cable between LV-HUB and master battery in group 1.
- 7) Then turn ON LV-HUB.

Detailed information please refer to manual of LV-HUB.

Multiple Battery Groups CAN Communication Cable Connection

Each Communication HUB connects maximum 6 battery piles.



- 1) The CAN IN connects to port 0
- 2) The A/CAN connects to port 1~7 freely
- 3) The B connect to A of next group: the B/RS485 of last group master battery is empty.



Master Battery Group 1



Master Battery Group 2



Master Battery Group 3



Master Battery Group N, max 6

Each battery pile can configure maximum 16pcs US2000C/US3000C.

6. Trouble shooting

- Communication related problem

Unable to communicate with inverter on compatible list.

Possible conditions:

- 1) RS485: baud rate. Check the dip switch1, set to correct one, and restart. All master battery shall be the same.
- 2) CAN: terminal resistance. Check the dip switch2, set to 0 and retry.
- 3) CAN: pin. Try connect the CAN-H, L, GND only and do not connect other pins to inverter.

- Functional related problem

- 1) Whether the battery can be turned on or not
- 2) If battery is turned on, check the red light is off, flashing or lighting
- 3) If the red light is off, check whether the battery can be charged/discharged or not.

Possible conditions:

- 1) Battery cannot turn on, switch ON and press the red SW the lights are all no lighting or flashing.
- a) Capacity too low, or module over discharged.

solution: use a charge or inverter to provide 48-53.5V voltage. If battery can start, then keep charge the module and use monitor tools to check the battery log.

If battery terminal voltage is $\leq 45\text{Vdc}$, please use $\leq 0.05\text{C}$ to slowly charge the module to avoid affect to SOH.

If battery terminal voltage is $> 45\text{Vdc}$, it can use $\leq 0.5\text{C}$ to charge.

If battery cannot start, turn off battery and repair.

- 2) The battery can turn on, but red light is lighting, and cannot charge or discharge. If the red light is lighting, that means system is abnormal, please

check values as following

- b) Temperature: Above 60°C or under -10°C, the battery could not work.
Solution: to move battery to the normal operating temperature range between 0°C and 50°C
 - c) Current: If current exceeds 90A, battery protection will turn on.
Solution: Check whether current is too large or not, if it is, change the settings on power supply side.
 - d) High Voltage: If charging voltage above 54V, battery protection will turn on.
Solution: Check whether voltage is too high or not, if it is, to change the settings on power supply side. And discharge the module.
 - e) Low Voltage: When the battery discharges to 44.5V or less, battery protection will turn on.
Solution: Charge the battery till the red light turns off.
 - f) Cell voltage high. The module voltage is lower than 54V, SOC LED does not all on. When discharge the module protection disappear.
Solution: keep charge the module by 53-54V or keep the system cycle. The BMS can balance the cell during cycling.
- 3) Unable to charge and discharge with red LED on. The temperature is 0~50 degree. Use charger to charge, not possible. Use load to discharge, not possible.
- g) Under permanent protection. The single cell voltage has been higher than 4.2 or lower than 1.5 or temperature higher than 80 degrees. Solution: Switch off the module and contact your local distributor for repair.
- 4) Unable to charge and discharge without red LED on. The temperature is 0~50 degree. Use charger to charge, not possible. Use load to discharge, not possible.
- h) Fuse broken.
Solution: Switch off the module and contact your local distributor for repair.
- 5) Buzzer rings and **all LED flash**
- i) High voltage protection.

Cell voltage higher than 4V or module voltage higher than 55.5V.

Solution: **Battery system requires properly established communication with inverter and correctly settings on inverter to run safely.** Check the setting of the inverter or charger, the charge voltage shall be 53.2~52.5Vdc; Check the communication between battery system and inverter whether established or not; Check the ADD switch on battery module whether is set correctly or not;

Under this condition, the BMS remains functional without damage. Just leave the module switched OFF and wait for the battery voltage drop down naturally(15mins) then restart. If then no alarm comes out, this means the module is ready for work

6) Buzzer rings and **ALM solid red**

j) Reverse connection of cables.

Solution: Power off all battery and inverters. Disconnect breaker. Check the cable connection and disconnect all power cables. Check the power port damaged or not. Then try turn on the single module, without any cable connected. If no alarm, then it is reverse connection of cables. Switch off the module and contact your local distributor.

k) MOSFAIL.

Solution: Power off all battery and inverters. Disconnect breaker. Check the cable connection and disconnect all power cables. Check the power port damaged or not. Check the setting of inverter or charger, check the communication between inverter and battery system.

Try turn on the single module, without any cable connected. If still buzzer rings. Then switch off the module and contact your local distributor.

7) After switch On, the module turns on directly

l) BMS failure.

Solution : Switch off the module and contact your local distributor.

Excluding the points above, if the faulty still cannot be located, turn off battery and contact your local distributor.

7. Emergency Situations

1) Leaking Batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. If one is exposed to the leaked substance, immediately perform the actions described below.

- a) Inhalation: Evacuate the contaminated area and seek medical attention.
- b) Contact with eyes: Rinse eyes with flowing water for 15 minutes and seek medical attention.
- c) Contact with skin: Wash the affected area thoroughly with soap and water and seek medical attention.

Ingestion: Induce vomiting and seek medical attention.

2) Fire

NO WATER! Only dry powder fire or carbon dioxide extinguisher can be used; if possible, move the battery pack to a safe area before it catches fire.

3) Wet Batteries

If the battery pack is wet or submerged in water, do not let people access it, and then contact Pylontech or an authorized dealer for technical support. Cut off all power switch on inverter side.

4) Damaged Batteries

Damaged batteries are dangerous and must be handled with the utmost care. They are not fit for use and may pose a danger to people or property. If the battery pack seems to be damaged, pack it in its original container, and then return it to Pylontech or an authorized dealer.




Caution

Damaged batteries may leak electrolyte or produce flammable gas.

8. Remarks

Recycle and disposal

In case a battery (normal condition or damaged) needs disposal or needs recycling, it shall follow the local recycling regulation (i.e. Regulation (EC) N° 1013/2006 among European Union) to process, and using the best available techniques to achieve a relevant recycling efficiency.



Li-ion 

Storage, Maintenance and Expansion

- 1) It is required to charge the battery at least once every 12 months, for this charge maintenance make sure the SOC is charged to higher than 90%
- 2) Every year after installation. The connection of power connector, grounding point, power cable and screw are suggested to be checked. Make sure there is no loose, no broken, no corrosion at connection point. Check the installation environment such as dust, water, insect etc. make sure it is suitable for IP20 battery system.
- 3) If the battery is stored for long time, it is required to charge them every six months, and the SOC should be higher than 90%.
- 4) A new battery module can be added onto an existing system at any time. Please make sure the new battery is acting as the master. The new module, due to a higher SOH may have a difference on SOC with existing system, but it will not affect the parallel connection system performance.



PYLONTECH

Pylon Technologies Co., Ltd.

5/F, No.71-72, Lane 887, ZuChongzhi Road, China (Shanghai) Pilot Free Trade Zone, Pudong, Shanghai 201203, China

T+86-21-51317699 | **F** +86-21-51317698

E service@pylontech.com.cn

W www.pylontech.com.cn

Residential BESS

US Series

Powercube X Series



Safety and Reliability

Ensured by by self-designed and manufactured cell, modules and BMS



Optimal Electricity Cost

Long cycle life and superior performance



Compact Size & Easy Installation

Module design for quick installation




Easy to Scale Up

Multi-groups in parallel to expand the capacity.



Compatibility


Compatible with Top inverter brands



How to save on bill from Residential ESS?

Self-Consumption Optimization


High energy demand in the morning and evening but solar energy generation is most sufficient during the Mid-Day. Battery storage system balances the feeding and demands. Realize your grid independence.



Benefits from Peak Shaving

House: Load Shifting

Store energy during off-peak and use energy at peak-time. Save on the electricity bills by reducing peak demand.



VPP Revenue

VPP creates a network of renewable energy sources and battery storage systems, connected through a cloud-based technology that manages the stability of clean electricity to maximize your revenue.

Enabling a cost reduction, as well as boosting the system's efficiency



SPECIFICATION (48V)



| Model | | US2000C | US3000C | US5000 |
|-----------------------------|-------------------|--|---|---|
| Basic Parameters | | | | |
| Nominal Voltage (Vdc) | | 48 | 48 | 48 |
| Nominal Capacity(kWh) | | 2.4 | 3.55 | 4.8 |
| Usable Capacity(kWh) | | 2.28 | 3.37 | 4.56 |
| Dimension(mm) | | 442*410*89 | 442*410*132 | 442*420*161 |
| Weight(kg) | | 22.5 | 32 | 39.7 |
| | (Recommend) | 25 | 37 | 80* |
| Charge/ | (Max. Continuous) | 25 | 37 | 100* |
| Discharge Current(A) | (Peak 1) | 50~89@60sec | 74~89@60sec | 101~120@15min |
| | (Peak 2) | 90~200@15sec | 90~200@15sec | 121~200@15sec |
| Communication Port | | | RS485,CAN | |
| Single string quantity(pcs) | | 16 | 16 | 16 |
| Working Temperature/ °C | Charge | 0~50 | | |
| Working Temperature/ °C | Discharge | -10~50 | | |
| Shelf Temperature/ °C | | -20~60 | | |
| Short current/duration time | | <4000A/2ms | <4000A/2ms | <2000A/1ms |
| IP rating | | | IP20 | |
| Cooling type | | | Natural | |
| Humidity | | | 5% ~ 95%(RH) No Condensation | |
| Altitude(M) | | | <4000 | |
| Design life | | 15+ Years (25 °C /77 °F) | 15+ Years (25 °C /77 °F) | 15+ Years (25 °C /77 °F) |
| Cycle Life | | >8,000 25 °C | >8,000 25 °C | > 8,000 25 °C |
| Certification | | UL1642/ IEC62619 /ICE63056 /ICE61000-6-2/3 UN38.3 | UL1973 /UL1642 /UL9540A/VDE2510-50 /IEC63056/IEC62619 /IEC62040/IEC62477-1 /ICE61000-6-2/UN38.3 | UL1973/UL9540A IEC62619/IEC63056 /ICE61000-6-2/3 /UN38.3 |

SPECIFICATION (96~864V)



Powercube X1/H1



Powercube X2/H2

| Battery Model | Powercube X1/H1 | Powercube X2/H2 |
|---|--------------------------------|--------------------------------|
| Data Parameter | | |
| Battery Module | H48050 | H48074 |
| Battery Module Voltage(Vdc) | 48 | 48 |
| Battery Module Capacity(Ah) | 50 | 74 |
| Battery Module Capacity(kWh) | 2.4 | 3.55 |
| Dimension (W*D*H mm) | 442*390*100 | 442*390*132 |
| Weight(kg) | 24 | 32 |
| Configuration (Max. in 1 battery group) | 2~18 | 2~18 |
| Battery System Voltage(V) | 864 | 864 |
| Battery System Capacity(Ah) | 50 | 74 |
| Battery System Capacity(kWh) | 43.2 | 63.9 |
| Depth of Discharge | 95% | |
| Efficiency(@0.5C-rate) | 96% | |
| Communication | Modbus RTU/CAN | |
| Short circuit rating/Duration | <3000 2ms | |
| IP rating | IP 20 | |
| Operation Temperature(℃) | 0~50℃ | |
| Shelf Temperature(℃) | -20~60℃ | |
| Humidity | 5%~95% | |
| Design Life | 15+ Years (25℃/77℉) | |
| Cycle Life | > 8,000 25℃ | > 8,000 25℃ |
| Multi-Group | Max. 6 systems in parallel | |
| Certification | IEC62619/VDE2510-50 /CE/CEC | IEC62619/VDE2510-50 /CE/CEC |