

# Maintenance Manual Neuver Maritime

## Frydenbö IRV-2 Steering Gear

Doc. no. DMN000285831				
Rev.	Date	Reason for issue	Author, dept. and name	Authorizing dept. name, sign
D	26 MAY 2025	Change to Neuver Maritime layout template. Removed chap. 13	Ø.B, E.K	

# Table of Contents

1. Introduction .....	5
2. Maintenance Overview.....	5
3. Safety.....	7
3.1. General statement.....	7
3.2. Safety Annotations.....	8
4. Steering Gear Actuator and Power Pack.....	9
4.1. Steering Gear system errors not detected by the Automatic Isolation system .....	12
5. Docking Related Service and Maintenance task.....	14
5.1. Service and maintenance intervals.....	16
5.2. Tools Needed.....	17
5.3. Weight of Cover and Rotor.....	17
6. Routine Maintenance tasks .....	18
7. Oil Recommendations .....	23
8. System Oil Volume .....	25
9. Grease Recommendation for Stuffing Box.....	26
10. Tightening Torque for Bolts .....	27
11. Maintenance Instructions .....	29
11.1. Oil Sampling.....	30
11.2. Venting.....	31
11.3. Filling and Refilling of Oil.....	32
11.4. Maneuvering Time Test .....	33
11.5. Replacement of Gland Seals .....	34
11.6. Replacement of Filter Element .....	36
11.7. Replacement of Flexible Coupling in Pump Unit .....	37
11.8. Adjustment of Haenni Contents Gauge .....	38
11.9. Cleaning of Water/Oil Cooler .....	41
11.10. Cleaning of Air/Oil Cooler.....	42
11.11. FB40 Feedback Inspection.....	44
11.12. Stuffing Box (if NEUVER MARITIME delivery).....	46
11.13. Function Test of Alarm System .....	47
11.14. Function Test of IMO System.....	49
11.15. Adjustment of Rudder Angle Indicator System.....	55
11.16. Adjustment of Rudder Angle Indicator Amplifier (if NEUVER MARITIME delivery) .....	56
11.17. Adjustment of Limit Switches in Feedback Unit.....	57
11.18. Adjustment of Amplifier Card (if NEUVER MARITIME delivery).....	58
11.19. Adjustment of FU-Controller (if NEUVER MARITIME delivery) .....	59
11.20. Replacement of Alarm System Card.....	60
11.21. Replacement of Pump Control Card.....	61
11.22. Replacement of Amplifier Card.....	62
11.23. Replacement of Selector Card .....	63

11.24. Replacement of Start Relay.....	64
11.25. Replacement of Start Relay.....	65
11.26. Replacement of Limit Switches in Feedback Units .....	66
11.27. Replacement of Proximity Switch .....	67
12. Troubleshoot Hydraulic Lock Alarm (Only AS02) .....	69
13. Spare parts.....	70
13.1. Spare Part Kits and Items .....	72
13.2. Pump Spare Parts and Overhaul Procedure .....	73
14. Contact .....	78

# 1. Introduction

This manual provides the Neuver Maritime maintenance recommendations and instructions for all Frydenbö IRV-2 type Steering Gears. Pictures and illustrations used in this manual may deviate from the equipment on board your vessel. All recommendations are provided in relation to general Class requirements and guidelines.

The NEUVER MARITIME IMO Steering Gear (IRV) fulfils the single failure criteria of IMO for tankers over 100 000 DWT. The IRV Steering Gears comprise two identical power actuating systems separated with a double hydraulic sealing system within a single housing.

# 2. Maintenance Overview

Neuver Maritime (NM) Steering Gears are designed for safe operation with a minimum maintenance need. However, to prevent unexpected problems or downtime, it is recommended that the users maintain the Steering Gear system at regular intervals.

For scheduled class survey and general service or repair, it is recommended to use Neuver Maritime service engineers. This will decrease the time of repair to a minimum and ensure continuous safe operation.

This document describes all relevant maintenance procedures and activities to be carried out by the crew, in addition to the maintenance recommended to be performed by Neuver Maritime service engineers. Any other information may be found in the Steering Gear USER MANUAL or by contacting [support@neuver.com](mailto:support@neuver.com).

The IRV Steering Gears are of robust design and by following the recommended maintenance schedule, long and reliable operation is secured. However, after a certain number of years in operation, it is necessary to overhaul the equipment and change internal wear parts. The internal wear parts mainly consist of internal seals, radial bearings (linings) and axial bearings (thrust bearing). The overhaul interval is dependent on factors such as:

- Weight of rudder and rudderstock.
- Alignment of rudderstock and Steering Gear.
- Radial forces from rudder and the operation profiles of the Steering Gear.
- Oil temperature and oil condition.
- Number of operating hours.
- Other conditions such as DP operations that will generate more wear than steaming.

The condition of most wear parts is possible to detect by visual inspection or testing. However, the thrust bearing, for example, can normally only be inspected by draining oil from the actuator and opening the top cover to physically measure the clearance under the rotor. For some of the new generation actuators there is a measuring device available, as an option, for control of the thrust bearing without draining oil and removal of the top cover.

Although the internal wear parts are designed to last well in excess of 5 years, it is wise to use the opportunity during the regular class survey dockings to confirm the Steering Gear internal condition. If more than half worn, it should be considered if the parts can last until next planned docking.

Monitoring the condition and performance of the equipment and taking notice of any changes is important in order to reveal any problems developing before a breakdown occurs.

**NOTE!**

It is requested that any failures or maintenance work on the equipment, no matter how small, should be reported to Neuver Maritime at; [support@neuver.com](mailto:support@neuver.com)

By reporting any failures or maintenance work, an accurate equipment history is maintained. This history can continuously be monitored and compared to other vessels with similar equipment. With this information, NEUVER MARITIME can provide better service, faster delivery of spare parts and guidance for preventive maintenance of the products.

## 3. Safety

Please take the time to read this chapter carefully, as it concerns your safety.

### 3.1. General statement

"UNDERTAKING ANY WORK ENVISAGED BY THIS DOCUMENT MAY EITHER DIRECTLY OR INDIRECTLY CREATE RISKS TO:

[1] THE SAFETY AND HEALTH OF THE PERSON UNDERTAKING THE WORK  
OR,

[2] THE PRODUCT AND/OR ITS COMPONENTS WHILST THE WORK IS BEING UNDERTAKEN.

IT IS THE RESPONSIBILITY OF THE USER TO ENSURE THAT APPROPRIATE CONTROLS AND PRECAUTIONS ARE IDENTIFIED AND APPLIED IN RELATION TO THE WORK ENVISAGED BY THIS DOCUMENT IN ACCORDANCE WITH RELEVANT STATUTORY, LEGAL AND INDUSTRY REQUIREMENTS TO PROTECT THE HEALTH AND SAFETY OF THE PERSONS UNDERTAKING THE WORK.

IT IS ALSO THE USER'S RESPONSIBILITY TO ENSURE THAT APPROPRIATE CONTROLS AND PRECAUTIONS ARE IDENTIFIED AND APPLIED IN RELATION TO WORK ENVISAGED BY THIS DOCUMENT TO PROTECT AGAINST RISKS TO THE NEUVER MARITIME STEERING GEAR AND/OR ITS COMPONENTS WHILST THE WORK IS BEING UNDERTAKEN.

NEITHER THIS DOCUMENT, NOR ITS USE, IN ANY WAY ABSOLVES THE USER FROM THEIR RESPONSIBILITY TO ENSURE THAT THE CONTROLS AND PRECAUTION REFERRED TO ABOVE ARE IMPLEMENTED.

IF, WHILST UNDERTAKING ANY WORK ENVISAGED BY THIS DOCUMENT, YOU BECOME AWARE OF ANY NEUVER MARITIME PRODUCT DESIGN RELATED FEATURE WHICH COULD CREATE RISK TO A PERSON UNDERTAKING WORK OR TO THE PRODUCT AND/OR ITS COMPONENTS PLEASE CONTACT THE RESPECTIVE TECHNICAL PRODUCT MANAGER AT NEUVER MARITIME IMMEDIATELY."

### 3.2. Safety Annotations

All safety directions must be respected in order to avoid damage to personnel, environment and equipment. In this document the following annotations are used with belonging significance:



#### **WARNING!**

Indicates possibilities for hazards or unsafe practices, which **COULD** result in fatal or severe personnel injuries or substantial product or property damage, if the required precautions are not taken.


#### **NOTE!**

Draws attention to specific information of technical significance, which might not be obvious to specialist personnel, or points at important remarks in the procedures to follow.

## 4. Steering Gear Actuator and Power Pack

The main components of the IRV Steering Gear are illustrated below. The rotor, turning in bearings at top and bottom, is equipped with vanes upon which the oil pressure is acting and thereby developing turning torque. The turning movement is limited by stoppers fixed to the housing. The stoppers also act as mechanical rudder stoppers in hard-over position. In addition to the stoppers, the actuator is equipped with electrical limit switches stopping the turning movement at a predetermined angle.

The rudder carrier bearing of the actuator has sufficient capacity to carry the full weight of rudder, rudderstock and rotor, eliminating the need for a separate rudder carrier bearing. The bearing is lubricated by the system oil. The sealing system consists of synthetic oil resistant material resting in seal grooves. The sealing system prevents both internal and external leakage.



The IRV Steering Gear comprise two identical actuator power systems separated by a double sealing system. In addition, the IRV Steering Gear consists of a double set of valves:

- Control valves (Power Pack)
- Lock valves (Actuator)
- Isolating valves (Actuator)
- Safety Relief/By-pass valves (Actuator)

The Control valve is activated according to command and initiate rudder movement. The Lock valve on the actuator is opened by an increase of external pressure. A loss of external pressure will cause the lock valve to close, keeping the actuator intact for operation by


means of the stand-by pump if necessary. The Interconnecting/Isolating valves connect the two power actuating systems during normal operation. If one of the systems are defect, the Interconnecting/Isolating valve will isolate the systems and enable the intact system to continue with normal operation. The Safety Relief/By-pass valve protect against excessive external pressure transmitted from the rudder and will by-pass the defect system if necessary.

The Power Pack consists of two pump units operated separately or combined. Each pump unit provides oil with sufficient flow to develop the specified rudder angle. One pump unit is normally in operation, while the other is acting as a stand-by unit. However, it is possible to run both pump units simultaneously and thereby doubling the turning rate when shortest possible steering time is required. The pump unit are normally remotely controlled but may also be controlled manually at the Control valve on the Power Pack in the Steering Gear room.

### Emergency steering – automatic isolation

The IMO-function of the IRV Steering Gear is activated when a significant loss of hydraulic oil in one of the systems is detected. In this case, emergency steering mode is automatically activated.

Detection is done by the electrical level switches located in the hydraulic Power Pack tank, illustrated in the figure below.



For a situation where the system starts to loose oil, the following alarms and actions will develop:

Case 1: Both pump units in operation	Case 2: One pump unit in operation
<ol style="list-style-type: none"> <li>1. Common Oil Level switch is activated; Low Oil Level alarm will appear.</li> <li>2. Low Oil Level switch is activated; Isolation valves will be activated and closed, separating system 1 and 2.</li> <li>3. Steering continues with both systems.</li> <li>4. Low Low Oil Level switch is activated on defect system; by-pass valve on defect system activated. Automatic stop of pump unit on defect system will not occur. Pump unit on defect system must be stopped.</li> </ol>	<ol style="list-style-type: none"> <li>1. Common Oil Level switch is activated; Low Oil Level alarm will appear.</li> <li>2. Low Oil Level switch is activated; Isolation valves will be activated and closed, separating system 1 and 2. Pump 2 will start automatically!</li> <li>3. Steering continues with both systems.</li> <li>4. Low Low Oil Level switch is activated on defect system; by-pass valve on defect system activated. Automatic stop of pump unit on defect system will not occur. Pump unit on defect system must be stopped.</li> </ol>

#### 4.1. Steering Gear system errors not detected by the Automatic Isolation system

### Scenario

1

#### **Rudder response is very poor or non-existent**

1. Separate system by pressing “MANUAL ISOLATION”. Both Pump 1 and Pump 2 will now be running. Press “Manual By-pass System 1” and stop Pump 1.  
Give rudder command from Steering Control system.
2. Outcome;  
Rudder response POSITIVE: Failure in system 1. Rudder response NEGATIVE: Failure in system 2.
3. Continue operation with “MANUAL ISOLATION” activated.  
Failed system should be kept closed.
4. Torque capacity is reduced to 50% of maximum.

**Cause:** By-pass valve may be locked in OPEN position.

### Scenario

2

#### **System works normally until “Automatic Isolation” is activated by loss of hydraulic oil**

1. System working as normal.
2. Loss of hydraulic oil from system.  
“Automatic Isolation” will separate system 1 and system 2.
3. Outcome – loss of steering!  
Defect system will be identified by “Low Low Oil Level” alarm.
4. Press “MANUAL ISOLATION”.  
Continue operation – Check situation in Steering Gear room!

**Cause:** By-pass valve may be locked in CLOSED position.

### Scenario

3

#### **System works normally until “Automatic Isolation” is activated by loss of hydraulic oil**

1. System working as normal.
2. Loss of hydraulic oil from system.  
“Automatic Isolation” will separate system 1 and system 2.
3. Outcome; Steering continues with system 1 and system 2 working separately.
4. Defect system will be detected automatically and isolated depending on which system is losing oil.

**Cause:** One Isolating valve may be locked in OPEN position.

---

## Scenario

### 4

**System works normally until “Automatic Isolation” is activated by loss of hydraulic oil**

1. System working as normal.
2. Loss of hydraulic oil from system.  
“Automatic Isolation” will separate system 1 and system 2.
3. Outcome; Separation fails for line affected by failing isolation valves.
4. Check situation in Steering Gear room!

**Cause:** Both Isolating valves on same line may be locked in OPEN position.

---

## Scenario

### 5

**System running with one pump only**

1. Loss of steering.
2. Press “MANUAL ISOLATION”. Pump 2 will start automatically.
3. Outcome; system will work as “normal”.  
Continue operation with both pumps in parallel.

**Cause:** One or more Isolating Valves may be locked in CLOSED position.

---

## 5. Docking Related Service and Maintenance task

Please see below intervals for service and maintenance recommended in relation to scheduled class surveys or docking.

Service and maintenance	5 YEAR	10 YEAR	15 YEAR	20 YEAR	25 YEAR
<b>Actuator*</b>					
Internal seal kit	x	x	x	x	x
Cover gasket	x	x	x	x	x
Gland set	x	x	x	x	x
Bleed plugs & bonded seals	x	x	x	x	x
Liners		x		x	
Thrust bearing**	x**	x	x**	x	x**
Pressure valve		x		x	
<b>Power Pack*</b>					
Flexible coupling	x	x	x	x	x
Filter and filter seal	x	x	x	x	x
Pump overhaul	x	x	x	x	x
O-ring return pipe and bend	x	x	x	x	x
Tank cover gasket	x	x	x	x	x
Hydraulic hose cooler ***		x		x	
Seal kit valves	x		x		x
Overhaul kit IMO-valves		x		x	
O-ring and plugs for hydraulic nut	x**	x	x**	x	x**
Stuffing box seals ***		x		x	
Water cooler ***		x		x	

\* Recommended to be carried out in dry dock/port, by Neuver Maritime service engineers.

\*\* For RV/IRV4200-2, the thrust bearing is recommended to be replaced every 5 year.

\*\*\* If installed by Neuver Maritime.

x - Service or maintenance interval is depending on factors such as weight of rudder/rudderstock, alignment of rudderstock/Steering Gear, radial forces from rudder and the operation profile of the Steering Gear.

### **Steering Gear Performance Monitoring System (SG PMS):**

The purpose of the performance monitoring system is to continuously monitor, process and record performance and operation parameters of the Steering Gear and provide an alarm when degraded or irregular performance detected. The SG PMS solution is available as an upgrade on all **RV Steering Gear installations completed in 2005 or later with NM Follow-up control system.**

## 5.1. Service and maintenance intervals

---

### 5 years

**Service and maintenance recommendations:**

- Open rudder actuator for inspection and measure clearances. Replace all accessible internal seals and upper gland seals.
- Power Pack: Replace filter, flexible coupling, tank cover gasket and carry out pump overhaul.

---

### 10 years

**Recommended service and maintenance according to above table, and previous service history.**

- Open rudder actuator, secure rudderstock and remove rotor. Replace all internal seals, bearings, upper and lower gland seals and pressure valves.
- Power Pack: Replace filter, flexible coupling, tank cover gasket and carry out pump overhaul.

---

### 15 years

**Service and maintenance recommendations**

- Open rudder actuator for inspection and measure clearances. Replace all accessible internal seals and upper gland seals
- Power Pack: Replace filter, flexible coupling, tank cover gasket and carry out pump overhaul.

---

### 20 years

**Recommended service and maintenance according to above table, and previous service history:**

- Open rudder actuator, secure rudderstock and remove rotor. Replace all internal seals, bearings, upper and lower gland seals and pressure valves.
- Power Pack: Replace filter, flexible coupling, tank cover gasket and carry out pump overhaul.

---

### 25 years

**Service and maintenance recommendations:**

- Open rudder actuator, secure rudderstock and remove rotor. Replace all internal seals, bearings, upper and lower gland seals and pressure valves.
  - Power Pack: Replace filter, flexible coupling, tank cover gasket and carry out pump overhaul.
-

## 5.2. Tools Needed

The information below describes tools needed when servicing the Steering Gear, and the weight of actuator cover and rotor.

5 Year Service	10 Year Service
<ul style="list-style-type: none"> <li>• Lifting equipment for removal of cover</li> <li>• Hydraulic torque wrench 500 - 3700Nm</li> <li>• Equipment for draining oil from the actuator</li> </ul>	<ul style="list-style-type: none"> <li>• 2 High pressure pumps with gauges. Minimum 1000 bar.</li> <li>• Dial gauge</li> <li>• Hydraulic torque wrench 500 - 3700Nm</li> <li>• Equipment for draining oil from the actuator</li> <li>• Lifting equipment for removal of cover and rotor</li> <li>• Hydraulic cylinder and hand pump to secure the rudder</li> <li>• Liquid nitrogen for replacement of liners</li> </ul>

## 5.3. Weight of Cover and Rotor

Actuator Type	Cover	Rotor
IRV 900-2	1100 kg	3400 kg
IRV 1400-2	1100 kg	4800 kg
IRV 2050-2	2145 kg	7100 kg
IRV 2700-2	2145 kg	8950 kg
IRV 3050-2	2830 kg	8850 kg
IRV 4200-2	2830 kg	11650 kg

See chapter [8 System Oil Volume](#)

See chapter [10 Tightening Torque for Bolts](#)

## 6. Routine Maintenance tasks

The maintenance instructions below details all preventative maintenance activities to be carried out by the Crew on a regular basis. Please add below tasks to applicable vessel maintenance system.

System (a)	Sub-System (b)	Part (c)	Maintenance Task (d)	Maint (e)	Freq (f)	Type (g)	Skill Level (h)	Facility (i)
Steering Gear system		Actuator	Check for any leakage around the Steering Gears inboard part.	Prev	1 day	CHK	A	A
Steering Gear system		Actuator	Check surface temperature of the equipment( pipes from pumps)	Prev	1 day	CHK	A	A
Steering Gear system		Actuator	Check for abnormal vibrations/noises on the equipment.	Pre	1 day	CHK	A	A
Steering Gear system		Actuator	Check that there are no leakage from Stuffing Box (if delivered by NM)	Prev	1 wk	CHK	A	A
Steering Gear system	Hydraulic System	Oil Tank	Check oil level in the Power Pack and top up if necessary	Prev	1 wk	CHK	A	A
Steering Gear system	Hydraulic System	Standby Pump	Start/stop standby pump	Prev	1 wk	TST	A	A
Steering Gear system	Hydraulic System	Duplex Filter	Check filter blockage indicators, change filter element if necessary.	Prev	1 wk	CHK	A	A
Steering Gear system		Actuator	Lubricate seals on Stuffing Box according to procedure (if delivered by NM). If using EAL grease, lubricate every 2 weeks	Prev	2 wk/ 1 mth	LUB	A	A

System (a)	Sub-System (b)	Part (c)	Maintenance Task (d)	Maint (e)	Freq (f)	Type (g)	Skill Level (h)	Facility (i)
Steering Gear system			Cleaning of Steering Gear unit and surroundings	Prev	1 mth	CL	A	A
Steering Gear system	Hydraulic System		Perform test of Steering Gear modes, Emergency Steering and normal steering from all stations.	Prev	1 mth	TST	A	A
Steering Gear system		Actuator	Test and verify electrical and mechanical limit switch function.	Prev	1 mth	TST	A	A
Steering Gear IMO system	Hydraulic System		Perform test of all valves and IMO-functions to avoid non-detectable system errors.	Prev	1 mth	TST	A	A
Steering Gear system	Hydraulic System	Actuator	Check maneuvering time according to SOLAS (30 to 0 to 35 degree)	Prev	1 mth	CHK	A	A
Steering Gear system		Actuator	Check for any paint work and damages	Prev	1 mth	CHK	A	A
Steering Gear system	Controls System	Control Panels	Make sure that all electrical indications push buttons back light bulbs are ok	Prev	1 mth	CHK	A	A
Steering Gear system	Hydraulic System		Check filter indicator, If filter alarm or the filter indicator is in the red zone, replace the filter element.	Prev	1 mth	FC	A	A
Steering Gear system	Alarm System	Alarms	Function test of alarm system according to manual.	Prev	1 mth	CHK	A	A
Steering Gear system		Coolers	Visual inspection of coolers (if applicable)	Prev	6 mth	CHK	A	A

System (a)	Sub-System (b)	Part (c)	Maintenance Task (d)	Maint (e)	Freq (f)	Type (g)	Skill Level (h)	Facility (i)
Steering Gear system	Hydraulic System		Collect sample of hydraulic oil from the actuator	Prev	6 mth	SAM	A	A
Steering Gear system	Hydraulic System	Power Pack	Replace filters	Prev	1 yr	REP	A	A
Steering Gear system	Intercom system	Steering Gear room	Check communication system between Steering Gear room and the bridge.	Prev	1 yr	CHK	A	A
Steering Gear system	Controls System	Electric Motor	Megger test electric motors	Prev	1 yr	MEG	A	A
Steering Gear system	Control System	EI system	Perform a visual check of all Electrical components, earings, cable connections.	Prev	1 yr	INSP	A	A
Steering Gear system	EI system	EI system	Replace vibration dampers (if applicable)	Prev	5 yr	REP	A	A

### Column description:

- Columns **a**, **b** & **c** illustrate the hierarchical relationship between the components/sub-assemblies (column c) on which maintenance is performed and the high level module (column a).
- Column **d** describes the maintenance activity.
- Column **e** identifies the maintenance activity as either Preventative or Corrective.
- Column **f** details the frequency of the maintenance activity.
- Column **g** groups the maintenance activity into a category which facilitates the rapid analysis of the maintenance data, eg one can search on OC to identify when the equipment underwent an oil change.
- Column **h** identifies which skill level is required for the maintenance activity.
- Column **i** identifies what facility is required for the maintenance activity.

**Maintenance type:**

Abbreviation	Description
BC	Bearing Change
CHK	Check
CL	Clean
FC	Filter Change
FLU	Flush
INSP	Inspect
LUB	Lubricate
MEA	Measure
MEG	Megger
OC	Oil Change
OVH	Overhaul
REP	Replace
NM OVH	Neuver Maritime Overhaul
SAM	Sample
TST	Test

**Skill level and facilities:**


The skill levels indicate the skill level of the person responsible for the maintenance task. The facility indicates the physical location of the vessel during the maintenance procedure.

The skill level and facility codes are:

- Maintenance Level A is general operational maintenance carried out by the ship's crew on board, with no additional support or facilities.
- Maintenance Level B is maintenance carried out in port, using ship's crew and local port supplied support and facilities.
- Maintenance Level C is maintenance carried out in dry dock, requiring specialist Neuver Maritime support.
- Maintenance Level D is repair and overhaul activities undertaken in a Neuver Maritime specialist workshop.

### Steering Gear and Power Pack Illustrations:

Below illustrations show where the different critical parts are found on the Steering Gear and Power Pack unit. Please note that the illustrations can deviate from the equipment on board your vessel.



## 7. Oil Recommendations

### WARNING!

- Using oil other than specified by NEUVER MARITIME may cause malfunctions when maneuvering the vessel. This can cause personal injury and equipment damage. Before using other brands, please contact Neuver Maritime.
- Do not mix hydraulic oils.

### NOTE!

*Oil temperature must be limited to 70°C.*

For vessels operating worldwide, NEUVER MARITIME recommend oil according to ISO-VG 68. Viscosity Index of minimum 110.

*Only use oil approved and recommended by NEUVER MARITIME.*

The performance of the unit is highly depended on the viscosity of the oil. The surrounding temperatures of the hydraulic components when operating at extreme temperature conditions, tropic or arctic waters, must be considered when selecting type of oil.

The oil must be checked regularly for contamination and the relevant oil company and NEUVER MARITIME recommendation for oil change must be followed. Change the oil if components in the hydraulic system are broken down or if significant color or smell change occurs. If laboratory tests show a change in the number of additives or a high number of insoluble particles in the oil, oil change is required. If the water content exceeds 300ppm, a separator or similar for water removal should be applied.

The following hydraulic oils are approved and recommended by Neuver Maritime:

Manufacturer	Oil type	Viscosity Index	Kinematic Viscosity [cSt]			Pour point [°C]
			0°C	40°C	100°C	
CASTROL	HYSPIN AWH-m 68	150	580	68	10,9	- 39
TOTAL	VISGA 68	155	700	73	11,7	- 36
ESSO	UNVIS N 68	155	560	66	10,7	- 36
GULF	GULFSEA HYDRAULIC HVI PLUS 68	148	-	68,9	-	- 30
MOBIL	MOBIL DTE 10 EXCEL 68	156	-	68,4	11,17	- 39

Manufacturer	Oil type	Viscosity Index	Kinematic Viscosity [cSt]			Pour point [°C]
			0°C	40°C	100°C	
NYNÄS	HYDOL 68	150	500	58	9,6	- 39
SHELL	TELLUS S2 VX 68	143	-	68	10,5	- 30
TEXACO	RANDO HDZ 68	181	500	69	12,3	- 36
FUCHS	HYDRAWAY HVXA 68	172	-	62	11,0	- 39
FUCHS	RENOLIN B 68 HVI	153	-	68	11,0	-36

For storage of hydraulic oil, follow practice recommended from the relevant oil company. All oil drums must be stored in horizontal position with oil cap below the maximum level indicator.

For the hydraulic oil circulating in the Steering Gear, it is highly recommended to keep the cleanliness within 20/18/15 according to ISO 4406-1999 (comparable to NAS 1638 or SAE AS 4059 class 9). If oil cleanliness is no longer within the above limits, renew the filter elements.

## 8. System Oil Volume

Model type	Oil volume
IRV 900-2	Approx. 270 litre
IRV 1400-2	Approx. 470 litre
IRV 2050-2	Approx. 680 litre
IRV 2700-2	Approx. 880 litre
IRV 3050-2	Approx. 800 litre
IRV 4200-2	Approx. 1050 litre

### Oil volume for Power Pack – approximate values:

Power Pack	Oil volume
PPS 2" Small	Approx. 2x 300 litre
PPSI 2" Small	Approx. 2x 300 litre + 450 litre
PPS 2"	Approx. 2x 500 litre
PPSI 2"	Approx. 2x 500 litre + 1100 litre
PPS 3" Small	Approx. 2X 700 litre
PPSI 3" Small	Approx. 2x 700 litre + 1450 litre
PPS 3"	Approx. 2x 1000 litre
PPSI 3"	Approx. 2x 1000 litre + 1850 litre
PPS 3" Large	Approx. 2x 1400 litre
PPSI 3" Large	Approx. 2x 1400 litre + 2850 litre

## 9. Grease Recommendation for Stuffing Box

### Standard Grease:

The following standard greases are approved and recommended for use in the Stuffing Box delivered by Neuver Maritime:

Manufacturer	Oil type
SHELL	GADUS S3 AI300 C2
MOBILITH	SHC 460
FUCHS	RENOLIT GREASEWAY CAH 92

### EAL Grease:

The following EAL (Environmentally Acceptable Lubricants) greases are approved and recommended for use in the Stuffing Box delivered by Neuver Maritime:

Manufacturer	Oil type
KLUBERBIO	AG39-602 N
KLUBERBIO	BM 32-142
CASTROL	BIOTAC MP

## 10. Tightening Torque for Bolts

### NOTE!

Make sure to follow recommended tightening torque and friction coefficient as described below.

A friction coefficient  $\mu = 0,15$  - normally oiled threads, is assumed in the calculations of the preceding tightening torques. For other values of the friction coefficient, the tightening torques should be adjusted accordingly.

### Torque for bolts with normally oiled threads:

Dim	Qual	Nm
M 10	8.8	50
M 12	8.8	86
M 16	8.8	215
M 20	8.8	410
M 24	8.8	710
M 30	8.8	1400

Dim	Qual	Nm
M 10	12.9	84
M 12	12.9	145
M 16	12.9	360
M 20	12.9	700
M 24	12.9	1243
M 30	12.9	2400

### Torque for actuator cover bolts using Molykote G Rapid+:

Dim	Qual	Nm
M 24	8.8	500
M 30	8.8	1000
M 36	8.8	1600

Dim	Qual	Nm
M 24	12.9	650
M 30	12.9	1250
M 36	12.9	1625

**Torque for actuator stay bolts using Molykote G Rapid+:**

Dim	Qual	Nm
M 24	12.9	700
M 30	12.9	1350
M 36	12.9	2100
M 42	12.9	3700

## 11. Maintenance Instructions

Please see the maintenance support procedure and guidelines described below required for maintaining the Steering Gear system in a safe and correct manner.



### WARNING!



- Never work alone when installing heavy components, even when using secure lifting equipment such as lockable block and tackle. Most lifting devices require two people, one to oversee to the lifting device and the other to ensure that the components do not get caught and damaged.
- Always wear protective goggles if there is a risk of splinters, grinding sparks and splashes from acid or other chemicals. Eyes are extremely sensitive and an injury to them can result in loss of sight.
- Using hydraulic oil other than the one specified in this manual may cause malfunctions when operating the equipment. This may cause personal injury and equipment damage

### NOTE!

- Most chemicals intended for the product (engine and gearbox oils, glycol, gasoline and diesel), or the workshop (degreasing agent, paints and solvents) can be harmful to your health. Read the instructions on packaging carefully! Always follow protective measures such as using a protective mask, goggles, gloves etc. Ensure that other personnel are not unknowingly exposed to harmful substances in the air that they breathe; ensure adequate ventilation. Dispose used and excess chemicals according to instructions.
- Ensure that the warning or information labels on the product are always visible. Replace labels that are damaged or painted over.
- Take care of the hydraulic oil when replacing parts in the hydraulic system. Any oil spillage, even a small one, will cause environmental damage. Used filter elements and worn out hydraulic oil should be disposed safely
- To avoid unexpected stops, the importance to maintain the equipment on a regular basis is emphasized.
- Use spare parts supplied by Neuver Maritime. Use of other than Neuver Maritime approved spare parts will void the warranty and may result in system failure or reduced lifetime.
- For scheduled class survey, general overhaul or repair it is advised to use Neuver Maritime service engineers. This will limit the time of repair to a minimum and ensure continuous safe operation.
- It is requested that any failures or maintenance work on the equipment shall be reported to Neuver Maritime dep. Steering Gear - Hagavik. By reporting failures and maintenance work, an accurate equipment history can be maintained by Neuver Maritime. This history will be continuously monitored and compared to other vessels with similar equipment. With this information, NEUVER MARITIME can provide better service, faster delivery of spare parts, and guidance for preventive maintenance.


### 11.1. Oil Sampling

1. Start one of the pump units by turning the selector switch on the corresponding motor controller to position 3 "LOCAL CONTROL".
2. Let the pump unit run for at least five minutes.
3. Turn the selector switch on the motor controller to position 2 "STOP".
4. Unscrew an unused plug [1] in the return filter.
5. Connect a measuring hose (preferable with a valve mounted on it) and make sure the other end is secured in a bucket.
6. Again, start the same pump unit by turning the selector switch on the relevant motor controller to position 3 "LOCAL CONTROL".
7. Make sure the hose valve (if mounted) is completely open, and let the pump run until you are completely sure that the hose is flushed thoroughly.
8. Fill a new and chemically pure sample bottle with oil, min 200ml.
9. Close the sample bottle
10. Turn the selector switch on the motor controller to position 2 "STOP".
11. Disconnect the sampling equipment and mount the plug.
12. Again, start the pump unit and let it run for at least one minute. This will make sure that any trapped air will evacuate through the filter and into the tank.
13. Manually move the rudder by using the red and green Steering Gear handles as illustrated. If any noise or steering problems present, follow the venting procedure.
14. Mark the bottle with AQM type and number, date, oil type, sample taken by and how long used.
15. Repeat steps 1-14 for the opposite pump system.
16. Compare the oil sample with new oil. If color or smell has significantly changed or there are impurities in the oil, change the oil.
17. Send the oil samples to examination immediately



## 11.2. Venting


1. Start the pump unit not connected to the leakage pipe by turning the selector switch on the corresponding motor controller to position 3 “LOCAL CONTROL”.
2. While the pump is idling, open the venting plugs [1] one at a time and evacuate all air. Close the plugs when only oil is coming out.



### NOTE!

Do not open the venting plugs more than 2-3 rotations

3. Manually move the rudder from hard over to hard over a few times by using the handles on the control valve.
4. Loosen the leakage pipe coupling [2] and fill the pipe connector with oil while turning the rudder.
5. While the pump is idling, open the venting plugs one at a time and evacuate all air. Close the plugs when oil is coming out.
6. Stop the pump unit by turning the selector switch on the motor controller to position 2 “STOP”.
7. Start the other pump unit (connected to the leakage pipe), by turning the corresponding selector switch on the motor controller to position 3 “LOCAL CONTROL”.
8. Repeat step 3 and 4 above.
9. Vent the leakage pipe by turning the coupling 1-2 rotations.
10. Repeat Step 6 above.
11. Stop the pump unit by turning the selector switch on the motor controller to position 2 “STOP”.



### NOTE!




The system shall now operate smoothly without noise. If noise still occur, repeat the venting procedure.

### 11.3. Filling and Refilling of Oil

**NOTE!**

Ensure that the cleanliness of the new hydraulic oil is within what is recommended; 20/18/15 according to ISO 4406-1999 (comparable to NAS 1638 or SAE AS 4059 class 9). If the cleanliness level cannot be stated, or is not within what is recommended, use a 10µm mesh sized filter, to filter the oil before filling it into the Steering Gear.

1. Turn the selector switch on the motor controller to position 2 “STOP”.
2. Open the breathing filter [1] and fill oil into the oil tank.
3. Open the venting plugs [2] on top of the rudder actuator as illustrated.
4. Start the pump units by turning the selector switch on the motor controller to position 3 “LOCAL CONTROL”
5. Fill oil into the rudder actuator by operating the handles on the control valve manually for a few seconds.
6. Pay attention to oil level in oil tank and repeat the procedure until the rudder actuator is filled up with oil.
7. Turn the selector switch on the motor controller to position 2 “STOP”.
8. Repeat the same procedure on the second pump unit.
9. Oil level in oil tank to be within min and max.
10. Perform the venting procedure.



## 11.4. Maneuvering Time Test



For the purpose of confirming the healthy condition of the internal seal of the Steering Gear unit, the following test procedure should be followed. The procedure relies on timing the movement from 30° rudder position on one side to 35° on the opposite side. Read the pressure on the pump manometer when performing the test.

### NOTE!

Performance of this test should be managed by the Chief Engineer when vessel is lying still in sheltered waters. The test should be done first with pump no 1 and then again with pump no 2.

The maneuvering time must be taken while the rudder is moving. The rudder must start at 35°. When passing 30°, the stopwatch must be started, and stopped when passing 35° on the opposite side.

1. Set the selector switch on the motor controller 2 to position 2 “STOP”.
2. Set the selector switch on motor controller 1 to position 3 “LOCAL CONTROL”.
3. Operate the Steering Gear using the solenoid valve to 35° STBD.
4. Measure the time used from 30°STBD - 35°PORT.
5. Measure the time used from 30°PORT- 35°STBD.
6. Set the selector switch on motor controller 1 to position “STOP”.
7. Set the selector switch on motor controller 2 to position 3 “LOCAL CONTROL”.
8. Repeat test with pump No 2.
9. Set both selector switches in position 1 “REMOTE CONTROL”.
10. Operate the Steering Gear from the bridge and follow instruction 3-5.
11. Return to 0° position and stop the pumps.



	Direction	Time	Pressure
Pump 1	STBD - PORT	Sec	Bar
Pump 1	PORT- STBD	Sec	Bar
Pump 2	STBD – PORT	Sec	Bar
Pump 2	PORT- STBD	Sec	Bar
Pump 1+2	STBD - PORT	Sec	Bar
Pump 1+2	PORT- STBD	Sec	Bar

### NOTE!

For vessels with two Steering Gears, please perform one test per unit!

## 11.5. Replacement of Gland Seals

The gland seals may need to be replaced if leakage occurs. Please see below procedure for replacement of the gland seals. Remember to test Feedback units and any dismantled arrangement on the actuator after replacement to ensure correct reassembly.

To avoid unnecessary leakage while waiting for new gland seals, run the Steering Gear system with the pump unit not connected to the leak oil from the actuator. Remember to start the pump connected to the leak oil every other day to ensure lubrication of seals.

### Upper gland seals – 2 pcs [1]

Remove the upper gland ring. Remove the old gland seals. Grease the new seals with *Mobilith SHC 460*

before installment and fill voids with grease before assembling the gland ring.

### Lower gland seals – 2 pcs [2]


The new seals must be cut and inserted around the rudderstock before the seals are glued back together around the rudderstock. Use *Loctite 406* or *Loctite superglue 495*.

#### NOTE!


Cutting and bonding of gland seals is a temporary solution, used when vessel is in operation. All glued gland seals must be replaced with new gland seals during the next docking.

NEUVER MARITIME recommend doing this before the dismantling of the old seals to prevent contaminants when gluing, and to provide the glue some time to harden.

Grease the new seals with *Mobilith SHC* before installing and fill voids with grease before assembling the gland ring. To facilitate re-assembly of the lower gland ring, NEUVER MARITIME recommend lowering the gland ring by means of two lengthened screws/threaded rod with nut.

**Illustration 1****NOTE!**

All seals are supplied in correct lengths and must **NEVER** be shortened. The correct way of inserting the gland seals is shown in illustration 2.

**Illustration 2: Rotor and gland seal seen from above.**

## 11.6. Replacement of Filter Element

### NOTE!

After the first 200 hours running, every oil filter units shall be opened for inspection and the disposable filter elements changed if necessary. If any impurities are found, the element must be replaced at short intervals until it stays clean. After this, replace the relevant filter element when the filter indicator is in the RED zone. It is recommended to change the filter elements at least once a year.

12. Turn the selector switch on the motor controller to position 2 “STOP”.
13. Open the cover on the filter housing by loosening the nuts in diagonal order.

### NOTE!


Be aware of spring-loaded cover

14. Lift the disposable filter element with the filter holder out of the housing.
15. Place a bucket underneath the filter bowl.
16. By using an Allen key, unscrew the bolt [1] on top of the filter element holder.
17. Remove the supporter ring [2].
18. Remove the internal disposable filter element from its holder, and then replace with new disposable filter.

### NOTE!



The filter elements are disposable and shall be replaced with new filter elements when clogged. Never rinse or air blow a clogged filter element for reuse, as it will destroy the filter.

19. Before replacing the supporter ring [2], check the condition of the O- ring. Change to new one if necessary.
20. Fasten the new disposable filter element by replacing the supporter ring
21. [2] and fastening the bolt [1] on top of the element holder.
22. Insert the new filter element with its holder to the housing
23. Replace the cover and tighten the screws in a diagonal order.
24. Follow the venting procedure.
25. Turn the selector switch on the motor controller to position 1 “REMOTE CONTROL”.




### 11.7. Replacement of Flexible Coupling in Pump Unit

1. Turn the selector switch on the motor controller to position 2 "STOP".
2. Disconnect the electrical cables in the outlet box.
3. Loosen the bolts [1] and remove the electric motor.
4. Replace the flexible coupling [2].
5. Align the couplings and lower the motor vertically on to the bell house.
6. Fasten the bolts [1].
7. Turn the selector switch on the motor controller to position 1 "REMOTE CONTROL".



## 11.8. Adjustment of Haenni Contents Gauge



### Adjustment

1. Meter the exact height.
2. Detach the bezel with bayonet fixing, by turning it CCW approx. 1" (until it stops). Carefully pull off the bezel and the cover glass. Hold the annular top dial by the sides and pull it off the securing pins.
3. Use the tables on the following page and find the conversion factor based on tank height and oil density (normally 0,88 for ISO 68). Place the adjusting lever accordingly.
4. Perform 0-adjustment by turning the slotted screw CW or CCW maximum 1 revolution until the pointer shows 0 on the main dial. Confirm the 0-adjustment by tapping the case lightly and readjust as necessary.
5. Replace the top dial on the securing pins by pressing lightly. Please note that the standard dial is printed on both sides (0-1/4-1/2-3/4-1). The circular symbol is for horizontal round or oval tanks, while the rectangular symbol is for vertical and cubic tanks
6. Place the cover glass with the adjusting pointer on the front of the casing and make sure that the securing pins fit into the recess in the cover glass. Vent the leakage pipe by turning the coupling 1-2 rotations.
7. Put on the bezel by pressing the cover glass lightly against the casing and secure the bezel with
8. bayonet fixing by turning CW approx. 1" (until it stops).

**Height measurements for setting:****Settings for Power Packs w/ integrated storage tanks (oil density 0,88):**

Power Pack model	Tank Volume	Internal Height	Haenni Setting
PPSI 2"	2X300L + 450L	672 mm	0,74
PPSI 2"	2X350L + 650L	613 mm	0,67
PPSI 2"	2X500L + 1100L	802 mm	0,88
PPSI 3"	2X700L + 1450L	792 mm	0,87
PPSI 3"	2X1000L + 1850L	871 mm	0,96
PPSI 3"	2X1400L + 2850L	1171mm	1,29

**Settings for separate storage tanks (oil density 0,88):**

Tank (item no.)	Tank Volume	Internal Height	Haenni Setting
13423	500L	1000 mm	1,10
13345	1050L	1400 mm	1,54
13402	1350L	1800 mm	1,98
13225	2000L	1800 mm	1,98

**Complete Conversion table:**

Density	Tank Height or Tank Diameter in meters													
	0,7	0,8	0,9	1,0	1,1	1,2	1,3	1,4	1,5	1,6	1,7	1,8	1,9	2,0
0,84	0,74	0,84	0,95	1,05	1,16	1,26	1,37	1,47	1,58	1,68	1,79	1,89	1,99	2,10
0,86	0,75	0,86	0,97	1,07	1,18	1,29	1,40	1,50	1,61	1,72	1,83	1,93	2,04	2,15
0,88	0,77	0,88	0,99	1,10	1,21	1,32	1,43	1,54	1,65	1,76	1,87	1,98	2,09	2,20
0,90	0,79	0,90	1,01	1,12	1,24	1,35	1,46	1,57	1,69	1,80	1,91	2,02	2,14	2,25
0,92	0,81	0,92	1,04	1,15	1,27	1,38	1,50	1,61	1,73	1,84	1,96	2,07	2,18	2,30

## Operation and Gauging

When performing gauging:

1. Pull the pump handle downwards until it stops and release
2. Observe the movement of the indicator
3. The position where the indicator stops will be the contents (tank) level.

### NOTE!

Gauging shall not be done during filling.

## Faultfinding

Fault	Possible reason	Action
The pointer goes beyond the max value on scale.	The connection pipe is blocked.	Disconnect the connection pipe from the instrument and check pipe for any obstructions.
	The measurement range of the instrument is set incorrect.	Check tank height or tank diameter setting.
The instrument gives no reading, or the reading is too low.	Leak on the connection pipe or at the pump piston.	Tighten the screw connections and check the seal ring on the pump piston.
	Tank is empty	
	The measurement range of the instrument is set wrongly.	Check tank height or tank diameter setting.

## 11.9. Cleaning of Water/Oil Cooler

Clogging will reduce the heat transfer capacity of the Water/Oil cooler. Methods for establishing a clogging problem:

- Check water inlet and outlet temperature. Clogging results in reduced difference in water inlet and outlet temperatures and a rise in oil temperature.
- Check for a pressure drop across the cooler. Clogged and narrow passages will cause acceleration in flow rate and increased pressure drop.

If temperature or pressure measuring reveals a clogged cooler:

1. Clean the Water/Oil cooler by removing all minor deposits by back flushing the cooler with water.

Fouling can be dealt with using a light acid.

2. Use 5% phosphoric acid or, when cleaned frequently, 5% oxalic acid or similar light organic acid.
3. Rinse the cooler with a large quantity of water.

### **NOTE!**

Make sure all acids are removed before restarting the system.

## 11.10. Cleaning of Air/Oil Cooler



### WARNING!

- The Air/Oil cooler can be hot during operation. Make sure that the Air/Oil cooler is cool before touching.
- There is a warning label fitted to the air oil cooler at delivery, high temperature surface, use ear defenders, rotating fan. Always replace a damaged or missing label.
- The fan can generate static electricity by air friction. Do not put sensitive equipment (electronics etc.) in the immediate vicinity of the cooling system.

### NOTE!

- When cleaning the exterior of the cooler, for instance using water, be aware of the electric motor protection standard.
- The manufacturers are not to be held responsible for any consequences due to inside cleaning of the pump.

1. Ensure all power is disconnected.
2. Clean the air fins of the matrix by blowing through with compressed air. If using a high-pressure washing system, point the jet perpendicular to the air fins, as illustrated.
3. Make sure the system is depressurized and disconnect the hydraulic pipes from the cooler matrix.
4. Loosen the screws with washer [1] fixing the cooler matrix to the fan housing, as illustrated.
5. Remove the cooler matrix.
6. Clean the inside of the fan housing by using compressed air, blow with compressed air from the electric motor side through the fan guard.
7. Refit the cooler matrix to the fan housing by fastening the screws with washer [1].
8. Connect the flexible hydraulic hoses to the cooler matrix.
9. Connect the electric motor power supply.




10. Prior to start-up, check:

- The matrix and fan guard for damage
- That all hydraulic connections are tight
- That the cooling system is correctly connected
- That valves and similar components are open at start

11. When starting, check:

- Noise level
- Fan direction




### 11.11. FB40 Feedback Inspection

To verify that the transmitter arrangement is correctly installed, please go through all checkpoints in the list below.

#### NOTE!



Before proceeding with the inspection, make sure to switch motor control cabinet to “LOCAL CONTROL” position to avoid unintended operation of the Steering Gear while work is carried out.

**Figure 1**



Item	Component	Description	Reference	Status	Sign
1.	Feedback Units	Make sure the locking nuts [15] is properly tightened.	Figure 2		
2.	Shaft [4]	<p>Check that the center shaft is locked against rotation in the flat bar on the rudderstock/hydraulic nut by tightening the lower nut and securing it with a counter nut, each properly tightened.</p> <p>Tightening torque; Lower nut, lightly oiled threads – 160 Nm</p> <p>Counter nut, lightly oiled threads – 100 Nm</p>	Figure 1		

Item	Component	Description	Reference	Status	Sign
3.	Chains [6A, 6B]	The chain shall travel horizontally; make sure the chains is not climbing.	Figure 1		
4.	Chain tensioners	Check that the chain tensioners is positioned halfway between the two chain wheels when the rudder is in center position.	Figure 1		
5.	Chain tensioners	Check that the chain tensioners is pre-tensioned according to figure 8, 5mm is ideal, but 4-10mm can be accepted. Pre-tension obtained by adjusting position of bracket.	Figure 3		
6.	Feedback Unit	With one of the pump units activated, operate the Steering Gear to maximum rudder angle Port and maximum rudder angle Stbd. Confirm that correct angle limit is achieved for both directions.			
7.	Feedback Unit	Repeat the above test with the opposite pump unit activated.			


**Figure 2****Figure 3**

### 11.12. Stuffing Box (if NEUVER MARITIME delivery)

When manufacturing the Walker seal, each ring is cast in one piece in a mold. The reverse side of the Walker seal is made from a synthetic rubber-proofed cotton fabric and the lip from a high nitrile base, synthetic rubber with a hardness of 80 IRHD.

The walker seal ring is equipped with a compression element with a length of 30-50 mm depending on size of ring. After the casting is complete, the ring is split in the middle of this compression element. This compression element is made of rubber only, and the purpose of this element is to absorb the necessary compression created at installation. In special cases, it can be used for small adjustment of the length of the Walker seal prior to installation.

During installation, there should be a pressure in the joint, leading to pressure in the compression element. Without this pressure, there will most likely be a leakage in the joint since the ends of the Walker seal can slide away from each other. The gap created will then lead to a leakage.



#### Seal lubrication:

A liberal lubrication during assembly will ensure lubrication from the start. During operation, the seals should be checked on a weekly basis and grease added once a month as necessary.

#### Preparations:

The Stuffing Box should be mounted on a levelled deck. In order to avoid sea water from penetrating between Stuffing Box housing and deck a separate seal between deck and housing to be used. A seal for this purpose is supplied with the Stuffing Box. The maximum curvature on the levelled deck when using this seal is 1 mm across the Stuffing Box surface.

### 11.13. Function Test of Alarm System

Please follow below procedure in order to complete a function test of the alarms on the alarm system installed.

#### NOTE!

There is a 5 sec delay in the alarm system. If any alarm is present in the alarm system, the auto start will not work, so please check all alarms on the alarm panel before you test the next alarm.

Alarm test	
Overload	Test Push Button
Phase failure	Remove fuse F17
Power failure	Turn of main switch
Power control failure	Turn selector switch to position 2
Low oil level	Disconnect sensor from PP
Hydraulic lock	Keep selector switch in remote and operate the Steering Gear locally
Clogged filter	Disconnect sensor from PP
High oil temp	Disconnect sensor from PP
Low oil pressure	Close handle before starting the pump
Power failure aux. steering	Remove fuse F41-42-43-44

#### Overload alarm:

Push the test button on the overload relay in motor controller. The stand-by pump should start if not already running.

#### Phase failure alarm:

Remove one of the fuses supplying the phase failure monitoring relay in the motor controller cabinet, the stand-by pump should start if not already running.

#### Power failure:

Turn of main switch S1 in the motor controller or the circuit breaker from switch board. The stand-by pump should start if not already running.

#### Power control failure alarm:

Set the S2 selector switch located on the outside of the motor controller cabinet to local control or stop, the stand-by pump should start if not already running.

**Low oil level alarm:**

Disconnect the connection plug on top of the expansion tank. The stand-by pump should start if not already running.

**Hydraulic lock alarm:**

Activate manual solenoid in either direction while the motor controller is in remote control. Keep activated for more than 5 seconds.

The stand-by pump should start if not already running.

**Clogged filter:**

Remove the plug on the filter sensor. This alarm does not include an auto start of the stand-by pump.

**High oil temp:**

Remove the plug on the temperature sensor. This alarm does not include an auto start of the stand-by pump.

**Aux alarm:**

Missing feedback from Steering Gear to the control system.


Locate the U10 module inside the control system cabinet. Remove the feedback line wires on terminals 9 to 11. Alarm should appear after 5 seconds. Vessels with DP2 class or higher also have “rudder freeze” due to this alarm.

## 11.14. Function Test of IMO System

To avoid any non-detectable system errors, all oil level sensors, valves and functions shall be checked and maintained every month. The following procedure shall be carried out to ensure proper function of the system. Prior to the function test it is recommended to perform a steering test with system operating in normal mode, with single pump and dual pump operation.

### 11.14.1. Manual Operation mode From Bridge

Manual operation of the system can be performed from the bridge control panel. Push buttons are fitted to enable the individual functions and to disable the system. The system mode selector shall be in position 1, Automatic/remote control.



### Manual Disconnection

By activating the push button Manual Disconnection, the system will be disabled, and monitoring of hydraulic system is switched off. Indication “System Disconnected” shall illuminate.

Expected outcome: the steering will operate as normal but will not meet the IMO requirement.

### Manual Isolation

Prior to the test, keep pump 1 running.

1. By activation of push button, “Manual Isolation”. The system will enable isolation mode, both pumps shall be brought into operation.
2. Apply direction order, first to port and then to starboard, notice the rudder movement.  
Expected outcome: rudder movement shall be at expected speed for two pump operation.
3. Deselect Manual Isolation and stop the pump 1 and start pump 2. Repeat test from step 1.
4. Return system to automatic mode by deselecting Manual Isolation push button.

**Manual By-pass system 1**

Prior to the test both pumps shall be running.

1. By activation of push button, "Manual By-pass System 1". The steering gear half connected to pump 1 is by-passed and the steering gear operated by pump 2 only. Indication, "System Isolated" and "System 1 By-passed" shall illuminate.
2. Apply a direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement shall be at expected speed for two pumps operation. Available torque is only half.

3. Stop pump 1, and apply the direction order again, the same rudder response is expected.
4. Return system to automatic mode by deselecting Manual By-pass System 1 push button.

**Manual By-pass system 2**

Prior to the test both pumps shall be running.

1. By activation of push button, "Manual By-pass System 2". The steering gear half connected to pump 2 is by-passed and the steering gear operated by pump 1 only. Indication, "System Isolated" and "System 2 By-passed" shall illuminate.
2. Apply a direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement shall be at expected speed for two pumps operation. Available torque is only half.

3. Stop pump 2, and apply the direction order again, the same rudder response is expected.
4. Return system to automatic mode by deselecting Manual By-pass System 2 push button.

**11.14.2. Local Operation from IMO Control Cabinet**

If the manual control from the bridge panel is out of function, the isolation and by-pass system can be activated from the "By-pass & Sep. System" selector switch on the IMO Control Cabinet. To verify the function, please follow the procedure below.

**Selector switch pos. 1 Auto/Remote**

System operates automatically by monitoring of the oil level, or from the bridge manual operation

**Selector switch pos. 2 System Disconnect**

System is switched off.

**Selector switch pos. 3 Isolating Mode Locked**

Prior to the test, establish communication with the bridge, keep pump 1 running.

1. By the mode selector, select position 3, "Isolation Mode Locked". The system will enable isolation mode, both pumps shall be brought into operation.
2. Ask bridge to apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement shall be at expected speed for two pump operation.

3. Return selector switch to position 1, ask bridge to stop pump 1 and start pump 2. Repeat the test from point 1.
4. Return selector switch to position 1.

**Selector switch pos. 4 By-pass System 1 Locked**

Prior to the test, establish communication with the bridge, and keep both pumps running and NFU steering mode activated.

1. By the mode selector, select position 4, By-pass System 1 Locked. Isolation mode and by-pass system 1 activated.
2. Ask bridge to stop pump 2.
3. Apply a steering command from pump 1 using manual steering lever.

Expected outcome: no rudder response as the system is by-passed.

4. Ask bridge to start pump 2 and stop pump 1, then to apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement at the speed of two pumps operation.

**Selector switch pos. 5 By-pass System 2 Locked**

Prior to the test, establish communication with the bridge, and keep both pumps running and NFU steering mode activated.

1. By the mode selector, select position 5, By-pass System 2 Locked. Isolation mode and by-pass system 1 activated.
2. Ask bridge to stop pump 1.
3. Apply a steering command from pump 2 using manual steering lever.

Expected outcome: no rudder response as the system is by-passed.

4. Ask bridge to start pump 1 and stop pump 2, then to apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement at the speed of two pumps operation.

5. Return selector switch to position 1.

### 11.14.3. IMO Oil Level Detection

To verify the function of the level switches in the oil tanks, please follow the procedure below.

#### S25 Common Oil Level

S25 Common Oil Level activates an alarm only. IMO system is not activated.

1. Activate the level switch by pushing the black ball handle and hold for 10 seconds. The ball handle is connected to a lever which will move the floater and activate the level switch.

#### S20 Low Oil Level – Isolation mode

S20 Low Oil Level switch activates the isolation valves and separates the two hydraulic systems. Operation of the steering gear shall be done using both pumps.

1. Activate the level switch by pushing the black ball handle. The ball handle is connected to a lever which will move the floater and activate the level switch. Maintain activation through all steps including test of by-pass system 1 and 2.

Solenoid Y20a, Y20b, Y20c and Y20d activates and isolate the two systems, both pumps will be brought into running condition and indication in bridge control panel and in the control cabinet shall state Isolation Mode active.


2. From bridge, apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: the rudder movement shall be at expected speed for two pumps operation.

#### S21 Low-Low Oil Level System 1 – By-pass System 1

S21 Low-Low Oil Level switch activates the bypass valve for system 1. Operation of the steering gear shall be done using pump 2 only.

1. Activate S20 level switch and maintain activation through all steps.
2. Open the connection box and activate the test function by pressing the coupling piece down as shown in the illustration. Maintain activation through all steps. If test function not fitted, lift the S21 oil level switch above the oil level in tank to allow the floater to activate the switch.



Solenoid Y21 activates and by-pass system 1, indication in bridge control panel and in the control cabinet shall state Bypass System 1. Alarm Low-Low Level 1 activates in steering gear alarm panel.

3. Ask bridge to stop pump 1, the then to apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement at the speed of two pumps operation.


4. Release activation of S21.

System status returned to Isolation mode. Both pumps are brought into operation.

### **S22 Low-Low Oil Level System 2 – By-pass System 2**

S22 Low-Low Oil Level switch activates the bypass valve for system 2. Operation of the steering gear shall be done using pump 1 only.

1. Activate S20 level switch and maintain activation through all steps.
2. Open the connection box and activate the test function by pressing the coupling piece down as shown in the illustration. Maintain activation through all steps. If test function not fitted, lift the S22 oil level switch above the oil level in tank to allow the floater to activate the switch.



Solenoid Y22 activates and by-pass system 2, indication in bridge control panel and in the control cabinet shall state Bypass System 2. Alarm Low-Low Level 2 activates in steering gear alarm panel.

3. Ask bridge to stop pump 2, then to apply direction order, first to port and then to starboard, notice the rudder movement.

Expected outcome: rudder movement at the speed of two pumps operation.

4. Release activation of S22 and S20. System returns to normal operation mode.

#### **11.14.4. Operation of IMO Valves**

To manually verify the function of the IMO valves, please follow the procedure below.

##### **Isolation valve System 1**


Prior to the test, select local control at the motor controller.

1. Activate Y20a by hand, then apply a starboard direction order from pump 1 valve.

Expected outcome: limited or no rudder movement.

2. Activate Y20b by hand, then apply a port direction order from pump 1 valve.

Expected outcome: limited or no rudder movement.



##### **Isolation valve System 2**

Prior to the test, select local control at the motor controller.

1. Activate Y20c by hand, then apply a port direction order from pump 2 valve.

Expected outcome: limited or no rudder movement.

2. Activate Y20d by hand, then apply a starboard direction order from pump 2 valve.

Expected outcome: limited or no rudder movement.

### **By-pass valve System 1**

Prior to the test, select local control at the motor controller.

1. Activate Y21 by hand.
2. Apply a port direction order from pump 1 valve.

Expected outcome: rudder shall not move.

### **By-pass valve System 2**

Prior to the test, select local control at the motor controller.



1. Apply a port direction order from pump 2 valve to verify that the rudder moves as normal.
2. Activate Y22 by hand, then apply a port direction order from pump 2 valve.

Expected outcome: rudder shall not move.

3. Return motor controller selector switch to position 1.

### 11.15. Adjustment of Rudder Angle Indicator System

1. Set the selector switch the Motor Controller to position 3 "LOCAL CONTROL".
2. Move rudder to zero position with the port/starboard push buttons.
3. Set the selector switch the Motor Controller to position 2 "STOP".
4. Remove the cover on the feedback unit.
5. At the terminal block, disconnect the red wire [2] to the center point of the feedback potentiometer and the end points; green [3] and yellow wires [4].
6. Measure the resistance between one end point and midpoint, red-green and red-yellow wire. The resistance should be approx. 2,5 k $\Omega$ . The resistance between each end point and midpoint must be equal.
7. If necessary, loosen the locking screws [5] and turn the potentiometer [6] until resistance between the end points and midpoint to each side is equal.
8. Tighten the locking screws [5].
9. Reconnect the red wire [2], green wire [3] and yellow wire [4] to the terminal block.
10. Install the feedback unit cover.




### 11.16. Adjustment of Rudder Angle Indicator Amplifier (if NEUVER MARITIME delivery)

1. Check that the Steering Gear is in zero position according to the mechanical rudder angle indicator on the actuator.
2. If the rudder indicators are out of zero position, a zero adjustment can be done on the rudder indicator amplifier adjuster P20 [2] (+/- 2 degrees).
3. Operate the Steering Gear manually from the Steering Gear room until the mechanical rudder indicator reaches 35° port.
4. If required, adjust the gain (P30) [3] on the rudder indicator amplifier until the one of the rudder indicators show 35° port. Additional rudder indicators can be adjusted separately if necessary.

#### NOTE!

Independent adjustments can be made on each rudder indicator by means of integrated gain controls on each indicator.

#### Illustration 3: Rudder angle indicator amplifier





5. If required, adjust the galvanic isolated +/- 10V rudder position signals as follows:
  - Position the Steering Gear 5° before the Steering Gear mechanical stop.
  - Adjust the P40 [4] until the rudder position signal equals 9V.

### 11.17. Adjustment of Limit Switches in Feedback Unit

1. Set the Steering Gear Motor Controller switches to position 3 “LOCAL CONTROL”.
2. Remove the cover of the feedback unit which limit switches are to be adjusted.
3. Loosen the nut installed on top of the cam rings.
4. Use a hexagonal key to open the locking screws [2].
5. Move the Steering Gear to the limit switch position.


The tripping cams are adjusted to interrupt the steering signal at max. electrical rudder angle. This value can be found in chapter 5 of the Electrical User Manual.

6. Adjust the position of each ring [2].
7. Tighten the locking screws [1] using a hexagonal key.
8. Replace the feedback unit cover.




### 11.18. Adjustment of Amplifier Card (if NEUVER MARITIME delivery)

1. Start the pumps from the main control panel.
2. Set the switch to follow-up steering [1] mode.
3. Move the selected controller [2] to 30 degrees port or starboard side.
4. Adjust gain on amplifier card P20 [4] until the position of the Steering Gear is 30 degree.
5. Increase sensitivity setting on adjuster P60 [3] (clockwise) until the follow-up system starts oscillating on rudder commands. The oscillation can be observed on the 4 LED (ordered signal port/starboard for each pump) on front of the amplifier card.
6. Adjust P60 [3] counterclockwise one-half turn to remove oscillation.
7. Turn the controller and check for oscillation. If oscillations are present repeat step 6 until oscillation stops.




**Illustration 4: Control system amplifier card**



### 11.19. Adjustment of FU-Controller (if NEUVER MARITIME delivery)

1. Start the pumps from the main control panel.
2. Push the corresponding “IN COMMAND” button [1] to engage the follow-up controller.
3. Operate the controller to mid-ship command and make sure that the rudder position to mid-ship position is correctly aligned. If it is misaligned loosen the clamp screw [2] adjust the 0-point and turn the potentiometer [3] until rudder mid-ship position is correctly aligned.
4. Operate the selector controller to 30 degrees port or starboard direction.
5. Make sure that the rudder position is correctly aligned. If not, adjust the potentiometer.
6. Tighten the clamp screw [2].




## 11.20. Replacement of Alarm System Card

1. At the bridge distribution board, make sure that the power supply to the alarm system is switched off.
2. Open the alarm panel.
3. Loosen the alarm system card(s) connection.
4. Remove the alarm system card(s).
5. Set the X8 and X9 nodes on the new card to the same as the defective card and install the alarm system card(s).
6. Tighten the alarm system card/cards connection.
7. Close the alarm system panel.
8. Turn on the power supply.



### 11.21. Replacement of Pump Control Card

1. Switch off the main power supply to the control system by disconnecting the power supply to the corresponding motor controller.
2. Open the control system cabinet.
3. Disconnect all connected wires from the pump control card.
4. Loosen the four screws securing the pump control card.
5. Replace the faulty pump control card.
6. Tighten the screws securing the card.
7. Connect all the wires.
8. Verify that all jumpers (JP1, JP2 and JP3) are in correct position.
9. Close the control system cabinet.
10. Turn on the main power supply to the control system
11. Perform adjustment of backlight level using TP1 and measure the voltage difference between X3.4 and X3.5 terminals. Set voltage to 11V for incandescent lamps and 5V for LEDs. Make sure that the controlled pump is not running during adjustment.



## 11.22. Replacement of Amplifier Card



### WARNING!

- Electrostatic discharges can damage components.
- To prevent damage always use a grounded electrostatic discharge bracelet while work is on going.

1. Switch off the main power supply to motor controller by turning the S1 isolating switch.
2. Open the control system cabinet.
3. Use the EDS wristband.
4. Remove the faulty amplifier card [1].
5. Install the new amplifier card [1].
6. Switch on the S1 isolation switch in the motor controller.
7. Close the motor controller doors.
8. Adjust the amplifier card as detailed in chapter [11.18 Adjustment of Amplifier Card](#) (if [NEUVER MARITIME](#) delivery)




### 11.23. Replacement of Selector Card



#### WARNING!


- Electrostatic discharges can damage components.
- To prevent damage always use a grounded electrostatic discharge bracelet while work is on going.

1. Switch off the main power supply to motor controller by turning the S1 isolating switch.
2. Open the control system cabinet.
3. Use the EDS wristband.
4. Remove the defective selector card [1]
5. Set the jumper settings on the new card to the same as the defective card.
6. Install the new card.
7. Close the controls system cabinet.
8. Switch on the S1 isolation switch in the motor controller.




## 11.24. Replacement of Start Relay

1. Ensure power supply to the motor controller is switched off.
2. Locate the defect relay.
3. Loosen all connection wires [1].
4. Loosen screws [2] on start relay.
5. Renew relay.
6. Refit wires and screws.
7. Turn on power supply.




### 11.25. Replacement of Start Relay

1. Ensure power supply to the motor controller is switched off.
2. Locate the defect relay.
3. Loosen all connection wires [1].
4. Loosen screws [2] on start relay.
5. Renew relay.
6. Refit wires and screws.
7. Turn on power supply.





## 11.26. Replacement of Limit Switches in Feedback Units

1. Switch off the main power supply to Motor Controller by turning off the S1 isolating switch.
2. Remove the cover on the feedback unit.
3. Identify the defective limit switch [2].
4. Loosen the screws [1] on top of the switch assembly.
5. Using a soldering iron, release the wiring from the switch.
6. Solder the wiring to the new limit switch.
7. Tighten the screws [1] on top of the switch assembly.
8. Switch on the power by turning the S1 isolation switch inside the motor controller.
9. Adjust the limit switch as detailed in chapter [11.17 Adjustment of Limit Switches in Feedback Unit](#)
10. Install the cover on the feedback unit



## 11.27. Replacement of Proximity Switch

1. Set the selector switch on motor control cabinet to position 2 "STOP".
2. There will be slight oil spill. Place a suitable container under the sensors to be replaced.
3. Disconnect the wires in the connection box for the sensor to be replaced. Note the positions of the coloured wires in the terminals.
4. Release the locknut [1] and unscrew the sensor [2] from the end housing.
5. Mount the new sensor, and make sure it is adjusted to correct length "L". See illustration and table below.
6. Fasten the locknut [1].
7. Connect the wires in the connection box.
8. Turn selector switch on Motor Controller back to position 1 "REMOTE CONTROL".




**2" Control valve**


Type	"L"
IRV 900-2	5 mm
IRV 1400-2	3 mm
IRV 1700-2	3 mm
IRV 2050-2	3 mm
IRV 2700-2	3 mm
IRV 3050-2	3 mm
IRV 4200-2	3 mm

**3" Control valve**

Type	"L"
All types	3 mm

**Control valve****NOTE!**

Springs in the 2" control- and control/lock valve delivered prior 2011 is recommended to be upgraded.



If needed, please contact  
[support@neuver.com](mailto:support@neuver.com)

Part number:  
 2" control valve **P82942**  
 2" control/lock valve **P82943**  
 One kit needed for each Control Valve

## 12. Troubleshoot Hydraulic Lock Alarm (Only AS02)

The alarm Hydraulic Lock is made by four signals, two from the steering control system and two from the Steering Gear control valves. All signals are connected in the pump motor controller, at unit U2, input 17, 18, 19 and 20.

Input 17 and 18 is from the steering system opto-couplers, and 19 and 20 from the pump control valve proximity switch. Additionally, the limit switches will disconnect input 17 & 18 at end position via aux. relays (early version) or a relay module (later version).

**Operate the steering from bridge and check the following signals:**

No rudder command	Port rudder command	STBD rudder command
Led 17 – OFF	Led 17 – ON	Led 17 – OFF
Led 18 – OFF	Led 18 – OFF	Led 18 – ON
Led 19 – ON	Led 19 – OFF	Led 19 – ON
Led 20 – ON	Led 20 – ON	Led 20 – OFF

Input is active when corresponding led is ON. Any other condition will activate hydraulic lock alarm after a 5 second delay.

If input 17 or 18 are missing, aux. relays/relay module should be checked, as well as the rudder command signal from the optocouplers located on the pump control card.

If signals 19 or 20 are irregular, the proximity switches should be checked. These are located in the control valve's end housings. Follow chapter [11.27 Replacement of Proximity Switch](#) for instructions.

If all above checks are found correct, and input 19/20 are still irregular, the proximity switch itself may be the cause. The proximity switch should therefore be replaced as a complete unit.

The order part number of the proximity switch is: **44771**

## 13. Spare parts

### NOTE!

Information regarding the Steering Gear type and installation number is found on a nameplate mounted on the Steering Gear housing and on the Power Pack unit, nameplate for each pump.

Information regarding the Steering Gear electrical system is found on a sticker on the inside of all the electrical cabinets.



NEUVER MARITIME recommend keeping the below listed spare parts on board as a minimum of on-board spare parts.

For additional tailored recommendations please contact [support@neuver.com](mailto:support@neuver.com).

### Mechanic / Hydraulic:

On board spare parts		On board	Need to replace
1x Gland seals kit			
1x Cover seal			
2x Flexible couplings			
2x Filters			

### Controls:

On board spare parts		On board	Need to replace
2x Proximity switches			
1x Phase failure relay			
1x Relay			
1x Relay socket			
1x Solenoid			
1x Solenoid driver			
1x Pump ECB			

When ordering spare parts, please make sure to include the following information to the spares department. Please see chapter [14 Contact](#) for contact information.

<b>Vessel name:</b>		<b>Shipping address:</b>	
<b>Owner name:</b>		<b>Invoicing address:</b>	
<b>IMO number:</b>		<b>Drawing number:</b>	
<b>Steering Gear type:</b>		Position number	
<b>Installation:</b>		Article number	

### 13.1. Spare Part Kits and Items

For spare parts needed for the recommended overhaul in relation to scheduled class surveys or docking every fifth year, please contact our service engineers at [support@neuver.com](mailto:support@neuver.com).

Please see below table for specified spare part kits and relevant maintenance items.

#### Seal kits for valves

Valve	Item No
2" Lock valve	RRM000389723
3" Lock valve	RRM000389724
2" Control valve	RRM000389720
3" Control valve	RRM000389719

#### Overhaul kits for valves

Valve	Item No
2" Lock valve	000113597
3" Lock valve	000113599
2" Control valve	000113601
3" Control valve	000113600

One kit needed for each valve.

#### Overhaul kit for IMO-valves

	Item No
3" Interconnecting/Isolation valve + Safety/Bypass valve	RRM000457147

One kit needed for each valve.

#### General service items for Power Pack

	Item No
Filter indicator (manual)	70116_FR
Filter indicator (electrical)	70117_FR

## 13.2. Pump Spare Parts and Overhaul Procedure


The Leistriz pumps on the Power Pack unit is illustrated below. Spare part kit for each Leistriz pump cartridge is available, given in the table. Please contact [support@neuver.com](mailto:support@neuver.com) if a pump overhaul spare part kit is needed. If both pumps are to be overhauled, two spare part kits are needed. A procedure for the pump overhaul is given in the following pages.

Leistriz pump type	Pump spare part kit
L3MF32	N35290
L3MF38	N35291
L3MF45	N35292
L3MF52	N35293
L3MF60	N35294
L3MF70	N35295
L3MF80	N35296
L3MF90	N35297
L3MF100	N35298

Please see below illustration for where to find the different parts on the Leistriz pump cartridge and the related item numbers in the spare part kit.

### Item numbers for Loctite needed:


Type	Item No
Loctite 577	N31556
Loctite 574	N22435_FR




### Procedure for the Leistriz pump overhaul:

#### Dismounting the Leistriz pump from the Power Pack unit

1. Set the selector switch on motor controller to position 2 "STOP".
2. Disconnect the electrical cables in the outlet box.
3. Disconnect SAE flanges and pipes [1] leading to the actuator.
4. Loosen the bolts [2] and remove the electrical motor.
5. Loosen the bolts [3] on the oil tank cover.
6. Lift the oil tank cover by using chain tackles in the four lifting ears [4].
7. Disconnect the SAE flanges [5] from the pump unit [6].
8. Disconnect the pump unit [6] from the bell housing [7].
9. Loosen the set screw [7] and disconnect the coupling [8] from the pump shaft by using an extracting tool.






The Leistritz pump cartridge is now dismantled from the Power Pack unit. If the old pump unit has failed, replace the pump unit with a new.

For replacement of the ball bearing and shaft seal ring:

1. Remove the key [9] and loosen the bolts [10] to remove the cover driving side [11].
2. Remove the circlip [12] and supporting disk [13].
3. Withdraw the ball bearings [14] from the shaft.
4. Refit new ball bearings on the shaft and replace the circlip [12] and supporting disc [13].




5. Remove the circlip [15] on the cover driving side
6. Grease and renew the shaft seal parts; shaft seal ring [16], supporting rings [17] and the spacer ring [18]

**NOTE!**

It is very important that the shaft sealing parts are inserted in correct position.

7. Reassemble the pump unit by refitting the cover [11], bolts [10] and key [9].



### Refitting the Leistritz pump to the Power Pack unit

1. Mount the pump to the bell housing [7] with Loctite 577 and 574 applied to the threads and between the connecting flanges respectively.
2. Mount the SAE flange [5] to the pump unit and replace the oil tank cover.
3. Replace the coupling [8] on the pump shaft. The coupling shall be mounted so that the distance to the bell house to the bottom of the coupling is equal to the distance from the motor flange to the lowest point on the motor side coupling with a 2 mm clearance added.
4. Fasten the coupling by tightening the set screw.
5. Insert a new flexible coupling.
6. Align the couplings and lower the motor vertically on to the bell house.
7. Fasten the motor, oil tank cover, SAE flanges and pipes [1] leading to the actuator and electrical cables.
8. Turn the selector switch on the motor controller to position 2 “REMOTE CONTROL”.

#### **NOTE!**

If necessary, perform the venting procedure as described in chapter [11.2 Venting](#)

## 14. Contact

---

**Contact information:**

**NEUVER MARITIME AS**  
Aarsundvegen 24  
6270 Brattvåg  
N-6270 Brattvaag



**All inquiries:**

Phone: +47 48 28 85 00  
E-mail: [support@neuver.com](mailto:support@neuver.com)

**Home page:**

[www.neuver.com](http://www.neuver.com)