

I'm not a bot



Lenel onguard hardware installation guide

Lenel onguard 8.0 installation guide. Lenel onguard client installation guide. Lenel onguard 7.6 installation guide. Lenel onguard. Lenel onguard 7.6 hardware installation guide. Lenel onguard installation guide. Lenel hardware installation guide. Lenel onguard hardware installation manual. How to install lenel onguard. Lenel onguard 7.5 installation guide.

Hardware Installation Guides and Warranty Information Lenel's warranty covers repairs or replacements for defective units, excluding consequential damages. Warranty Table of Contents page listed on page 17 Inputs, Outputs, and Interfaces section starts on page 19 RS-232 interfaces discussed on page 4 Installation guidelines begin on page 9 Maintenance information can be found starting on pages 11 and 20 Specifications for various modules, including the LNL-2210, LNL-3300, LNL-1100-U, LNL-1200-U, and LNL-1300U Table of Contents for Hardware Installation and Configuration Chapter 67: Installation and Setup (Pages 355-368) - 67.1 Wiring and Setup - 67.2 Recommended Settings for PoE - 67.3 Install Jumpers Chapter 78: External Tamper and Power Considerations (Page 399) - 78.7 External (Cabinet) Tamper - 78.8 Power and Communications - 78.9 UL Listed Installations Specifications (Page 401) LNL-1320 Dual Reader Interface Module (Page 403) Overview of the LNL-1320 (Page 405) - 80.1 Interfaces - 80.2 The Dual Reader Interface Module (Series 2) Chapter 89: Specifications (Page 449) LNL-8000 Star Multiplexer (Page 451) Overview of the LNL-8000 Board (Page 453) - 90.1 Interfaces - 90.2 The Star Multiplexer Board Installation Instructions for the LNL-8000 (Page 455) - 91.1 Wiring - 91.2 Wiring and Termination Chapter 100: DIP Switch/Jumper Settings and Configuration (Pages 482-486) - 100.2 DIP Switch/Jumper Setting - 100.3 Keypad Data and Tamper Monitor Signaling - 100.4 TTL Interface - 100.5 OnGuard Configuration - 100.6 Grounding the Reader - 100.7 Reader Verification - 100.8 Status Indicators - 100.9 Maintenance Chapter 104: Lenel OpenCard Readers (Page 535) Lenel OpenCard Readers Overview (Pages 537-542) - 104.1 OpenCard ISO-X Readers - 104.2 OpenCard XF1050-K - 104.3 OpenCard XF1500 BlueDiamond Mobile Readers (Pages 545-547) - 105.1 Readers Chapter 115: 4G Configuration for SecureAdmin and OnGuard (Page 609) - 115.3 4G Configuration in SecureAdmin - 115.4 4G Reader Interface Connections - 115.5 Wiring 4G Verification Readers - 115.6 4G Reader Configuration on OnGuard - 115.7 Enrollment Configuration - 115.8 Encoding Configuration Chapter 116: Biocrypt 3G Series Readers (Page 621) Biocrypt 3G Series Readers Overview (Pages 621-623) - 116.1 V-Pass FX and V-StationA Chapter 121: DIP Switches, Jumpers, and Reader Configuration (Pages 683-687) - 121.1 DIP Switches - 121.5 Jumpers - 121.6 Command Keypad Configuration - 121.7 Status Display - 121.8 OnGuard Configuration - 121.9 Command Programming - 121.10 Command Keypad Behavior Specifications (Page 689) **Hardware Installation and Power Requirements** Installing access/alarm systems requires careful consideration of interface compatibility, power supply sizing, and reliable wiring. The recommended interfaces include RS-485, RS-232C, Modem, 20mA Loop, Mode of Differential DC, Single-ended DC, and Differential AC. **Power Supply Considerations** Choosing the right power supply is crucial for safe and reliable system operation. A minimum 25% overvoltage should be applied when sizing the supply to prevent current overload. Isolated, non-switching, regulated power supplies are recommended. Specific device power requirements are listed in tables for devices such as LNL-1100-U, LNL-1320-U, and others. **Device Power Requirements** Devices like LNL-XF1100D, LNL-XF2100D, and LNL-XF2110D require specific voltage and current ranges. The typical door strike power is estimated at 24VDC, 300mA. Consult manufacturer specifications for actual values. **Hardware Installation Guidelines** System wiring must be properly planned and executed to ensure safe and reliable operation. Improper or incorrect wiring can lead to system failure or damage. Care must be exercised when power wiring system components with different power sources. **Physical Installation Considerations** The LNL-CTX-6 hardware enclosure supports up to six Lenel access hardware modules, while the ABT-12 battery kit provides a 12VDC, 12Ah power supply. Physical installation guidelines include mounting the hardware standoffs and using support standoffs for certain devices. **Important Notes** Refer to specific device diagrams for termination configuration guidance. The LNL-CTX knockout can be used in standard 2-gang or 3-gang junction enclosures. The LNL-AL001UX installation should follow the National Electrical Code (NEC) article 760 and NFPA70 guidelines, as well as local codes. Install the enclosure in the desired location. Connect the unswitched AC power to terminals marked L, G, N, dedicated to the Burglar Alarm/Access Control Subsystem. The input requires 120 VAC, 60 Hz, 1.45 amp, with a DC output and battery & AC supervision circuit (power limited). For UL-certified installations, wire connections crossing the hinge side of the door must be wrapped or tied together. Install multiple Lenel hardware panels into a single enclosure using the provided guidelines. Connect the cabinet tamper switch to the cabinet tamper circuit on the Lenel access hardware. Each hardware product must be grounded for ESD protection, personnel safety, and signal reference. Grounding provides a shield against external transients. All alarm inputs require twisted pair wires with an end-of-line (EOL) resistor terminator for each supervised alarm input. Connect normally closed (NC) contacts in series and normally open (NO) contacts in parallel. Refer to the diagrams for RS-485 Signal Ground and Termination. For multi-drop wiring, use the provided diagrams for ISC and LNL-500B, Shield Earth Ground, one point only per ISC. When using multiple power supplies on a single ISC, connect DC, when necessary. Protecting DC inductive loads is feasible using clamp diodes, selecting ones with a reverse breakdown voltage ten times higher than the circuit voltage. AC inductive loads can be safeguarded by metal-oxide varistors (MOVs), particularly effective when the load voltage falls within 100V to 200V. When turning up a system, it should never be powered and cycled at once; instead, allow a step-by-step process ensuring no power is applied to any device. Verify all wiring and device switch settings before proceeding. Before connecting a device to an RS-485 communication line, check for potential damage to connected devices. For wireless readers functionality, the LNL-500W requires firmware version 1.10 or higher; the most current firmware is shipped with OnGuard software and can be updated through its interface. Equipment installation should take place in a temperature-controlled environment (13°C - 35°C or 55°F - 95°F) maintained by an HVAC system, ensuring at least 24 hours of standby time for the system. For UL1076 compliance, systems must meet requirements specified in Section 25A and use UL Listed power supplies along with specific hardware configurations. This guide outlines requirements and installation procedures for HID Edge devices, Lenel OpenCard XF series, and other compatible hardware for access control applications. Specific devices such as LNL-CK are mentioned for remote arming purposes. Installation involves creating local I/O functions in the Access Control panel, including steps for mask groups and alarm points. Hardware must meet CAN/ULC-S319-05 requirements, particularly for OnGuard monitoring software versions 7.0 through 7.3. Additionally, EN Certified Readers such as AWID Sentinel Pro KP-6840GRMP are approved for use with the OnGuard system. Troubleshooting sections address potential causes of system problems and provide specific solutions related to software configuration and panel memory verification. The guide also includes an overview of the LNL-500 Intelligent System Controller, detailing its features and installation procedures, including wiring requirements for unsupervised alarm inputs, upstream host communication, and downstream device communication. Direct-connect RS-232 cables should not exceed 50 feet; leased lines or fiber optics can be used instead, while RS-485 requires a specific type of twisted pair cable. RS-485 cable configuration can be used for a maximum distance of 4000 feet (1219 meters), with an impedance of no more than 20 ohms, using the 9842 4-wire or 9841 2-wire terminum cables. The drop cables to readers and other devices should not exceed 19 feet in length. An RS-232 to RS-485 converter is required at the host workstation if RS-485 communication is used. To connect the ISC (Intelligent System Controller) to the Reader Port via 2-wire RS-485, the toggle RTS low checkbox should be checked in the Rocket Port settings. For downstream device communication wiring, the Port 2-3 configuration uses TR1+, TR1-, RI+, and so on. The LNL-500 ISC can be located anywhere along the RS-485 line, with an RS-485 terminator installed at each end-of-line device. The ISC accepts either a 12 VDC or 12 VAC ± power supply. Configuration involves setting DIP switches and jumpers on the ISC board for system-specific settings. Communication handshake status is configured using DIP switch 5, with specific settings depending on the type of communication being used (RS-232, RS-485, etc.). The LNL-500 ISC requires firmware updates periodically. Verification of correct installation can be done using the three Status LEDs on the ISC board after power up. The LNL-500 is designed for use in low-voltage, class 2 circuits only, with specific power and memory requirements outlined in the specifications. This document is designed for technicians who will be setting up and maintaining the Intelligent System Controller (ISC). The ISC acts as the main access control system and provides power, performance, and flexibility for demanding applications. It contains an ISC board with various components such as alarm inputs, interfaces, power input, switches, and jumpers. To install the ISC, follow the procedures in order, starting from wiring the unsupervised alarm inputs to the downstream device communication. For RS-485 communication, use a 24 AWG twisted pair cable no longer than 4000 feet with a maximum impedance of 10 ohms. The drop cables to readers and other devices should be kept as short as possible, not exceeding 10 feet. Note that an RS-232 to RS-485 converter is required at the host workstation if using RS-485 communication. The ISC can communicate downstream with up to 16 input/output devices through Port 2, Port 3, Port 4, and Port 5. Each port can be wired as an RS-485 interface for multi-drop communication on a single bus up to 4000 feet. The power source should be a 12 VDC or 12 VAC ±10%, with a maximum current draw of 500mA. The device features primary power options of 12 VDC @ 250mA and 24 VDC @ 150mA. These specifications are subject to change without notice, and the latest version of EFWebCon can be downloaded from the Lantronix website for configuration details. For LAN connections, any device, a jumper between D1 and LED terminals is required. Additionally, wiring specifications are given for OSPB readers, including GROUND, DATA 0, DATA 0, and READER PORT connections on TB8 or TB9 terminal blocks. The LNL-2220 Intelligent Dual Reader Controller also supports the connection of Biocrypt Readers, requiring specific power and ground connections as per the provided diagram. Furthermore, guidelines are given for installing a standard supervised circuit with 1K Ohm resistors near the sensor to facilitate proper reporting. Hardware Installation Guide for LNL-2220 emphasizes the importance of using sufficient gauge wire to avoid voltage loss and selecting appropriate diodes based on strike current and voltage requirements. Wiring configurations for power, power fault, and cabinet tampering are also provided. Lastly, instructions are given for clearing memory by pressing the reset button or power up, accompanied by LED indicators during this process. Initial IP Addressing Mode **## Set the board for the desired initial IP addressing mode. The board can be initially configured using a fixed static IP address or an automatically assigned IP address by a DHCP server. Page 162 - LNL-2220 Intelligent Dual Reader Controller The Home page indicates the device type and has a Notes field, where you may add a description and save it. To configure network settings, click [Network] **##. If using DHCP, specify a host name. The default host name consists of "MAC" followed by the device's MAC address number. Page 163 - Hardware Installation Guide Access View allowed Edit allowed Apply Setting page Level 2: No Level 3: No For pages that cannot be viewed, a message is displayed when users attempt to access the page. "This page is unavailable due to one of the following reasons: your user name is not authorized to view this page, or another level 1 user is logged in at this time..." LNL-2220 Intelligent Dual Reader Controller Maintenance Refer to Firmware Updates in the Hardware Installation Guidelines section for instructions on downloading firmware. 30.1 Verification Power-up: All LEDs OFF. Initialization: LEDs are sequenced during initialization. Running - After initialization is complete, LEDs have the following meanings: AT power up, send data, received data, and carrier detect. The modem can be configured using AT commands, such as AT+FLAN and AT+PIG=1+PMH=1+POC=3. **Security Modem** The Security Modem Unit DC-336 modem is the recommended modem for ISC dial-up configurations. It has a two-pin jumper that can be set to either dumb or smart mode, with the default setting being smart mode. The modem also features a 25-pin female RS-232 connector and a power switch. **RocketPort Hub Settings** The RocketPort hub settings can be modified in Device Manager. The settings include port mode, baud rate, timeout periods, and modem emulation options. It's recommended to install the driver for the RocketPort Si Hub before configuring the hub. **Configuring the RocketPort Hub** To configure the RocketPort hub, refer to the Single Multi-Mode Duplex Data Transmitters Receivers Installation Guide, which is included with the device. The DFDMM001-TX and DFDMM001-RX are both needed, as they work as a pair connecting upstream to a Lenel Access or Security Series controller. **Important Safety Notes** When disconnecting the fiber optic connector from the RocketPort hub, be sure to turn off the power first to avoid exposure to Class I invisible optical radiation. To ensure safe radiation exposure, follow specified procedures and avoid making unauthorized adjustments or performing operations. The LNL-1100 Input Control Module (ICM) provides high-speed acknowledgment of critical alarm points in monitored areas, featuring sixteen configurable input control points and two output control relays. The ICM supports various circuit types, including normally open, normally closed, supervised, and non-supervised circuits. Scalars To configure the elevator control, navigate to the Elevator Hardware tab in the System Administration software's Readers window. The device communication address can be set by configuring DIP switches 1-5 on the Input Control Module board according to a specific table. For communication baud rate, set DIP switches 6 and 7 to match one of three available options: 38400 bps, 19200 bps, or 9600 bps, but only when OnGuard software supports 38400 bps. The communication password status is controlled by DIP switch 8. Installation involves setting the board, address, and LED control switches, installing jumpers, and mounting the board in an enclosure. The Input Control Module board has three available DIP switches for output relays, including baud rate, and other functions, as well as an RS-485 termination jumper. 2. For RS-485 communication termination, a jumper must be installed on the last ISC unit on the communication line. Refer to page 293 of the upstream wiring diagram for more information. LNL-1100-U Input Control Module 483 Status LEDs Note: The status LEDs only function when the cabinet door is open. When closed, they remain off. 48.3.1 LED Table for Series 2 LNL-1100 Module. Page 287 Hardware Installation Guide: CPU Status LED and Module Error Conditions Error condition Flashing Description pattern No valid application firmware Red The module is not operational. Firmware must be loaded using a console, e.g., HyperTerminal with Xmodem. LNL-1100-U Input Control Module Mounting The ICM can be mounted in various enclosures using the Universal Mounting Plate (UMP). Mounting the ICM in specific enclosures requires reference to page 289 and page 288 of the Hardware Installation Guide. LNL-1100-U Input Control Module Wiring Wire inputs I1 through I16 using a twisted pair cable with a maximum resistance of 30 ohms. Use a minimum of 24 AWG wire. For UL installations, refer to section UL Listed Installations on page 296. ICM input wiring requires reference to the Input Resistor Table. Each supervised alarm must be terminated with two (2) 1K (1000) ohm resistors, provided with the module. Given text here The Power In input with a minimum 18 AWG twisted pair cable is required. DC power source requirements include: - Isolated, non-switching, regulated DC power - Current: 300mA for 12VDC and 150mA for 24VDC Note: Do not observe polarity. Power source wiring must be installed according to 50.7 UL Listed Installations specifications. LNL-1100-U is for low-voltage, class 2 power-limited circuits only. Primary power: - 12 to 24 VDC ± 10% - Nominal values: 12VDC @ 300 mA and 24VDC @ 150 mA - 12.3 BTU/hour Input Control Module: - Revision 7 - LNL-1200 Output Control Module - RS-485 communication Each OCM is an individually addressed device with a maximum of 16 devices on each ISC. OCM can be powered by 12 to 24 VDC power. Dedicated camera and power failure input contacts are included with every OCM. Output Control Module - Series 2 board contains components such as alarm output relays, unsupervised alarm inputs, RS-485 interface, power input, DIP switches, and jumpers. 20 LEDs verify correct installation after power up. Power-up All LED's OFF. Initialization begins once power is applied. A LED turns on at the beginning of initialization. If application program cannot be run, A LED flashes rapidly. To install Output Control Module, perform procedures in Hardware Installation Guide sections, in order presented. Wiring includes unsupervised alarm inputs for power fault and cabinet tamper monitoring, upstream host communication, RS-485 communication is asynchronous, half-duplex with 1 start bit, 8 data bits, 1 stop bit. LNL-1200 series 2 upstream controller communication wiring: 2-wire (port 1) RS-485. Elevator Control OnGuard hardware supports elevator control for up to 128 floors. Application software must be configured for elevator control on Elevator Hardware tab in Readers window of System Administration software. "Elevator" box should be checked for reader's type, name, port, address, access panel definition. To set up communication on the LNL-1200 Output Control Module (OCM), you need to configure the baud rate using DIP switches 6 and 7. The default baud rate is 38400 bps, but you can change it to 19200 bps or 115200 bps if needed. The OCM board has two types of ports: 2-wire and 4-wire. It also has RS-485 interface that allows for communication with other devices on the same circuit. The board is designed for use in low-voltage, class 2 circuits only. To install the OCM board, you need to set up the DIP switches, install jumpers, and mount the board into an enclosure. The board has two 8-position DIP switches that control addressing, baud rate, and other functions. One of these switches controls the utilization of encryption. The OCM board also has status LEDs that indicate the state of the relays and power supply. There are 16 alarm output relays with corresponding status LEDs, as well as two unsupervised alarm inputs and one RS-485 interface. To configure the OCM board, you need to set up the DIP switches, install jumpers, and configure the RS-485 termination jumper. This jumper is used to enable RS-485 communications on the last OCM on the communication line. The OCM board also has a package contents list that includes the board itself, as well as any necessary jumpers or screws. Finally, there are some error conditions described in the text, including flashing LED patterns that indicate when the boot loader is loading a firmware file, or if an invalid EFL file is detected. The EFL specifies for loading with Console 2 Green loader is not a valid EFL file. The Output Control Module (OCM) can be mounted in various enclosures using the Universal Mounting Plate (UMP). For specific mounting instructions, refer to the Hardware Installation Guide. The OCM features two unsupervised alarm inputs for power fail and external tamper monitoring. It also uses Port 1 for upstream communication with the Intelligent System Controller via a 2-wire RS-485 interface. The module contains 16 form-C dry-contact relay outputs and is capable of supporting elevator control for up to 128 floors. The OnGuard software must be configured for elevator control, which can be done through System Administration. For UL installations, specific wiring requirements apply, including the use of 22 AWG minimum for RS-485 wiring. The module is designed for connection to low-voltage, class 2 power-limited circuits only. The LNL-1300 Single Reader Interface (SR) module supports various access control solutions, including readers with keypads and off-line access modes. It also supports lock/unlock and facility code functionality on all connected readers. The Single Reader Interface Module Board contains components for supervised alarm inputs, RS-485 interface, relay outputs, power input, and jumpers. This module communicates with the Intelligent System Controller using a 2-wire RS-485 interface and can be configured to select door contact and REX status through access control software. The Single Reader Interface Module uses Port 1 for communication, requiring a specific type of RS-485 cable. The module also contains two form-C dry-contact relay outputs, K1 and K2, which are used for various functions such as reader authentication and system configuration. In addition to its primary function, the Single Reader Interface Module can communicate downstream with one keypad or card reader using a six-wire interface (GREEN LED) connection, Reader Data 1 connection, and Ground connection. The LNL-1300U Single Door IP Interface Module supports various input circuit wiring configurations, but these may not be typical. For standard supervised circuits, normally open and closed contacts are used, as well as unsupervised circuits with normally open and closed contacts. When using power-over-Ethernet (PoE) on the LNL-1300U, it is recommended to configure the network switch to 10 Mbps or half duplex to avoid intermittent communication issues. Two addressing modes are available: static IP addresses and low-voltage DHCP. To set up a static IP address, users must configure the DIP switches to "0010" and enter three digits in the address field with leading zeros. After completing this setup, the device will display its assigned IP configuration. The LNL-1300U is capable of supporting elevator control for up to 128 floors, but requires OnGuard software configuration. The mounting plate dimensions are 00.16 [04.0] and 00.16 [04.0] with specific holes for the magnetic switch set and blank cover. LEDs on the device indicate status updates, including a power-up sequence and periodic pulsing of the LED to its opposite side if input IN1, IN2, or IN3 is defined. The LNL-1300-U Single Door Controller Module is a solution for interfacing with Wiegand/RS-485 type readers and door hardware. It can accept data from a reader using various signaling methods. For UL installations, it's crucial to note that RS-485 cannot be used, and each field-wiring terminal must support single conductor only. The module provides tri-stated LED control and buzzer control, with detailed mounting instructions available in the Hardware Installation Guide (DOC-600). The

LNL-1300U Single Door IP Interface Module operates within low voltage Class 2 circuits only, powered by PoE at 12.95 watts or a 12 VDC ±10% power supply up to 900 mA maximum. The module is FCC Part 15 compliant and CE marked, adhering to RoHS and WEEE standards. Its specifications may be subject to change without notice. Installation involves setting baud rate, address, and LED control switches, installing jumpers, and mounting the board into an enclosure, requiring the LNL-CONV-U for Future Mounting Plate for CTX enclosures. Configuration is facilitated through two 8-position DIP switches and four jumpers. The module offers various settings, including communication baud rate, LED mode, address selection, jumper configuration, and status LEDs that only function when the cabinet tamper switch is open. The SDC (Single Door Controller) can be mounted in various enclosures using the Universal Mounting Plate (UMP). This plate can hold up to two LNL-1300-U modules. The SDC requires specific wiring and connections for alarm inputs, which are configured according to a standard resistor table. For UL installations, refer to page 400 for wiring specifications. The alarm inputs use a twisted pair cable with resistors to terminate each input. The Single Reader SDC Interface Module can communicate downstream with one card reader using six wires that include buzzer and LED control. The interface uses an open collector type switching circuit and requires power voltage of 12V DC or optional 5V DC jumper selectable. The Open Supervised Device Protocol (OSDP) enables bi-directional communication between readers and the reader interface, providing real-time monitoring and control of reader operation and configuration. The SDC supports elevator control for up to 128 floors, requiring software configuration from System Administration. An external cabinet tamper can be configured by connecting a device across pins 3 & 4 of J18 on the SDC. Note that power fail is not supported on the SDC, and an AC transformer should not be used to directly power the Single Reader SDC Interface Module. For UL installations, specific requirements must be observed as outlined in the Hardware Installation Guide. • Primary power: 12 to 24 VDC, with a nominal 24 VDC at 350 mA (includes reader current), or 12 VDC at 700 mA (includes reader current) @ 10% variation. • The LNL-1320 Dual Reader Interface Module supports up to 64 access control card readers, keypads, or combinations of both that use standard data I/data0 and clock/data Wiegand communications. • Lock/unlock and facility code functions are supported for all readers connected to the DRI. • The module features eight supervised/non-supervised alarm inputs, one RS-485 interface, two reader interfaces, six relay outputs, one power input, one cabinet tamper, jumpers, and eight DIP switches. 81.1.4. Page 414 LNL-1320 Dual Reader Interface Module Typical Reader Wiring RED (1) BRN (4) ORG (5) WHT (3) DJ CLK GRN (2) DO/DA BLK (6) All readers with a buzzer will beep during pre-alarm in extended held open mode, including primary and alternate readers. Page 415 Hardware Installation Guide Unsupervised F/2F Reader Wiring Callouts Callout Description TB8 or TB9 on LNL-1320 Unsupervised F/2F Reader TB8-1: +12 VDC connections TB8-2: LED terminal to Reader DO (GREEN LED) connection TB8-4: Reader Data 1 connection TB8-6: Ground connection Typical Supervised F/2F Reader Edge Inputs Inputs for door position monitor and REK switches are directly wired to the F/2F reader, configured for 2-State or 4-State Supervision. Page 416 LNL-1320 Dual Reader Interface Module Supervised 4-State F/2F Reader Edge Wiring Callouts Callout Description TB8 or TB9 on LNL-1320 Supervised F/2F Reader TB8-1: +12 VDC connection For supervised readers, install jumper between D1 and LED terminals. TB8-3: Buzzer terminal to Reader DO (GREEN LED) connection TB8-4: Reader Data 1 connection TB8-6: Ground connection Normally Closed contact for door monitor switch... Page 417 Hardware Installation Guide Supervised Board Edge Wiring Callouts Callout Description TB8 or TB9 on LNL-1320 Supervised F/2F Reader TB8-1: +12 VDC connection For supervised readers, install jumper between D1 and LED terminals. TB8-3: Buzzer terminal to Reader DO (GREEN LED) connection TB8-4: Reader Data 1 connection TB8-6: Ground connection 81.1.6... Page 418 LNL-1320 Dual Reader Interface Module Wire BA and CT inputs using twisted pair cable, 30 ohms maximum. No EOL resistors are required. CABINET IN 9 TAMPER POWER FAULT IN 10 The Electronic Industries Association standard defines RS-485 for multi-port communications on a bus transmission line. Hardware Installation Guide Supply Power to the Interface 12 to 24 VDC 81.2 Elevator Control Currently, elevator control is supported for up to six floors on the dual Reader Interface Module. Access Control System Intelligent System Controller Maximum: 500 feet Dual Reader 6 conductors Interface... Page 420 LNL-1320 Dual Reader Interface Module Contact Wiring for Elevator Control DRI Alarm Input Contact Wiring DRI Alarm Output Contact Wiring Floor Output 1 Reader Aux 1 In 1 RLY 1 Reader Aux 2 In 2 RLY 2 Floor Output Reserved for Future Use In 3 Floor Output 3 Device communication address (0 - 31) 6, 7 Communication baud rate Downstream encryption (available with OnGuard 2009 or later) Given article text here Looking for a controller to manage doors, this dual door controller module seems like a good option. It has a specific voltage range of 12-24VDC and can handle up to 550mA of power. There are different settings and configurations to consider, such as baud rate and address switches, which can be adjusted using DIP switches or jumpers. The board contains seven jumpers that need to be configured for the system, including jumper J33 for RS-485 communications termination and jumper J17 for +12VDC readers. It's also important to note that there are different LED modes, such as series 2 LNL-1320 mode, which can be achieved by setting switch 5 to the ON position. To install the Dual Door Controller (DDC), you need to follow a specific order of installation procedures, including mounting the board in an enclosure and configuring the baud rate, address, and LED control switches. The DDC has two user-selectable DIP switches that allow for addressing and baud rate adjustments. The LNL-1320-U Dual Door Controller Module can be installed using the Universal Mounting Plate (UMP) LNL-CONV-U with enclosures such as the LNL-AL400ULX or LNL-CTX, and the LNL-AL600ULX-4CB6 or LNL-CTX6. For UL installations, refer to section UL Listed Installations on page 447. For wiring, use twisted pair cable with a maximum of 30 ohms and a minimum of 24 AWG for inputs I1 through I8 (J19 - J22). The DDC can communicate with two card readers using the six-wire interface that includes buzzer and LED control. Reader power is optional at 12 VDC or jumper-selectable to 5 VDC, with a maximum current of 400 mA. The module supports Open Supervised Device Protocol (OSDP) for bi-directional communications between readers and the reader interface. The DDC also features two unsupervised alarm inputs for power fail and external tamper monitoring. Hardware Installation Guide Refer to UL Listed Installations on page 447. The LNL-1320 is designed for connection to low voltage, class 2 power-limited circuits only. Specifications subject to change without notice. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific guidelines to ensure compliance with part 15 of the FCC Rules. This includes not causing harmful interference and accepting any received interference, including that which may cause undesired operation. To disconnect the keypad, follow the previously described steps in reverse. It is crucial not to disconnect the keypad without disengaging the connector first. The readers are designed for heavy traffic areas, with extended life read heads available from the factory at the time of order, extending the read head life up to 1 million card swipes. For outdoor readers in heavy traffic areas, cleaning should be performed at least once per month. Configuration options include standard format codes and DIP switch/jumper settings. Keypad data and tamper monitor signaling are transmitted on the data lines as 6-bit blocks, encoded using the same signaling method selected for the card data output. Wiring for these readers includes connecting to an LNL-1300 or LNL-1320-U device, with specific wire descriptions and typical software settings provided. The reader has two blinking LEDs that signify its status, including card and PIN verification, cipher lock emulation, and facility behavior. **Installation Guide** This guide provides information on installing the LNL-2010W/2020W/2020W-NDK/NDKV2 Magnetic Card Access Reader and LenelProx readers. **Product Identification** The reader product identification is provided on labels with information such as program ID, revision, product ID, supply voltage, and copyright notice. **Reader Specifications** The reader operates in low-voltage class 2 circuits only. * Power: 5V model (4.9-6.4 VDC) or 12V model (10.2-13.8 VDC). * Current: 80mA (25mA typical). **Installation Requirements** * Mounting dimensions: + LNL-2020W-NDK: 1.25" x 2x 0.18" mounting hole, 1.0" x 2.56" dimension + Optional wall plate WP-10: 2.75" x 2x 0.18", 1.4" x 1.2" * Weather shield (part # LNL-WS10): + Must have rounded/smoothed edges with a radius of 0.015". + Material: stainless steel, 304-2B, 18GA. **LenelProx Readers** The LenelProx readers are radio-frequency proximity readers with integrated keypads or without. Supported models include LPM-6800, LPSP-6820, LPKP-6840, LPSR-2400, and others. **Important Installation Considerations** * Do not install the reader in areas with sources of broadband noise. * Do not bundle reader wires together with AC power cables or other signal wiring. * Ensure all readers are connected to a single ground point for multiple reader installations. Snap open the reader's top cover by inserting a screwdriver blade into the slot at the bottom edge of the cover and twisting it gently. Connect the reader to the access control panel according to the diagram. For unused wires, use tape or caps individually. Power up the reader; the LED will be steady amber. Present any Lenel proximity credential (card, keytag, or wafer) briefly to the reader. The beeper should sound a single short beep, and the LED will turn steady red, indicating standby mode. The reader is now initialized and prepared to read authorized cards. To change the LED standby mode from blinking red to steady red or vice versa, use an LED Mode Changer card (available from Lenel) by removing power from the reader for a few seconds, then restoring it while the LED is amber. For hardware installation, place a single-gang utility box at the desired mounting height, observing ADA requirements. Alternatively, drill clearance holes for the reader and one hole for the cable. When wiring the LPKP-6840 and LNL-1320 readers, ensure correct pin assignments according to the table provided. The typical software settings include setting the reader type to Wiegand/Prox, keypad output to 8-Bit, data 0 to green, and ground to black. It is essential to comply with FCC regulations by avoiding harmful interference in residential areas. Users are prohibited from modifying the product, as any such change will void their authority to operate under FCC Part 15 Subpart A Section 15.21 regulations. To change the LED mode of your LPRK-4600, use an LED Mode Changer card from Lenel. Simply shut down power for a few seconds, then turn it back on while holding the card near the reader during its amber phase. This will toggle the LED's standby mode between blinking-red and steady-red. When mounting your reader, consider using a single-gang electric utility box or drilling clearance holes for screws and cable access. Ensure the surface is securely mounted to prevent damage from environmental factors. Use epoxy resin to protect against harsh conditions. For initialization, insert a valid Lenel proximity credential (card, keytag, or wafer) near the reader's lower-end indent. This will initialize the device. To read a credential or enter keystrokes, hold the card or press the marked key firmly over the designated area. If you have a LenelProx Reader with radio communications, be aware that its operation in residential areas may cause interference, requiring correction at your expense. Any modification to this product voids your authority to operate under FCC regulations. When using the LPMR-1824 reader, always mount it on a metal surface larger than its 8 x 8 inch opening, ideally with a minimum of 12 square inches. This enhances the device's performance and ensures proper functioning. For optimal read range, use Lenel's Prox-Linc CS clamshell cards or GR/GRMAG cards for rated performance. KT key tags offer about 75% of the GR cards' range, while PW proximity wafers provide approximately 40%. During installation, present a Lenel card to the reader, observing how its LED changes from red to amber and back to steady red. The Magnetic Card Access Readers are available in both 5VDC and 12VDC models, with fully weatherized metal casing shells providing strength and durability. The readers comply with FCC Part 15 rules and must accept any interference received to operate properly. Key features include DIP switches for configuration/parameter setting, keypad connectors, and RJ-11 jack connections. To install the reader, remove the top mounting bracket and access the DIP switches using a small tool. Clean the read head(s) as contamination can cause accelerated wear. The reader's wiring diagram shows typical settings for the keypad, terminal output, and LED modes. The reader is designed for use in low-voltage, class 2 circuits only and requires power between 5.8VDC (4.9-6.4VDC) or 12VDC (10.2-13.8VDC). It has a current rating of 80mA (25mA typical) and data output capabilities. For mounting, the reader comes with an optional wall plate and requires a mounting hole that is 1" x 1". The weather shield should be cleaned, sanded, and brushed to provide a smooth finish. The installation guide notes important specifications and precautions for safe operation. The Magnetic Card Access Readers, including LNL-2010W, LNL-2020W, LNL-2020W-NDK, and LNL-2020W-NDKV2 models, offer durability, dependability, convenience, and competitive pricing. These readers are available in both 5 VDC and 12 VDC versions. The LNL-2010W is a magnetic swipe-only model, while the LNL-2020W/NDK/V2 features a twelve-position keypad. Installation of these devices involves following specific