



Scan me for our
installation
tutorial



Scan me for
our Quick
Guide



01	About this document	3
01.1	Purpose of this document	
01.2	How to use this document	
01.3	Language	
01.4	Symbols and signal words used in this document	
02	Safety	4
02.1	General	
02.2	Connect to the inverter	
03	Packaging	5
04	Description	6
04.1	Overview of the system	
04.2	Overview of the gateway	
04.3	Data cables delivered separate from gateway	
04.4	Status shown by the indicator light in the power switch	
04.5	Status shown by indicator lights 1 and 2	
05	Installation	8
05.1	Preliminary requirements	
05.2	Install the gateway	
06	Declaration of conformity	13
07	Technical specification	14
07.1	Gateway	
07.2	Smart module M6	
07.3	Smart module M10	
08	Drill template	17

01 About this document

01.1 Purpose of this document

This document is only applicable for the gateway. Refer to the technical specifications for the applicable part numbers. From here on, this document refers to the gateway as the equipment.

The equipment is part of a solar power system, from here on in this document referred to as the system.

The document is for approved personnel and gives the information that is necessary to install the equipment.

01.2 How to use this document

1. Make sure that you know the structure and contents of this document.
2. Read the safety chapter and make sure that you know all the instructions.
3. Do the steps in the procedures fully and in the correct sequence.
4. Keep the document in a safe location that you can easily access. This document is a part of the equipment.

01.3 Language

The original instructions of this document are in English (EN-US). All other language versions are translations of the original instructions.

01.4 Symbols and signal words used in this document

Symbol	Signal word	Description
	Warning	Obey the instruction. If not, this can cause injury.
	Caution	Obey the instruction. If not, this can cause damage to the machine, to equipment or to property.
	Note	A note gives more data, to make it easier to do the steps, for example.
	-	Read the instructions.

02

Safety

02.1 General



Warning


- Before you switch the inverter on or off, stop the gateway. Set the power switch of the gateway in the off position (0).
- Incorrect installation can cause electric shock or can cause damage to the equipment and property. Obey the local regulations and electrical standards. The system must be installed and maintained by trained and authorized personnel.
- The gateway is designed to apply within the Taylor system, do not use it for any other purposes.
- Use the equipment only in combination with inverters that are approved by Taylor.
- Before you install the equipment, read all instructions.
- When the photovoltaic array is exposed to light, it supplies a DC voltage.
- Read the documentation and safety instructions of the inverter.
- Do not disconnect the junction box under load.
- Do not install the equipment in areas that contain flammable materials or gases.
- Install the equipment in a dry location.
- If the power cable has damage, switch off the gateway and remove the power source before you touch the power cable.
- If the equipment has damage, disconnect the power cable. Replace the equipment.
- Do not open the equipment.
- Do not make changes to the equipment.
- Recycle the equipment as electronic waste. Do not put the equipment in unsorted municipal waste. Obey the local regulations.

02.2 Connect to the inverter



Caution

- On the inverter, do not connect more than one string of solar panels to an MPPT connection.




- Refer to the documentation of the inverter.


03

Packaging


A. Gateway




B. Installation manual
(this document)




C. Power cable



D. Fastening materials




E. Drill template
(see back of this document)




04

Description

04.1 Overview of the system



04.1 Overview of the gateway



04

Description

04.3

Data cables delivered separate from gateway

Data cable	Part number (P/N)	To use with this inverter
A.	TAYLOR-GTW-C-03	Goodwe, Fox ESS
B.	TAYLOR-GTW-C-SL-02	Solis

04.4

Status shown by the indicator light in the power switch

Indicator light in the power switch	Status of the gateway	Remarks
 On	On	The system produces energy. The cable from the solar string is energized.
 Off	Off	When the gateway is off, the system is in safety mode. The cable from the solar string has approximately 1 Volt per solar panel.  Warning To make sure that the system is in safety mode, disconnect the power adapter of the gateway.

04.5

Status shown by indicator lights 1 and 2

Indicator light 1	Equipment status
Flashes 7 times	There is a connection with the 4G network.
On	The gateway updates the software.
Flashes	The gateway does a factory reset.
Indicator light 2	Equipment status
Flashes 1 time	Inverter connection fault.
Flashes 2 times	Solar module connection fault.
Flashes 3 times	Inverter & Solar module connection fault.


05 Installation

05.1 Preliminary requirements

05.1.1

Scan the barcode of each individual solar panel. In the onboarding application on your mobile device, On the 'Scan' screen (A), select the 'Scan' button (B).

05.1.1




05.1.2

The solar panels (A) are installed and the smart modules (B) are connected.

05.1.3

The inverter is installed.

05.1.2




Warning

- Obey the instructions that come with the solar panels, the smart modules and the inverter.
- When the photovoltaic array is exposed to light, it supplies a DC voltage.

Design rules

- Multiple orientations within one string are allowed.
- Each orientation should reach the start-up voltage (input DC).




05 Installation

05.2 Install the gateway




Warning

- Obey the safety instructions of the inverter.
- Make sure that the inverter is off and de-energized.
- Do not connect more than one string of solar panels to a MPPT connection.
- Do not connect parallel module strings per MPPT tracker



05.2.1

Scan the gateway. Select the 'SCAN GTW' button (A).



Note If necessary, drill holes. Drill safely. Do not drill or screw in electricity lines, water pipes, and such items. Use the correct type of wall plugs.


05.2.2

Install the fasteners. Use the drill template on the last page of this manual.

05.2.3

Attach the gateway to the fasteners (B).

05.2.3



05 Installation



Caution

Never put both cables through the hole (B).

05.2.4

Put one of the cables (A) (either + or -) through the hole (B).

05.2.5

Put the other cable through the clamp (C)

05.2.6

Connect the cables to the inverter (D). Refer to the documentation of the inverter.


05.2.7

Connect the data cable to the inverter (B). Refer to the website: <https://www.taylor.solar/manuals>


05.2.8

Connect the data cable to the data connection (A).


05.2.4-5



05.2.6



05.2.7-8



05 Installation

05.2.9

Connect the power cable (A).

05.2.10

Put the power adapter (B) in a wall socket.



Warning

- Make sure that the solarpanels, the smart modules and the inverter are installed correctly.
- Before you switch the inverter on or off, stop the gateway. Set the power switch of the gateway in the off position (O).

05.2.11

Start the inverter. On the inverter, set the DC switch to on.

05.2.12

On the 'launch' screen (A), select the 'launch' button (B). When the system onboarding is confirmed, the customer receives an e-mail to register to the Taylor dashboard.

05.2.13


Set the switch (A) in the on position. The light in the switch comes on.




Note

- A few seconds may be necessary for the system to start.
- If a 4G connection is not available, use a wired LAN connection.
- If a WiFi connection is necessary, please refer to taylor.


05.2.9-10



05.2.12



05.2.13



05

Installation

05.3 Crosstalk



Warning

In case of larger projects where multiple gateways are being used, make sure the DC kabela of the different projects are more than 10cm apart.

If the DC cables of different projects are routed through the same cabletray, 1 gateway can activate panels of multiple projects.

06 Declaration of conformity

Hereby, Taylor Technologies B.V. declares that the radio equipment type TAYLOR-GTW-2C is in compliance with Directive 2014/35/EU. The full text of the EU declaration of conformity is available at this internet address:

www.taylor.solar/declaration

07 Technical specifications

07.1 Gateway

Item		Specification	Value
Gateway	Input	Part number (P/N)	TAYLOR-GTW-2C
		Voltage	12 VDC
		Maximum current	1.5 A
		Maximum power	18 W
	Environment	IP code	IP3X
		Environmental category	Indoor, unconditioned
		Maximum altitude rating	2000 m
		Temperature	Operating: (0 ~ 40) °C Storage: (-20 ~ 85) °C
	Frequency bands	Humidity	Operating: (8 ~ 90)% RH Storage: (5 ~ 95)% RH non condensing
		Cat-M	B1/B2/B3/B4/B5/B8/B12/B13/B14/B18/B19/B20/B25/B26/B27/B28/B66/B85
		Cat-NB	B1/B2/B3/B4/B5/B8/B12/B13/B18/B19/B20/B25/B26/B28/B66/B71/B85
	Radio transmitted power	GSM	850/900/1800/1900 MHz
		LTE RF Power Class	Class 5 (Typ. 21dbm)
Power adapter	Output	Model	SYS1308-2412-W2E
		Min. load	0 A
		Max. load	2 A ±5%
		OCP	3.5~5.5 A
		OVP	14~16 V
		Efficiency	>70%
		Max. power	24 W
		Ripple & N	120 mV
		Overvoltage category	II
	Input	Voltage	(90 ~ 264) VAC
		Frequency	(47 ~ 63) Hz
		Current	1A @ 230VAC
		Surge current max.	60Amax. @ at 240Vac input, with rated load and 25° ambient
		Leakage current	< 0.25 mA @ 240Vac input
	Protection	Over load OCP	Fold back
		Over voltage OVP	Voltage limiting
		Short circuit	Yes, Output to Ground, Auto recovery when fault has been removed. Short Current & Over Current can not exceed 8A max. after 1minute at nominal line input.
		Protection	Class II
		No load operation	Yes, to protect the power supply and system from damage.

07.1 Gateway

Item		Specification	Value
	Others	Dielectric strength	HI-POT B / I/P-O/P (FG): 3KVAC / 10mA / 1 minute
		Set up time	7s max. @ AC low line Input & Output full load
		Hold-up time	10ms @ AC nominal Input and Output full load
		MTBF qualification	> 35K hours
		DC cable & connector	Standard length of the cable 1,8m & It depends on customer requirements and upon specifications
		Efficiency (normal)	>77.6% min. @ 240VAC input & Full load
		Power consumption	ax. 0.5W @ AC nominal Input and Output min. load
		Input fuse	1A protected against power line surges and any abnormal conditions
	EMC	EMI	EN55022 Class B / FCC part 15 subpart B Class B / EN61000-3-2(2000) / EN61000-3-3(1995) + A1(2001)
		EMS	IEC61000-4-2,5,8(2001) / IEC61000-4-3(2002) / IEC61000-4-6(2002)+ A1(2003) / IEC61000-4-4,11(2004) EN55024(1998)+A1(2001)+A2(2003)

07.2 Smart module M6


Output operational mode	Cell-string (3 per module)	Module
Nominal output current (STC)		12 A
Nominal output voltage (STC)	10 V	30 V
Max. output current limit		14 A
Max. bypass current		14 A
Max. output voltage if installed on solar module	Voc of cell-string	Voc of solar module
Max. output voltage if separate from solar module	20 V	60 V
Max. output power		475 W
Max. reverse current		0 A
Output safe mode		
Output voltage		1.1±10%Vdc
Compliance		
Junction box certification		IEC 62790, IEC 62109-3
RoHS		Yes
General data		
Operating temperature range junction box		-40 °C / +85 °C
Output wire		2x 1.2 m 4mm ² (standard configuration)
Connectors		MC4 (standard configuration)
Overvoltage category		III
Pollution degree		Pollution 1 for potting part Pollution 2 for non-potting part
Degree of protection		P65/IP67
Protection class		II
Max. system voltage		1000 V

07 Technical specifications

07.3 Smart module M10

Output operational mode	Cell-string (3 per module)	Module
Nominal output current (STC)		14.7 A
Nominal output voltage (STC)	9.5 V	28 V
Max. output current limit		16 A
Max. bypass current		16 A
Max. output voltage if installed on solar module	Voc of cell-string	Voc of solar module
Max. output voltage if separate from solar module	20 V	60 V
Max. output power		600 W
Max. reverse current		0 A
Output safe mode		
Output voltage		1.1±10%Vdc
Compliance		
Junction box certification		IEC 62790, IEC 62109-3
RoHS		Yes
General data		
Operating temperature range junction box		-40 °C / +85 °C
Output wire		2x 1.2 m 4mm ² (standard configuration)
Connectors		MC4 (standard configuration)
Overvoltage category		III
Pollution degree		Pollution 1 for potting part Pollution 2 for non-potting part
Degree of protection		P65/IP67
Protection class		II
Max. system voltage		1500 V

08 Drill template



Caution

- Measure the control line (X). If the control line is not 100 mm, do not use this drill template.
- Do not drill or screw in electricity lines, water pipes, and such items. Drill safely.

Use the wall plugs, use a 06 diameter drillbit size and Pozidriv Z1 for driver.

taylor.

taylor. technologies B.V.

VAT: NL861599640B01

CoC: 80237193

www.taylor.solar

info@taylor.solar

+31 (0)85 888 0605

Torenallee 32-14

5617 BD Eindhoven

The Netherlands

taylor.gateway installation manual

2023-016-R-0017-E7

