

Standard Operating Procedure Oxipack Leak Tester

Before each shift:

1. Clean the membranes and seal with a damp cloth or alcohol wipe
2. Perform an empty machine test

Result should always be: Pack OK.

With a Pack OK result you have successfully checked the integrity of the Oxipack leak tester.

In case you have another result:

- a. Error 202/201/101

The machine has a leak; check for damages on the membrane and/or seal.

If damages are found on the membrane or seal: replace membrane or seal (see instructional videos).

If debris or dirt is found on the seal clean the seal with a damp cloth or alcohol wipe.

- b. Error 203

Non-return valve is leaking: contact Oxipack support immediately.

3. Perform a dummy test

Result should always be: Pack leak.

With a Pack leak result you have successfully checked the ability of the Oxipack leak tester to find micro leaks.

In case you have another result:

- a. Pack OK

The micro-hole in the insert is clogged or blocked: contact Oxipack support immediately

4. The Oxipack leak tester is ready to test any packages.

Measurement cycle:

1. Open lid
2. Place pack
3. Close lid
4. Press start

- a. Result: Pack OK

The package does not have any leaks; the package can be returned to the production line.

- b. Result: Pack NOK

The package has a leak; keep the package separate and report the package for further inspection if necessary.

- c. Result: Error 202/201/101

The package has a big leak; keep the package separate and report the package for further inspection if necessary.