




THE CORNELIUS COMPANY

41-6025-XXX
41-6026-XXX

ONE CORNELIUS PLACE - HIGHWAY 10 WEST □ ANOKA, MINNESOTA 55303 □ PHONE (612) 421-6120 □ TELEX 29-0443

SERVICE MANUAL

FCB Dispenser Post-Mix



Manual Part No. 325151-000
November 8, 1977
Revised: August 8, 1988

THIS DOCUMENT CONTAINS IMPORTANT INFORMATION

This Service Manual must be read and understood before the installation and operation of this dispenser.




TABLE OF CONTENTS

	<u>Page</u>
SECTION I GENERAL DESCRIPTION	1-1
<u>UNIT DESCRIPTION</u>	1-1
<u>THEORY OF OPERATION</u>	1-3
SECTION II INSTALLATION	2-1
<u>UNPACKING AND INSPECTION</u>	2-1
<u>INSTALLING LOOSE-SHIPED PARTS</u>	2-2
<u>SELECTING LOCATION</u>	2-4
<u>INSTALLING UNIT</u>	2-4
INSTALLING PRIMARY CO ₂ REGULATOR ON CO ₂ CYLINDER	2-5
CONNECTING SOFT DRINK TANK CO ₂ LINES TO PRIMARY CO ₂ REGULATOR ASSEMBLY	2-5
CONNECTING UNIT INLET SYRUP LINES	2-5
CONNECTING WATER INLET SUPPLY LINE TO UNIT	2-5
CONNECTING ELECTRICAL POWER CIRCUIT TO UNIT	2-6
<u>Model No. 416025 Without Step-up Transformer.</u>	2-6
<u>Model No. 416026 With Step-up Transformer.</u>	2-7
<u>PREPARATION FOR OPERATION</u>	2-7
<u>OPERATION</u>	2-8
SECTION III OPERATORS INSTRUCTIONS	3-1
SECTION IV SERVICE AND MAINTENANCE	4-1
<u>PREPARING UNIT FOR SHIPPING OR RELOCATING</u>	4-1
<u>PERIODIC INSPECTION</u>	4-1
<u>REMOVAL OF SIDES AND BACK PANELS, UPPER AND LOWER FRONT GRILLES, FRONT ACCESS PANEL, AND DRIP TRAY</u>	4-1
<u>LUBRICATION</u>	4-4
BEATER DRIVE MOTORS	4-4
VISCOSITY SENSOR, DISPENSING VALVE O-RINGS, AND BEATER SHAFT SEAL ASSEMBLIES	

TABLE OF CONTENTS (cont'd)

	<u>Page</u>
SECTION IV SERVICE AND MAINTENANCE (cont'd)	
<u>CLEANING CONDENSER COILS</u>	4-6
<u>ADJUSTMENTS</u>	4-8
WATER FLOW RATE	4-8
CO ₂ REGULATORS	4-9
<u>Primary CO₂ Regulator.</u>	4-9
<u>Secondary CO₂ Regulators.</u>	4-9
BRIX, VISCOSITY, AND CARBONATION	4-9
<u>BRIX Adjustment.</u>	4-9
<u>Viscosity Adjustment.</u>	4-10
<u>Product Carbonation Adjustment.</u>	4-11
<u>SANITIZING SYRUP SYSTEMS</u>	4-11
<u>YEARLY (OR AFTER WATER SYSTEM DISRUPTION)</u>	4-14
SERVICING WATER PUMP WATER STRAINER SCREEN	4-14
SERVICING WATER PUMP CHECK VALVE	4-16
SERVICING WATER FLOW REGULATORS CHECK VALVES	4-17
<u>REPLENISHING SYRUP SUPPLY</u>	4-18
<u>REPLENISHING CO₂ SUPPLY</u>	4-19
<u>SYRUP FLAVOR CHANGE</u>	4-19
RECOMMENDED EQUIPMENT AND PROCEDURE FOR INSTALLING REFRIGERATION COMPRESSOR KIT	4-20
<u>USE CAUTION</u>	4-20
<u>TROUBLESHOOTING</u>	4-21
COMPRESSOR COOLS BUT IS <u>VERY NOISY</u> , ESPECIALLY WHEN STOPPING AND STARTING	4-21
COMPRESSOR COOLS, BUT IS <u>MODERATELY NOISY</u> ; LOUD ENOUGH TO BE NOTICED, BUT NO SHARP BANGS OR CLATTERING	4-21
COMPRESSOR OPERATES BUT REFRIGERATION SYSTEM DOES NOT COOL	4-21
COMPRESSOR STARTS AND OPERATES FOR A FEW SECONDS, THEN STOPS	4-22
COMPRESSOR WILL NOT START	4-22
ELECTRICAL CHECK	4-23
<u>Single-Phase Compressor.</u>	4-23

TABLE OF CONTENTS (cont'd)

	<u>Page</u>
SECTION IV SERVICE AND MAINTENANCE (cont'd)	
<u>EQUIPMENT AND SUPPLIES NEEDED</u>	4-24
<u>COMPRESSOR REPLACEMENT PROCEDURE</u>	4-24
SECTION V TROUBLESHOOTING	5-1
TROUBLESHOOTING WARNING LIGHTS AND SAFETY DEVICES	5-1
<u>WARNING LIGHT(S) DO NOT GO ON AT SPECIFIED TIMES</u>	5-1
<u>BEATER STOPPED LIGHT(S) GO ON</u>	5-1
<u>LIGHT IN DEFROST SWITCH DOES NOT GO ON WHEN SWITCH IS PRESSED</u>	5-2
<u>OUT OF CO₂ LIGHT GOES ON DURING OPERATION</u>	5-2
<u>OUT OF WATER LIGHT GOES ON DURING OPERATION</u>	5-2
<u>OUT OF SYRUP LIGHT(S) GOES ON DURING OPERATION</u>	5-3
<u>PRE-COOL TOO COLD LIGHT GOES ON</u>	5-3
<u>DEFROST SWITCH IS PRESSED BUT CYLINDER DOES NOT GO ON DEFROST</u>	5-3
<u>UNIT DOES NOT GO OFF DEFROST CYCLE</u>	5-3
TROUBLESHOOTING CARBONATOR-BLENDERS AND WATER PUMP	5-4
<u>WATER PUMP MOTOR WILL NOT OPERATE</u>	5-4
<u>WATER PUMP WILL NOT SHUT OFF</u>	5-5
<u>ERRATIC WATER PUMP CYCLING</u>	5-5
TROUBLESHOOTING PRODUCT DISPENSED	5-5
<u>BRX TOO LOW</u>	5-5
<u>BRX TOO HIGH</u>	5-5
<u>IMPROPER PRODUCT DISPENSED</u>	5-6

TABLE OF CONTENTS (cont'd)

	<u>Page</u>
SECTION V TROUBLESHOOTING (cont'd)	
<u>PRODUCT WILL NOT DISPENSE OUT OF DISPENSING VALVE, IN ONLY SMALL AMOUNTS, OR ONLY LIQUID</u>	5-6
<u>FREEZE CYLINDER DOES NOT REFILL AT ALL TIMES WHEN DISPENSING</u>	5-6
<u>FROZEN PRODUCT CONSISTENCY VARIES EXCESSIVELY</u>	5-7
<u>CYLINDER FREEZE-UP</u>	5-7
ACCESSORIES AND TOOLS	5-8
SECTION VI ILLUSTRATED PARTS BREAKDOWN	6-1
WARRANTY	6-29

LIST OF FIGURES

SECTION I GENERAL DESCRIPTION

<u>Figure</u>	<u>Title</u>	<u>Page</u>
1-1	FCB Post-Mix Dispenser	1-2
1-2	Flow Diagram	1-5

SECTION II INSTALLATION

<u>Figure</u>	<u>Title</u>	<u>Page</u>
2-1	Freeze Cylinder-Cutaway View	2-3

SECTION III OPERATORS INSTRUCTIONS

SECTION IV SERVICE AND MAINTENANCE

<u>Figure</u>	<u>Title</u>	<u>Page</u>
4-1	Operating Controls	4-2
4-2	Unit Internal Components	4-3
4-3	Installing Shaft Seal Assembly in Freeze Cylinder	4-7
4-4	Water Strainer	4-15
4-5	Check Valve	4-15
4-6	Installing Dryers	4-26

TABLE OF CONTENTS (cont'd)

LIST OF FIGURES (cont'd)

SECTION IV SERVICE MAINTENANCE (cont'd)

<u>Figure</u>	<u>Title</u>	<u>Page</u>
4-7	Schematic Wiring Diagram (Common to both Models 416025 and 416026)	4-29
4-8	Wiring Diagram (Model 416025)	4-30
4-9	Wiring Diagram (Model 416026)	4-31

SECTION VI ILLUSTRATED PARTS BREAKDOWN

<u>Figure</u>	<u>Title</u>	<u>Page</u>
6-1	Frozen Carbonated Beverage Dispenser	6-2
6-2	Buck and Boost Transformer	6-7
6-3	Control Panel Assembly	6-8
6-4	Condenser Fan and Shroud Assembly	6-9
6-5	Pre-Cool Refrigeration Assembly	6-10
6-6	Freeze Cylinder Faceplate Assembly	6-11
6-7	Dispensing Valve Assembly	6-12
6-8	Beater Drive Shaft Assembly	6-13
6-9	Bearings and Support Bracket Assembly	6-14
6-10	Idler and Channel Assembly	6-15
6-11	Beater Drive Motor and Mounting Plate Assembly	6-16
6-12	Hot Gas Control Box Assembly	6-17
6-13	Carbonator-Blenders and Control Box Ass'y	6-18
6-14	Carbonator-Blenders Platform Assembly	6-19
6-15	Check Valve Assembly, Plastic	6-22
6-16	Flow Regulator Assembly	6-23
6-17	Check Valve Assembly	6-24
6-18	Drip Tray Panel Assembly	6-25
6-19	Secondary CO ₂ Regulators and Bracket Assembly	6-26
6-20	Water Pump and Motor Assembly	6-28


LIST OF TABLES

SECTION I GENERAL DESCRIPTION

<u>Table</u>	<u>Title</u>	<u>Page</u>
1-1	DESIGN DATA	1-3

SECTION II INSTALLATION

<u>Table</u>	<u>Title</u>	<u>Page</u>
2-1	LOOSE-SHIPED PARTS	2-1



IMPORTANT

TO THE USE OF THIS MANUAL - THIS MANUAL IS A GUIDE FOR INSTALLING, OPERATING, AND MAINTAINING THIS EQUIPMENT. REFER TO TABLE OF CONTENTS FOR PAGE LOCATION OF DETAILED INFORMATION PERTAINING TO QUESTIONS THAT ARISE DURING INSTALLATION, OPERATION, SERVICE AND MAINTENANCE, OR TROUBLESHOOTING THIS EQUIPMENT.

SECTION I

GENERAL DESCRIPTION

This section gives the description, theory of operation, and design data for the Single-Phase, Two-Flavor Post-Mix Frozen Carbonated Beverage (FCB) Dispensers with Hot Gas Defrost (see Figure 1-1) hereafter referred to as units.

UNIT DESCRIPTION

The Models 416025 and 416026 are basically identical units and consist of two freeze cylinders containing two beaters belt driven by two electric motors, three refrigeration systems (one for each freeze cylinder and one for the pre-cool plate, a pre-cool plate, two carbonator-blenders, a water pump with motor, a thermostatically controlled hot-gas-defrost system controls, tubing, and fittings necessary to regulate, transfer, and dispense the product. The components are attached to a steel frame and are enclosed in a painted steel cabinet. The cabinet panels are easily removed (one screw on lower center of each panel) to facilitate installation, service, and maintenance. A transparent faceplate, with an integral relief valve and a removable dispensing valve, is mounted at the front of each freeze cylinder. A drip tray, with a cup rest, is located directly below the dispensing valves. Model No. 416026 is equipped with a buck and boost transformer for locations where a low-voltage condition exists and you are unable to get local electrical utility company to increase the voltage or determine the reason for low voltage. This transformer will step up the electrical input voltage by 12 percent of the electrical supply. With a borderline of 191 VAC, this transformer will increase voltage to 215 VAC. This transformer is also available in a kit form for the Model No. 416025. Order Transformer Kit (P/N 511027-000).

CAUTION !

Before shipping or relocating unit, syrup systems must be sanitized and flushed with potable water and all water must be purged from syrup and plain water systems. A freezing ambient environment will cause residual water remaining inside unit to freeze resulting in damage to internal components.




Figure 1-1. FCB Post-Mix Dispenser

TABLE 1-1. DESIGN DATA

Model Numbers:	
FCB Post-Mix Dispenser w/o Transformer	416025
FCB Post-Mix Dispenser with Transformer	416026
Overall Dimensions:	
Height	55-inches
Width	19-1/4 inches
Depth Without Drip Tray	31-1/2 inches
Depth With Drip Tray	37-1/4 inches
Shipping Weight (approximate)	625 pounds
Compressor Horsepower:	
Cylinder Compressor (each compressor)	1 H. P.
Pre-Cool Compressor	1 H. P.
Refrigeration System:	
Refrigerant Type	R-502
Refrigerant Charge	See Nameplate
Ambient Operating Temperature	40°F to 100°F
Electrical Requirements:	
Operating Voltage:	
Model No. 416025	230VAC, 60HZ, Single Phase
Model No. 416026	200VAC, 60HZ, Single Phase
Current Draw	28 Amps

THEORY OR OPERATION

A CO₂ cylinder delivers carbon dioxide gas (CO₂) through secondary CO₂ regulators to the soft drink tanks. CO₂ forces syrup out of soft drink tanks into carbonator-blender tanks through solenoids and adjustable syrup flow regulators. At the same time, a water pump delivers plain water to each carbonator-blender tank through a solenoid, an adjustable water flow regulator, and a pre-cool plate. Water is cooled before entering the carbonator-blender tanks. On carbonator-blender tank fill cycle, syrup and water solenoids open allowing syrup and plain water to enter tank and after tank has been filled to proper level, solenoids close and water pump cycles off. The carbonator-blender tanks serve two purposes: (1) plain water and syrup enter tank properly proportioned and are blended for desired BRIX and (2) CO₂, regulated by secondary CO₂ pressure regulators, mixes with syrup-water blend to produce a carbonated drink. From the carbonator-blender tank, product enters freeze cylinder which maintains product at a selected viscosity. The beater in each freeze cylinder is belt driven by an electric motor. Scraper blades attached to each beater scrape product from cylinder walls as it freezes. A transparent faceplate, attached to front of each freeze cylinder, mounts

a dispensing valve and a spring-loaded relief valve that protects freeze cylinder from accidental over-pressure. The relief valve is also used to bleed CO₂ from freeze cylinder to atmosphere when filling cylinder and if gas pockets form in cylinder. A viscosity sensing mechanism for each freeze cylinder provides a means of adjusting consistency of product to suit customer preferences.





Figure 1-2. Flow Diagram



SECTION II INSTALLATION

This section covers unpacking and inspection, identification of LOOSE-SHIPED PARTS, selecting location, installing unit, preparing unit for operation, and unit operation.

UNPACKING AND INSPECTION (see Figure 4-3)

NOTE

The unit was thoroughly inspected before leaving the factory and the carrier has accepted and signed for it. Any damage or irregularities should be noted at the time of delivery and immediately reported to the delivering carrier. Request a written inspection report from the Claims Inspector to substantiate any necessary claim. File the claim with the delivering carrier, not with The Cornelius Company.

- 1) After unit has been unpacked, remove shipping tape and other packing material.
- 2) Remove sides and back panels by removing one screw on lower center of each panel, then lift panels straight up about two inches and pull out. Remove shipping bolts that secure unit to skid, then remove skid.
- 3) Unpack LOOSE-SHIPED PARTS. Make sure all items are present and in good condition.

TABLE 2-1. LOOSE-SHIPED PARTS

<u>Item No.</u>	<u>Part No.</u>	<u>Name</u>	<u>Quantity</u>
1	322235	Drip Tray	1
2	322236	Cup Rest	1
*3 (item 23)	320935	Beater	2
*4 (item 2)	320568	Scraper Blade	4
5	186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in. long	4
6	343304	Lock Washer, No. 10	4
7	322218	Drip Tray Support, Left-hand	1
8	322219	Drip Tray Support, Right-hand	1
9	151689	Spanner Wrench (flow regulators)	1
10	322859	Spanner Wrench (dispensing valve)	1
11	321534	Dispensing Lever Stop Sleeve	2
12	511044	Operators Instructions	1
13	325216	Cleaning Brush	1

*Numbers in parentheses are reference to items in Figure 2-1.


INSTALLING LOOSE-SHIPED PARTS (see Figure 2-1)

- 1) Remove shipping tape that holds VALVE LEVERS, KNOBS, and VISCOSITY RODS to FACEPLATES (see Figure 2-1). Install DISPENSING LEVER STOP SLEEVES (item 11) on DISPENSING VALVES, then carefully install valve levers and knobs on dispensing valves.
- 2) Remove four KNURLED NUTS and FLATWASHERS (see Figure 2-1) that secure each faceplate to freeze cylinders. Pull faceplates off freeze cylinders.
- 3) Position SCRAPPER BLADES (item 4) on nipples at ends of BEATER (item 3) cross arms. Place elongated holes in blades on back end of each beater. Slide beater into one of the freeze cylinders so the slotted hooks engage DRIVE PIN on DRIVE SHAFT as shown in Figure 2-1.
- 4) Repeat procedure outlined in step 3) preceding to assemble and install beater in other freeze cylinder.

NOTE

Before installing faceplate on each freeze cylinder, check all the items assembled to faceplate for secure mounting, proper lubrication of O-rings, and free movement of spinner and viscosity sensor.

- 5) Lubricate each faceplate O-ring (see Figure 2-1) with Dow-Corning (DC 111) light grade silicone to facilitate installing faceplates on freeze cylinders. Position each FACEPLATE on freeze cylinders so (a) DISPENSING VALVES faucets face down, (b) free ends of VISCOSITY RODS are in slots of SWITCH ACTUATORS, and SPINNERS clear ends of SCRAPPER BLADES. Secure each faceplate to unit with four KNURLED NUTS and FLAT WASHERS removed in step 2) preceding. Tighten knurled nuts until faceplates touch all the way around on freeze cylinder flanges. DO NOT USE TOOLS TO TIGHTEN KNURLED NUTS.
- 6) Attach DRIP TRAY SUPPORTS (item 7 and 8) to drip tray panel below dispensing valves with MACHINE SCREWS (item 5) and LOCKWASHERS (item 6) so speed nuts on drip tray supports face inward. Install DRIP TRAY (item 1) on drip tray supports, then place cup rest (item 2) in recess of drip tray.
- 7) SPANNER WRENCH (item 9) is used to adjust flow regulators inside unit.
- 8) SPANNER WRENCH (item 10) is used to remove shank nuts securing dispensing valves to face plates.
- 9) CLEANING BRUSH (item 13) is used to clean faceplates relief valves passages.



- | | | |
|--------------------------|----------------------|--------------------------|
| 1. Product inlet fitting | 10. Flat washer (4) | 19. Relief valve port |
| 2. Scraper blade (2) | 11. Knurled nut (4) | 20. O-ring |
| 3. Evaporator coil | 12. Faceplate | 21. Reducer |
| 4. Viscosity sensor | 13. Relief valve | 22. Teflon washer |
| 5. Spinner | 14. Valve lever | 23. Beater |
| 6. Relief valve port | 15. Knob | 24. Drive pin |
| 7. Switch actuator | 16. Bushing | 25. Drive shaft assembly |
| 8. O-ring | 17. Dispensing valve | 26. Shaft seal assembly |
| 9. Viscosity rod | 18. O-ring (2) | 27. Sheave |

NOTE: Numbers in parentheses indicate quantities used, other than one, in each freeze cylinder.

Figure 2-1. Freeze Cylinder-Cutaway View

SELECTING LOCATION

IMPORTANT

AMBIENT TEMPERATURE FOR COOLING UNIT MUST NOT EXCEED 100°F. UNIT OPERATING AMBIENT IN EXCESS OF 100°F WILL AUTOMATICALLY VOID FACTORY WARRANTY AND WILL EVENTUALLY RESULT IN UNIT FAILURE. SEVERAL MEANS ARE AVAILABLE TO ACHIEVE PROPER AMBIENT TEMPERATURE AND AIR CIRCULATION AROUND THE UNIT WHICH ARE WALL AIR INTAKE GRILLES AND CEILING EXHAUST FANS, AIR CONDITIONING, ETC. CONSULT LOCAL CODES.

Locate the unit so the following requirements are satisfied:

- 1) Near a properly grounded 230 VAC, 60 Hz single-phase electrical circuit with a 30 amp minimum-rated disconnect switch (not furnished) fused at 30 amps (slow-blow). ALL WIRING MUST CONFORM TO NATIONAL AND LOCAL CODES. MAKE SURE UNIT IS PROPERLY GROUNDED.
- 2) Close to a potable water inlet supply line with a minimum pressure of 12-psi.

NOTE

Circulating air required to cool the refrigeration system's condenser coils inside the unit is drawn in through grilles on front of the unit and exhausted out through louvered panels on sides and back of the unit. Restricting air circulation through the unit will decrease its cooling efficiency.

- 3) When installing unit do not allow obstruction to block grilles on front of unit blocking off air intake to inside of unit. If installation dictates only one side or back of unit being unobstructed, allow 18-inches clearance between unit and obstruction. If both sides or one side and back of unit are unobstructed, allow 12-inches clearance. If both sides and back of unit are unobstructed, allow 6-inches clearance.

INSTALLING UNIT

- 1) Place unit in location meeting requirements of SELECTING LOCATION.
- 2) After unit has been installed in operating position, make sure front (dispensing valve side) of unit is approximately 1/4-inch higher than the rear to eliminate gas pockets being trapped inside freeze cylinders.
- 3) To comply with National Sanitation Foundation (NSF) requirements, unit install with base contacting floor must have base sealed to floor with Dow Corning RTV 731 or equivalent.

INSTALLING PRIMARY CO₂ REGULATOR ASSEMBLY ON CO₂ CYLINDER



WARNING !

TO AVOID PERSONAL INJURY AND/OR PROPERTY DAMAGE, ALWAYS SECURE CO₂ CYLINDER WITH SAFETY CHAIN TO PREVENT IT FROM FALLING. SHOULD THE VALVE BECOME ACCIDENTALLY DAMAGED OR BROKEN OFF, CO₂ CYLINDER CAN BECOME AN UNGUIDED MISSILE.

- 1) Unscrew protector cap (with chain attached) from CO₂ cylinder valve. Open CO₂ cylinder valve slightly counterclockwise to blow any dirt or dust from outlet fitting before installing primary CO₂ regulator, then close valve.
- 2) Remove shipping plug from CO₂ regulator coupling nut and make sure gasket is in place in nut. Install regulator on CO₂ cylinder so gages can be easily read, then tighten coupling nut. DO NOT open CO₂ cylinder valve at this time.

CONNECTING SOFT DRINK TANKS CO₂ LINES TO PRIMARY CO₂ REGULATOR ASSEMBLY (see Figure 1-2)

- 1) Connect soft drink tanks CO₂ lines to primary CO₂ regulator.
- 2) Install gas quick disconnects on ends of soft drink tanks CO₂ lines. DO NOT CONNECT CO₂ LINES TO TANKS AT THIS TIME.

CONNECTING UNIT INLET SYRUP LINES

- 1) Route unit inlet syrup lines, labeled No. 1 and No. 2, through hole provided in unit base out to soft drink tanks location.
- 2) Install liquid disconnects on ends of unit inlet syrup lines. DO NOT CONNECT SYRUP LINES TO TANKS AT THIS TIME.

CONNECTING WATER INLET SUPPLY LINE TO UNIT

NOTE

The Cornelius Company recommends that a water shutoff valve and water filter be installed in plain water inlet supply line (see Figure 1-2). A Cornelius Water Filter (P/N 313860-000) and Quick Disconnect Set (P/N 313867-000) are recommended.

- 1) If fitting connector is not available, tap into water supply line with a 3/8-flare Saddle Valve (P/N 315664-000) or equivalent.

- 2) Before connecting water inlet supply line to unit, open shutoff valve in water supply line for a period of time to flush out any metal shavings resulting from installing fitting or saddle valve.
- 3) Route 3/8-inch I. D. water inlet supply line through hole in bottom of unit base and connect to 1/4 NPT by 5/8-18 90° elbow on water strainer located on water pump. DO NOT OPEN WATER INLET SUPPLY LINE SHUTOFF VALVE AT THIS TIME.

CONNECTING ELECTRICAL POWER CIRCUIT TO UNIT

WARNING

MAKE SURE BOTH UNIT POWER SWITCHES AND 30 AMP MINIMUM-RATED DISCONNECT SWITCH (NOT FURNISHED) ARE IN THE OFF POSITION.

Model No. 416025 Without Step-up Transformer.

IMPORTANT

VOLTAGE ACROSS L₁ AND L₂, WITH ALL THREE COMPRESSORS RUNNING MUST BE BETWEEN 215 and 253 VAC. A STEP-UP TRANSFORMER IS AVAILABLE IN CASES WHERE A LOW-VOLTAGE CONDITION EXISTS AND YOU ARE UNABLE TO GET THE LOCAL ELECTRICAL UTILITY COMPANY TO INCREASE THE VOLTAGE OR DETERMINE THE REASON FOR LOW VOLTAGE. THIS TRANSFORMER WILL STEP UP THE ELECTRICAL INPUT VOLTAGE BY 12 PERCENT OF THE ELECTRICAL SUPPLY. WITH A BORDERLINE 191 VAC, THIS TRANSFORMER WILL INCREASE VOLTAGE TO 215 VAC. IF TRANSFORMER IS REQUIRED, ORDER TRANSFORMER KIT (P/N 511027-000).

- 1) Remove control box cover.

WARNING

THIS UNIT MUST BE ELECTRICALLY GROUNDED TO AVOID POSSIBLE FATAL ELECTRICAL SHOCK OR SERIOUS INJURY TO THE OPERATOR. A GREEN SCREW, WITH LOCK WASHER, IS PROVIDED INSIDE THE CONTROL BOX TO CONNECT GROUND WIRE ELECTRICALLY GROUNDING THE UNIT.

- 2) Voltage across L₁ and L₂, with all three compressors operating, must be between 215 and 253 VAC. Connect 230 VAC, 60 HZ, single phase electrical power from 30 amp minimum-rated disconnect switch (not furnished) fused at 30 amps (slo-blow) to L₁ to L₂ terminals on right-hand-side (as viewed from rear of unit) contactor. Use No. 8 AWG wire, or larger, depending upon line length, in suitable conduit or BX sheath. Connect ground wire under green screw and lockwasher provided inside control box. ALL WIRING MUST CONFORM TO NATIONAL AND LOCAL ELECTRICAL CODES.
- 3) Install unit control box cover.
- 4) Install unit sides and back panels by reversing removal procedure.

Model No. 416026 With Step-up Transformer.

- 1) Remove junction box cover.

WARNING

THIS UNIT MUST BE ELECTRICALLY GROUNDED TO AVOID POSSIBLE FATAL ELECTRICAL SHOCK OR SERIOUS INJURY TO THE OPERATOR. MAKE SURE INCOMING POWER CORD TO UNIT GROUND WIRE IS CONNECTED TO UNIT POWER CORD GROUND WIRE INSIDE JUNCTION BOX.

- 2) Voltage across L₁ and L₂ terminals of contactor inside control box must be a minimum of 215 VAC with all three compressors operating. Connect 191 to 229 VAC, 60 Hz, single phase electrical power from 30 amp minimum-rated disconnect switch (not furnished) fused at 30 amps (slo-blow) to unit power cord inside unit junction box. Use No. 10 AWG wire, or larger, depending upon line length, in suitable conduit or BX sheath. MAKE SURE POWER SOURCE GROUND WIRE IS CONNECTED TO UNIT GREEN GROUND WIRE INSIDE JUNCTION BOX. ALL WIRING MUST CONFORM TO NATIONAL AND LOCAL ELECTRICAL CODES.
- 3) Install unit junction box cover.
- 4) Install unit sides and back panels by reversing removal procedure.

PREPARATION FOR OPERATION

- 1) Make sure both POWER switches are pressed to "OFF" position. Turn on electrical power to unit at disconnect switch. OUT OF CO₂ and OUT OF WATER warning lights will go on.
- 2) Open CO₂ cylinder valve slightly to allow lines to slowly fill with gas, then open valve fully to back-seat valve. Back seating valve prevents leakage around valve shaft.

- 3) Adjust CO₂ cylinder primary CO₂ regulator as instructed.
- 4) Loosen two screws securing unit front access panel, then lift panel from unit.
- 5) Check secondary CO₂ regulators located behind front access panel which should read 25 to 30-psig for best textured product. If adjustment is necessary, adjust as instructed.
- 6) Open water inlet supply line shutoff valve. OUT OF WATER warning light should go out. Check for leaks and tighten loose connections.
- 7) Sanitize unit as instructed.

OPERATION

- 1) Connect CO₂ and syrup lines to soft drink tanks.
- 2) Bleed faceplate relief valves for approximately 5-seconds to remove trapped air from inside freeze cylinders.
- 3) Press both POWER SWITCHES to WASH position. Both beater motors and precool compressor will start. Precool compressor will cool cold plate so water is precooled when filling carbonator-blender tanks. When precool compressor cycles off, press both POWER switches to "OFF" position.
- 4) Adjust product BRIX on both systems as instructed.
- 5) Press both SYRUP switches to "AUTO" position. Open faceplates relief valves to bleed air from freeze cylinders and to fill cylinders with product.
- 6) If necessary, adjust product viscosity (product consistency) as instructed.
- 7) If necessary, adjust product carbonation as instructed.
- 8) Install unit front access panel by reversing removal procedure.

SECTION III

OPERATORS INSTRUCTIONS

This section describes operating controls and indicators, dispensed product conditions, operating characteristics, unit operation, replenishing syrup supply, product flavor change, checking CO₂ supply, operators daily cleaning of unit, and sanitizing requirements.

OPERATING CONTROLS AND INDICATORS

POWER SWITCHES

The two POWER switches (see Figure 4-1), located on front of the unit, are three-position electrical switches labeled WASH, OFF, and AUTO. The WASH position of the switches is used to operate the freeze cylinder beaters without refrigeration during flushing or sanitizing. The AUTO position is used during normal operation. The switch is placed in the OFF position for service and maintenance.

SYRUP SWITCHES

The two SYRUP switches (see Figure 4-1), located on front of unit, are three position electrical switches labeled FILL, OFF, AUTO. The FILL position, spring-loaded to return to OFF position, is used when filling syrup system during replenishing, changeover, or sanitizing. The switch is to be in AUTO position during normal operation and in OFF position for service and maintenance. The syrup and water solenoids and carbonator-blender will not operate when switch is placed in OFF position.

DEFROST SWITCHES

The two DEFROST switches (see Figure 4-1), located on front of unit, are two-position momentary-contact switches spring-loaded to return to OFF position when released. The switches actuate the defrost solenoids to permit hot gas to enter freeze cylinder refrigerant coils to defrost product in cylinders. A light included in each switch remains on until thermostatically controlled defrost cycle is complete.

PRODUCT VISCOSITY (PRODUCT CONSISTENCY) CONTROLS

The two viscosity controls (see Figure 4-1), located above the faceplates, control viscosity (product consistency) of the product dispensed. If a viscosity adjustment is desired, adjust as instructed.

FACEPLATE RELIEF VALVES

The faceplate relief valves (see Figure 4-1), located in each faceplate, is a spring-loaded valve that protects freeze cylinder from accidental over-pressure. The relief valve is also used to manually bleed CO₂ gas from freeze cylinder to atmosphere during filling and if gas pockets form in cylinder during operation.

PRODUCT SAMPLE VALVES

The product Sample Valves (see Figure 1-2), located behind front access panel, are manually operated lever-type ball valves used to check product BRIX. Turn valve lever to line up with attached line to open valve and at 90° angle with line to close valve.

PRECOOL THERMOSTAT CONTROL

The precool thermostat control (see Figure 4-2), located at the left behind front access panel, is used to control precool cold plate temperature. The thermostat is factory adjusted to maintain cold plate temperature between 38°F and 40°F (depending on ambient, water inlet temperature, and other variables) and should not normally require adjustment. If adjustment is necessary, adjust as instructed.

PRIMARY CO₂ REGULATOR

The primary CO₂ regulator (see Figure 1-2) controls CO₂ pressure to soft drink tanks and unit secondary CO₂ regulators located behind front access panel. If necessary to adjust primary CO₂ regulator, adjust as instructed.

SECONDARY CO₂ REGULATORS

The two secondary CO₂ regulators (see Figures 1-2 and 4-2), located behind front access panel, control CO₂ pressure in the carbonator-blenders. If necessary to adjust secondary CO₂ regulators, adjust as instructed.

WATER FLOW REGULATORS

The water flow regulators (see Figures 1-2 and 4-2), located in their respective systems, are adjustable regulators that control the water flow rate. The water flow regulators are factory adjusted at 1.5 ± 0.05 oz/sec and should not normally require adjustment. If adjustment is necessary, adjust as instructed.

SYRUP FLOW REGULATORS

The syrup flow regulators (see Figure 1-2 and 4-2), located in their respective systems, are adjustable regulators that control the syrup flow rate for desired BRIX of dispensed product. Adjust syrup flow regulators for desired BRIX as instructed.

DISPENSING VALVES

Dispensing valves (see Figure 4-1), located on faceplates on front of unit, are operated one at a time or simultaneously to deliver product to the customer.

WARNING LIGHTS

The warning lights (see Figure 4-1), located on unit front panel, are self-explanatory and are labeled as follows:

NOTE

The terms "left" and "right" designate locations when viewing unit from front (dispensing valve side) of unit.

Out of Syrup.

One OUT OF SYRUP light for each dispensing system. The light on right panel is for the right-side system and light on left panel is for the left-side system.

Out of Water.

Common to both dispensing systems and located on left panel.

Out of CO₂.

Common to both dispensing systems and located on right panel.

Beater Stopped.

One for each freeze cylinder. The light on right panel is for right-side cylinder and light on left panel is for left-side cylinder.

Pre-Cool Too Cold.

Common to both dispensing systems and located on right panel.

DISPENSED PRODUCT CONDITIONS

"OVERRUN", AS APPLIED TO FROZEN CARBONATED BEVERAGES

Overrun Defined.

Overrun is product expansion that takes place in the frozen carbonated drink. It is caused primarily by CO₂ gas breakout and secondary by freezing.

Overrun is a Variable.

The percentage or degree of overrun depends on a number of factors. The specific syrup, BRIX, low dispensing volume, carbonation level in liquid product, and freezing, all affect overrun. After these factors have been considered, desired viscosity control setting can be made on the unit. The unit viscosity control adjusts product texture from very wet to light.

Specific Product Ingredients Affect Overrun.

Each syrup has its own specific formulation or makeup. Baume, an important ingredient factor, may fall within an extremely wide range. Fruit flavors contain citric acids that colas do not. Colas also differ in ingredients from one brand to another. Each product formulation has its own peculiarities regarding the way the product will absorb carbonation and the way it will release carbonation.

BRIX Affects Overrun.

Sugar in a carbonated drink is like anti-freeze in water. The higher the BRIX in a product, the greater resistance the product has to freezing. Conversely, in products with lower BRIX, freezing takes place at higher temperatures than for high-BRIX products. Thus, BRIX affects overrun because the amount of sugar in a drink has a direct bearing on the product's freezing characteristics.

Low Dispensing Volume Affects Overrun.

When a unit sits idle for a period of time and no drinks are dispensed, the CO₂ gas in the system takes a "set". When the first few drinks are drawn off after an idle period, the CO₂ gas has less tendency to break out as the drink is dispensed. The result is these casual drinks have less overrun than drinks dispensed during peak-use periods.

Carbonation Level in Liquid Product Affects Overrun.

The higher the specific carbonation level in a given product, the greater the potential for carbonation breakout in the frozen carbonated form of that drink. For example, drinks with 3.0 volume of carbonation will have more gas breakout in frozen carbonated form, and more overrun, than will drinks that contain 2.0 volumes of CO₂ gas.

Freezing Affects Overrun.

Freezing causes approximately a 10 percent expansion in the dispensed frozen carbonated drink. The degree of freezing is limited because the finished drink is intended to be sipped through a straw. This is not possible if the product is too "solid".

OPERATING CHARACTERISTICS

The product consistency can be varied by the viscosity control and secondary CO₂ regulator setting from a high overrun light drink to a wet heavy drink. The length of the freezing cycle and the amount of CO₂ present in the product combine to create the drink dispensed. The dispensed product will have a normal variance due to the following conditions:

- 1) If some time has elapsed since the last drink was drawn from the particular freeze cylinder and the compressor has not cycled on, the drink dispensed will have a tendency to be wetter, have slightly less overrun than normal for the setting, and will not mound up as high. See Drawing 1.

- 6) Make sure POWER and SYRUP switches are in AUTO positions.
- 7) Place cup under dispensing valve, then dispense cup full of product.
- 8) Make sure product viscosity (product consistency) is as desired. If not, adjust as instructed.

REPLENISHING SYRUP SUPPLY

Syrup supply should be checked daily and replenished as necessary.

PRODUCT FLAVOR CHANGE

Change product flavor as instructed.

CHECKING CO₂ SUPPLY

Make sure CO₂ cylinder shutoff valve is fully opened and regulator assembly 2000-psi gage indicator is not in shaded ("change CO₂ cylinder") portion of dial. If so, CO₂ cylinder is almost empty and must be replaced.

CLEANING AND SANITIZING

DAILY CLEANING

Daily; or more often if necessary, wash all external surfaces of unit, rinse with clean water, then wipe dry with clean soft cloth. DO NOT USE ABRASIVE CLEANERS. Remove and wash drip tray, rinse with clean water, then install drip tray on unit.

SANITIZING

The unit should be sanitized every 90 days and before and after storage periods following parent company requirements and sanitizer manufacturers recommendations.

CLEANING CONDENSER COILS

NOTE

Circulating air required to cool the refrigeration systems condenser coils inside the unit is drawn in through grilles on front of unit and exhausted out through louvered panels on sides and back of unit. Restricting air circulation through the unit will decrease its cooling efficiency.

Condenser coils must be cleaned periodically as instructed.

LUBRICATION

Beater drive motors must be lubricated once a year as instructed.

NOTE

If an attempt is made to eliminate the drink described above by turning the viscosity control thumbwheel in, a cylinder freeze-up may be expected under casual draw conditions.

- 2) If product is drawn from the freeze cylinder quite regularly, its consistency will be maintained at whatever setting was made within the normal variance of the compressor off and on cycle. See Drawing 2.



DRAWING 1



DRAWING 2



DRAWING 3

- 3) If product is drawn continuously from the freeze cylinder and the rate is approaching the capacity of the dispensing unit, the overrun of the drink will increase just prior to the point the capacity is exceeded, and the drink dispensed will turn slightly wetter.

NOTE

When wet drinks are caused by exceeding the capacity of the dispensing unit, do not attempt to make drinks drier or stiffer by adjusting the viscosity control thumbwheel. Adjustments made under these conditions cause cylinder freeze-ups under casual draw.

OPERATING UNIT

- 1) Make sure both OUT OF SYRUP warning lights are out indicating ample syrup supply is available. If light is on, replenish syrup supply.
- 2) Make sure OUT OF WATER warning light is not on indicating water supply is available to unit. If light is on, open water inlet supply line shutoff valve.
- 3) Make sure OUT OF CO₂ warning light is off indicating ample CO₂ supply is available. If light is on, replenish CO₂ supply.
- 4) Make sure BEATER STOPPED warning lights are not on which indicates beaters are not operating.
- 5) Make sure PRE-COOL TOO COLD light is not on indicating a precool plate freeze-up condition. If light is on, adjust precool thermostat as instructed.

ADJUSTMENTS

WATER FLOW RATE

The water flow regulators, which control water flow rate into carbonator-blenders, are factory adjusted and normally do not require further adjustment. If adjustment should become necessary, adjust as instructed.

CO₂ REGULATORS

Primary CO₂ regulator.

The primary CO₂ regulator regulates CO₂ pressure to the soft drink tanks and the secondary CO₂ regulators inside the unit. If necessary to adjust primary CO₂ regulator, adjust as instructed.

Secondary CO₂ Regulators.

The secondary CO₂ regulators regulate CO₂ pressure to the carbonator-blenders. If necessary to adjust secondary CO₂ regulators, adjust as necessary.

BRIX

BRIX is the water-to-syrup mixture of the dispensed product. If necessary to adjust BRIX of dispensed product, adjust as instructed.

VISCOSITY

The viscosity (stiffness) of the dispensed product was adjusted at the factory but may be varied to the customers preference. If necessary to adjust viscosity, adjust as instructed.

PRODUCT CARBONATION

Carbonation of dispensed product can also be varied to the customers preference. If necessary to adjust product carbonation, adjust as instructed.

WATER STRAINER SCREEN AND CHECK VALVES MAINTENANCE

WARNING !



THE WATER PUMP WATER STRAINER SCREEN AND CHECK VALVE AND THE WATER FLOW REGULATOR ASSEMBLIES CHECK VALVES MUST BE INSPECTED AND SERVICED AFTER ANY DISRUPTIONS (PLUMBING WORK, EARTHQUAKE, ETC.) TO THE WATER SUPPLY SYSTEM, AND AT LEAST ONCE A YEAR UNDER NORMAL CIRCUMSTANCES. A WATER PUMP WITH NO SCREEN OR A DEFECTIVE SCREEN IN THE STRAINER WOULD ALLOW FOREIGN PARTICLES TO FOUL THE CHECK VALVES. CO₂ GAS COULD THEN BACK FLOW INTO THE WATER SYSTEM AND CREATE A HEALTH HAZARD IN THE WATER SYSTEM.

Service water strainer screen and check valves as instructed.

SECTION IV

SERVICE AND MAINTENANCE

This section describes service and maintenance to be performed on the unit.

IMPORTANT

ONLY QUALIFIED PERSONNEL SHOULD SERVICE
INTERNAL COMPONENTS OR ELECTRICAL WIRING.

PREPARING UNIT FOR SHIPPING OR RELOCATING

CAUTION !

Before shipping or relocating unit, syrup systems must be sanitized and flushed with potable water and all water must be purged from syrup and plain water systems. A freezing ambient environment will cause residual water remaining inside unit to freeze resulting in damage to internal components.

PERIODIC INSPECTION

- 1) Make sure CO₂ cylinder valve is fully open and CO₂ cylinder regulator assembly 2000-psi gage indicator is not in shaded ("change CO₂ cylinder") portion of dial. If so, CO₂ cylinder is almost empty and must be replaced.
- 2) Make sure soft drink tanks contain sufficient amount of syrup for unit operation.
- 3) Circulating air required to cool the refrigeration systems condenser coils inside the unit is drawn in through grilles on front of unit and exhausted out through louvered panels on sides and back of unit. Make sure grilles and panels are not obstructed and refer to CLEANING CONDENSER COILS in this section.

REMOVAL OF SIDES AND BACK PANELS, UPPER AND LOWER FRONT GRILLES, FRONT ACCESS PANEL, AND DRIP TRAY (see Figure 4-1)

Instructions for removal of sides and back panels, upper and lower front grilles, front access panel, and drip tray for service and maintenance is as follows: Install removed parts by reversing removal procedure.

- 1) Remove sides and back panel by removing one screw on lower center of each panel, then lift panels straight up about two inches and pull out.
- 2) Remove upper front grille by removing screw and flat washer securing top of grille, then lift grille up and out.
- 3) Remove lower front grille by pulling top of grille out, then pull grille up and out of unit.




Figure 4-1. Operating Controls




Figure 4-2. Unit Internal Components

- 4) Remove front access panel by loosening two screws securing panel, then pull panel out of unit.
- 5) Remove drip tray by pulling straight off unit.

LUBRICATION

BEATER DRIVE MOTORS

Beater drive motors must be lubricated once a year.

VISCOSITY SENSOR, DISPENSING VALVE O-RINGS, AND BEATER SHAFT SEAL ASSEMBLIES

NOTE

If both freeze cylinders will be serviced at one time, shut off CO₂ supply to unit and relieve systems CO₂ pressure through faceplates relief valves. If only one freeze cylinder will be serviced, remove front access panel and turn applicable secondary CO₂ regulator adjusting screw to the left (counterclockwise) until gage reads 0-psig. Relieve applicable system CO₂ pressure through faceplate relief valve.

Lubricate the viscosity sensor and dispensing valve O-Rings (see Figure 2-1) and beater shaft seal assemblies (see Figure 4-3) each time the unit is sanitized as follows:

NOTE

Item numbers in parenthesis in this paragraph are in reference to Figure 2-1.

- 1) Remove KNURLED NUTS (item 11), and FLAT WASHERS (item 10) to remove faceplate assembly.
- 2) Unscrew RELIEF VALVE (item 13) from FACEPLATE (item 12).
- 3) Hold VISCOSITY ROD (item 9) and unscrew VISCOSITY SENSOR (item 4) from FACEPLATE (item 12). Pull SPINNER (item 5), O-RING (item 20), and TEFLON WASHER (item 22) from viscosity rod. Remove viscosity rod from faceplate. Remove REDUCER (item 21) from viscosity sensor.
- 4) Remove BUSHING (item 16) and O-RINGS (item 8) from FACEPLATE (item 12). Carefully remove O-RINGS from bushing.
- 5) Carefully remove large O-RING (item 8) from FACEPLATE (item 12).
- 6) Unscrew KNOB and LEVER assembly (item 15 and item 14) from DISPENSING VALVE (item 17). Press valve with caged O-Ring down and out of dispensing valve body. Carefully remove caged O-Ring from valve.

- 7) Wash all parts in warm water. Remove all traces of syrup and lubricant, especially from faceplate, O-Rings, and dispensing valve. If parts are excessively coated, wipe clean with paper towel to remove syrup and lubricant, especially from caged O-Ring and dispensing valve. Use BRUSH (item 13, table 2-1) to clean faceplates relief valve passages.
- 8) Submerge all parts in four percent solution of approved sanitizing agent for time recommended by sanitizer manufacturer.
- 9) Remove parts from sanitizing solution and place on clean paper towels.

NOTE

Use Dow-Corning DC-111 (P/N 321471-000) light grade silicone lubricant.

- 10) Lubricate caged O-Ring. Carefully install caged O-Ring on valve from straight end (opposite tapered end). Lubricate grooves in which O-Ring rides to fill in all void areas around O-Ring. Carefully install valve with caged O-Ring in dispensing valve body. Screw KNOB and LEVER assembly (item 15 and item 14) in DISPENSING VALVE (item 17). Wipe off all excess lubricant.
- 11) Lubricate two viscosity sensor bushing O-RINGS (item 18). Carefully install O-Rings on BUSHING (item 16). Carefully press bushing with O-Rings into center hole of FACEPLATE (item 12) from back side.
- 12) Install threaded end of VISCOSITY ROD (item 9) through BUSHING (item 16) in FACEPLATE (item 12) from outer end. Apply lubricant all around O-Ring seat in counterbore of bushing. Carefully install O-RING (item 20) in bushing counter-bore.
- 13) Install REDUCER (item 21) in VISCOSITY SENSOR (item 4). Assemble SPINNER (item 5), TEFLON WASHER (item 22), and viscosity sensor on VISCOSITY ROD (item 9). Do not overtighten viscosity sensor.
- 14) Screw RELIEF VALVE (item 13) into FACEPLATE (item 12).
- 15) Service the beater shaft seal assemblies (see Figure 4-3) as follows:

NOTE

Use Dow-Corning DC-111 (P/N 321471-000) light grade silicone lubricant.

- a. Pull BEATER (item 23) and SCRAPER BLADES (item 2) from freeze cylinder.
- b. Pull Shaft seal assembly (Figure 4-3) from freeze cylinder socket using seal puller, (Cornelius P/N 322063-000) from front side. Disassemble shaft seal assembly and discard O-Rings.

- c. Remove old lubricant from plastic sleeve and stainless steel seal retainer with paper towels. Do not scrape the sleeve. Wash sleeve, retainer, and socket at back of freeze cylinder in warm water.

NOTE

If the old lubricant cannot be removed from the plastic sleeve by washing, use a nylon "pot and pan" scrubber (3M Co. "Scotchbrite", or equivalent) to remove the residue. Do not scrape the sleeve. Replace any sleeve that has rough edges in the O-Ring sealing areas.

- d. Install No. 1 stationary O-Ring in groove of plastic sleeve and No. 2 stationary O-Ring in inner groove of stainless steel seal retainer. Lubricate both O-Rings.
- e. Install new "running" O-Rings No. 3 and No. 4 in outergrooves of stainless steel seal retainer, then lubricate O-Rings with generous amount of special light grade silicone grease.
- f. Slide stainless steel seal retainer in plastic sleeve until "running" O-Ring No. 3 is just covered by plastic sleeve, as shown in View B of Figure 4-3.
- g. Carefully place shaft seal assembly over beater drive shaft and locate slots of seal retainer on drive shaft pin. Then, carefully and simultaneously, push and turn plastic sleeve to locate locking tabs on sleeve in notches of freeze cylinder retainer. When tabs are seated in notches, press assembly firmly in place.
- h. Position SCRAPPER BLADES (item 2) on nipples at ends of beater cross arms. Place elongated holes in blades on back of BEATER (item 23). Slide beater into freeze cylinder so slotted hooks engage DRIVE PINS (item 24) on DRIVE SHAFT (item 25). Turn beater clockwise to lock in place.
- i. Position large O-RING (item 8) on FACEPLATE (item 12). Install faceplate on unit so dispensing valve spout faces down and VISCOSITY ROD (item 9) is positioned in slot of SWITCH ACTUATOR (item 7). Lubricate O-RING (item 8) with water to facilitate faceplate installation. Tighten knurled nuts until faceplate touches freeze cylinder all around flange. DO NOT USE TOOLS TO TIGHTEN KNURLED NUTS.

CLEANING CONDENSER COILS

NOTE

Circulating air required to cool the refrigeration systems condenser coils inside the unit is drawn in through grilles on front of unit and exhausted out through louvered panels on sides and back of unit. Restricting air circulation through the unit will decrease its cooling efficiency.





Figure 4-3. Installing Shaft Seal Assembly in Freeze Cylinder

Periodically clean condenser coils as follows:

- 1) Turn POWER switches to OFF position.
- 2) Remove upper and lower front grilles as instructed.
- 3) Vacuum or wipe coils with clean cloth or if available, use low compressed air to blow dust out of coils.
- 4) Install upper and lower front grilles on unit.
- 5) Turn POWER switches to ON position.

ADJUSTMENTS

WATER FLOW RATE

The two black water flow regulators (see Figures 1-2 and 4-2) are factory adjusted for a water flow rate of 1.5 ± 0.05 ounces per second and normally do not require adjustment. However, if adjustment is necessary, proceed as follows:

- 1) Remove screws on lower centers of side panel, then lift side panels straight up about two inches and pull out to remove.
- 2) Loosen two screws and lift front access panel from unit.
- 3) Disconnect electrical power from unit.
- 4) Press applicable SYRUP switch to OFF position.
- 5) Disconnect unit inlet syrup line from applicable soft drink tank.
- 6) Dispense from applicable freeze cylinder until carbonator-blender tank is empty.
- 7) Note pressure setting on applicable secondary CO₂ regulator gage, then turn adjusting screw on CO₂ regulator out (counterclockwise) until gage reads 0-psi. Pull up on applicable blender tank relief valve to release CO₂ pressure from system.
- 8) Disconnect line from outlet side of water flow regulator. Connect line (long enough to reach outside unit) with 7/16-20 fitting to outlet of water flow regulator, then route line to outside of unit.
- 9) Connect electrical power to unit.
- 10) Press applicable SYRUP switch to AUTO position to start water pump. When steady stream of water is flowing from added length of line, catch water in container graduated in ounces for exactly 10-seconds. Press SYRUP switch to OFF position. In 10-seconds, 14 to 16 ounces of water should have been dispensed.

- 11) If adjustment is necessary, loosen jam nut on water flow regulator and turn adjusting screw out (counterclockwise) to reduce water flow rate or turn screw in (clockwise) to increase flow rate. Tighten jam nut and tap on regulator to register adjustment.
- 12) Repeat steps 10) and 11) until proper water flow rate is achieved.
- 13) Remove added length of line from outlet side of water flow regulator. Connect line disconnected from water flow regulator in step 8) preceding.
- 14) Turn secondary CO₂ regulator adjusting screw in (clockwise) until gauge registers pressure noted in step 7) preceding.
- 15) Install front access panel on unit and secure with two screws.
- 16) Install side panels on unit and secure with screws.
- 17) Connect unit inlet syrup line to soft drink tank.
- 18) Press SYRUP switch to AUTO position.
- 19) Pull relief valve on faceplate to bleed air from system and fill freeze cylinder with product.

CO₂ REGULATORS

Primary CO₂ Regulator. (see Figure 1-2)

Adjust primary CO₂ regulator by turning regulator adjusting screw to the right (clockwise) until regulator pressure gage reads 80-psi.

Secondary CO₂ Regulators. (see Figures 1-2 and 4-2)

- 1) Loosen two screws securing front access panel, then pull panel out of unit.
- 2) Adjust secondary CO₂ regulators by turning regulator adjusting screw to the right (clockwise) until gages read 25 to 30-psig.
- 3) Install front access panel and secure with two screws.

BRUX, VISCOSITY, AND CARBONATION

BRUX Adjustment. (see Figure 4-2)

Perform the following to adjust BRUX of dispensed product.

- 1) Loosen two screws and lift front access panel from front of unit.

- 2) Check secondary CO₂ regulators located behind front access panel which should read 25 to 30-psi for best textured product. If adjustment is necessary, adjust as instructed.
- 3) Pull product sample valve from inside unit.
- 4) Place SYRUP switch in OFF position.
- 5) Open product sample valve and take a sample (approximately 6-ounces) of product in cup or glass. Check the product BRUX with a temperature compensated hand-type refractometer. BRUX should read 12.5 ± 0.5 . If BRUX is not within tolerance, adjust syrup flow regulator.

NOTE

Temperature compensated type refractometers are available from The Cornelius Company (P/N 511004-000).

- 6) To adjust syrup flow regulator, loosen jam nut on regulator and turn screw to the left (counterclockwise) no more than 1/8 turn to reduce flow rate; or turn screw to the right (clockwise) no more than 1/8 turn to increase flow rate. Tighten jam nut, then lightly tap flow regulator to register adjustment.
- 7) Dispense from dispensing valve to purge all product from carbonator-blender tank. Open sample valve to purge all product from line and valve.
- 8) Place SYRUP switch in AUTO position for approximately 2 to 3 seconds to run new product sample into blender tank, then place switch in OFF position.
- 9) Repeat step 5) preceding to check product sample for BRUX.
- 10) Repeat steps 7) through 9) until proper BRUX setting is achieved.
- 11) Perform steps 4) through 9) to adjust BRUX on other system.
- 12) Install front access panel on unit and secure with two screws.
- 13) Place SYRUP switch in AUTO position.

Viscosity Adjustment.

The viscosity (stiffness) of the product to be dispensed is set at the factory but can be varied to the customers preference as follows:

- 1) When freeze cylinder compressor cycles off, draw several cups of product from dispensing valve.

- 2) Check product for viscosity. If stiffer (more viscous) product is desired, loosen hex nut behind viscosity control thumbwheel and turn the wheel (above faceplate on front of unit) to the right (clockwise) to increase viscosity. When wheel is turned in this direction, spring tension in control mechanism increases and causes compressor to run longer. Tighten lock nut after each adjustment.

NOTE

When making a viscosity control adjustment, do not adjust the thumbwheel more than necessary to obtain the desired product. The probability of cylinder freeze-ups increases when the thumbwheel is tightened excessively.

- 3) When adjustment for stiffer product is made, allow freeze cylinder compressor to cycle on and off three or four times before rechecking.
- 4) Turn viscosity control thumbwheel to the left (counterclockwise) to decrease viscosity. When wheel is turned in this direction, spring tension in control mechanism decreases and reduces time compressor will run. When adjustment for less viscous product is made, resultant effect of adjustment is not known until compressor cycles on and off three or four times. Tighten lock nut after each adjustment.

Product Carbonation Adjustment.

Carbonation of dispensed product can also be varied to suit consumer preference by adjusting the unit secondary CO₂ regulators as follows:

- 1) Loosen two screws and lift access panel from front of unit.
- 2) Read CO₂ pressure on each secondary CO₂ regulator pressure gage.
- 3) To lower CO₂ pressure, turn regulator adjusting screw to the left (counterclockwise) until pressure gage reads 15-psi below desired reading, then turn adjusting screw to the right (clockwise) until gage reads desired pressure. Do not set pressure below 25-psi.
- 4) To raise CO₂ pressure, turn regulator adjusting screw to the right (clockwise) until gage reads desired pressure. Do not set pressure higher than 30-psi. Make sure primary regulator on CO₂ cylinder is set at 80-psi.
- 5) Install front access panel on unit and secure with two screws.

SANITIZING SYRUP SYSTEMS

The unit should be sanitized every 90 days and before and after storage periods following parent company requirements and sanitizer manufacturer's recommendations. Either or both dispensing systems can be sanitized at the same time. An economic practice is to arrange any syrup changeover to coincide with the sanitizing operation. Proceed as follows:

- 1) Disconnect inlet (CO₂) and outlet (syrup) lines from applicable soft drink tank.
- 2) Press applicable POWER switch to OFF position.
- 3) Connect CO₂ line and unit inlet syrup line to a clean empty soft drink tank, then open dispensing valve and dispense all product from freeze cylinder. As product level lowers in freeze cylinder, partially close dispensing valve to avoid spurting. OUT OF SYRUP light will go on during this time. Close dispensing valve when cylinder is empty.
- 4) Remove front access panel. Extend applicable product sample valve from unit. Open valve slowly and drain product from line and valve, then close valve.
- 5) Disconnect inlet (CO₂) and outlet (syrup) lines from empty soft drink tank.

WARNING !



DO NOT ATTEMPT TO REMOVE SOFT DRINK TANK COVER UNTIL CO₂ IS BLED FROM TANK THROUGH RELIEF VALVE ON TANK COVER.

- 6) Pull up on soft drink tank cover relief valve to release CO₂ pressure from tank.

WARNING !



IF POWDER TYPE SANITIZER IS USED, IT MUST BE THOROUGHLY DISSOLVED WITH WATER PRIOR TO ADDING TO SOFT DRINK TANK.

NOTE

The sanitizing solution is used in a more concentrated form because it will be diluted approximately four-to-one in the carbonator-blender tank.

- 7) Refer to sanitizer manufacturer's directions and mix (four times normal strength) two quarts or more, depending upon length of unit inlet syrup lines, sanitizing solution in clean soft drink tank. Install and secure tank cover.
- 8) Connect CO₂ line to inlet fitting and unit inlet syrup line to outlet fitting of soft drink tank containing sanitizing solution.
- 9) Press and hold SYRUP switch in FILL position until OUT OF SYRUP light goes out, then release switch. Press SYRUP switch to AUTO position. Carbonator-blender water pump will start to dilute sanitizing solution to proper ratio in carbonator-blender tank.

- 10) After water pump cycles off, completely fill freeze cylinder with sanitizing solution by repeatedly pulling and releasing relief valve knob on faceplate of freeze cylinder and until sanitizing solution comes out of relief valve port. Open dispensing valve until sanitizing solution flows from valve, then close valve. Open product sample valve until sanitizing solution flows from valve, then close valve.
- 11) Press POWER switch to WASH. Allow sanitizing solution to remain in unit for contact time recommended by sanitizer manufacturer.
- 12) When sanitizing solution contact time has elapsed, open dispensing valve and allow carbonator-blender water pump to cycle on and off until OUT OF SYRUP light goes on and carbonator-blender water pump shuts off. Continue dispensing until freeze cylinder is empty. As sanitizing solution level lowers in freeze cylinder, partially close dispensing valve to avoid spurting. Close dispensing valve. Press and hold SYRUP switch in FILL position to purge sanitizing solution out of line, then release switch. Open product sample valve to purge remaining sanitizing solution out of carbonator-blender tank, product sample valve line, and product sample valve, then close valve. Disconnect inlet (CO₂) line from soft drink tank, then release tank CO₂ pressure by pulling up on relief valve on tank cover.
- 13) Remove soft drink tank cover. Pour one half gallon of warm (104° max) potable water into tank, then install tank cover.
- 14) Connect inlet (CO₂) line to soft drink tank containing warm water.
- 15) Press and hold applicable SYRUP switch to FILL position until OUT OF SYRUP light goes out, then release switch. Press SYRUP switch to AUTO position to start carbonator-blender water pump.
- 16) Press POWER switch to OFF position. Completely fill freeze cylinder with water by repeatedly pulling and releasing relief valve knob on faceplate of freeze cylinder and until water comes out of relief valve port, then release knob. Press POWER switch to WASH position.
- 17) Open dispensing valve and allow carbonator-blender pump to cycle on and off until OUT OF SYRUP light goes on and carbonator-blender water pump shuts off. Continue dispensing until freeze cylinder is empty. As water level lowers in freeze cylinder, partially close dispensing valve to avoid spurting. Close dispensing valve. Pull relief valve knob on faceplate to purge water from relief valve port, then release knob. Press POWER switch to OFF position.
- 18) Press and hold SYRUP switch in FILL position to purge water out of line, then release switch. Open product sample valve to purge remaining water out of carbonator-blender tank, product sample valve line, and product sample valve, then close valve.
- 19) Disconnect inlet (CO₂) and outlet (syrup) lines from empty soft drink tank.

- 20) Refer to VISCOSITY SENSOR, DISPENSING VALVE O-RINGS AND BEATER SHAFT SEAL ASSEMBLIES under LUBRICATION and perform procedure to lubricate viscosity sensor, dispensing valve O-Rings, and beater shaft seal assemblies.
- 21) Connect CO₂ and syrup lines to soft drink tank containing syrup.
- 22) Press and hold SYRUP switch in FILL position until OUT OF SYRUP light goes out, then press switch to AUTO position to start carbonator-blender water pump. Press POWER switch to AU TO position.

CAUTION !

Do not relieve cylinder pressure too fast or product will foam excessively in freeze cylinder and loose carbonation.

- 23) After water pump cycles off, intermittently pull and release relief valve knob on faceplate of applicable freeze cylinder. This bleeds CO₂ from cylinder and allows product to enter and fill cylinder.
- 24) Position product sample valve back in unit, then install front access panel.
- 25) Product will be ready for dispensing in approximately 10 minutes.

YEARLY (OR AFTER WATER SYSTEM DISRUPTION)

WARNING !



THE WATER PUMP WATER STRAINER SCREEN AND CHECK VALVE AND THE WATER FLOW REGULATOR ASSEMBLIES CHECK VALVES MUST BE INSPECTED AND SERVICED AFTER ANY DISRUPTIONS (PLUMBING WORK, EARTHQUAKE, ETC.) TO THE WATER SUPPLY SYSTEM, AND AT LEAST ONCE A YEAR UNDER NORMAL CIRCUMSTANCES. A WATER PUMP WITH NO SCREEN OR A DEFECTIVE SCREEN IN THE STRAINER WOULD ALLOW FOREIGN PARTICLES TO FOUL THE CHECK VALVES. CO₂ GAS COULD THEN BACK FLOW INTO THE WATER SYSTEM AND CREATE A HEALTH HAZARD IN THE WATER SYSTEM.

SERVICING WATER PUMP WATER STRAINER SCREEN. (see Figure 4-4 and 6-20)

- 1) Close (counterclockwise) CO₂ cylinder valve, then close shutoff valve in inlet water supply line to unit.
- 2) Press both POWER switches to OFF position.





Figure 4-4. Water Strainer



Index No.	Part No.	Name
1	317963	Housing
2	312415	Flat Washer, Stainless Steel
3	*312418	Ball Seat (quad ring)
4	312419	Ball
5	312196	Spring
6	317965	Retainer

*Install new ball seat at each servicing.

Figure 4-5. Check Valve

- 3) Remove both sides and rear panels by removing one screw on lower center of each panel, then lift panels straight up about two inches and pull out.
- 4) Loosen screen retainer and pull screen retainer and screen from water pump water strainer housing.
- 5) Pull screen from screen retainer. Clean any sediment from screen retainer and port in water strainer housing.
- 6) Inspect screen for holes, restrictions, corrosion, and other damage. Discard damaged screen.
- 7) Check O-Ring on screen retainer. Replace worn or damaged O-Ring (P/N 310784-000).

NOTE

A screen should always be used, otherwise particles could foul the check valves.

- 8) Install good or new screen (P/N 313253-000) in screen retainer, then screw screen retainer into water strainer housing and tighten only fingertight.
- 9) Proceed to **SERVICING WATER PUMP CHECK VALVE.**

SERVICING WATER PUMP CHECK VALVE. (see Figure 4-5 and 6-20)

- 1) Service water pump water strainer screen before servicing water pump check valve.
- 2) Disconnect swivel nut tee fitting from top of check valve. Unscrew check valve from adapter fitting in water pump outlet.
- 3) Disassemble check valve as shown in Figure 4-5.
- 4) Wipe each part with clean lint-free cloth. Inspect each part, especially the ball for burrs, nicks, corrosion, deterioration, and damage. Discard ball seat and any damaged or suspicious parts and replace with new parts during assembly.
- 5) Assemble check valve as shown in Figure 4-5. **ALWAYS INSTALL NEW BALL SEAT (QUAD RING) (P/N 312418-000).**
- 6) Install check valve on water pump outlet adapter fitting, then connect swivel tee fitting to top of check valve.

SERVICING WATER FLOW REGULATORS CHECK VALVES

- 1) Service water pump water strainer screen and water pump check valve before servicing water flow regulators check valves.
- 2) Disconnect line from water flow regulator assembly (see Figure 4-2 and 6-14)
- 3) Remove water flow regulator assembly and connector fitting from top of check valve.
- 4) Unscrew check valve from elbow fitting on water solenoid valve.
- 5) Disassemble check valve as shown in Figure 4-5.
- 6) Wipe each part with clean lint-free cloth. Inspect each part, especially the ball for burrs, nicks, corrosion, deterioration, and other damage. Discard ball seat and any damaged or suspicious parts and replace with new parts during assembly.
- 7) Assemble check valve as shown in Figure 4-5. ALWAYS INSTALL NEW BALL SEAT (QUAD RING)(P/N 312418-000).
- 8) Install check valve water solenoid valve elbow fitting.
- 9) Install water flow regulator assembly and connector fitting on check valve outlet.
- 10) Connect line to water flow regulator assembly.
- 11) Open inlet water supply line and CO₂ cylinder shutoff valves to unit. Check for leaks and tighten any loose connections.
- 12) Install both sides and rear panels by reversing removal procedure.
- 13) Press both POWER switches to AUTO position.

REPLENISHING SYRUP SUPPLY

NOTE

Sugar free diet type syrups cannot be used with this unit.

Although syrup replenishment can be accomplished as desired, the applicable syrup supply must be replenished when the OUT OF SYRUP light goes on.

NOTE

The following instructions are applicable only when replenishing syrup. Refer to SYRUP FLAVOR CHANGE when changing syrup flavors.

- 1) Press applicable POWER switch to OFF position.
- 2) Disconnect inlet (CO₂) and outlet (syrup) lines from soft drink tank.
- 3) Check soft drink tank quick disconnects for sticky or restricted operation. Clean disconnects in warm water.
- 4) Connect CO₂ and syrup lines to full soft drink tank.
- 5) Press applicable SYRUP switch to FILL position until OUT OF SYRUP light goes out, then press SYRUP switch to AUTO position.
- 6) If freeze cylinder is not full of product, leave POWER switch in OFF position. Repeatedly pull and release faceplate relief valve knob to slowly bleed CO₂ from freeze cylinder and allow product to fill cylinder. Do not relieve pressure too fast or "break out" will occur. When cylinder is full, press POWER switch to AUTO.

REPLENISHING CO₂ SUPPLY

NOTE

When indicator on primary CO₂ cylinder regulator assembly 2000-psi gage is in shaded ("change CO₂ cylinder") portion of the dial, CO₂ cylinder is almost empty and should be changed.

When the OUT OF CO₂ warning light on the front of the unit goes on, make sure the CO₂ cylinder valve and the CO₂ regulators are open. If the valve and regulators are open and the OUT OF CO₂ warning light is on, replace the CO₂ cylinder as follows:

- 1) Fully close (clockwise) CO₂ cylinder valve.
- 2) Slowly loosen CO₂ regulator assembly coupling nut allowing CO₂ pressure to escape, then remove regulator assembly from empty CO₂ cylinder.
- 3) Unfasten safety chain and remove empty CO₂ cylinder.

WARNING !



TO AVOID PERSONAL INJURY AND/OR PROPERTY DAMAGE, ALWAYS SECURE CO₂ CYLINDER WITH SAFETY CHAIN TO PREVENT IT FROM FALLING. SHOULD THE VALVE BECOME ACCIDENTALLY DAMAGED OR BROKEN OFF, CO₂ CYLINDER CAN BECOME AN UNGUIDED MISSILE.

- 4) Position CO₂ cylinder and secure with safety chain.
- 5) Make sure gasket is in place inside CO₂ regulator coupling nut, then install regulator on CO₂ cylinder.
- 6) Open (counterclockwise) CO₂ cylinder valve slightly to allow lines to slowly fill with gas, then open valve fully to back-seat valve. (Back-seating valve prevents leakage around valve shaft).
- 7) Check CO₂ connections for leaks. Tighten loose connections.

SYRUP FLAVOR CHANGE

NOTE

Either or both syrup flavors can be changed at the same time. This allows dispensing to continue on one system while a syrup changeover is being made on the other dispensing system.

- 1) Refer to SANTITIZING SYRUP SYSTEMS, steps 1) through 19), and perform sanitizing procedure on syrup system where syrup flavor change will be made.
- 2) Refer to VISCOSITY SENSOR, DISPENSING VALVE O-RINGS, AND BEATER SHAFT SEAL ASSEMBLIES under LUBRICATION and perform procedure to lubricate viscosity sensor, dispensing valve O-Rings, and beater shaft seal assemblies.
- 3) If both faceplates were serviced, restore CO₂ supply to unit. If only one faceplate was serviced, turn applicable secondary CO₂ regulator adjusting screw to the right (clockwise) until gage reads 25 to 30-psig. Install front access panel.
- 4) Connect CO₂ and syrup lines to soft drink tank containing new flavor syrup.
- 5) Press and hold SYRUP switch in FILL position until OUT OF SYRUP light goes out, then press switch to AUTO position to start carbonator-blender water pump. Press POWER switch to AUTO position.

CAUTION !

Do not relieve cylinder pressure too fast or product will foam excessively in freeze cylinder and lose carbonation.

- 6) After water pump cycles off, intermittently pull and release relief valve knob on freeze cylinder faceplate. This bleeds CO₂ from cylinder and allows product to enter and fill cylinder.
- 7) If necessary adjust BRX, viscosity (stiffness) of product dispensed, and product carbonation as instructed.

RECOMMENDED EQUIPMENT AND PROCEDURE

FOR INSTALLING REFRIGERATION COMPRESSOR KIT

Read and understand these instructions thoroughly before proceeding to install refrigeration compressor kit.

IMPORTANT

**ONLY QUALIFIED PERSONNEL SHOULD INSTALL
REFRIGERATION COMPRESSOR KIT.**

USE CAUTION

Read and understand the CORNELIUS WARRANTY before any repairs are performed on the refrigeration system.

- 1) If the compressor is within warranty period, contact The Cornelius Company Service Department, One Cornelius Place, Highway 10 West, Anoka, Minnesota 55303 Phone (612) 421-6120 for compressor return shipment instructions.
- 2) DO NOT change compressor until you know it is inoperative. Refer to troubleshooting guide included in these instructions.
- 3) DO NOT "frost line" charge refrigeration systems. Use charge listed on unit serial plate.
- 4) DO NOT use line tapping valves or poppet type valves for system processing. They cause restriction during evacuation and are prone to leak.
- 5) USE only type and amount of refrigerant specified on unit serial plate to charge system. DO NOT USE "USED" REFRIGERANT.

TROUBLESHOOTING

Before a compressor is replaced, a few simple checks should be made to confirm that the compressor is actually at fault. The following is a list of symptoms, probable causes, and test procedures to be considered before proceeding to replace the compressor.

COMPRESSOR COOLS BUT IS VERY NOISY, EXPECIALLY WHEN STOPPING AND STARTING

Probable Cause - Compressor cools, but is very noisy, expecially when stopping and starting. This is either a broken suspension spring or loose crank shaft extension.

Remedy - Compressor must be changed.

COMPRESSOR COOLS, BUT IS MODERATELY NOISY; LOUD ENOUGH TO BE NOTICED, BUT NO SHARP BANGS OR CLATTERING

Probable Cause - Compressor cools and is moderately noisy, loud enough to be somewhat annoying, but no sharp bangs or clattering.

Remedy - This is probably a discharge or suction tube rattling inside the compressor. If noise level can be tolerated, compressor need not be changed. The noise will not affect the performance or shorten compressor life.

COMPRESSOR OPERATES BUT REFRIGERATION SYSTEM DOES NOT COOL

Probable Cause - Look for a refrigerant leak or oil at tubing joints. If compressor is moderately noisy and no leaks are evident, it is probably a broken valve inside compressor.

Remedy - Compressor must be changed.

COMPRESSOR STARTS AND OPERATES FOR A FEW SECONDS, THEN STOPS

Probable Cause - Compressor running too hot due to condenser coil fins plugged with dust, lint, and grease restricting cooling air flow through the condenser coil.

Remedy - Clean condenser coil fins with vacuum cleaner, low-pressure compressed air, or a soft brush, then allow compressor to cool and restart.

COMPRESSOR WILL NOT START

- 1) Check line voltage across "T" terminals on contactor. Cannot be more than 15% below nominal voltage.
- 2) Check for loose or disconnected wires.
- 3) Check control circuit; contactor must pull in.
- 4) Visually examine start capacitor for signs of excessive heat (blown up). If none visible, check for open by connecting test cord and checking amp draw. If no current is drawn (or very little), capacitor is open and must be replaced.
- 5) If capacitor is blown, look for a defective start relay, or low voltage.
- 6) Shorted or grounded motor windings.
- 7) If all above checks have been made and compressor still will not start, increase starting capacitor value by about 15% and try to start. This can be done two ways:

IMPORTANT

THE SUBSTITUTE CAPACITOR MUST HAVE A VOLT-AGE RATING EQUAL TO OR GREATER THAN THE EXISTING START CAPACITOR.

- a. Remove existing capacitor and replace with one having a 15% greater MFD rating or (step b).
 - b. Wire a capacitor that has 15% of the MFD rating in parallel with the existing capacitor.
 - c. Try to start compressor.
- 8) If all above will not make compressor run, label "stuck", and replace.

ELECTRICAL CHECK

Single-Phase Compressor.

Compressor starts but will not operate for more than a few seconds.

Inoperable Start Relay - To check start relay, remove wire from No. 1 terminal on start relay and touch to No. 2 terminal. Start compressor and immediately remove wire from No. 2 terminal. If compressor starts and operates, problem is in the start relay.

Remedy - Replace start relay.

Low Voltage - Remove compressor terminal cover and connect voltmeter test leads between "C" (top terminal) and "R" (lower right terminal). Start compressor a minimum of 200 VAC must be present to operate compressor.

Remedy - If less than 200 VAC is present, either upgrade unit power source or install Step-Up/Step-Down Transformer Kit (P/N 511027-000).

WARNING !



TO AVOID ELECTRICAL SHOCK EVEN AFTER ELECTRICAL POWER HAS BEEN DISCONNECTED FROM UNIT, RUN CAPACITORS MUST BE DISCHARGED BY MOMENTARILY TOUCHING BOTH CAPACITOR TERMINALS AT THE SAME TIME USING AN INSULATED SCREWDRIVER.

Inoperative Run Capacitor - Inspect capacitor for bulges, cracks, or any external deformation. If found, assume the capacitor is inoperable. If none of the mentioned conditions are found, disconnect electrical wires from capacitor. Connect test cord to capacitor terminals. Connect ammeter to one wire of test cord. Plug test cord into electrical outlet and observe amp reading. For 230 VAC input into capacitor, amp reading should be between 1 and 3 amps. If less than or greater than these values, the capacitor is open or shorted and should be replaced.

Remedy - Replace run capacitor.

Grounded or Shorted Motor Windings - Disconnect all electrical wires from compressor terminals. Set ohmmeter on 100,000 ohm scale. Touch one lead to copper line or bare metal of compressor. Touch other lead to each of the compressor terminals in succession. Continuity must not be indicated. If an ohmmeter reading is obtained, the compressor is grounded and must be replaced. To check for shorted windings, set ohmmeter on 10 ohm scale. Attach one lead to "C" (top terminal on compressor). Touch other lead to "R" (lower right

terminal). The reading should be approximately 1 to 1-1/2 ohms. Leave one lead on "C" terminal and touch other lead to "S" (lower left terminal). The reading should be 3-1/2 to 5 ohms. Leave one lead on "S" terminal and touch other lead to "R" terminal. This reading should be exactly the sum of the first two readings obtained. If the resistance readings do not fall within these limits, the compressor is "shorted" or has an "open" winding and must be replaced.

Remedy - Replace compressor.

EQUIPMENT AND SUPPLIES NEEDED

- 1) Oxy-fuel (acetylene, propane, etc.) torch with tip size No. 2 or 3.
- 2) Vacuum pump - preferably a high vacuum type capable of at least a 50-micron blank off pressure. Alternate: A pump capable of 28.5-in. HD minimum.
- 3) Adequate gaging matched to the pump's capability.
- 4) Charging cylinder - visual indicating type with a refrigerant R-12 and R-502 scale and temperature correction curve or a closed container with an accurate scale. Charging equipment must be able to deliver the correct charge within 1/4-ounce. USE A PRE-MEASURED CHARGE ONLY.
- 5) Pinch-off tool - used to seal process lines after recharging.
- 6) Normally used hand tools - pliers, screwdrivers, etc.
- 7) Brazing alloy - use a phosphorous bearing copper-silver alloy for copper-to-copper connections such as "phos-copper" or "Silfos". These alloys have about 15% silver content. Use a high (50%) silver alloy such as "Easy-Flow" and flux for copper-to-steel joints. NEVER USE "SOFT" OR "HARD" SOLDER.

COMPRESSOR REPLACEMENT PROCEDURE (see Figure 4-6)

Clean condenser coil fins of any foreign matter or blockage. Make sure unit has enough air flow through the condenser coil to insure proper operation. Inadequate air flow will cause premature compressor failure.

WARNING !



TO AVOID POSSIBLE FATAL ELECTRICAL SHOCK OR SERIOUS INJURY, DISCONNECT ELECTRICAL POWER FROM UNIT BEFORE PROCEEDING TO INSTALL COMPRESSOR KIT.


- 1) Disconnect electrical power from unit.

- 2) Tag electrical wires for identification, then disconnect electrical wires from compressor terminals.
- 3) Break low-side suction process line (located on compressor) and high-side discharge process line (located on dual inlet drier) at crimp, and allow refrigerant to exhaust slowly to atmosphere.
- 4) Cut or split rubatex insulation covering suction line and cap tube.
- 5) Apply heat shields, as necessary, on electrical wiring and lines adjacent to compressor joints for protection against burning.
- 6) Unsolder cap tube from suction line for a distance of 12 to 15-inches. Cut out 4-inches of suction line in preparation to install new filter dryer (P/N 511031-000) provided with kit. BE CAREFUL NOT TO CUT OR CRIMP CAP TUBE.
- 7) Clean lines with emery cloth or wire brush until "shiny". Do not allow chips or sand from cloth to enter tubes. Do NOT cool tubes with water or allow water or moisture to enter system.

IMPORTANT

NOTE ARROW ON FILTER DRYER INDICATING FLOW DIRECTION THROUGH FILTER. NEW DRIER TO BE INSTALLED IN SUCTION LINE BETWEEN ACCUMULATOR AND COMPRESSOR WITH INLET PORT OF DRIER ON ACCUMULATOR SIDE OF CONNECTION.

- 8) Install new filter dryer in suction line. TO INSTALL NEW DRIER IN PRE-COOL SYSTEM, TWO 1/2-IN. TO 3/8-IN. REDUCERS (P/N 511033-000) ARE PROVIDED IN KIT AND MUST BE USED TO MAKE CONNECTIONS.
- 9) Remove compressor mounting clips or bolts.
- 10) Heat joints and remove suction and discharge lines from compressor.
- 11) Clean lines with emery cloth or wire brush until "shiny". Do not allow chips or sand from cloth to enter tubes. Do NOT cool tubes with water or allow water or moisture to enter system.
- 12) Install new compressor and insert suction and discharge lines in compressor.
- 13) Replace dual inlet strainer drier with new dual inlet strainer drier (P/N 320650-000) (supplied with kit) in a horizontal position; insert liquid, process, and cap tube lines.



***DUAL INLET DRYER TO BE INSTALLED IN HORIZONTAL POSITION AS SHOWN.**

Figure 4-6. Installing Dryers

CAUTION !

DUAL INLET STRAINER DRYER MUST BE INSTALLED IN A HORIZONTAL POSITION TO AVOID PREMATURE COMPRESSOR FAILURE.

NOTE 1

Cap tube must not be cut off more than 2-inches. (NOTCH WITH FILE AND BREAK OFF.)

NOTE 2


Cap tube must not be inserted into drier opening more than 1/2-inch.

NOTE 3

Drier must not be uncapped more than 10 minutes before brazing into system.

- 14) Connect "dry" nitrogen (-75°F dewpoint minimum) to suction process line and open discharge process line to purge system. DO NOT PURGE WITH CO_2 .
- 15) Purge system at least 10 minutes with dry nitrogen prior to brazing.
- 16) Adjust nitrogen flow until a very small amount (less than 1-psi) of nitrogen is flowing through refrigeration system.
- 17) While nitrogen is slowly flowing through refrigeration system, braze all but the last joint.
- 18) Disconnect dry nitrogen from refrigeration system, then braze the last joint.
- 19) Clean all flux from braze joints with cold water.
- 20) When brazing is complete, pressurize system to saturation with clean dry refrigerant of type specified on unit serial plate.
- 21) Leak-check system including newly brazed joints. If joint is suspected of a leak, tape envelope made of poly over joint to trap leaking refrigerant. Wait 10 minutes, then use leak detector to check air inside envelope for traces of refrigerant.
- 22) Exhaust refrigerant and evacuate. If high-vacuum pump is used, evacuate to at least 200-microns (preferably 100-microns) prior to charging.
- 23) Use clean dry refrigerant, in amount and type specified on unit serial plate, to charge unit through suction process line. It should not be necessary to run system to install correct charge in liquid form.

- 24) Pinch off. Use crimp tool and pinch tube twice, leaving crimp tool applied to second (inner) pinch until weld is cold. Cut tube approximately 1/2-inch from outer pinch. Open end of tube and fill with copper brazing alloy. Repeat for other process line. Do not use line-tapping valves or poppet-type valves for system processing. They cause too much restriction for evacuation and have great potential for refrigerant leaks, causing malfunction and additional service calls, and voids warranty.
- 25) Press cap tube back to suction line as close as possible, then wrap cap tube and suction line with insulation.
- 26) If your kit contains a loose-shipped start capacitor, install capacitor on unit. Transfer applicable parts from old to new compressor, then connect electrical wiring to compressor. Make sure electrical wiring is properly connected by referring to wiring diagram on inside of control box.
- 27) Connect electrical power to unit, then test run and check unit for peoper operation.



3-21-62 GAW/B

Duplicate Wiring Diagram Decal Located on Inside of Control Box Cover.

Figure 4-8. Wiring Diagram (Model 416025)



SECTION V TROUBLESHOOTING

IMPORTANT

ONLY QUALIFIED PERSONNEL SHOULD SERVICE INTERNAL COMPONENTS OR ELECTRICAL WIRING.



WARNING!

DISCONNECT ELECTRICAL POWER TO UNIT BEFORE ATTEMPTING ANY ELECTRICAL REPAIRS TO INTERNAL COMPONENTS. IF SERVICE AND MAINTENANCE TO DISPENSING SYSTEM MUST BE PERFORMED, DISCONNECT ALL ELECTRICAL POWER TO UNIT, SHUT OFF CO₂ SUPPLY, THEN BLEED SYSTEM PRESSURE BEFORE PROCEEDING.

Trouble	Probable Cause	Remedy
TROUBLESHOOTING WARNING LIGHTS AND SAFETY DEVICES		
<u>WARNING LIGHT(S) DO NOT GO ON AT SPECIFIED TIMES.</u>	<ol style="list-style-type: none">Burned out lamp.Loose or broken electrical wires.Inoperative switch.	<ol style="list-style-type: none">Replace lamp.Tighten connections or replace wiring.Replace switch.
<u>BEATER STOPPED LIGHT(S) GO ON.</u>	<ol style="list-style-type: none">POWER switch in OFF position.Loose or broken beater motor electrical wires cause beater motor to stop.Centrifugal switch spring broken.Overheated motor cut off by overload protector.	<ol style="list-style-type: none">As applicable, press switch to WASH AUTO position.Tighten connections or replace wires.Replace switch.Check for proper line voltage. Reduce load by decreasing product viscosity.

Trouble	Probable Cause	Remedy
<u>BEATER STOPPED LIGHT(S) GO ON.</u>	<ol style="list-style-type: none"> 5. Inoperative centrifugal switch or beater motor. 6. Cylinder freeze-up. 	<ol style="list-style-type: none"> 5. Replace switch or motor. 6. Refer to <u>CYLINDER FREEZE-UP.</u>
<u>LIGHT IN DEFFROST SWITCH DOES NOT GO ON WHEN SWITCH IS PRESSED.</u>	<ol style="list-style-type: none"> 1. Product temperature too high. 2. Loose or broken electrical wires. 3. Lamp burned out. 4. Inoperative switch. 5. Defective light relay. 	<ol style="list-style-type: none"> 1. Defrost unnecessary. 2. Tighten or replace wires. 3. Replace defrost switch. 4. Replace switch. 5. Replace relay.
<u>OUT OF CO₂ LIGHT GOES ON DURING OPERATION.</u>	<ol style="list-style-type: none"> 1. CO₂ supply turned off or exhausted. 2. Primary CO₂ regulator set too low. 3. Inlet CO₂ line disconnected, loose, or broken. 4. Inoperable CO₂ pressure switch. 	<ol style="list-style-type: none"> 1. Open CO₂ cylinder valve or replenish CO₂ supply. 2. Adjust primary CO₂ regulator. 3. Connect, tighten, or replace line. 4. Replace switch.
<u>OUT OF WATER LIGHT GOES ON DURING OPERATION.</u>	<ol style="list-style-type: none"> 1. Water supply turned off or pressure inadequate. 2. Plugged water filter or water pump strainer. 3. Inlet water line or water pressure switch capillary tube disconnected or broken. 4. Inoperative water pressure switch. 	<ol style="list-style-type: none"> 1. Turn on water supply or check water supply line pressure. 2. Change water filter or clean pump strainer. 3. Connect or replace water line or replace water pressure switch. 4. Replace switch.

Trouble

Probable Cause

Remedy

OUT OF SYRUP LIGHT(S)
GOES ON DURING OPERATION.

1. Soft drink tank empty.
2. When optional gas bypass valve is used on soft drink tank, valve causes OUT OF SYRUP light to go on if either line on soft drink tank is disconnected.

1. Replenish syrup supply.
2. Reconnect line to soft drink tank.

PRE-COOL TOO COLD LIGHT
GOES ON.

1. Control thermostat set too cold.
2. Inoperative refrigeration solenoid.
3. Inoperative control thermostat.

1. Decrease setting. (Should be between 2 and 1-1/2.)
2. Replace solenoid.
3. Replace thermostat.

DEFROST SWITCH IS PRESSED
BUT CYLINDER DOES NOT GO
ON DEFROST

1. Product temperature too high.
2. Loose or broken electrical wires.
3. Inoperative defrost switch.
4. Inoperative defrost thermostat.
5. Inoperative hot gas defrost relay.
6. Inoperative hot gas solenoid.

1. Defrost unnecessary.
2. Tighten or replace wires.
3. Replace switch.
4. Replace thermostat.
5. Replace relay.
6. Replace coil and/or solenoid body and plunger.

UNIT DOES NOT GO OFF
DEFROST CYCLE.

1. Loose or broken electrical wires.
2. Inoperative defrost thermostat.
3. Inoperative hot gas defrost relay.
4. Stuck hot gas valve.

1. Tighten or replace wires.
2. Replace thermostat.
3. Replace relay.
4. Replace valve body and plunger.

Trouble	Probable Cause	Remedy
TROUBLESHOOTING CARBONATOR-BLENDERS AND WATER PUMP		
<u>WATER PUMP MOTOR WILL NOT OPERATE.</u>	<ol style="list-style-type: none"> 1. No electrical power to unit. 2. SYRUP switch in OFF position. 3. <u>OUT OF WATER</u> light on. 4. <u>OUT OF CO₂</u> light on. 5. <u>OUT OF SYRUP</u> light on. 6. Water pump motor may be operative but <u>OUT OF WATER</u> light burned out. 7. Loose or broken electrical wires. 8. Overheated water pump motor cut off by overload protector. 9. Inoperative water pump relay. 10. Inoperative carb relay. 11. Inoperative blender-level switch. 12. Binding water pump (new or replacement pumps only). 13. Inoperative water pump and/or motor. 	<ol style="list-style-type: none"> 1. Connect unit to electrical power or check power source. 2. Press switch to AUTO. 3. Refer to <u>OUT OF WATER LIGHT GOES ON DURING OPERATION.</u> 4. Refer to <u>OUT OF CO₂ LIGHT GOES ON DURING OPERATION.</u> 5. Refer to <u>OUT OF SYRUP LIGHT(S) GOES ON DURING OPERATION.</u> 6. Replace lamp. 7. Tighten connections or replace wires. 8. Check for proper line voltage. Check for restricted pump discharge. 9. Replace relay. 10. Replace carb relay. 11. Replace switch. 12. Remove water pump from motor. Rotate pump coupling shaft 180 degrees. Reinstall pump. 13. Replace pump and/or motor.

Trouble	Probable Cause	Remedy
<u>WATER PUMP MOTOR WILL NOT SHUT OFF.</u>	<ol style="list-style-type: none"> 1. Inoperative carb relay. 2. Inoperative blender-level switches or loose electrical wires. 	<ol style="list-style-type: none"> 1. Replace relay. 2. Replace switch or repair wiring.
<u>ERRATIC WATER PUMP CYCLING.</u>	<ol style="list-style-type: none"> 1. Insufficient water supply pressure. OUT OF WATER light goes on and off intermittently and water pump cycles on and off during carbonator tank fill cycle. 2. Water filter restricted. 	<ol style="list-style-type: none"> 1. Increase water supply line pressure. Water inlet supply line must have large enough I. D.. 2. Replace water filter.
<u>TROUBLESHOOTING PRODUCT DISPENSED</u>		
<u>BRIX TOO LOW.</u>	<ol style="list-style-type: none"> 1. Disconnect not secure on soft drink tank. 2. Syrup flow regulator set too low. 3. Water flow regulator set too high. 4. Syrup flow regulators stuck. 5. Restriction in syrup line. 6. Baume of syrup not in proper range. 	<ol style="list-style-type: none"> 1. Secure tank quick disconnect. 2. Adjust BRIX of dispensed product. 3. Water flow regulator must be set at 1.5 + 0.05 oz./sec. 4. Clean regulators. 5. Sanitize unit. 6. Change syrup.
<u>BRIX TOO HIGH.</u>	<ol style="list-style-type: none"> 1. Syrup flow regulator set too high. 	<ol style="list-style-type: none"> 1. Adjust BRIX of dispensed product.

Trouble	Probable Cause	Remedy
<u>BRIX TOO HIGH. (cont'd)</u>	<ol style="list-style-type: none"> 2. Water flow regulator set too low. 3. Water flow regulators stuck. 4. Stop guide restricted. 5. Baume of syrup not in proper range. 6. Restricted water filter. 	<ol style="list-style-type: none"> 2. Water flow regulator must be set for 1.5 + 0.05 oz./sec. 3. Clean regulators. 4. Clean or replace stop guide. 5. Change syrup. 6. Replace water filter.
<u>IMPROPER PRODUCT DISPENSED.</u>	<ol style="list-style-type: none"> 1. Secondary CO₂ regulators out of adjustment. 2. Dirty CO₂. CO₂ must be clean and free of water, oil, and dirt. Water will not absorb dirty CO₂ gas in the same ratio as clean gas. This can also cause off-taste problems. 	<ol style="list-style-type: none"> 1. Adjust secondary CO₂ regulators. 2. Replace CO₂ supply.
<u>PRODUCT WILL NOT DISPENSE OUT OF DISPENSING VALVE, IN ONLY SMALL AMOUNTS, OR ONLY LIQUID.</u>	<ol style="list-style-type: none"> 1. Dispensing valve has ice particle in it. 2. Cylinder freeze-up. 	<ol style="list-style-type: none"> 1. Open and close valve repeatedly. Press DEFROST switch to defrost. Check BRX and adjust if necessary. Adjust viscosity. 2. Refer to <u>CYLINDER FREEZE-UP.</u>
<u>FREEZE CYLINDER DOES NOT REFILL AT ALL TIMES WHEN DISPENSING.</u>	<ol style="list-style-type: none"> 1. SYRUP switch in OFF position. 2. Water pump not operating. 3. Lines restricted. 	<ol style="list-style-type: none"> 1. Press SYRUP switch to AUTO. 2. Check switches or pump relay. 3. Sanitize unit.

Trouble	Probable Cause	Remedy
---------	----------------	--------

FROZEN PRODUCT
CONSISTENCY VARIES
EXCESSIVELY.

- | | | |
|---------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|--|
| 1. Torque sensing device sticking in face-plate bushing. | 1. Sanitize unit. | |
| 2. BRIX of product varying because: | 2. | |
| a. Syrup and/or water flow regulator sticking. | a. Clean regulator(s). | |
| b. Primary CO ₂ regulator pressure insufficient. | b. Primary CO ₂ pressure must be 80-psig. | |
| 3. Cylinder freeze-up causing ice formation in center of cylinder and liquid product channels around ice formation. | 3. Refer to <u>CYLINDER FREEZE-UP.</u> | |

NOTE
Press DEFROST switch to defrost cylinder.

CYLINDER FREEZE-UP.

- | | |
|--------------------------------------------------------|-----------------------------------------------------|
| 1. Beater stopped. | 1. Refer to <u>BEATER STOPPED LIGHT(S) GOES ON.</u> |
| 2. BRIX too low. | 2. Refer to <u>BRIX TOO LOW.</u> |
| 3. Viscosity control thumbwheel set clockwise too far. | 3. Adjust viscosity control as instructed. |

ACCESSORIES AND TOOLS

294039-100	Primary CO ₂ Regulator
323169-000	Syphon Tube (1 hole)
511005-000	Cup Holder
511006-000	Cup Holder
511027-000	B & B Transformer Kit
511031-000	Filter-Drier Suction Line
511035-000	CO ₂ Changeover Kit
511042-000	Cup Holder Spring Loaded
511043-000	Cup Holder Spring Loaded

SERVICE TOOLS

151689-000	Spanner Wrench Flow Regulator
281884-400	3-gallon Sanitizing Tank
322063-000	Shaft Seal Assembly Puller
322859-000	Spanner Wrench Dispensing Valve
511004-000	Refractometer 0-30 Scale




THE CORNELIUS COMPANY
ONE CORNELIUS PLACE
HIGHWAY 10 WEST
ANOKA, MINNESOTA 55303

FCB Dispenser Post-Mix

Model Numbers

416025

416026



SECTION VI ILLUSTRATED PARTS BREAKDOWN

REV: 8-8-88

11-8-77

©The Cornelius Company, 1977-88

6-1

325151-000




Figure 6-1. Frozen Carbonated Beverage Dispenser

Figure 6-1. Frozen Carbonated Beverage Dispenser

IMPORTANT

INCLUDE MODEL NUMBER AND SERIAL NUMBER
WHEN ORDERING REPLACEMENT PARTS.

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	416025	Frozen Carbonated Beverage Dispenser
	416026	Frozen Carbonated Beverage Dispenser with Transformer
1	314097	Cup Rest
2	322235	Drip Tray
3	*320106	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 1-in.
4	*322967	Lock Washer, Ext Tooth, No. 6, .146 I. D.
5	*120280	Hex Nut, No. 6-32
6	325116	Shield, Compressor
7	325119-033	Panel, Top
8	*189075	Sheet Metal Screw, Sl Pan Hd, Type B, No. 6 by 3/8-in.
9	*320539	Flat Washer, No. 8
10	325123	Control Panel Ass'y (see Figure 6-3)
11	320761-033	Grille, Top Front
12	322822	Wire Insulator
13	*188206	Thread Rolling Screw, Phil Truss Hd, No. 10-24 by 3/8-in.
14	*343304	Lock Washer, Ext Tooth, No. 10
15	325285-033	Panel, Side
16	325286-033	Panel, Back
17	*186394	Cap Screw, Hex Hd, 1/4-20 by 5/8-in.
18	341019	Lock Washer, Ext Tooth, Stainless Steel, .261 I. D.
19	325072	Shield, Control Panel
20	*186309	Machine Screw, Phil Rd Hd, No. 10-24 by 5/16-in.
21	*343304	Lock Washer, Ext Tooth, No. 10
22	320643	Condenser Fan, Motor and Shroud Ass'y (see Figure 6-4)
23	321290	Hex Nut, Keps, Chrome-plated Steel, 3/8-16
24	*322330	Washer, .390 I. D.
25	322339	Insert, 29/32 O. D.
26	189723	Grommet, Rubber
27	322718	Compressor Kit
28	322324	Refrigeration Ass'y (see Figure 6-5)
29	325217	Cover, Soffit Panel
30	320553-001	Knob
31	320916	Flat Washer, Special, Stainless Steel, .450 I. D. by .062 thk
32	324091	Freeze Cylinder Face Plate Ass'y (see Figure 6-6)
33	320568	Scraper Blade
34	320935	Beater
35	320815	O-Ring, 1.234 I. D. by .139 C. S.
36	320550	Sleeve
37	320533	O-Ring, .859 I. D. by .130 C. S.

*Zinc-plated steel unless indicated otherwise.

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
38	320814	O-Ring, .734 I. D. by .139 C. S.
39	320808	Retainer Seal, Stainless Steel
40	*320899	Cap Screw, Hex Hd, 5/16-18 by 3/4-in.
41	*186147	Flat Washer, 5/16-in.
42	*343313	Lock Washer, Ext Tooth, 5/16-in.
43	186146	Hex Nut, Stainless Steel, 5/16-18
44	320923	Bracket, Support Angle
45	*313672	Clamp
46	325260	Coil, Hot Gas Solenoid (230 VAC, 60Hz)
47	322893	Solenoid Body and Plunger, No. 1 Compressor
48	322894	Solenoid Body and Plunger, No. 2 Compressor
49	313456	Decal
50	*189429	Hex Nut, Keps, 1/4-20
51	322249	Freeze Cylinder and Cold Plate Ass'y
52	*320940	Thread Rolling Screw, Hex Hd, No. 10-24 by 5/8-in.
53	*186130	Sheet Metal Screw, Phil Truss Hd, Type A, No. 6 by 1/2-in.
54	321785-033	Grille, Lower Front
55	*311462	Cap Screw, Hex Hd, 5/16-18 by 1/2-in.
56	*343313	Lock Washer, Ext Tooth, 5/16-in.
57	320604	Twin Nut, 5/16-18
58	*320940	Thread Rolling Screw, Hex Hd, No. 10-24 by 5/8-in.
59	321836	Collar
60	320723	Drive Shaft Ass'y (see Figure 6-8)
61	320736-088	Bearing and Support Bracket Ass'y (see Figure 6-9)
62	*186394	Cap Screw, Hex Hd, 1/4-20 by 5/8-in.
63	*341019	Lock Washer, Ext Tooth, Stainless Steel, .261 I. D.
64	*150779	Flat Washer, 1/4-in.
65	325279	Idler and Channel Ass'y (see Figure 6-10)
66	325030	Drive Belt
67	325027	Sheave, includes Setscrews
68	325143	Beater Drive Motor and Mounting Plate Ass'y (see Figure 6-11)
69	*312251	Thread Rolling Screw, Phil Pan Hd, No. 10-24 by 3/8-in.
70	*343304	Lock Washer, Ext Tooth, No. 10
71	322680	Electrical Box Ass'y (see Figure 6-12)
72	*151576	Machine Screw, Phil Truss Hd, No. 10-24 by 3/8-in.
73	*343304	Lock Washer, Ext Tooth, No. 10
74	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
75	325115	Shield, Compressor
76	325121	Wiring Diagram, w/o Transformer
	325223	Wiring Diagram, with Transformer
77	320544	Cover, Control Box
78	178025-200	Tapered Gasket, Red
79	325173	Tube Ass'y, .250 I. D. by 39-in. long
80	322727	Tube Ass'y, .250 I. D. by 27-in. long
81	*312251	Thread Rolling Screw, Phil Pan Hd, No. 10-24 by 3/8-in.

*Zinc-plated steel unless indicated otherwise.

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
82	324096	Cover, Relay
83	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
84	325130	Cover, Relay Box
85	325124	Carbonator Blenders and Control Box Ass'y (see Figure 6-13)
86	*398024-603	Hex Nut, Keps, No. 10-24
87	*343304	Lock Washer, Ext Tooth, No. 10
88	*186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
89	322218	Support, Drip Tray, Left-Hand
	322219	Support, Drip Tray, Right-Hand
90	321504	Speed Nut
91	321503	Bullet Catch
92	323880	Label, Cleaning and Sanitizing
93	322277	Drip Tray Panel Ass'y (see Figure 6-18)
94	322267	Door Access
95	320771	Screw Fastener
96	320773	Retaining Washer
97	330495	Pin
98	178025-100	Tapered Gasket, White
99	*398024-603	Hex Nut, Keps, No. 10-24
100	325141	Secondary CO ₂ Regulators and Bracket Ass'y (see Figure 6-19)
101	*320293	Thread Rolling Screw, Phil Pan Hd, No. 4-40 by 3/8-in.
102	320718	Track, Molding, Bottom
103	321505	Angle, Trim, Lower Front
104	320716	Trim, Molding, Bottom
105	320714	Trim, Molding, Right-hand w/o Transformer (shown)
	320693	Trim, Molding, Right-hand with Transformer
	320715	Trim, Molding, Left-hand
106	*320293	Thread Rolling Screw, Phil Pan Hd, No. 4-40 by 3/8-in.
107	320717	Track, Molding, Side
108	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
109	320692-033	Corner Post, Front, Left-hand/Right-hand
110	320604	Twin Nut, 5/16-18
111	176193	Fitting, Straight, 7/16-20
112	325144	Tube Ass'y, .250 I. D. by 95-in. long, CO ₂ Inlet
113	322606	Tube Ass'y, .265 I. D. by 95-in. long, Syrup Inlet
114	*187243	Wing Nut, No. 10-24
115	325075	Flat Washer, 7/32 I. D.
116	*186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
117	325074	Cover, Inlet Lines
118	320972	Clip
119	320650	Strainer, Drier
120	187917	Tube, Elbow, 1/4 O. D.
121	322625	Condenser Fan, Shroud and Motor Ass'y (see Figure 6-4)
122	*398034-603	Hex Nut, Keps, No. 10-24

*Zinc-plated steel.

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
123	320628	Condenser Fan, Shroud and Motor Ass'y (see Figure 6-4)
124	**140594	Drain Tube, 5/16 I. D. by 26-in. long
125	**140594	Drain Tube, 5/16 I. D. by 8-in. long
126	**140594	Drain Tube, 5/16 I. D. by 2-1/8 in. long
127	186152	Drain Tee
128	186146	Hex Nut, Stainless Steel, 5/16-18
129	*343313	Lock Washer, Ext Tooth, 5/16-in.
130	*186147	Flat Washer, 5/16-in.
131	178025-100	Tapered Gasket, White
132	325117	Shield, Motor
133	322624	Motor and Pump Ass'y (see Figure 6-19)
134	187888	Clip, Compressor
135	189723	Grommet, Rubber
136	325118	Cover, Compressor
137	331304	Snap Bushing
138	322718	Compressor Kit
139	322628-033	Frame
140	317658	Self-Threading Nut, .188 stud
141	317656-033	Grille
142	325282	Self-Tapping Screw, Hex Washer Hd, No. 2 Point, No. 8-18 by 1/2-in.
143	325284-033	Panel
144		Transformer, Buck and Boost (see Figure 6-2)

*Zinc-plated steel unless indicated otherwise.

**Sold in bulk quantity only.




Figure 6-2. Buck and Boost Transformer

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
1	150904	Hex Nut, No. 10-24
2	343304	Lock Washer, Ext Tooth, No. 10
3	186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
4	186207	Flat Washer, No. 10
5	322865	Connector
6	325182	Power Cord (6-ft long)
7	325181	Power Cord (5-ft long)
8	511017	Transformer
9	511013	Mounting Bracket




Figure 6-3. Control Panel Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325123	Control Panel Ass'y
1	*187254	Sheet Metal Screw, Phil Truss Hd, Type A, No. 6 by 3/8-in.
2	*150904	Hex Nut, No. 10-24
3	*186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
4	325070	Washer
5	320959	Clip, Wire
6	325073	Insulator
7	322650-033	Panel, Top
8	325114	Wiring Harness, Right-Side (shown)
	325113	Wiring Harness, Left-Side
9	*188074	Sheet Metal Screw, Sl Truss Hd, Type A, No. 4 by 1/2-in.
10	200717-005	Lock Washer, Ext Tooth, No. 4
11	324065-059	Panel, Warning Lights, Left-Side
12	324066-059	Panel, Warning Lights, Right-Side
13	322480	Lamp
14	320708	Switch, Rocker-Type, SYRUP
15	322632	Switch, Rocker-Type, DEFROST
16	320530	Switch, Rocker-Type, POWER
17	322633	Decal, Power, Syrup, and Defrost Switches
18	322634	Housing, Control Panel

*Zinc-plated steel.




Figure 6-4. Condenser Fan and Shroud Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	320643	Condenser, Fan, and Shroud Ass'y 3/4 H. P. Pre-Cool
	320628	Condenser, Fan, and Shroud Ass'y, 1-1/2 H. P. Pre-Cool, No. 1 Compressor, Lower Shroud
	322625	Condenser, Fan, and Shroud Ass'y, 1-1/2 H. P. Pre-Cool, No. 2 Compressor, Upper Shroud
1	*187254	Sheet Metal Screw, Phil Truss Hd, Type A, No. 6 by 3/8-in.
2	325071	Shield, Insulation, for 3/4 H. P. Compressor
3	322529	Coil, Condenser, for 3/4 H. P. Compressor
	322321	Coil, Condenser, for 1-1/2 H. P. Compressor
4	*186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
5	*120227	Lock Washer, Spring, No. 10
6	*320539	Flat Washer, No. 8
7	186202	Eyelet
8	321484	Grommet
9	186220	Pad
10	320639	Shroud, Condenser, for 3/4 H. P. Compressor
	320625	Shroud, Condenser, for 1-1/2 H. P. Compressor, Lower Shroud
	322601	Shroud, Condenser, for 1-1/2 H. P. Compressor, Upper Shroud
11	*186154	Machine Screw, Phil Pan Hd, Sems No. 8-36 by 5/16-in.
12	320619	Bracket, Motor
13	*189429	Hex Nut, Keps, 1/4-20
14	310429	Fan, Condenser
15	187394	Silencer
16	320651	Motor, Condenser, Fan (230 VAC, 60 Hz)

*Zinc-plated steel.




Figure 6-5. Pre-Cool Refrigeration Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	322324	Pre-Cool Refrigeration Ass'y
1	*310461	Thread Rolling Screw, Phil Pan Hd, No. 8-32 by 3/8-in.
2	*343311	Lock Washer, Ext Tooth, No. 8
3	*320106	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 1-in.
4	340739	Switch, Viscosity Control
5	322216	Bracket, Switch
6	187875	Set Screw, Headless Hex Soc, Stainless Steel, Cup Pt, No. 6-32 by 1/8-in.
7	321011	Thumb Wheel, Viscosity Control
8	320610	Spring, Tension
9	*321478	Threaded Rod, No. 10-24 by 3-1/2-in. long
10	*150904	Hex Nut, No. 10-24
11	321010	Plate, Torque Sensor
12	311777	Clip, Reuseable
13	343387	Flat Washer, Brass, .250 I.D.
14	320949	Bearing, Flange
15	320554	Torque Arm
16	322323	Base

*Zinc-plated steel.




Figure 6-6. Freeze Cylinder Faceplate Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	324091	Faceplate Ass'y
1	320678	O-Ring
2	172265	O-Ring
3	321652	Nut, Shank
4	311086	O-Ring
5	321671-088	Dispensing Valve Ass'y, (Plastic) Motorman (see Figure 6-7)
6	324089	Relief Valve Ass'y (includes 7-10)
7	391245	Knob
8	187629	Bushing, Retainer
9	320614	Spring
10	322275	Stem Ass'y
11	322441	Sensor, Viscosity
12	322442	Reducer
13	321545	Washer, Teflon
14	321544	O-Ring
15	321542	Arm, Viscosity Sensor
16	321269	Spinner
17	322069	Bushing
18	324090	Faceplate




Figure 6-7. Dispensing Valve Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	321671-088	Dispensing Valve Ass'y
1	321653	O-Ring
2	321540	Knob
3	321651	Lever, Valve
4	321646	Valve Body and Shank
5	321514	O-Ring, Caged
6	322828	Valve
7	321534	Sleeve, Lever Stop




Figure 6-8. Beater Drive Shaft Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	320723	Beater Drive Shaft Ass'y
1	321836	Collar
2	325291	Boot, Rubber
3	320557	Bearing
4	320812	Slinger
5	322953	Shaft Ass'y




Figure 6-9. Bearings and Support Bracket Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	320736-088	Bearings and Support Bracket Ass'y
1	186146	Hex Nut, Stainless Steel, 5/16-18
2	*186148	Lock Washer, Spring, 5/16
3	*320737	Flat Washer, 5/16
4	320622	Carriage Bolt, 5/16-18 by 3/4-in.
5	320558	Flange, Bearing
6	320557	Bearing
7	320578	Bracket, Bearing Support

*Zinc-plated steel.




Figure 6-10. Idler and Channel Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325279	Idler and Channel Ass'y
1	322663	Spring, Extension
2	*189429	Hex Nut, Keps, 1/4-20
3	325293	Bearing, Flange
4	325294	Spacer
5	*325292	Machine Screw, Sl Rd Hd, No. 1/4-20 by 1-3/4 in.
6	325029-003	Pulley, Idler (includes Setscrew)
7	*199732	Machine Screw, Sl Rd Hd, No. 6-32 by 1-in.
8	*188490	Lock Washer, No. 6
9	311802	Speed Nut, Twin, (for 6-32 Screw)
10	320777	Switch, Centrifugal, SPDT
11	320719	Insulation, Switch
12	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
13	325278-003	Bearing Bracket and Activator Ass'y
14	323365-005	Channel, Idler

*Zinc-plated steel.




Figure 6-11. Beater Drive Motor and Mounting Plate Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325143	Beater Drive Motor and Mounting Plate Ass'y
1	325028	Pulley, Motor (includes set-screw)
2	186146	Hex Nut, Stainless Steel, 5/16-18
3	343313	Lock Washer, Ext Tooth, 5/16-in.
4	*186147	Flat Washer, 5/16-in.
5	321344	Plate, Motor Mounting
6	322821	Motor, Beater Drive, 1/8 HP (230 VAC, 60 Hz)

*Zinc-plated steel.




Figure 6-12. Hot Gas Control Box Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	322680	Hot Gas Control Box Ass'y
1	*320289	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 1/4-in.
2	322652	Cover, Control Box
3	322671	Wiring Harness
4	187188	Machine Screw, Phil Rd Hd, Sems, No. 8-32 by 1/4-in.
5	320710	Thermostat, Safety
6	*320289	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 1/4-in.
7	322678	Relay
8	322648	Control Box

*Zinc-plated steel.




Figure 6-13. Carbonator-Blenders and Control Box Ass'y

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325124	Carbonator-Blenders and Control Box Ass'y
1	321497	Flanged Nut, No. 10-24
2	325125	Carbonator-Blenders Flat Form Ass'y (see Figure 6-14)
3	*320734	Machine Screw, Phil Pan Hd, Sems, No. 6-32 by 3/8-in.
4	320669	Cut Out Switch, Low Pressure Water
5	320670	Cut Out Switch, Low Pressure CO ₂
6	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
7	322012	Strap, Capacitor
8	320677	Capacitor, Run
9	320623	Relay Pump
10	320620	Contactor (Relay)
11	324092-001	Relay, Time Delay
12	320648	Relay, Start (230 VAC, 60 Hz)
13	325192	Snap Bushing
14	*325145	Washer, Int Tooth, No. 10
15	*325069	Machine Screw, Sl Hex Hd, No. 10-24 by 1/2-in.
16	325197	Control Box

*Zinc-plated steel.




Figure 6-14. Carbonator-Blenders Platform Assembly

Figure 6-14. Carbonator-Blenders Platform Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325125	Carbonator-Blenders Platform Ass'y
1	*311751	Machine Screw, Sl Hex Washer Hd, No. 4-40 by 1/4-in.
2	311743	Nipple Retainer
3	312519	Tube Ass'y, CO ₂ , No. 1 Side, 17-in. long
	321748	Tube Ass'y, CO ₂ , No. 2 Side, 33-in. long
4	325138	Tube Ass'y, Syrup, No. 1 Side, 21-in. long
	325139	Tube Ass'y, Syrup, No. 2 Side, 33-in. long
5	325077	Check Valve Ass'y, Plastic (see Figure 6-15)
6	183008	O-Ring
7	322743	Syphon Tube (2 hole)
8	310380	Stop Guide, Red
9	325132	Water and Product Line Ass'y, No. 1 Side (includes 10-16)
	325133	Water and Product Line Ass'y, No. 2 Side (includes 10-16)
10	**940068	Rubatex Insulation, 5/8-in. I.D. by 26-in. long
11	325137	Tube Ass'y, Water, No. 1 Side
	325135	Tube Ass'y, Water, No. 2 Side
12	325136	Tube Ass'y, Product, No. 1 Side (includes 13-16)
	325134	Tube Ass'y, Product, No. 2 Side (includes 13-16)
13	311908	Tube Clamp (crimp; for 7/16 O.D. tube)
14	325012	Product Sample Valve
15	**174103	Tube, No. 1 Side, 1/4-in. I.D. by 33-in. long
	**174103	Tube, No. 2 Side, 1/4-in. I.D. by 42-in. long
16	311791	Tee, Barbed, 1/4-in.
17	187627-888	Relief Valve (75-psi)
18	*320770	Machine Screw, Phil Pan Hd, Sems, No. 8-32 by 3/8-in.
19	325128	Solenoid Valve and Water Flow Regulator Ass'y (includes 20-27)
20	344142	Tube Ass'y, Water, 10-in. long
22	176107-001	Adapter, 1/4 NPTF male by 7/16-20 male
23	312002	Flow Regulator Ass'y, Water (see Figure 6-16)
24	325019	Connector, 1/4 by 1/4 female flare
25	311764-001	Check Valve Ass'y, Stainless Steel (see Figure 6-17)
26	187485-001	Elbow, 1/4 NPTF male by 7/16-20 male
27	320667	Solenoid Valve, Water
28	331304	Snap Bushing
29	310461	Thread Rolling Screw, Phil Pan Hd, No. 10-24 by 3/8-in.
30	315930	Relay, Sold-Out
31	*320271	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 3/8-in.
32	325129	Relay Box, Syrup Sold-Out
33	312519	Tube Ass'y, Syrup, 17-in. long
34	178025-100	Tapered Gasket, White
35	176107-001	Adapter, 1/4 NPTF male by 7/16-20 male
36	*343487	Machine Screw, Phil Pan Hd, No. 8-32 by 1/2-in.

*Zinc-plated steel.

**Sold in bulk quantity only.

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
37	*343845	Flat Washer, No. 8
38	320734	Machine Screw, Phil Truss Hd, Sems, No. 6-32 by 1/4-in.
39	315927	Bracket, Solenoid
40	320663	Solenoid Valve, Syrup
41	150058	O-Ring
42	315929	Fitting, Solenoid Adapter
43	183008	O-Ring
44	*343487	Machine Screw, Phil Pan Hd, No. 8-32 by 1/2-in.
45	315925	O-Ring
46	325170	Float Switch Ass'y (includes 47-49)
47	325149	Retaining Clip
48	325148	Float
49	325147	Stem and Swt
50	315931	O-Ring
51	315916	Cover, Float Switch
52	315915	Body, Float Switch
53	*312251	Thread Rolling Screw, Phil Pan Hd, No. 10-24 by 3/8-in.
54	331303	Snap Bushing
55	186570	Strain Relief
56	*343487	Machine Screw, Phil Pan Hd, No. 8-32 by 1/2-in.
57	325131	Support, Switch Holder
58	325288	Float Switch Ass'y (includes 59-61)
59	325149	Retaining Clip
60	325148	Float
61	325147	Stem and Swt
62	315931	O-Ring
63	315925	O-Ring
64	325001	Holder, Float Switch
65	324099-888	Carbonator Tank, No. 1 Side
	324098-888	Carbonator Tank, No. 2 Side
66	*320767	Machine Screw, Phil Pan Hd, Sems, No. 10-24 by 3/8-in.
67	*312251	Thread Rolling Screw, Phil Pan Hd, No. 10-24 by 3/8-in.
68	322678	Relay
69	325127	Support, Carbonator Tank
70	325126	Platform

*Zinc-plated steel.




Figure 6-15. Check Valve Assembly, Plastic

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325077	Check Valve Ass'y, Plastic
1	183008	O-Ring
2	311662	Ball
3	311740	Retainer, Ball
4	*311197	Flat Washer
5	311739	Body
6	312196	Spring

*Zinc-plated steel.

CAUTION
ITEMS 6 AND 7 ARE
A MATCHED SET
DO NOT REPLACE SEPARATELY

FOR SYRUP FLOW REGULATOR
USE SLEEVE AND PISTON ASS'Y
P/N 315553-000
FOR
WATER FLOW REGULATOR
USE SLEEVE AND PISTON ASS'Y
P/N 313437-000




Figure 6-16. Flow Regulator Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	310198-133	Flow Regulator Ass'y, Syrup
	312002	Flow Regulator Ass'y, Water
1	310477	Lock Nut, 7/16
2	310488	Coupling Nut
3	310483	Fitting, Inlet
4	311509	Ring, Expansion
5	311236	Quad Ring
6	310755	Sleeve
7	310480	Piston (used on Syrup Flow Regulator)
	310754	Piston (used on Water Flow Regulator)
8	310482	Spring
9	313657	Quad Ring, .612 I. D. by .103 C. S.
10	180025	O-Ring
11	310632	Adjusting Screw
12	310484-833	Body, Syrup Regulator
	310484-839	Body, Water Regulator




Figure 6-17. Single Check Valve Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	311764-001	Single Check Valve Ass'y
1	317965	Retainer
2	312196	Spring
3	312419	Ball
4	312415	Washer, .300 L D.
5	312418	Quad Ring
6	317963	Body




Figure 6-18. Drip Tray Panel Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	322277	Drip Tray Panel Ass'y
1	310198-133	Flow Regulator Ass'y, Syrup (see Figure 6-16)
2	189267	Decal, Thermostat Indicator
3	187188	Machine Screw, Phil Rd Hd, Sems, No. 8-32 by 1/4-in.
4	320709	Thermostat, Precool, Control
5	320710	Thermostat, Precool, Safety
6	*320289	Thread Rolling Screw, Phil Pan Hd, No. 6-32 by 1/4-in.
7	320776	Strap, Tube
8	320754	Drain Tube (brass)
9	*320293	Thread Rolling Screw, Phil Pan Hd, No. 4-40 by 3/8-in.
10	320772	Strike, Door
11	322274-059	Panel, Drip Tray

*Zinc-plated steel.




Figure 6-19. Secondary CO₂ Regulators and Bracket Assembly

Figure 6-19. Secondary CO₂ Regulators and Bracket Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	325141	Secondary CO ₂ Regulators and Bracket Ass'y
1	*150904	Hex Nut, No. 10-24
2	*120227	Lock Washer, Spring, No. 10
3	*186207	Flat Washer, No. 10
4	*186770	Machine Screw, Phil Rd Hd, No. 10-24 by 5/8-in.
5	322620	Bracket, Pressure Regulator
6	183456	Pressure Regulators and Gages Ass'y (includes 7-15)
7	187485-001	Elbow, Male, 1/4 NPT by 7/16-20
8	183061-001	Connector, Male, 1/4 NPT by 7/16-20
9	187556	Elbow, Male, 1/4 NPTF by 7/16-20
10	183044	Hex Nut, No. 10-32
11	183040	Machine Screw, Phil Fil Hd, No. 10-32 by 7/8-in.
12	322388	Foot, Mounting
13	130101	Gage, Pressure, 60-pound
14	183047-001	Manifold Nipple, Hex, 1/4 NPT
15	183460	Pressure Regulator Ass'y (includes 16-31)
16	*120081	Machine Screw, Phil Fil Hd, No. 10-32 by 1/2-in.
17	183233	Cover Kit (includes Non-Removeable Adjusting Screw)
18	183021	Spring Retainer
19	130166	Adjusting Spring, Black, 60-psi
20	130174	Diaphragm Ass'y
21	183011	Baffle
22	130167	Guide, Grey
23	183010	Gasket, Baffle
24	183009	Seat Retainer
25	183008	O-Ring
26	183007	Filter Screen
27	183006	Spring, Poppet
28	130170	Valve Poppet
29	130168	Reducing Valve Seat
30	183003	Gasket, Seat
31	183001-006	Regulator Body
	183099	Secondary Regulator Repair Kit (includes 20, 22, 23, 25, and 28)

*Zinc-plated steel.

*Zinc-plated steel.




Figure 6-20. Water Pump and Motor Assembly

<u>Index No.</u>	<u>Part No.</u>	<u>Name</u>
	322624-088	Water Pump and Motor Ass'y
1	311437	Adapter, 3/8 NPT male by 7/16-20 male
2	311738	Male Elbow, 1/4 NPT by 5/8-18
3	311035	Strainer, Water
4	310961	Male Tee, 1/4 NPT run by 7/16-20 leg
5	311284	Bushing, 3/8 NPT male by 1/4 NPT female
6	187483	Coupling
7	311400	Pump, Water (100 gph)
8	320626	Motor, Pump Drive, 1/4 HP (230 VAC, 60 Hz)
10	311764	Single Check Valve (see Figure 6-17)
11	176231-100	Tee, 7/16-20 male by 7/16-20 female swivel run, by 7/16-20 male leg

COMMERCIAL WARRANTY

THE CORNELIUS COMPANY ("CORNELIUS") does warrant to the original purchaser from CORNELIUS who buys solely for commercial or industrial uses, or for resale in the ordinary course of business, that each of the Products covered by this Commercial Warranty shall be free from defects in material and/or workmanship, under normal and proper use and service conditions.

Any products covered by this **Commercial Warranty** (including components thereof) demonstrated to have been defective when shipped by CORNELIUS will be either repaired, replaced (with new or rebuilt replacement) or the purchase price therefor refunded, as CORNELIUS may determine solely in its discretion. A product or component thereof covered by this Commercial Warranty supplied as a Warranty Replacement will assume the balance of the Period of Warranty applicable to the original measured from the date of replacement. This Commercial Warranty does **not** include, and CORNELIUS will not assume or pay, the expense of any repair, replacement, analysis or any other services or parts furnished by any party other than CORNELIUS unless specifically authorized in writing by CORNELIUS. This Commercial Warranty does **not** include labor for diagnosis, removal or installation of any products or components.

Products covered by this Commercial Warranty include all beverage and food dispensing or vending equipment manufactured or sold by CORNELIUS after the date hereof (not excluded hereinafter) and this Commercial Warranty is further limited to the use of that equipment in connection with soft drinks, soft drink syrups, beer, coffee, hot chocolate, tea or food commodities for which use the particular product has been identified by CORNELIUS.

Specific exclusions to this Commercial Warranty are OEM Sales, water filter cartridges, coin mechanisms, light bulbs, fuses, glass, diaphragms, seals, o-rings, silicone or rubber parts, refrigeration access valves or related refrigeration leaks, parts in contact with water or the product dispensed and which become inoperative due to scale or chemical change, normal maintenance items. This Commercial Warranty shall not apply to damage resulting from improper voltage, inadequate wiring, abuse, accident, alteration, misuse, neglect, unauthorized repair, improper cleaning or failure to follow installation, operating or maintenance instructions. Remote water-cooled refrigeration systems must have properly sized and installed remote cooling towers or systems. Failure of refrigeration components (compressor-valves) due to remote condenser system failure, incorrect sizing, operation, or installation are not covered by this Commercial Warranty.

The **Period of Warranty** is (i) one (1) year from the date of installation, or, (ii) fifteen (15) months from the date of shipment by CORNELIUS of a product covered hereby, whichever time period elapses first. For products incorporating a refrigeration system the Period of Warranty, with respect to the refrigeration system only (defined as the compressor, evaporator, condenser, and interconnecting tubing [not to include any access valves]), is five (5) years from the date of installation or sixty-three (63) months from the date of shipment by CORNELIUS, whichever time period elapses first.

Any **claim** under this Commercial Warranty must be made as promptly as is reasonably possible, but in no event later than thirty (30) consecutive calendar days, after the discovery of the defect. Such claims are to be directed to the CORNELIUS SERVICE DEPARTMENT at One Cornelius Place, Anoka, MN 55303-1592 (612) 421-6120.

Under no circumstances should the entire unit be returned to CORNELIUS except for repair or replacement of the sealed refrigeration unit. Whenever a product is returned to CORNELIUS for repair or replacement of the sealed refrigeration system under the terms of the Commercial Warranty and the defect is found to exist in parts other than the sealed refrigeration system (example: ice bank control, agitator motor, condenser fan motor, start capacitor or relay), an evaluation fee of twenty-five dollars (\$25.00) may be charged. If such defective part needs replacement or repair and is within its Period of Warranty, such part will be replaced or repaired at no charge, except for labor for removal and installation of such part; if not within its Period of Warranty, a charge for such part and the labor will be made.

The product covered by this Commercial Warranty, or components thereof, must not be returned to CORNELIUS without authorization from the CORNELIUS SERVICE DEPARTMENT. Instructions for return will be given with any such authorization. All returned products and/or parts must be shipped prepaid to CORNELIUS. Return shipping costs of repaired or replacement products or parts will be prepaid by CORNELIUS, except that as to original purchasers in Alaska or Hawaii, CORNELIUS will pay shipping costs only to Seattle or San Francisco respectively. CORNELIUS will not accept collect shipments. Replaced products or parts become the property of CORNELIUS. Any product or parts returned to CORNELIUS under the terms of this Commercial Warranty must be accompanied by a Returned Goods Tag, properly filled out as to unit model number and serial number and detailed explanation of failure.

Except for descriptions of size, quantity and type, which may appear on CORNELIUS' invoices and other written materials, and except for any statements of conformity of CORNELIUS' products with specifications of certain industry, government or professional organizations standards, which may appear as product information disclosures in CORNELIUS' literature and other documents from time to time, THIS COMMERCIAL WARRANTY IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

CORNELIUS' LIABILITIES ARE LIMITED SOLELY AND EXCLUSIVELY TO THE REPLACEMENT OR REPAIR OF THE DEFECTIVE PRODUCT OR REFUND OF THE PURCHASE PRICE OF SAID PRODUCT. CORNELIUS IS NOT LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND WHATSOEVER, WHETHER ANY CLAIM FOR RECOVERY IS BASED ON THEORIES OF CONTRACT, NEGLIGENCE OR TORT. Without limitation, these liabilities do not include shipping charges, labor, installation or any other losses or expenses incurred in operation or installation of any replaced, repaired or returned product or component. In those jurisdictions where liability for damages cannot be disclaimed, the original purchaser's recovery shall not exceed the cost of the product to which this Commercial Warranty may apply.

CORNELIUS neither assumes, nor authorizes any salesperson, distributor, employee, agent or other person to assume for it, any liability of obligation of any kind which is different from the terms of this Commercial Warranty.

CORNELIUS MAKES NO WRITTEN WARRANTY OF ANY KIND WHATSOEVER TO ANY PURCHASER WHO BUYS FOR PERSONAL, FAMILY OR HOUSEHOLD USE.

For CORNELIUS Warranties on products other than covered hereunder, see the Warranties covering each product category.

CORNELIUS may in its discretion direct an Authorized Service Center reasonably proximate to the Original Purchaser to perform its obligations under this Commercial Warranty. That Service Center may also perform such other services as the purchase may require at purchaser's expense.



31-7490-000

THE CORNELIUS COMPANY

ONE CORNELIUS PLACE
ANOKA, MINNESOTA 55303-1592

7-88

10
M
1951

