




TRINITY BICIPES / TRICEPS PIN LOADED

SK-TRIN-023

USER MANUAL



**TO OBTAIN THE WARRANTY OF THIS
PRODUCT, WE RECOMMEND THAT
A QUALIFIED TECHNICIAN
CARRIES OUT THE FULL ASSEMBLY.**



CAUTION

**BEFORE USING THIS EQUIPMENT,
READ ALL PRECAUTIONS AND
INSTRUCTIONS IN THIS MANUAL.
KEEP THIS MANUAL FOR FUTURE
REFERENCE.**

IMPORTANT WARNINGS & SAFETY INSTRUCTIONS

PROPER INSTALLATION

The Gym facility shall ensure that all exercise equipment and machines are properly installed, anchored, and secured to the floor or wall in accordance with the manufacturer's instructions and applicable safety standards to prevent tipping, movement, or other hazards.

LIMITATION OF LIABILITY

Evolution Group LLC and its affiliates shall not be liable for any damages, injuries, or losses arising from the improper installation, maintenance, or use of the equipment. The Gym facility agrees to hold harmless and indemnify Evolution Group LLC and its affiliates against any claims, demands, or liabilities resulting from such incidents.

COMPLIANCE WITH INSTRUCTIONS

The Gym facility confirms that it has received and understood the manufacturer's instructions and safety guidelines for the equipment. The Gym facility is responsible for ensuring that its staff and members are aware of and comply with these instructions.

NO WARRANTY FOR MISUSE

Evolution Group LLC and its affiliates do not warrant the equipment's performance or safety in cases of misuse, improper installation, or failure to maintain the equipment as recommended.

PURCHASER INSTRUCTIONS

It is the sole responsibility of the purchaser of products to read, understand, and comply with the this equipment. Use this product only for its intended purpose as described in the owner's manual. Failure to do so may result in injury or damage . It is recommended that all users be informed of the following information prior to use.

RISK OF INJURY AND ASSUMPTION OF RISK; NO CHILDREN

- Before starting any exercise or conditioning program, you should consult your physician. This is especially important if you are new to exercise or training equipment, inactive, pregnant, or suffer from any illness or mental condition. Using training equipment can result in injury or death, and the purchaser is assuming that risk. This makes understanding the owner's manual and instructing others particularly important.
- If at any time during exercise you feel faint, dizzy, or experience pain, stop exercising immediately and consult your physician.
- Keep children away from the equipment, and particularly moving parts. If using the product near children or pets, ensure constant supervision to prevent accidents and ensure that there is no ability for the child or pet to get near the moving parts. If authorized by a legal guardian or parent, a child should be under direct and immediate supervision at all times. Under no circumstances should a child younger than 15 years old use the equipment.

SECURE ENVIRONMENT

Skelcore equipment must:

- Be secured to or set up on a solid, level surface to stabilize and eliminate rocking or tipping over during training.
- Be set up with sufficient ventilation to ensure proper operation.

IMPORTANT WARNINGS & SAFETY INSTRUCTIONS

- Be set up with sufficient space around the equipment so that all exercises can be completed safely. It is recommended that there should be at least 1 meter of space around the equipment where access is required to exercise.

INSTALLATION

Risk of Injury:

- Installation of this product involves certain risks, including the risk of injury. Follow the installation instructions carefully, and if you are unsure, seek professional assistance.
 - For optimal safety, professional installation is recommended. If you choose to install the product yourself, ensure that you have the necessary skills and tools.
 - Before installation, verify that the installation location can support the weight and forces exerted by the product. Consult a professional if needed.
- If you encounter difficulties during installation or have any questions, contact the distributor/sales person from which you purchased the equipment from for assistance.

Failure to follow these installation guidelines may result in injury or damage or void your warranty. By installing and using this product, you acknowledge and accept all associated risks. If you have questions, please contact our customer support.

USER WEIGHT LIMITATIONS

This product has a maximum weight limit. Do not exceed the specified weight capacity. Doing so may compromise the stability of the equipment and result in injury. This machine has a max. user weight of **136 KG / 300 LB**

INSPECTION AND CLEANING

- Before any use, examine all accessories approved for use with the Skelcore equipment for damage or wear.
- Do not use or permit the use of any equipment that is damaged or has worn or broken parts. For all Skelcore equipment, use only replacement parts supplied by Skelcore.
- Always make sure that all nuts and bolts are tightened prior to each use.
- Maintain labels and nameplates – do not remove labels for any reason. They contain important information.
- Equipment maintenance – preventative maintenance is the key to smooth operating equipment. Please ensure that you follow our maintenance tips to ensure the continued correct function of your Skelcore equipment.
- If there are damages to small parts, please stop using the equipment at once and contact the purchasing company or agency for replacements. Install the new small parts properly and make sure the connected joints and working parts are fastened, avoiding danger during use.
- Should your Skelcore equipment appear damaged or worn, do not attempt to use or repair the equipment yourself.
- Do not use caustic cleansers to clean and/or wipe it.

OPERATING PROCEDURES AND WARNINGS

- It is the purchaser's responsibility to instruct all users as to the proper operating procedures of all

IMPORTANT WARNINGS & SAFETY INSTRUCTIONS

Skelcore equipment.

- Do not wear loose-fitting clothing or jewelry when using the equipment. It is also recommended that users tie up long hair to avoid contact with moving parts.
- Ensure that anyone not using the equipment stays clear of the user, accessories, and moving parts while the machine is in operation.
- To avoid muscular pain and strain, begin each workout by stretching and warming up, and end each session by cooling down and stretching.
- If the user experiences any injury during use, they should immediately stop using the product and seek medical attention.

PROPER INSTALLATION


The Gym facility shall ensure that all exercise equipment and machines are properly installed, anchored, and secured to the floor or wall in accordance with the manufacturer's instructions and applicable safety standards to prevent tipping, movement, or other hazards.

LIMITATION OF LIABILITY

Evolution Group LLC and its affiliates shall not be liable for any damages, injuries, or losses arising from the improper installation, maintenance, or use of the equipment. The Gym facility agrees to hold harmless and indemnify Evolution Group LLC and its affiliates against any claims, demands, or liabilities resulting from such incidents.

SAVE THIS INSTRUCTION MANUAL FOR FUTURE USE AND REFERENCE.



ASSEMBLY LIST



SPECIFICATIONS

Unit Dimensions: 1360mm(L)×1020mm(W)×1540mm(H)

User Weight≤150kg




NO.	NAME	SPECIFICATION	QUANTITY
1	Screwdriver	Philips	1
2	Open-ended Spanner	17-19	2
3	Socket Wrench	19	1
4	Allen Wrench	8mm	1
5	Allen Wrench	6mm	1
6	Allen Wrench	5mm	1
7	Allen Wrench	4mm	1
8	Allen Wrench	3mm	1

ASSEMBLY STEPS

- 1.As the unit has a large size, please assemble it in a space which is big enough.
- 2.Open the packing box, take out the parts and remove packing materials. Classify all parts and tidily put them on vacant floor.
- 3.Ensure that it's correctly assembled and the parts are complete according to assembly steps.
- 4.It requires at least two persons.

I.Assemble Weight Cage


1. Take out the counterweight box frame and place it in the designated area without bumping or scratching.
- 2.Assemble weight plates. Insert two guide rods into the corresponding mounting holes on the lower part of weight cage; pass them through shock pads; pass them through weight plates successively.
- 3.Assemble head plate. Now the weight plates are assembled.
- 4.Assemble circlips on the upper parts of two guide rods; fix guide rods.
- 5.Pass steel cable through cord lock; fasten steel cable with screws.
 - ① The 3 screws at the cable locker need to be tightened to the max.
 - ② Limit tube threads must be screwed in more than 10 teeth.
 - ③ The limit screws must be tightened.
 - ④ Re-check the screw threads to see whether they are tight or ot.
- 6.Assemble steel cable as the diagram shows; check whether all the pulleys move smoothly.
7. Before and after installation, the protective plates are fixed to the counterweight box frame with special screws.
8. Install the decorative cover and tighten the screws.
- 9.Now the weight cage is assembled.



II.Assemble User Frame


1. Put the assembled Weight Cage in the area where the machine will be used. Check whether all the other parts are there according to the diagrams below; remove packing materials and place the parts tidily. Assemble Main Frame; as the diagram shows, attach Upper and Lower Connecting &Supporting Assemblies (AE1; AE2) and Boom support group (AD1) to Weight Cage, fasten Main Frame Weldment Assembly (AC1) to Connecting &Supporting Assemblies.(Diagram 1)
2. Fasten Transmission welding group (AD2), Rope disc fixing group (AD3),Adjusting the disc welding group (AD4), Boom welding group (AD5), and Bearing fixing plate (D11) to Main Frame Weldment Assembly. Ensuring that it moves smoothly without any twist or slack. During assembling the bearing, please tighten the screws only when you adjust the armrest well. (Diagram 2)
3. Assemble Arm pad support welding group (M506-AC2) and Handle welding group (AF1) to Main Frame Weldment Assembly. (Diagram 3)
4. Assemble Long seat cushion (YSL02A-J01) and D3 elbow pad (D06-J01) to Main Frame Weldment Assembly. (Diagram 4)
5. Assemble steel cable as the diagram shows; make sure that it moves along the trajectory as the arrow shows. (Diagram 5)
6. Recheck all links and tighten all screws in case of slack.
7. Finally, a trial must be taken by professional to assure that it's correctly assembled.

(1)




REF#	DESCRIPTION	SPEC.	QTY.
AB1	Counterweight box group		1
AC1	Main frame welding group		1
AD1	Boom support group		1
AE1	Upper connection support group		1
AE2	Lower connecting support group		1
GB173	Socket head cap screw	M12*30	14
GB91	Flat washer	M12	14
GB211	Spring washer	M12	14

(2)




REF#	DESCRIPTION	SPEC.	QTY.
AD2	Transmission welding group		1
AD3	Rope disc fixing group		1
AD4	Adjusting the disc welding group		1
AD5	Boom welding group		1
D11	Bearing fixing plate		1
D06	Spacer sleeve	φ30	1
D22	Spacer ring		1
M422	Flat aluminum end cover	φ60	1
GB118	Deep groove ball bearing	GB6005	2
GB119	Deep groove ball bearing	GB6006	2
GB1024	Bearing with seat	FL205	1
GB1074	Outer spherical ball bearing with vertical seat	UCP206	1
GB979	25 axis circlip		1
GB50	Hexagon socket flat round head screw	M8*25	1
GB34	Hexagon socket head cap screw	M12*40	2
GB35	Hexagon socket head cap screw	M12*45	2
GB173	Hexagon socket head cap screw	M12*30	2
GB91	Flat washer	M12	6
GB211	Spring washer	M12	2

(3)





REF#	DESCRIPTION	SPEC.	QTY.
M506-AC2	Arm pad support welding group		1
AF1	Handle welding group		1
D14	Handle shaft	φ25*331	1
D35	Shaft fixing cover	φ49*5.0	1
GB122	Deep groove ball bearing	GB61805	2
GB35	Hexagon socket head cap screw	M12*40	2
GB50	Hexagon socket flat round head screw	M8*25	1
GB91	Flat washer	M12	2
GB211	Spring washer	M12	2
GB979	Shaft circlip	φ25	1

(4)



REF#	DESCRIPTION	SPEC.	QTY.
YSL02A-J01	Long seat cushion		1
D06-J01	D3 elbow pad		1
GB50	Hexagon socket flat round head screw	M8*25	10
GB89	Flat washer	M8	10
GB92	Spring washer	M8	10

(5)



WARRANTY

For a period of either 120 days or 24 months after the purchase date (the “Warranty Period”), a warranty will apply on moving parts, pulley's, cables, buttons, upholstery, hydraulic seats and cables for a period of 120 days, with the balance of the machine being a 24 month warranty. Skelcore warrants that the equipment for materials and workmanship such that, when installed and used in accordance with the owner's manual, will operate for its intended purpose. The warranty applies to equipment installed in air conditioned and temperature controlled environments and will be null and void if used outdoors or in an environment with no air conditioning. Skelcore will, at its expense and as its sole obligation and your exclusive remedy for any breach of this warranty, repair or replace the equipment or any parts, in its discretion, provided that such malfunction or defect is reported to Skelcore by you in writing during the Warranty Period and that you provide all information that may be necessary or requested to assist Skelcore in resolving the malfunction. If Skelcore determines that it is unable to repair the malfunction or replace the equipment, Skelcore or its authorized reseller may refund you the fees you actually paid for the defective equipment, in which case you agree to immediately cease using and to destroy, throw out, or otherwise take steps to ensure no one can use the equipment ever again.

If there are any problems or malfunctions with the Skelcore equipment you purchased, please contact your sales manager promptly. They will help you identify the cause of the problem and assist you in resolving it. If the issue involves parts that cannot be quickly addressed, the company's professional after-sales service personnel will provide specialized support.

COST OF REPAIRS

UNDER WARRANTY

Any items still under warranty will be repaired free of charge, if the repair complies with the terms and conditions of the warranty (refer to the “warranties” section in this manual). Any items that need to be repaired that are not covered under the warranty will be at your expense. A quote for the repair or replacement of these items will be provided to you for approval prior to any repairs being conducted.

OUT OF WARRANTY

Any items that need to be repaired once the warranty has expired will be at your expense, including call-out fees. A quote for the repair or replacement of these items will be provided to you for approval prior to any repairs being conducted.

Save this instruction manual for future use and reference.

SAVE THIS INSTRUCTIONAL MANUAL FOR FUTURE USE AND REFERENCE.

WARRANTY

To maintain your warranty, please complete the form below upon receiving your machine and email it back to the representative who sold you the goods.

Failure to do so will result in the loss of warranty.

SKELCORE ATTACH RECEIPT

CLIENT DETAILS

- NAME:
- EMAIL:
- CELL:
- TEL(H):
- TEL(W):
- FAX:
- ADDRESS:

PRODUCT DETAILS

- DATE OF PURCHASE:
- SERIAL NUMBER:
- TILL SLIP NUMBER:
- DESCRIPTION OF PURCHASE:

Signature: _____

Date: _____