STRONG

4K Google TV Smart Box

LEAP-S4

Google TV | Android™ 14 | 4K Dolby Vision® | Wi-Fi 6 | 64 GB



User Manual

www.strong-eu.com

SERVICE CENTER

Country	Email	Phone
AT	support_at@strong-eu.com	0820 400 150
BG	support_bg@strong-eu.com	+359 32 634451
CZ	support_cz@strong-eu.com	844 44 44 90
DE	support_de@strong-eu.com	0800 7788 787 (frei)
DK	support-dk@strong-eu.com	—
ES	support_es@strong-eu.com	+34 91 119 61 76
FR	support_fr@strong-eu.com	—
HU	support_hu@strong-eu.com	+36 1 445 26 10
IT	support_it@strong-eu.com	—
NL	support_nl@strong-eu.com	—
PT	support_pt@strong-eu.com	+351 2 100 06 125
SK	support_sk@strong-eu.com	0850 15 05 50

Supplied by STRONG Austria — Represented by STRONG Ges.m.b.H.

Teinfaltstraße 8/4.Stock, A-1010 Vienna, Austria | Email: support_at@strong-eu.com | www.strong-eu.com

Licenses

This product contains one or more programs protected under international and U.S. copyright laws as unpublished works. They are confidential and proprietary to Dolby Laboratories. Their reproduction or disclosure, in whole or in part, or the production of derivative works therefrom without the express permission of Dolby Laboratories is prohibited. Copyright 2003-2009 by Dolby Laboratories. All rights reserved.

EU Declaration of Conformity

Hereby, STRONG declares that the device LEAP-S4 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at https://eu.strong-eu.com/downloads/

Subject to alterations. Wi-Fi, WPA2, WPA3 are registered trademarks of Wi-Fi Alliance®. The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. Google TV is a trademark of Google LLC. Dolby Vision is a trademark of Dolby Laboratories. All other product names are trademarks or registered trademarks of their respective owners. © STRONG 2026. All rights reserved.

TABLE OF CONTENTS

1.0 INTRODUCTION	Safety Instructions, Storage, Package Content
2.0 THE LEAP-S4 BOX AND REMOTE	Box ports, remote control, batteries, power adapter
3.0 CONNECTION GUIDE	Connecting to TV
4.0 SETTING UP YOUR DEVICE	13-step first-time setup wizard
5.0 SETTINGS	Wi-Fi, Language, Bluetooth, Factory Reset, About
6.0 DOWNLOADING APPS	Google Play Store
7.0 DEVICE PREFERENCES	Date & Time, Display & Sound, AI PQ, CEC, Audio
8.0 FIND MY REMOTE	Locating the remote with the box button
9.0 GOOGLE CAST	Screen mirroring, screensaver, energy saver
10.0 REMOTE & ACCESSORIES	Bluetooth pairing and CEC setup
11.0 ABOUT	System info and firmware update
12.0 GOOGLE ASSISTANT	Voice commands and usage examples
13.0 SIMPLE TROUBLESHOOTING	Common issues and solutions
14.0 TECHNICAL SPECIFICATIONS	Full hardware and software specs
15.0 ACCESSIBILITY	TalkBack, EN 301 549 compliance
16.0 PRIVACY AND SECURITY	Network ports and data protection

1.0 INTRODUCTION

Thank you for choosing the STRONG LEAP-S4 4K Google TV Smart Box. It has been produced with the latest technology and offers extensive entertainment and great versatility. We wish you many hours of great experiences exploring the Google TV world!

1.1 Safety Instructions

Read all the instructions before operating the device. Keep these instructions for later use. Only use attachments and accessories specified or provided by the manufacturer.

- Do not expose this apparatus to rain, moisture, dripping or splashing.
- Do not place objects filled with liquids (such as vases) on the apparatus.
- The ventilation should not be impeded by covering the ventilation openings.
- Do not install in a confined space such as a bookcase. Keep away from direct sunlight and dusty places.
- Never try to open the device. Opening the device voids the warranty.
- When connecting cables, ensure the device is disconnected from the mains supply. Wait a few seconds after switching off before moving the device or disconnecting equipment.
- Do not use near damp or cold areas. Protect from overheating.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.

⚠ **WARNING —** BATTERY SAFETY — The batteries should not be recharged, disassembled, electrically short-circuited, or mixed with other types. Danger of explosion if incorrectly replaced. Replace only with the same or equivalent type. Do not expose batteries to excessive heat (sunlight, fire). Disposing of batteries in fire or a hot oven can result in an explosion.

This mark indicates a risk of electric shock. To prevent injury, this apparatus must be securely attached in accordance with the installation instructions.

1.2 Storage

Your device has been carefully checked and packed before shipping. When unpacking it, make sure that all parts are included. Keep the packaging away from children. We recommend keeping the carton during the warranty period to protect your device in the event of repair or warranty service.

Symbols used in this manual:

WARNING:	Indicates safety-critical warning information.
NOTE:	Indicates additional important or helpful information.

MENU	Represents a button on the remote control or the product.
Move to	Represents a menu item within a screen.

1.3 Package Content

- 1 × LEAP-S4 Smart Box
- 1 × Voice-enabled remote control with numeric keypad (2 × AAA batteries included)
- 1 × USB-C cable with power adapter (5 V / 2 A)
- 1 × HDMI 2.1 cable
- 1 × Installation instructions
- 1 × Safety & warranty document

> **NOTE —** Only use the original USB-C power adapter (5 V / 2 A). Some adapters supply only 0.5 A, which is insufficient to power the LEAP-S4 reliably.

WEEE Directive

Correct Disposal: This product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please recycle it responsibly. To return your used device, use the return and collection systems in your country or contact the retailer.

2.0 THE LEAP-S4 BOX AND REMOTE

2.1 Box — ports and physical overview



Fig. 1 — LEAP-S4 rear/side view

Component	Description
Button / STRONG logo ring (top)	Multi-function button on the top of the box: • Press 1 second: Find My Remote — the remote vibrates to help you locate it. • Hold 5 seconds: enter Bluetooth search / pairing mode. • Hold 30 seconds: factory reset (erases all settings).
USB-C POWER port	USB-C input for the power adapter (5 V / 2 A). Labelled “POWER USB-C”.
HDMI port	HDMI 2.1b output (CEC & HDCP 2.3). Connect to your TV with the supplied cable.

2.2 Remote control



Fig. 2 — LEAP-S4 voice-enabled remote with numeric keypad

The remote has three functional zones:

Zone 1 — Function Zone (Keys 1–5, top section)

Key	Function
Key 1 (□) — top left	Power On/Off. Press to turn the box to On or Standby.
Key 2 (★) — top right	Customisable shortcut. Short press: open the assigned app. Long press: select which app to assign.
Key 3 (👤) — row 2 left	Account. Opens the account menu to switch between Google profiles.
Key 4 (🎙) — row 2 centre	Voice Control. Press to activate Google Assistant.
Key 5 (⚙) — row 2 right	Settings. Opens the device settings.

Zone 2 — Numeric and Control Zone (Keys 6–15)

Key	Function
Keys 0–9 (numeric pad)	Direct number input for PINs, channel numbers, etc.
Subtitle (⊞)	Toggle subtitles on or off.
Info (ⓘ)	Display content or programme information.
Red / Green / Yellow / Blue	Colour buttons — function varies by app or service.
Navigation ring ↑↓←→ + OK	Navigate menus and confirm selections.
Back (←)	Return to the previous screen.
Home (⌂)	Return to the Google TV home screen.
TV Guide (📺 icon)	Open the channel guide or TV Guide in supported apps.
Live TV	Open the Live TV application (customisable in settings).
VOL+ / VOL−	Adjust TV or soundbar volume via IR/CEC.
Mute (🔇)	Mute or unmute the audio via IR/CEC.
CH+ / CH−	Change channel up or down in Live TV applications.

Zone 3 — Application Shortcuts (Keys 16–19, bottom section)

Key	Function

YouTube	Press for direct access to YouTube.
NETFLIX	Press for direct access to Netflix. (Subscription required.)
prime video	Press for direct access to Amazon Prime Video. (Subscription required.)
Disney+	Press for direct access to Disney+. (Subscription required.)

NOTE — Voice control and some functions (Google Assistant, screen mirroring) require the remote to be paired with the LEAP-S4 via Bluetooth. Pairing is automatic during setup.

2.3 Installing batteries in the remote

Open the battery cover on the back of the remote and insert 2 × AAA batteries into the compartment. Observe the +/− polarity markings printed inside the compartment.

- 1. Open the cover (slide or press the release tab).
- 2. Insert the batteries with correct polarity.
- 3. Close the cover until it clicks.

WARNING — The batteries should not be recharged, disassembled, or electrically short-circuited. Do not mix battery types.

2.4 Power adapter

The LEAP-S4 is supplied with a USB-C power adapter (5 V / 2 A). Input: 100–240 V AC, 50/60 Hz. Output: DC 5 V, 2 A (10 W maximum). Only use the supplied adapter or an equivalent model with identical electrical specifications.

3.0 CONNECTION GUIDE

> **NOTE —** Before getting started, turn off all devices to be connected.

Follow the diagram below to connect the LEAP-S4 to your TV:

- 1. Connect the HDMI cable (supplied) between the HDMI port of the LEAP-S4 and an available HDMI port on your TV.
- 2. Connect the USB-C cable to the POWER USB-C port of the LEAP-S4 and to the supplied power adapter.
- 3. Plug the power adapter into a wall outlet.
- 4. Turn on your TV and select the correct HDMI input source (HDMI 1, HDMI 2, etc.).
- 5. The LEAP-S4 powers on automatically. The STRONG logo ring will light up.

> **NOTE —** The LEAP-S4 supports Wi-Fi 2.4 GHz and 5 GHz. To connect to Wi-Fi after setup, go to Settings → Network & Internet.

> **NOTE —** Before turning on your device, switch the signal input of your TV to the correct HDMI source.

4.0 SETTING UP YOUR DEVICE

After connecting the LEAP-S4 and turning on the TV, the Google TV setup wizard starts automatically.

To pair the remote and use Google Assistant, the Bluetooth remote must first be paired to the LEAP-S4. Press any button on the remote, then press the BACK (←) and HOME (⌂) buttons simultaneously for 3 seconds until the LED on the remote blinks green. Pairing will start automatically.

> **NOTE —** If the remote loses pairing: remove the USB-C power adapter, wait 5 seconds, reinsert it, wait until the Google logo appears on screen, then press BACK + HOME simultaneously for 3 seconds until the LED blinks green.

Step 1 — Language

Select your preferred display language from the list.

Step 2 — Select a region/country

Select the country or region where you are using the device. This determines app availability, content recommendations, and regional settings.

Step 3 — Set up your Google account

Choose one of two options:

- Continue: transfer your Google account from your Android phone by following the instructions on your phone.
- Manual Setup: set up the account on screen using the remote.

Step 4 — Set up Wi-Fi network

The LEAP-S4 scans for available Wi-Fi networks. Select your network from the list.

Step 5 — Wi-Fi password

Enter the password for your Wi-Fi network using the on-screen keyboard. Select → to confirm and continue.

> ⚠ **WARNING —** Routers using Wi-Fi 6 with WPA3 security are not supported. If your router uses WPA3 only, switch it to WPA2 or WPA2/WPA3 mixed mode in your router settings before connecting.

Step 6 — Google Account

Sign in with your Google account. Enter your email address and press →, then enter your password and confirm.

Step 7 — Terms of Service & Privacy Policy

Read and accept Google's Terms of Service and Privacy Policy to continue.

Step 8 — Diagnostic Report Settings

Choose whether to allow the LEAP-S4 to send automatic diagnostic and usage data to Google. This setting can be changed later in Settings.

Step 9 — Meet your Google Assistant

Enable Google Assistant to activate voice control via the microphone button (🎙) on the remote.

Step 10 — Select a Home

If you have other Google smart home devices, select or create a home name to group them together in the Google Home app.

Step 11 — Choose your services

Select the streaming services you subscribe to. The selected app icons will be pinned to your Google TV home screen for quick access.

Step 12 — Choose an Energy mode

Select your preferred power-saving mode. This determines how quickly the LEAP-S4 enters standby when not in use.

> **NOTE —** More steps may be available depending on your Google TV version. Choose as required.

Step 13 — Welcome to Google TV



Fig. 3 — Google TV home screen — personalised recommendations and your apps

Your setup is complete. Select “Go to Google TV” to start. The home screen shows personalised content recommendations from all your connected streaming services.

5.0 SETTINGS

Press the Settings button (⚙) on the remote to open the Settings menu. Here you can check device information, add or remove accounts, and change all system settings.

Wi-Fi Settings

Go to Settings → Network & Internet. Enable Wi-Fi. The LEAP-S4 scans for nearby networks. Select your network, enter the password if prompted, and select Connect.

Language Settings

Go to Settings → System, then select Language to change the language set during initial setup.

Bluetooth Pairing

Go to Settings → Remotes & accessories → Add accessory. Press OK on the remote to begin scanning. Ensure the Bluetooth device is in pairing mode. Select it from the list and press OK.

Remove a Bluetooth Device

Go to Settings → Remotes & accessories. Select the Bluetooth device you want to remove and choose Forget (Unpair). Press OK to confirm.

> ⚠ **WARNING —** If you remove (Forget) the remote control itself, you will no longer be able to control the LEAP-S4 until you pair it again. See the pairing instructions in Section 4.0.

Adding and Switching Google Accounts

Go to Settings → Accounts & sign-in to add a new Google account or switch between existing accounts. You can also press the Account button (👤) on the remote to quickly switch accounts.

Factory Reset

Go to Settings → System → About → Reset, then select Factory data reset and confirm. The LEAP-S4 will erase all apps, accounts, and settings and restart with the initial setup wizard. Alternatively, hold the top button on the LEAP-S4 for 30 seconds (see Section 8.0).

> ⚠ **WARNING —** A factory reset permanently and irreversibly deletes all installed apps, Google accounts, settings, and downloaded content. This action cannot be undone.

About

Go to Settings → System → About. This screen shows the model (LEAP-S4), Android version, firmware version, and build information. Press System update to check for and install firmware updates.

6.0 DOWNLOADING APPS

Apps are available for download from the Google Play Store. Access it from the Apps tab on the Google TV home screen. You can:

- Browse categories or search by name using the on-screen keyboard.
- Press the microphone button (🎙) and say “Open Play Store” or “Install [app name]”.
- When the app appears on screen, select Install to begin the installation.

> 💡 **NOTE —** The LEAP-S4 has 64 GB of internal storage, providing generous space for apps, games, and downloaded content. To manage or uninstall apps, go to Settings → Apps, select the app, and choose Uninstall or Clear cache.

Certifications: The LEAP-S4 is certified by Netflix, Amazon Prime Video, DRM Google Widevine Level 1, and DRM Microsoft PlayReady 3.0, ensuring maximum streaming quality (HD/4K) from these services.

7.0 DEVICE PREFERENCES

This is the main settings area for adjusting the LEAP-S4's operating parameters. Access via Settings → System (for system settings) or Settings → Display & Sound (for video and audio).

Date & Time

Settings → System → Date & time. Select the time zone where you are using the device to match local time. You can also choose between 12-hour and 24-hour clock formats.

Language

Settings → System → Language. Change the display language.

Keyboard

Settings → System → Keyboard. Choose a different keyboard layout if preferred.

Display & Sound

Settings → Display & Sound. Key options:

Setting	Description
Display Format → Screen resolution	Set the output resolution (4K UHD / 1080p / 720p) and Auto Refresh Rate (ARR) mode.
Display setting → AIPQ	Toggle AI Picture Quality (AI PQ) on or off. AI PQ uses the NPU to optimise brightness, contrast and colour in real time.
Display setting → AISR	Toggle AI Super Resolution 2 (AI SR2) on or off. Upscales HD content towards 4K quality.
CEC input → CEC switch	Enable HDMI CEC to let the LEAP-S4 remote control the TV's volume and power.
Audio → Advanced sound settings	Set audio output format: Auto (passthrough to soundbar/receiver) or Off (PCM stereo only). Dolby TrueHD, Dolby Digital Plus and Dolby Digital passthrough require a compatible receiver.
Quick Media Switching (QMS)	Minimises the black screen during frame rate transitions between content.
Source-Based Tone Mapping (SBTM)	Adapts HDR tone mapping dynamically to each source signal for optimal Dolby Vision / HDR10+ rendering.

Google Assistant

Use the microphone button () on the remote for all Google Assistant functions. See Section 12.0 for full usage examples.

8.0 FIND MY REMOTE

The button on the top of the LEAP-S4 (STRONG logo ring) has three functions depending on how long it is held:

Press duration	Function	Result
Press 1 second	Find My Remote	The remote control vibrates, helping you locate it quickly.
Hold 5 seconds	Bluetooth search mode	The LEAP-S4 enters Bluetooth pairing mode to pair a new accessory.
Hold 30 seconds	Factory reset	All settings, accounts, and apps are permanently erased. The LEAP-S4 restarts with the initial setup wizard.

Find My Remote

When you cannot find the remote control:

- 1. Press the top button on the LEAP-S4 for 1 second.
- 2. The remote will vibrate. Follow the vibration to find it.
- 3. The vibration stops after a few seconds, or when you press any button on the remote.

> **NOTE —** Find My Remote requires the remote to have sufficient battery charge and to be within Bluetooth range of the LEAP-S4.

Bluetooth search mode

To pair a new Bluetooth accessory without using the Settings menu:

- 1. Hold the top button on the LEAP-S4 for 5 seconds until the LED ring indicates pairing mode.
- 2. Put your Bluetooth device in pairing mode.
- 3. The LEAP-S4 will detect and connect to the device.

Factory reset via button

As an alternative to the Settings menu, the LEAP-S4 can be factory reset using the top button:

- 1. With the LEAP-S4 powered on, hold the top button for 30 seconds.
- 2. Release when the LED ring indicates the reset is starting.
- 3. The LEAP-S4 erases all settings and restarts with the initial setup wizard.

⚠ **WARNING —** Factory reset via the button permanently erases ALL settings, Google accounts, installed apps and downloaded content. This action cannot be undone.

9.0 GOOGLE CAST

The LEAP-S4 has Google Cast built in, which allows you to cast content from an Android phone, tablet, or Google Chrome browser directly to your TV screen.

- 1. Open a Google Cast-compatible app on your mobile device or Chrome browser.
- 2. Navigate to the screen you wish to cast.
- 3. Tap the Cast icon (📡) within the app, or click the ⚙ icon in Chrome and select Cast.
- 4. Select LEAP-S4 from the list of available devices.
- 5. To stop casting, select the Cast icon again and choose Stop casting.

> **NOTE —** Your phone/tablet and the LEAP-S4 must be connected to the same Wi-Fi network for casting to work. The video is streamed directly from the internet to the LEAP-S4 — your phone acts as a controller only.

Cast Settings

Settings → Device Preferences → Cast. Select the notification setting you prefer: Always, While casting, or Never.

Screensaver

Settings → Display & Sound → Screen saver. Set the inactivity time before the screensaver starts.

Power & Energy Saver

Settings → System → Power & Energy. Set the inactivity time before the LEAP-S4 enters standby. Default: 3 hours. Options: 1, 3, 4, 6, 8 hours or Never.

10.0 REMOTE & ACCESSORIES

This menu lets you add new Bluetooth devices (speakers, keyboards, gamepads) and configure the remote control's TV control settings.

Bluetooth Pairing

Settings → Remotes & accessories → Add accessory. Press OK to start scanning. Put the Bluetooth device in pairing mode. Select it from the list and press OK. Enter a PIN code if required and follow the on-screen instructions.

Remove a Bluetooth Device

Settings → Remotes & accessories. Select the device and press OK. Choose Forget (Unpair) or Rename. The battery level of the selected remote is also displayed here.

Volume and Power Control via CEC

The LEAP-S4 remote can control the volume, power, and input source of your TV or connected soundbar via HDMI CEC. To set this up:

- Enable CEC on the LEAP-S4: Settings → Display & Sound → HDMI CEC control → enable CEC switch.
- Enable CEC on your TV (may be labelled Anynet+, Bravia Sync, SimpLink, EasyLink, or HDMI-CEC depending on brand).
- In Settings → Remotes & accessories, configure which device's volume and power the remote should control.

11.0 ABOUT

Settings → System → About. This screen shows:

Field	Content
Model	LEAP-S4
Android version	Android 14
Software version	The currently installed firmware build.
Build number	The hardware/firmware build identifier.

System Update

Press System update from the About menu to check for and install the latest firmware over Wi-Fi (OTA). The LEAP-S4 also checks for updates automatically on start-up when connected to Wi-Fi.

> ⚠ **WARNING —** Do not disconnect the power during a firmware update. The LEAP-S4 will restart automatically when the update is complete.

12.0 GOOGLE ASSISTANT

> **NOTE —** To use Google Assistant, the Bluetooth remote must be paired to the LEAP-S4. Pairing is automatic during setup.

Press the microphone button (🎙) on the remote and speak your command. Examples:

Category	Example voice commands
Movies & TV shows	“Play Squid Game on Netflix” • “Open YouTube” • “Search for comedies”
Video clips	“Play cat videos”
Playback control	“Pause” • “Stop” • “Resume” • “Rewind 30 seconds”
Volume control	“Louder” • “Softer” • “Mute”
Power	“Turn off”
Music, news, podcasts	“Play music by [artist]” • “Play the news”
Questions	“What is the weather in Paris?” • “How far is the moon?” • “What does ‘ludic’ mean?”

Learn more about Google Assistant at assistant.google.com, or say “What can you do?” to the assistant.

13.0 SIMPLE TROUBLESHOOTING

Issue	Possible reason	Solution
No LED or image after power on	Power adapter not properly connected	Check that the USB-C cable is firmly connected to both the POWER port on the LEAP-S4 and the power adapter. Ensure the adapter is plugged into a working wall outlet.
No sound	TV is muted or volume is low; device is muted	Press Mute ( ) on the remote to toggle mute. Press VOL+ to increase volume. Check Settings → Display & Sound → Advanced sound settings.
Failed to connect to network	Wi-Fi is disabled or signal is too weak	Go to Settings → Network & Internet and enable Wi-Fi. Move the TV or router closer together. Check the password is correct.
Remote not working / lost control	Remote lost Bluetooth pairing or batteries are flat	Replace batteries (2 × AAA). Re-pair: remove power adapter, wait 5 s, reinsert, wait for Google logo on screen, press BACK + HOME for 3 s until LED blinks green.
No picture on TV screen	Wrong TV HDMI input selected	Select the correct HDMI source on your TV (usually via the Input or Source button).
Voice search not working	Remote not paired via Bluetooth	See the Bluetooth pairing steps in Section 4.0 and Section 5.0.
No audio via Dolby passthrough	Audio format not set correctly for your soundbar/receiver	Settings → Display & Sound → Advanced sound settings → set to Auto. Also enable CEC on the soundbar/receiver.
4K content drops to 1080p	HDMI cable or TV port does not support HDMI 2.0/2.1	Use the supplied HDMI 2.1 cable and connect to an HDMI 2.0 or 2.1 port on your TV.
App crashes or device is slow	Cache needs clearing or storage is full	Settings → Apps → select app → Clear cache. Uninstall unused apps. Restart: remove power adapter for 10 seconds and reinsert.
Find My Remote not working	Remote battery too low or out of range	Replace the remote batteries (2 × AAA). Press the top button for only 1 second (not longer). Ensure you are within Bluetooth range.

14.0 TECHNICAL SPECIFICATIONS

System

Specification	Value
OS	Google TV certified (Android 14)
SoC	Amlogic S905X5M-J (S9 Gen 6, 6 nm)
CPU	ARM Cortex-A55, Quad-Core @ 0.1 / 2.5 GHz, 28,420 DMIPS
GPU	ARM Mali-G310 V2, 52.6 GFLOPS
NPU	AI-SR2 / AI-PQ, 4 TOPS
RAM	2 GB DDR4
Storage	64 GB eMMC

Video

Specification	Value
Max resolution / frame rate	4K UHD (3840 × 2160) at 75 fps
Aspect ratios	4:3 and 16:9
Video formats	HEVC H.265, MPEG-4, AV1, VC-1 / VP8 / VP9
HDMI output	HDMI 2.1b with CEC (HDCP 2.3). HDMI 2.1 cable included.
HDR formats	Dolby Vision®, HDR10+
AI video features	AI Super Resolution 2 (AI-SR2), AI Picture Quality (AI-PQ)
Auto Refresh Rate (ARR)	Yes
Quick Media Switching (QMS)	Yes
Source-Based Tone Mapping (SBTM)	Yes
UI rendering	4K UHD HDR (Dolby Vision & HDR10+)

Audio

Specification	Value
Dolby Audio technology	Yes
HDMI passthrough formats	Dolby TrueHD ≤ 7.1 / Dolby Digital Plus ≤ 7.1 / Dolby Digital ≤ 5.1
Internal decode	AAC & MPEG (stereo), Dolby Audio

Audio passthrough via HDMI	Yes — all formats
Multicanal decode	AAC & MPEG variants

Connectivity

Specification	Value
Wi-Fi	Wi-Fi 6 (IEEE 802.11ax) dual-band 2.4 GHz / 5 GHz
Wi-Fi speed (AX1800)	574 Mbps @ 2.4 GHz + 1,201 Mbps @ 5 GHz
Bluetooth	Bluetooth 5.2
Ports	HDMI 2.1b • USB-C POWER

Remote Control

Specification	Value
Type	2-in-1: Bluetooth (LEAP-S4 control) + Infrared (TV CEC control)
Special function	Find My Remote — press box button, remote vibrates
Customisable shortcut	★ button (long press to assign app)
Application shortcuts	YouTube • Netflix • Prime Video • Disney+
Keypad	Full numeric keypad (0–9), 4 colour buttons, subtitle, info
Batteries	2 × AAA (included)
Mobile remote	Yes (Google TV app)

Physical & Power

Specification	Value
Dimensions (L × W × H)	80 × 80 × 19.5 mm
Weight	94.5 g
Power supply input	100–240 V AC, 50/60 Hz
Power supply output	DC 5 V, 2 A (10 W max)
Power consumption	< 10 W
Operating temperature	0 °C – +45 °C
Storage temperature	−10 °C – +70 °C
Operating humidity	5 % – 90 % (non-condensing)
Storage humidity	0 % – 95 % (non-condensing)

EAN	9120137872309

15.0 ACCESSIBILITY COMPATIBILITY STATEMENT

This product adheres to universal design principles, aiming to provide accessible and stable user experiences for individuals with disabilities. This chapter details accessibility compatibility, technical basis, and usage guidelines.

Compliance with accessibility standards

- EU Standard: adheres to the core principles of EU Directive 2019/882 — perceptible, operable, understandable, and robust, in compliance with EN 301 549 accessibility technical requirements.
- Mobile devices (Android): complies with the system accessibility service interface specifications.
- Web version: complies with ARIA 1.2 accessibility standards.

Compatibility type	Product implementation
Compatibility with auxiliary devices	Reserved USB and Bluetooth ports for connecting screen readers (e.g. Braille readers); Bluetooth for external headphones; compatible with adaptive keyboards.
Accessibility tools	Screen reader: compatible with TalkBack (Android). Input devices: supports adaptive keyboards. Bluetooth earbuds: compatible with certified devices (AirPods, Galaxy Buds, Sony WH-1000XM5, etc.) with automatic audio sync.
Compatible operations	Shortcut key operations; high contrast mode support.

TalkBack Screen Reader

TalkBack reads interface elements (menus, buttons, messages) aloud in real time, enabling independent operation for visually impaired users.

- 1. Press HOME on the remote to access the main interface.
- 2. Use direction keys to select Settings and press OK.
- 3. Navigate to Accessibility and press OK.
- 4. Select TalkBack and press OK to enable.
- 5. In TalkBack Settings, adjust voice volume and speaking rate.

> **NOTE —** You can also press the DOWN direction key and BACK key simultaneously on the remote to enable TalkBack quickly.

16.0 PRIVACY AND SECURITY

Some network ports (TCP) on the LEAP-S4 are open by default and may transmit data. For your security and to comply with Network-Security RED certification, please be aware of the following:

Service	Port(s)	Description
Google TV Remote Service	TCP 6466/6467	Enables remote control of Google TV apps (e.g. Google TV Remote app) on smartphones, supporting navigation, play/pause and volume.
Google Cast Service	TCP 8008/8009/8443/9000	Associated with Google Cast functionality for media streaming from mobile devices.
Google Netlink test ports	TCP 36703/44333 (dynamic)	Test port for Google Netlink. Dynamic ports may vary.

It is recommended to limit access to these ports and check active services to reduce any risk of personal data exposure.

Data Protection

Please be aware that STRONG, its manufacturing partners, application providers and service providers may collect and use technical data and related information, including technical information about this device, system and application software. STRONG may use such information to improve its products or to provide services or technologies to you, in a form that does not personally identify you.

Additionally, some services included on the device or installed by you may request registration requiring personal data. STRONG cannot be held liable for a possible breach of data protection by third-party services not pre-installed.

Copyright STRONG © 2026. All Rights Reserved. | Subsidiary of Skyworth | www.strong-eu.com

Availability of apps depends on your country. STRONG cannot be held liable for third-party services. Third-party offers may be changed or removed at any time.