nubi

NK68 HE
User Manual

nubi.gg/drivers

FR Manuel d'utilisation **DE** Benutzerhandbuch **ESP** Manual de usuario **BG** Ръководство за потребителя **FI** Käyttöopas **NO** Brukerhåndbok **TR** Kullanım Kılavuzu **SE** Användarhandbok **DK** Brugervejledning **SK** Užívateľská príručka **PL** Instrukcja obsługi **CZ** Uživatelská příručka **LV** Lietotāja rokasgrāmata **UA** Посібник користувача **RS** Корисничко упутство **HR** Korisnički priručnik **RO** Manual de utilizare

In this manual, you will find everything you need to know about NK68 HE keyboard functions and settings. Please read this information carefully before using the keyboard.

You can set up your keyboard however you like using our web software at **web.nubi.gg**.

If you have questions or your problem is not covered here, please contact our technical support. We will do everything we can to help!

help@nubi.gg

web.nubi.gg

Here are a few points that will help keep your keyboard in top condition:

1. DO NOT connect the keyboard to an electrical outlet or other high-voltage power source. This may damage the device's board and render the keyboard inoperable. We recommend connecting/charging the keyboard only from the USB port of your computer/laptop.

2. DO NOT spill liquid on the keyboard. If any liquid gets on the keyboard, immediately turn it and contact your local service center.

3. We strongly recommend using the included cable to connect the keyboard.

4. Keep your keyboard clean and give it regular care. Your keyboard will thank you with years of reliable performance.

5. If you decide to customize or modify your keyboard, please do so carefully. Yes, we designed the keyboard to allow for it BUT please be aware that opening, altering, or customizing the keyboard will void your warranty. Mechanical damage includes but is not limited to disassembly, immersion, impact, wire breakage, excessive pressure, and similar actions.

6. The warranty period is 12 months from the date of purchase. If you have any questions or issues after the warranty has expired, contact our support team—we'll be happy to help you resolve any problem, even beyond the warranty period.

7. Handle your keyboard with love and care. We've spent countless hours and a lot of heart making the NK68 Series the best it can be—just like we would for ourselves <3

KEYBOARD MODE INDICATORS

LED stripes indicate main keyboard modes separated into three blocks (3+4+3 lights):

First Block — Caps Lock

Second Block — Snap Tap

Third Block — Win/Cmd Lock

Want to change the LED light bar indicator mode? Just press FN + K, and keep pressing it to cycle through the three modes.

▸ First Mode: Overlay

Indicators are displayed on the LED strip in overlay mode. White indicators appear on top of the lighting animations.

▸ Second Mode: Indicators Only

LED strip only displays white indicators, animations are completely disabled.

▸ Third Mode: Animations Only

In this mode, the indicators are shown right on the keys themselves—no indicator lights on the LED strip, just animations. The indicator functions are moved to the keys (**CAPS — Caps Lock**, **Win/Cmd — Win/Cmd Lock**, **X — Snap Tap**) and will only be visible while you're holding the Fn key.

— Caps Lock

— Win/Cmd Lock

— Snap Tap

KEYBOARD MODE INDICATOR KEYS

Windows / macOS — if you see the M key flashing 🟠 when pressing (and holding) the FN key, you are using the macOS mode.
If the M key is flashing 🔵, you are using the Windows mode.

Scroll Lock — if you see the Backspace key flashing ⚪ when pressing(and holding) the FN key, Scroll Lock is turned on.
If the Backspace key is not flashing, Scroll Lock is turned off.

TOGGLES ON BACKSIDE

The 3-way switch (to the left of the Type-C port) controls the lighting modes, while the 2-way switch (to the right of the Type-C port) controls the Snap Tap function.

Left Toggle

- AP* 1.2mm
- AP* 2mm
- AP* 0.5mm

Right Toggle

- Snap Tap Off
- Snap Tap On

*Actuation Point

DISPOSAL INFORMATION

The crossed-out wheelie bin symbol means that you must not dispose of this product together with unsorted household & waste. As electrical devices can contain harmful substances which may cause environmental damage or harm to your health if not disposed of correctly, please dispose of this product only through the facilities provided for used electrical equipment. Return used electrical equipment at an official recycling point. For information about local recycling points, contact your local authority, civic amenity site or the business where you purchased this product. By disposing of electrical products at an official recycling point, you are doing your part to ensure equipment is recycled correctly and professionally, and the environment is protected. Wherever possible, remove any batteries before disposing of the device. Under law, as the end user you face risk of penalties if you dispose of devices and batteries illegally.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment, Applicable in the European Union and other European countries with separate collection systems). This marking shown on the product of its documentation indicates that it shouldn't be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

FUNCTION LAYER AND KEYBOARD SETTINGS

For more detailed customization and access to the full range of features, we recommend using the function layer.
This layer is activated by pressing the FN key together with other keys, as shown below:

When using any of the following combinations, first press and hold FN
Exemplo: pressing FN + PGUP works as the Home key which is not available in the regular layout.

Windows Hotkeys



macOS Hotkeys



Windows	macOS
F1	F1
F2	F2
F3	F3
F4	F4
F5	F5
F6	F6
F7	F7
F8	F8
F9	F9
F10	F10
F11	F11
F12	F12

Windows	macOS
My Computer	Brightness Down
E-mail	Brightness Up
Windows Search	Mission Control
Browser Home Page	Spotlight Search
Calculator	
Media Player	
Previous Track	Previous Track
Play/Pause	Play/Pause
Next Track	Next Track
Mute	Mute
Volume Down	Volume Down
Volume Up	Volume Up
Home	Home
End	End

Windows	macOS
Pause	Pause
`	`
Print Screen	Print Screen
Brightness Up	Brightness Up
Brightness Down	Brightness Down
Backlight Speed Down	Backlight Speed Down
Backlight Speed Up	Backlight Speed Up
Backlight Effect Switch	Backlight Effect Switch

Windows	macOS
Backlight Switch Color	Backlight Switch Color
Switching RGB LED strip backlight modes	Switching RGB LED strip backlight modes
Switching indicator modes	Switching indicator modes
Scroll Lock	Scroll Lock
Mac Layout	Windows Layout
Win Lock	Cmd Lock
Reset all settings to factory defaults	Reset all settings to factory defaults
Enable keypress force display mode	Enable keypress force display mode

KEYPRESS FORCE DISPLAY MODE

This is a special mode that turns the LED strip into a keypress depth indicator. You can enable it by pressing **FN + G**.

Here's how it works: the deeper (or harder) you press a switch, the more the LED strip fills up in real time.

This mode has two variations:

1. Pressing **FN + G** once enables the basic mode with single-color depth (force) indication.

2. Pressing **FN + G** again switches to the advanced mode with dual-color indication. In this mode, the strip changes color when the switch is activated or released, depending on your chosen actuation settings.

RESET SETTINGS

Want to reset your keyboard to factory settings? Hold FN + DEL for 3 seconds—the light bar will flash three times as confirmation.

IMPORT INFORMATION

Purpose of product: computer accessory
Product name: NK68 HE
Product material: plastic/metal/rubber
Used for: entering information into a personal computer
Please check with your local authorities for shipping regulations before shipping.
Manufacturer:
Nubi LTD, Office 3906, 39th, The Center, 99 Queen's Road, Central, Hong Kong
EU Importer: FS-Holding Ltd. Profit Bas 4, Germasogeia, Limassol, Cyprus, 4046.
E-mail: care@fsgizmos.com. Tel: +35-725-26-01-66
UA Importer: ТОВ "ФС Дистрибюшн" вул. Чавдар Елизавети, будинок 13, НП 394А, 02072, Київ, Україна. E-mail: distribution@fs-d.com.ua. Tel: +38-044-592-4990
The importer is responsible for processing claims from buyers.
Made in China
Date of manufacture: indicated on the package
Serial number: indicated on the package