QUICK REFERENCE CARD

1) Fully unravel cable from winch spool.
2) Using 3/32 Allen key, remove set screw.



3) Remove cable from socket in winch spool.



4) Using the replacement cable, insert the ball end into the spool socket.



5) Insert set screw with 3/32 Allen key until tight.



6) Lightly pull-on winch cable to ensure set screw holds ball end in place.
7) Wind winch until excess cable is spooled.

NOTE: Be aware when handling winch cable for loose threads or rough surfaces.

QUICK REFERENCE CARD

1) Fully unravel cable from winch spool.
2) Using 3/32 Allen key, remove set screw.



3) Remove cable from socket in winch spool.



4) Using the replacement cable, insert the ball end into the spool socket.



5) Insert set screw with 3/32 Allen key until tight.



6) Lightly pull-on winch cable to ensure set screw holds ball end in place.
7) Wind winch until excess cable is spooled.

NOTE: Be aware when handling winch cable for loose threads or rough surfaces.

QUICK REFERENCE CARD

1) Fully unravel cable from winch spool.
2) Using 3/32 Allen key, remove set screw.



3) Remove cable from socket in winch spool.



4) Using the replacement cable, insert the ball end into the spool socket.



5) Insert set screw with 3/32 Allen key until tight.



6) Lightly pull-on winch cable to ensure set screw holds ball end in place.
7) Wind winch until excess cable is spooled.

NOTE: Be aware when handling winch cable for loose threads or rough surfaces.

QUICK REFERENCE CARD

1) Fully unravel cable from winch spool.
2) Using 3/32 Allen key, remove set screw.



3) Remove cable from socket in winch spool.



4) Using the replacement cable, insert the ball end into the spool socket.



5) Insert set screw with 3/32 Allen key until tight.



6) Lightly pull-on winch cable to ensure set screw holds ball end in place.
7) Wind winch until excess cable is spooled.

NOTE: Be aware when handling winch cable for loose threads or rough surfaces.