
LED Steady/Flashing Signal Light

Q60L series



Thank you for purchasing Qlight's products. Please read this user manual carefully prior to installation and operation to ensure safe and correct use.

⚠ Precautions for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.

1. During wiring or maintenance, please completely turn off the Power of the product. (Failure to follow this may lead to an electric shock.)
2. Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

⚠ Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.

1. Please remove any objects that can interrupt ventilation around the product.
2. Please turn off the Power of the product immediately if it fails to operate properly.
3. Carefully wire the product according to each product's specification.
4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
5. Do not apply excessive force/impact to the product.
6. Failure to follow any of the instructions above may cause malfunction or damage to the product, fire, and electric shock.

Ordering Specifications

Q60LP	BZ	12/24	R	QZ18
[Model number]	[Buzzer]	[Voltage]	[Color]	[Mounting option]
• Q60L • Q60LW • Q60LP	• None - No buzzer type • BZ -Built-in buzzer type	• 12 / 24 - DC12V - 24V • 110 / 220 - AC110V - 220V	R-Red A-Amber G-Green B-Blue	• None - Standard type • Mounting type - LB18 - LW18 - SZ18 - QZ18 - SL18 - QL18 - SLB370

Product Specifications

Model number	Voltage	Current	Certificate	Weight	Color
Q60L Q60LW Q60LP	DC12V -24V	Max. 155mA	CE UL	Q60L-0.16kg Q60LW-0.18kg Q60LP-0.30kg (Including buzzer & standard pipe)	R-Red A-Amber G-Green B-Blue
	AC110V -220V	Max. 60mA			

※ UL listed : DC24V

- **Protection rating : IP65**
- **Ambient operating temperature : -30°C to +50°C**


Please scan the QR code for more detailed product information.

www.qlight.com


Dimensions

(Units : mm)


Q60L



Q60LP




Q60LW




Wiring Instructions

DC




AC



- External Power line - UL1015 AWG18(0.75sq) x 2C 400mm.
- This product can be wired regardless of polarity.
- For built-in buzzer type, there is a shared supply line for the buzzer and lighting element.


Parts Definition/ Installation/ Light Function Selection

■ Parts Definition




■ Light Function Selection

• Please refer to the chart below to use light function selection switch located inside the product.



▶ L : Steady



▶ LF : Flashing


• Default function is set at steady LED. Select the desired function for your application during installation.

■ Installation


• First, remove the flange nuts from bolts and place the product through the mounting surface holes.
• Fasten the flange nuts on the opposite side of the mounting surface until the product is tightened securely.

Mounting Hole Specifications

• Machine holes on the mounting surface referring to the diagram below.



Q60L











Q60LW

Installation Environment and Protection Rating

• This product is designed for use with protection rating of IP65.
• If the product is installed in locations that subject it to excessive dust or water other than the designated IP protection rating indicated(IP65), it may cause malfunction or damage to the product.
• In case of outdoor applications, install the product in the upright position. Do not install the product horizontal or upside-down positions where water can potentially penetrate into the product and impact it's operation.
• For further information, please visit our website (www.qlight.com).

Mounting Accessories (Sold Separately)

• Please refer to the dimensions below for installation of mounting brackets.

	Dimensions	
Q60LP	 18mm SCREW & NUT	 LB18
	 LW18	 SZ18
	 QZ18	 SL18
	 QL18	 SLB370


Product installation direction

■ **Install the product in accordance with the manual. Otherwise rainwater or moisture may penetrate into the product.**

· BEACON/SIGNALING LIGHT


※ For products with a protection rating of less than IPX4, please install it vertically.


Power cord inlet part shall not be facing the sky.



· ELECTRONIC SOUNDER/SIGNAL HORN


Sounder part shall not be facing the sky.





· HEAVY-DUTY & EXPLOSION PROOF SIGNALINGS


Sounder part shall not be facing the sky.



· SIGNAL TOWER LIGHTS

※ For products with a protection rating of less than IPX4, please install it vertically.

Power cord inlet part shall not be facing the sky.



MEMO

MEMO

⚠ For your safety

Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement.
The newest product information is available on our website.(www.qlight.com)
Please read the instruction manual attached to the product carefully before installation and use.

Korea Corporation Qlight Co., Ltd. www.qlight.com | trade@qlight.com
Head Office | Suite #1510, STX-V Tower, 128 Gasan Digital 1-ro, Geumcheon-gu, Seoul, 08507, South Korea
Tel: +82-2-2679-6152 Fax: +82-2-2679-6154
Factory(Gimhae Production Headquarters) | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnam-do, 50805, South Korea
Tel: +82-55-328-1111
Overseas Sales Department | Qlight Building, 704 Nakdong-daero, Sasang-gu, Busan 47044, South Korea Tel: +82-51-620-4100
Busan Business Centerr | Qlight Building, 704 Nakdong-daero, Sasang-gu, Busan 47044, South Korea Tel: +82-51-245-0017

China Corporation SHANGHAI Qlight Electronic Co., Ltd. www.qlight.com www.qlightcn.com | qlightcn@qlight.com
Sales Corporation (Shanghai) | Room 333 Building B, No.11, Lane 450, Zhenda Road, Baoshan District, Shanghai, China
Tel: +86-21-6651-7100 Fax: +86-21-6315-3929
Manufacturing Corporation (Qidong) | No.33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China
Tel: +86-513-8384-9999 Fax: +86-513-8384-9910

Qlightec
Innovation in Alarm & Signal

Product Operation Inquiry / Customer Support +82-51-620-4100
You can expect prompt service if you have exact information such as model name, symptom, telephone number and address.
※ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE.
Head office : Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code : 08507)
Factory : 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code : 50805)
www.qlight.com

EN - Q60L - 2608A