Service Bulletin

FAN STOPS WHEN COOLING STOPS

Bulletin No.: 005
Issue Date: June 12, 2026
Models: AHU, Slim Duct (SD), Ceiling Cassette (CC), and Floor/Ceiling Console (FL)
Controller: All XK-06 wired controllers

Equipment Needed

N/A

Tools Required

N/A

Purpose

Configure the unit so the indoor fan stops automatically when the set temperature is reached in Cooling mode.

Procedure

Follow these steps in order on the XK-06 wired controller:

1. **Access the service menu.** From the main menu, scroll to **FOR SERVICEMAN** and press **MENU/OK**.



2. **Enter the password.** At the ACCESS CONFIRMATION screen, enter the service password **1234**.



3. **Open parameters.** From the SERVICE menu, select **SET PARAMETERS** and press **MENU/OK**.



4. **Go to user settings.** Select **FOR USER** from the parameter list.



5. **Adjust the setting.** Scroll to **COOL OVER TEMP FAN** and change the value to **1**.



Expected Result

The indoor fan will stop **40 seconds** after the compressor shuts off, once the programmed set temperature has been reached.