

Chemical Resistance

Information for Use with MPM Construction Sealants

In answer to questions regarding the effects of solvents and industrial chemicals on cured silicone rubber, the following information has been compiled.

Silicones are, in general, chemically inert and are attacked by only a very few common materials; among them are concentrated sulfuric acid, hydrofluoric acid and under longterm exposure, high pressure steam.

Like any elastomer, cured silicone resin has a tendency to physically absorb those materials and, this absorption may cause the rubber to swell and soften slightly. In a few applications, this volume increase is advantageous. For example, a silicone rubber gasket exposed to certain solvents will swell to form a tighter seal.

The change undergone by silicone rubber in contact with an absorbed solvent is primarily physical. After the solvent has completely evaporated, the cured silicone resin will return to its original physical and mechanical properties. To assure complete evaporation a bake-out at elevated temperature may be necessary.

The following table shows RTV's resistance to various common materials. It indicates the volume change, which may be expected from RTV submerged in a chemical or solvent for one week at room temperature. The following definitions for resistance were arbitrarily assigned.

Less than 10% volume change Excellent
10-25% volume change Good
25-75% volume change Fair
Greater than 75% volume change Poor

Materials	Resistance	
ACIDS		
Citric	Excellent	
Hydrochloric, 3%	Fair	
Hydrochloric, Conc	Disintegrates	
Hydrofluoric	Disintegrates	
Phosphoric, dilute	Poor	
Sulfuric, 10%	Poor	
Sulfuric, Conc	Disintegrates	
Tannic	Excellent	
Nitric, Conc	Disintegrates	
Nitric, 7%	Poor	
Acetic, Conc	Good	
Acetic, 5%	Excellent	
BASES		
Ammonium Hydroxide 10	Poor	
Ammonium Hydroxide Conc	Disintegrates	
Potassium Hydroxide	Disintegrates	
Sodium Hydroxide 1%	Excellent	
Sodium Hydroxide 20%	Fair	
Sodium Hydroxide 50%	Poor	
INORGANIC CHEMICALS		
Anhydrous Ammonia	Excellent	
Sodium Chloride, 10%	Excellent	
Hydrogen Peroxide, 3%	Excellent	
Sodium Carbonate, 2%	Excellent	
Sodium Carbonate, 20%	Excellent	
Water	Excellent	
Water (70 Hrs. @212°F)	Excellent	
ORGANIC	CHEMICALS	
Detergents	Excellent	
Freon 12	Good	
Freon 114	Fair	
Methyl Chloride	Fair	
Tricresyl Phosphate	Excellent	



Materials	Resistance	
HYDRAULIC FLUIDS		
MIL-L-7808 (Diester Fluid) 70Hrs @ 212°F	Fair - Good	
Skydrol 500	Fair	
Skydrol 8000	Excellent	
Skydrol8000 (70Hrs. @ 212°F)	Excellent	
Silicate Base	Fair	
OILS		
ASTM #10.1 (Aliphatic), 70Hrs. @ 300°F	Excellent	
ASTM #30.1 (Aromatic), 70 Hrs @ 300°F	Fair	
Castor 0.1	Excellent	
Diester Oils	Good	
Diester Oils (70 Hrs. @ 350°F)	Fair	
Linseed Oil	Excellent	
Mineral Oil	Excellent	
Silicone, SF96 (100)	Excellent	
Silicone, SF96 (100) 70 Hrs @ 300°F	Fair	
Viscasil 60000 CSTKS 10,000-1,000,000	Good - Excellent	
Viscasil 60000 CSTKS (70 Hrs @ 300°F)	Good	
ASTM #10.1 (Aliphatic), 70Hrs. @ 300°F	Excellent	
ASTM #30.1 (Aromatic), 70 Hrs @ 300°F	Fair	
Castor 0.1	Excellent	
Pyranol 1476	Excellent	
Pyranol 1476 (70 Hrs @ 350°F)	Good	
Diester Oils	Good	
Diester Oils (70 Hrs. @ 350°F)	Fair	
Linseed Oil	Excellent	
Mineral Oil	Excellent	

Materials	Resistance	
SOLVENTS		
Acetone	Fair	
Butyl Alcohol	Good	
Carbon Tetrachloride	Poor	
Diacetone Alcohol	Excellent	
Ethyl Alcohol	Excellent	
Gasoline	Poor	
Jet Fuel, JP4	Fair	
Mineral Spirits	Poor	
Toluene	Poor	

siliconesforbuilding.com

