

90" Rack Installation Instructions

Drop-Down Bracket Installation



1. Slide Drop-Down Bracket Over Cross Bar

Align flush with the outside edge, ensuring it doesn't interfere with the van roof.



2. Mark & Drill Crossbar Holes

Use the bracket as a template to drill **two 11/32"** holes through each crossbar.

3. Fasten Bracket to Crossbar

Use **5/16"** hardware and tighten to **20 ft-lbs.**

4. Lower Rack Assembly

Rest the mounting angle on the drop-down brackets.



5. Drill Mounting Angle Holes

Use the bracket as a template, drilling upward with a **13/32"** bit (**one hole per bracket**).

6. Secure Rack to Brackets

Use **3/8"** hardware and tighten to **25 ft-lbs.**

Need assistance?
Contact us!

(856) 347-4001