



1. CUT TO LENGTH ACCORDING TO ROOM HEIGHT (+2" – 4").



2. APPLY THE HEAVY DUTY CLEAR ADHESIVE EVENLY ON THE WALL USING A 3/4" NAP ROLLER (0.66 OZ/SQFT, +/- 10%).



3. PLACE THE WALL COVERING STRIP ON THE WALL VERTICALLY AND SMOOTH IT WITH A PLASTIC SPATULA.



4. PLACE THE ADJACENT STRIP EDGE TO EDGE (RESPECT VERTICAL PATTERN REPEAT). REPEAT STEPS, 1, 2, AND 3, WITH OTHER STRIPS UNTIL YOU HAVE FINISHED THE ROOM.



5. CUT OFF ANY SURPLUS WITH A KNIFE.



6. APPLY A 1ST LAYER OF ACRYLIC PAINT WHEN THE PRODUCT IS DRY. APPLY A 2ND LAYER OF ACRYLIC PAINT WHEN THE PRODUCT IS DRY (+1 DAY)