

TEMPLATE FOR ESG
LBR F10
TS 1100/97/89 Series
VD 98/99 Series

4X $\phi \frac{15}{32}$ "

2X $1\frac{3}{8}$ "

$\phi \frac{3}{4}$

41" to floor
or as required

EXIT DEVICE

2X $3\frac{1}{2}$ "

$4\frac{31}{32}$ "

$\phi \frac{3}{4}$

SEE EXIT DEVICE
INSTRUCTIONS FOR
BACKSET & STRIKE
INFORMATION

RESPONSIBILITY
Door and Frame Manufacturers are
responsible for providing adequate
construction or reinforcements for
proper installation of hardware
shown. All architectural builders
hardware must be installed on
properly reinforced doors and
frames, regardless of the type,
material, or method of construction.

3"

$1\frac{17}{32}$ "

$\frac{9}{16}$ "

$\phi \frac{1}{8}$
WDD DRILL 4
PILOT HOLES
HMD TAP
#8-32
INSIDE ONLY

TEMPLATE SCALE IS 1:1 IF THIS MEASURES 1":

