



FITMENT INSTRUCTIONS

QUICK-EN-SUITE BAG FITMENT

TOOLS REQUIRED:

- 13 Spanner
- Chamfer Tool
- 4 x M6 Bolt (included)

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the Quick-en-Suite bag and unwrap the shower carefully to ensure there are no cuts while unwrapping the bag.
2. Use a chamfering tool to open the four (4) holes on the backbone of the Quick-en-Suite.



Chamfering mounting holes

3. Insert 4 x M6 bolts into the mounting holes on the backbone of the shower bag.

4. Insert these bolts into the mounting brackets or mounting surface.



5. When the bolts are inserted, tighten using a 13 spanner.



6. Enjoy your en-suite privacy.



PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.