



FITMENT INSTRUCTIONS

QUICK-EN-SUITE MAXX

TOOLS REQUIRED:

- 13 Spanner
- Chamfer Tool
- Drill
- 4 x M8 Bolt and Lock Nut

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the Quick-en-Suite Maxx Box and unwrap the shower carefully to ensure there are no cuts while unwrapping the bag.
2. Use a chamfering tool to open the four (4) holes on the backbone of the Quick-en-Suite.
3. Insert 4 x M8 bolts into the mounting holes of the shower box. Thereafter, insert these bolts into the mounting surface or brackets on the vehicle.



Step 2: Chamfering tool



Step 3: Inserting of bolts in mounting holes





4. When all the bolts are inserted, tighten them on the mounting surface, using a 13mm spanner.

Enjoy your en-suite privacy.



PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.