



FITMENT INSTRUCTIONS

ADJUSTABLE LOAD BAR BRACKETS

TOOLS REQUIRED:

- 2x 13 Spanner or 1x 13 Spanner with a 1x 13 Socket
- Straight edge

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Carefully **open** the Adjustable Load Bar brackets. Make sure not to cut the brackets while unwrapping.
2. Use the M8 hex head bolts supplied along with the brackets and slide them into the universal/mounting rail.
3. **Position** the brackets and tighten them in place.
4. Use the (2) two hex bolts on the sides, and adjust the height and angle. (Use a straight edge to ensure the mounting surface is level and aligned.)
5. Once the brackets are set to the correct height and angle, tighten the side bolts securely.
6. You can now proceed to mount your load bars or roof rack.



PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.