



## FITMENT INSTRUCTIONS

### RTT TRAX MOUNT

#### TOOLS REQUIRED:

- 13mm Spanner
- 5 Allen key

#### TO FIT

*Please use the images with the steps as a reference to help you with the fitment.*

1. Open the RTT Trax Mount brackets carefully. Make sure you do not cut the brackets while unwrapping.
2. Take the cup square bolts provided with the bracket and slide them into the tent rail.
3. Align and space the brackets on both sides equally on the rails.
4. When the brackets are aligned, tighten the nut on the top and insert the Max Trax.
5. Use the 5 Allen Key and 13 Spanner to ensure that the clamp arm is on the correct adjustment for the amount of trax wanted and inserted.

(If you want 2 Max trax, put them on the lower hole; if you wish to have 4, use the top hole.)



PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.  
THANK YOU FOR YOUR SUPPORT. WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.