



## FITMENT INSTRUCTIONS

### AWNING TO RHINO RACK BRACKET FITMENT

#### TOOLS REQUIRED:

- Pop rivet gun
- 13mm Spanner

#### TO FIT

*Please use the images with the steps as a reference to help you with the fitment.*

Open the Rhino Rack brackets carefully. Ensure you do not cut the brackets while unwrapping.

**1. Assemble the front bracket:** Use the 4 pieces provided and assemble them correctly with pop rivets.

**NB:** Ensure that the notches depicted in the photo below face the bottom of the bracket.

Front of Bracket



Notches in bracket



Back of Bracket



**2. Insert the flat bracket into the corner back bracket where slots are provided in the back main bracket.**

Back corner bracket



Flat bracket



Slots in bracket

### 3. Fitting the bracket onto the Roof Rack

Using the bracket, slide it over the back corner of the Rhino Rack with the mounting holes facing the side you will be installing the awning on.



Awning  
mounting  
holes

---

**4. Fastening of the brackets:** Once the bracket is in place, fasten the bracket using the bolts provided and a 13mm spanner. When the bracket is fastened, use the small L shape bracket that is left from the main back bracket and fasten it at **Position A** and to the Rhino Rack.



L Shape Bracket



Position A



---

**5. Fitting the front bracket:** Fit the front Rhino Bracket onto the Rhino Rack, as far to the front as possible or to where it lines up with the pre-lasered holes in the awning pan.



---

**6.** Once all the brackets are securely tightened, you can fit the awning.

**7.** Use the awning fitment instructions to fit the awning.

PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.  
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.