

		Name	Frame	Code							
<table border="1"> <tr><td>Seat</td><td>350</td></tr> <tr><td>H</td><td>650 750</td></tr> <tr><td>SWL</td><td>200</td></tr> <tr><td>Wt</td><td>8</td></tr> </table>	Seat	350	H	650 750	SWL	200	Wt	8	<b>Bolt Down Stool</b> Upholstered Seat Footrest	S/Steel	KMSTBDFOOT
	Seat	350									
	H	650 750									
	SWL	200									
Wt	8										
P/Coat	KMSTBDFOOT										
<b>Bolt Down Stool</b> Upholstered Seat No footrest	S/Steel	KMSTBD									
	P/Coat	KMSTBD									
<table border="1"> <tr><td>Seat</td><td>350</td></tr> <tr><td>H</td><td>650 750</td></tr> <tr><td>SWL</td><td>200</td></tr> <tr><td>Wt</td><td>8</td></tr> </table>	Seat	350	H	650 750	SWL	200	Wt	8	<b>Post only (no footrest)</b> <b>With cover - to cover bolt holes</b>	S/Steel	KMSTCOVER
	Seat	350									
	H	650 750									
SWL	200										
Wt	8										
P/Coat	KMSTCOVER										
With swivel seat mechanism											