

Tile-to-Tile Joints Over the Primary Vent

Per the Coronado Vent published installation instructions, if the row of tile is installed at least up to the edge of the Primary Vent hole, then the Coronado Secondary Vent (Flat or S) is installed, there will not be a tile-to-tile joint over the primary vent. However, if this condition is unavoidable, follow these instructions:

****Note - depending on the condition, warranty may or may not apply. The following is just a best practice situation.**

Apply a solid bead of polyurethane caulking on the bottom interlocking tile joint for the entire length of the joint. Then install / engage the next piece of tile, embedding the top tile into leg into the caulking. For extra precaution, you can apply another bead of caulking over the joint, however it is recommended that the caulking color be similar to that of the tile.

How to Install



coronadovents.com

Contact

info@coronadovents.com
Proudly made in Phoenix, AZ

© 2025 CORONADO VENTS™.
ALL RIGHTS RESERVED.

