

Procella Audio User Guide P21Si



Welcome to the world of perfected sound!
Thank you for choosing a Procella Audio loudspeaker system.

For optimal performance, we advise having your Procella loudspeakers installed and fine-tuned by a certified Procella Audio technician. For expert guidance on positioning your speakers perfectly within your space, please reach out to your authorized dealer or directly to Procella Audio. Let's ensure your audio experience is nothing short of extraordinary.

Package contents:

- Procella Audio P21Si subwoofer
- Grille
- 4x Vibration insulating feet
- This User Guide

External amplification and a DSP is required for operation of the P21Si. The P21Si is intended to be used with a Procella DA08-DSP a four channel professional power amplifier in Single or Bridged Mode. If you do not intend to use a DA08-DSP amplifier, please contact your dealer or Procella Audio for advice on external DSP settings.

INSTALLATION PROCEDURE

1. If no other instructions have been provided, when installing a single Procella P21Si subwoofer, it should be positioned on the floor, against a wall or built in into a wall or Baffle wall.
2. When installing a P21Si it is recommended that it is positioned below the screen, but not on the center line of the room.
3. For installation behind a screen, hidden behind acoustically transparent fabric, or in any case where the front of the loudspeaker is not visible, the cloth frame should be left off.
4. Position the four enclosed soft vibration insulating feet evenly under the enclosure.
5. Make sure the enclosure does not touch any other surfaces.

TIPS

- The subwoofer inputs are located on the left side of the cabinet. One pair of binding posts are provided and should be connected directly to the amplifier outputs.
- One set of speaker cable from the amplifier is required. The cable should be connected to one set of binding posts (one red, one black). This provides a 8 ohm load to the amplifier. Always make sure that there are no short circuits between the cables.
- For cable runs up to 12m (40 feet) from the amplifier, use minimum 2.5mm² /AWG14 cable.
- For cable runs up to 25m (80 feet) from the amplifier, use minimum 4mm² /AWG12 cable.
- The RED terminal is positive (+) and gives a forward cone movement.

The P21Si needs a break-in period of at least 24h at a SPL in excess of 75dB

Procella Audio BV Registered office and Factory address:
Rivaweg 1.02 | B-8720 Dentergem | Belgium

www.procella.audio
contact@procella.audio
+32 56 13 62 08