

# HOW TO HAND WRAP PALLETS WITH AIRFLOW



## TO START:

- **Knot** film before starting.
- **Tuck** film under corner.
- **Wrap with inner surface** of film against the product for best cling.
- **Stretch** film before each corner.

## WRAPPING: DO NOT OVERWRAP

AirFlow vented stretch film is ultra strong with superior holding force vs. traditional stretch films. Reinforced bands provide strength requiring only a 10% overlap allowing for maximum air flow. Over wrapping wastes film, labour and money.



## FINISHING PALLET:



Bunch film and cut with film cutter.



Tuck film into the edge of previous layer or under a corner.



Knot film for easy start next load.