



Liquid Tube Installation

1. Slightly bend the hose clamp as shown, then open it to fit over the fertilizer tube



2. Ensure the clamp is oriented as shown in the picture below



3. Tighten the clamp in the position shown below, this will draw the 1/4" tube toward the base of the casting



4. The picture below shows the tube correctly installed. 1/2" above the bottom of the casting



306-242-4955

<mailto:sales@pillarag.com>

Pillarag.com