



STARLINK FLAT HIGH PERFORMANCE

Instruction Guide

GEN 2 1

STARLINK FLAT HIGH PERFORMANCE

Table of Contents

Disclaimer.....	3
Starlink Antenna Setup Instructions.....	4

STARLINK FLAT HIGH PERFORMANCE

Disclaimer



Starlink cables only fit one way and only into the components they are designed for.

Forceful use and attempting to plug into the wrong ports may cause damage and will not be covered under warranty.

STARLINK FLAT HIGH PERFORMANCE

Starlink Antenna Setup Instructions

- Step 1** Lay out in unobstructed area with clear visibility to sky.
- Step 2** Connect Antenna to Power Supply via 25m Antenna cable.
- Step 3** Connect AC Power cable to power supply and connect to power source.
- Step 4** Connect Starlink Ethernet cable into the power supply and connect the other end to the Peplink WAN port.
- Step 5** Connect Peplink power supply to AC Power source.
- Step 6** If desired attach Wi-Fi antennas to Peplink router for Wi-Fi Access.
- Step 7** Once everything is powered on, connectivity should be available automatically within a few minutes.

Contact Peake Support
for configuration assistance, if required.

 1-800-719-4603
 support@peake.com

