



Hanging Oslo vertical yarn wallcoverings

This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 750003.

Occasional imperfections in yarn and weave are a natural characteristic of textile wallcoverings

- | Prepare the wall surface such that it is normally absorbent.
- | Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- | Cut and mark individual drop lengths in sequence as taken from the roll.
- | Paste the paper with an undiluted ready-mixed PVA wallcovering adhesive (e.g. Albany Speciality Wallcovering Adhesive (red top)) and leave for at least 3 minutes. (Do not use Solvite Red Top – it is not strong enough).
- | Once pasted, tear a 1cm strip of yarns at right angles to the drop along its entire length. The tear will follow the threads and remain straight. Smooth back any irregular backing paper that remains by running a flat hand along the edge of the drop where torn.

If in any doubt call us and we can supply an instructional video.

- | Straight hang the drops in sequence. Trim at skirting and ceiling. Butt join the torn edges taking care not to apply too much pressure.
- | Do not get adhesive onto the face of the wallcovering as it cannot be wiped off.
- | After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice.

STEREO
5 Bells Yew Green Business Centre, TN3 9BJ
Telephone: 01892 750003

stereo@stereointeriors.co.uk
 www.stereointeriors.co.uk