



Hanging Touch suede wallcoverings

This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 750003.

- | Prepare the wall surface such that it is normally absorbent.
- | Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- | Starting with highest numbered roll, cut and mark individual drop lengths in sequence as taken from the roll.
- | Paste the wall with an undiluted ready-mixed PVA wallcovering adhesive (e.g. Albany Speciality Wallcovering Adhesive (red top)) Do not use Solvite Red Top – it is not strong enough.
- | **Straight hang the drops in sequence.** Trim at skirting and ceiling. Butt join the seams.
- | Do not get adhesive onto the face of the wallcovering as it cannot be wiped off.
- | After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice.
- | **Once the material has been installed, use a soft brush to gently brush the nap in the same direction to create an even appearance.**

STEREO
5 Bells Yew Green Business Centre, TN3 9BJ
Telephone: 01892 750003

stereo@stereointeriors.co.uk

www.stereointeriors.co.uk