



Hanging Sumatra raffia wallcovering

This product should be hung by a professional paper hanger with experience of hanging textile wallcoverings. If you would like us to recommend someone, contact us on 01892 750003.

Occasional imperfections in yarn and weave are a natural characteristic of textile wallcoverings

- | Prepare the wall surface such that it is normally absorbent.
- | Ensure that the walls are a similar colour to the wallcovering, particularly where it will make a joint.
- | Cut and mark individual drop lengths in sequence as taken from the roll.
- | Bench trim a **minimum of 5cm** from the edge of each drop. (Alternatively, overlap and trim 5cm on the wall).
- | Damp the back of the material and allow to rest for at least 3 minutes.
- | Paste the wall with an undiluted ready-mixed PVA wallcovering adhesive (e.g. Albany Speciality Wallcovering Adhesive (red top)). Do not use Solvite Red Top – it is not strong enough.
- | Hang the drops in sequence. Trim at skirting and ceiling. Butt join bench trimmed material or overlap and trim if not previously trimmed.
- | Do not get adhesive onto the face of the wallcovering as it cannot be wiped off.
- | After hanging 3 drops inspect the wallcovering to ensure you are happy with the results. If you have any doubts, stop hanging and contact us for advice.

STEREO
5 Bells Yew Green Business Centre, TN3 9BJ
Telephone: 01892 750003

stereo@stereointeriors.co.uk