

# **BRICKMOLD DOOR**

## **INSTALLATION INSTRUCTIONS**



**IMPORTANT:**  
PLEASE READ BEFORE  
CONTINUING!

**IT IS HIGHLY RECOMMENDED FOR ALL BRICKMOLD DOORS TO BE INSTALLED WITH A PAN!** A pan is a waterproof tray that is placed under an exterior door with brickmold trim to channel any water that seeps past the door seal outside, protecting the home's walls from mold and rot.

**PANS ARE REQUIRED TO BE USED WITH ANY BRICKMOLD DOORS THAT DO NOT HAVE A STORM DOOR OR ELSE THEIR WARRANTY WILL BE VOIDED.**

Please refer to the "Brickmold Pan Installation Instructions" document for further information on installing a pan.

1. **Verify that the rough opening is the correct size for the door.** The opening must be level, with the corners as close to 90 degrees as possible to ensure squareness of the rough opening. The studs must be plumb (perfectly vertical).

**\*\* ALL CONDITIONS LISTED IN STEP ONE MUST BE MET before continuing any further with the installation process. \*\***

2. Hold the door unit by its sides and lift it; **insert the unit into the opening with the door sill first, then tilt it into position until the sill rests securely on the floor.** Shim as needed between the jamb and the stud.

3. **Visually check that the unit is square within the opening.** Ensure it is centered from side to side, with equal spacing between the studs and the jambs. The door sill must sit flat on the floor. Verify that the door itself is square within the jamb frame. Shim as needed between the jamb and the stud.

4. **Temporarily secure the door by placing a screw through the side jambs into the studs.** Ensure that the door is square within the opening, with the corners as close to 90 degrees as possible. **Once aligned, install three screws into each jamb.**

5. **Adjust the door sill as necessary to ensure the unit is level and properly seated.** After making this adjustment, if necessary, the installation process is complete.

LAST UPDATED: August 28, 2025