

**Installation Instructions for
ELIXIR IW DRIP CAP**

1. Apply putty tape on the backside of the 1-1/4" lip of the drip cap. This will be the side that makes contact with the home exterior. See picture "C".
2. Apply putty tape around the perimeter (all four sides) of the door frame to seal between frame and home exterior.
3. Position the drip cap on top of the door frame with the 1-1/4" side facing the door opening (color side out). Drip Cap must be even with the outer frame edge when using a "Vinyl J Channel". See pictures "A", "B" and "C".
4. Screw the door frame to the door opening. Recommend using #8 X 1 1/2" Pan Head Screws.
5. Caulk across the drip cap where the drip cap meets the wall of the home. See pictures "A" and "B".
6. Ensure the drip cap is bent down away from house to channel water away. See picture "B".

