



INSTALLATION INSTRUCTIONS

01

Always install Overwrap logo side up.

02

Estimate how much material is required to cover the protected areas.

03

Ensure the surface to be covered is clean – free of dirt, dust and debris.

04

Roll out the Overwrap and cut to the desired length

05

Overlap material at roll edges using the blue registration lines/marks on the roll for best performance.

06

Tape the seams with a minimum of 2 inch wide breathable tape. For best results it is recommended that the entire length of seams be taped.

07

Adhere the Overwrap outside edges to floor and/or surrounding surfaces, using tape with non-transferable adhesive – painter tape or equivalent.

08

Always test the tape adherence/adhesive transfer on site prior to installation.

09

Overwrap is 100% recyclable and can be re-used as suitable.

[Learn more at overwrap.net](http://overwrap.net)

USE AND HANDLING

- Light weight helps reduce installer body strain.
- Will not tear, curl or recoil, lays flat – unlike paper and chipboard products.
- Prevent discoloration of flooring substrates/covering by always using breathable seam tape.
- Temporary protection affords a window of opportunity to clear spills. Remove excessive surface contaminants in a timely manner to prevent damage to protected surfaces.

overwrap.net

Surface Performance Solutions
800 West 5th Ave / Suite 212
Naperville IL 60563