

KIT # 1934

INSTALLATION INSTRUCTIONS

For installing ROSS-TEMP Model RC-306-UF cuber on Remcor Model TW200/TJ200 dispenser.

- 1.) Seal icemaker to top of dispenser as follows:
  - a.) Run a bead of RTV on the dispenser cover around the outline of the spacer and inside edge of cover opening.
  - b.) Set spacer onto cover and position as shown.
  - c.) Run a bead of RTV on the spacer around the outline of the icemaker and inside edge of spacer opening.
  - d.) Set icemaker onto spacer and position as shown.
  - e.) Wipe away excess RTV.
- 2.) Fasten brackets as shown. Drill holes and install sheet metal screws provided into icemaker and dispenser cover.
- 3.) Follow the manufacturers instructions to complete the installation of the icemaker.

FIG 1

FRONT

ROSS-TEMP ICEMAKER  
MODEL RC-306-UF

SPACER

1" ICEMAKER OVER-HANG  
AT REAR OF DISPENSER

BRACKET  
(2)

MOUNTING SCREW  
(8)

$3\frac{3}{4}$

TJ250 DISPENSER  
REAR VIEW

