

KIT 2006

Installation Instructions
Scotsman CM650 IceMaker/Remcor TJ400 Dispenser

Use Fig. 1 as a guide for the following installation procedure:

1. Locate and drill holes into the dispenser cabinet for mounting the rear icemaker bracket.
2. Locate the outline of the icemaker base on the dispenser cover and rear bracket. Run a bead of RTV along this outline and set the icemaker on the dispenser. Wipe away excess RTV.
3. Install the adhesive-backed gasket strips on the (2) lids.
4. Locate lids on the dispenser cover and drill mounting holes into the cover.
5. Follow the manufacturers' instructions to complete the installation of the icemaker.

909570
2 of 2

