

KIT #2125

Installation Instructions

For installing Scotsman model CM500 cuber on a REMCOR® Model TJ300 dispenser.

1. Seal icemaker to top of dispenser as follows: (See Page 2)
 - A. Run a bead of RTV on the dispenser cover around the outline of the icemaker and inside edge of cover opening.
 - B. Set icemaker onto cover and position as shown.
 - C. Wipe away excess RTV.
2. Using the brackets as templates, locate and secure as shown. Drill holes and install sheet metal screws provided into icemaker and dispenser cabinet.
3. Follow the manufacturers instructions to complete the installation of the icemaker.

FIG. 1

