

REMCOR

Kit #8047
Installation Instructions

Instructions to convert from six (6) Concession Valves to six (6) Dole Valves

<u>PART LIST:</u>	<u>QTY.</u>	<u>DESCRIPTION</u>
40730	6	Dole Valves - PB
40439	12	Beverage Fittings
40407	6	S-clamp
70204	6	S-clamp Screw
52792	300"	Tubing
50249	480"	Insulation
50016	100	Prestite
40502	24	Oterker Clamps
31827	6	Connector Assy.
70015	24	Nut
40408	24	1 1/4 Screw
92276	1	Instruction Sheet

TOOLS NEEDED:

Philip Screwdriver
Slotted Screwdriver
Knife or cutters
Crimping tool for clamps

INSTRUCTIONS:

1. Disconnect power.
2. Remove 6 concessions valves from lower panel.
3. Remove beverage fittings and beverage tubing from carbonator water manifold.
4. Add new beverage tubing approx. 3 inches to manifold.
5. Add beverage valve fittings and beverage valves.
6. Insulate beverage lines and fittings to prevent condensation.

92276 ~~(10)~~
0496
REN B