

# REMCOR PRODUCTS COMPANY

500 Regency Drive

Glendale Heights, IL. 60139

Telephone: (708) 539-6850

## Installation Instructions

1. Turn off water, CO<sub>2</sub>, and electrical power to carbonator.
2. Bleed off beverage valves.
3. Disconnect electrical power to dispenser.
4. Remove beverage valves and mounting block from panel.
5. Remove splash and beverage panels.
6. Remove all fittings from the beverage panel, use markers to identify tubing, and replace in new panel, for proper flavor line-up. No tubing changes have to be made.
7. Reconnect all 24 V. harness, and beverage valves to panel.
8. Fasten panels to dispenser.
9. Connect syrup and plain water to tubing from valves #5 and 6.
10. Reconnect water, CO<sub>2</sub>, and electrical power to carbonator.
11. Brix valves.
12. Unit is now ready for operation.