

# MIKROSKIN™

## INSTALLATION GUIDE

---

**MIKROSKIN™** is a flexible architectural surface wrap system designed for low-demolition interior transformations and architectural resurfacing applications. This guide outlines the recommended installation procedures for cabinetry, splashbacks and approved interior surfaces.

## TOOLS & MATERIALS REQUIRED

---

- MikroSkin™ sheets
- Pressure-sensitive adhesive
- 4mm nap roller
- Sharp utility knife
- Measuring tape
- Straight edge
- Microfibre cloths
- Sandpaper (where required)
- Surface cleaning products

## APPROVED SUBSTRATES

---

MikroSkin™ may be installed over properly prepared:

- Laminate cabinetry
- MDF joinery panels
- Existing tiled splashbacks
- Painted plasterboard
- Stable interior wall surfaces

Substrates must be:

- Structurally stable
- Dry and clean
- Properly fixed
- Free from movement and contamination

## IMPORTANT TILE PREPARATION NOTICE

---

Tiles intended for MikroSkin™ application should be properly rectified and grout joints flush-filled prior to installation. Tile lippage, uneven grout lines or poorly laid substrates may telegraph through the finished surface and negatively affect final finish quality. MikroSkin™ is not intended to conceal significant substrate irregularities or movement.

## **SURFACE PREPARATION**

---

1. Clean all surfaces thoroughly.
2. Remove grease, contaminants and loose material.
3. Sand glossy substrates where required.
4. Rectify and fill imperfections flush.
5. Ensure substrate is dry and stable prior to installation.

## **ADHESIVE APPLICATION**

---

Apply approved pressure-sensitive adhesive evenly using a 4mm nap roller. Avoid excessive adhesive build-up. Allow adhesive to become tacky before positioning MikroSkin™ sheets. Always follow adhesive manufacturer recommendations regarding application and open times.

## **SHEET POSITIONING**

---

Carefully align MikroSkin™ prior to applying pressure. Work gradually to minimise trapped air and ensure even adhesion. Maintain consistent pressure across the sheet surface during installation. Avoid overstretching or creasing the material during handling.

## **CUTTING & DETAILING**

---

Use sharp blades and clean straight edges when trimming. Replace blades regularly to maintain clean cuts. Detailed areas, edges and internal corners should be approached carefully to minimise stress on the material.

## **SURFACE ORIENTATION NOTICE**

---

MikroSkin™ is primarily designed for installation using the approved matte architectural surface orientation. Use of polished or non-standard surface orientations may alter:

- Surface durability
- Sealer compatibility
- Long-term maintenance performance
- Visual consistency

Non-standard surface orientations may fall outside standard MikroSkin™ recommendations or warranty provisions.

## POST INSTALLATION

---

After installation:

- Avoid excessive cleaning immediately after application.
- Avoid concentrated heat exposure.
- Inspect edges and detailing thoroughly.
- Allow adhesive systems to stabilise in accordance with manufacturer recommendations.

## CARE & MAINTENANCE

---

For ongoing maintenance:

- Clean using non-abrasive cleaners.
- Avoid harsh chemical products.
- Use soft microfibre cloths.
- Avoid aggressive scrubbing or abrasive pads.

## IMPORTANT NOTICE

---

MikroSkin™ is a decorative architectural surface system and relies entirely on the quality, stability and preparation of the underlying substrate. Substrate suitability and installation practices remain the responsibility of the installer. MikroSkin™ is not intended to rectify structural movement, framing deficiencies, tile lippage or poor workmanship by prior trades.

---

**MIKROSKIN™**

Surface Transformation. Simplified.

[mikroskin.com.au](https://mikroskin.com.au)