

Emergency power supply connection diagram of
SZ-CNP100/80/60WR-H-ACP and SZ-CNP100/80/60W-H-ACP

When Connect emergency power supply
connects input wires like below

When connecting to emergency power,
connect the output terminal to this part.

