


APEVIA



USER'S MANUAL

— AERO RGB COOLING FAN —


Daisy-Chain
Design


High Airflow
Performance


Quiet
Operation


Safe &
Reliable

FAN SERIES CONNECTION GUIDE


— Connection Method & Interface Indication —

- 1 Connect the **5V 3PIN** male and female connectors between the fans in series.
- 2 Connect the **PWM 4PIN** male and female connectors between the fans in series.
- 3 Connect the **5V 3PIN** female connector to the motherboard's **5V 3PIN** interface.
- 4 Connect the **PWM 4PIN** female connector to the motherboard's **SYS_FAN** or **CHA_FAN** interface.



Plug into the correct port and operate with power off to avoid short circuits and burns!

Connect to Motherboard
5V 3PIN Interface



Connect to Motherboard
SYS_FAN or **CHA_FAN**
Interface



i The **5V 3PIN** male connector of the last fan and the **PWM 4PIN** male connector do not need to be connected.



Connect all fans in series as shown.
This diagram applies to both 4-Pack and 6-Pack configurations.