

Emergency power supply connection diagram of SZ-LSXW-XFT-ACP

When Connect emergency power supply
connects input wires like below

When connecting to emergency power,
connect the output terminal to this part.

