

Product Code

711411

Name

Passive holder with tilt swivel for Zebra EM45

Description

Product Details

Keep your unit in a passive holder and you will always have it within easy sight and reach! Neat, discreet and convenient. Custom made with a perfect, firm fit. You have full access to the camera and all buttons and outlets when the device is in the holder. You can connect a charging cable or portable handsfree to the device when it is in the holder.

The holder is equipped with a tilt swivel so you can easily adjust the angle for better viewing, or switch between portrait and landscape mode. Tilts 17° and swivels 360°. Mounting plate 42x50 mm with 4 mm AMPS-holes. Made of high grade black ABS/Acetal plastic. Color: black. Made in Sweden. Attach onto a ProClip Mounting Platform or a Pedestal Mount.

Installation Instructions

Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.
2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.
3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the holder is firmly in place, but still can be adjusted.
4. The holder is in place.





[View Product Online](#)

