


HT730 Plus Series 4-Slot Cradle Series (Ethernet & Charging)

-Support HT730 Plus & HT730 Plus UHF-



Quick Start Guide

V1.3

► Package

Please make sure the following contents are in the HT730 Plus 4-Slot Cradle gift box. If something is missing or damaged, please contact your Unitech representative.

► The Package Contents

- HT730 Plus 4-Slot Charging Cradle / HT730 Plus 4-Slot Ethernet Cradle
- Power Supply (12V / 5A) without power cord

► Optional Accessories





- US Power Cord
- EU Power Cord
- UK Power Cord

► Getting Started

There are two options to charge HT730 Plus / HT730 Plus UHF:


1. Charge the device w/o the bumper case on
2. Charge the device with the bumper case after removing the detachable cover.

► Product View Comparison of Different Four Slot Cradles

Models	Front View	Rear View
Four Slot Cradle (Charge Only)	 Detachable Part Power LED	 • Charging terminal via DC jack
Four Slot Ethernet Cradle	 Ethernet LED (4-Slot Ethernet Cradle Only)	 LAN Port WAN Port Power Port • LAN Port: Used for connecting to a 4-Slot Cradle • WAN Port: Used for connecting to an Ethernet hub • Power Port: Used for connecting to a power adapter

► How to Remove the Detachable Part

Use your thumb to press against both ends of the detachable part and remove it upwards.



► Checking the LED status

1. 4-Slot Terminal Charging Cradle

Power LED	Description
Red Light	Cradle Power On
LED Off	Cradle Power Off

2. 4-Slot Ethernet Cradle


Power LED	Description
Red Light	Cradle Power On
LED Off	Cradle Power Off
Ethernet LED	Description
Blue Light & Red Light Blinking	Ethernet Communication

Note:

For charging status of the HT730 Plus / HT730 Plus UHF is on itself.

► Charging the Devices

We highly recommend using the adapter provided in the HT730 Plus 4-Slot Cradle package.



CAUTION!

To ensure the unit working properly, please keep all connectors away from the contaminants such as dust, grease, mud, and water. Negligence may cause the unit to lose communication, short circuit, or overheated. If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid short circuit.

DO charge between 20% and 80% to protect your battery.
Avoid full discharges (<0%) or charging all the time (always 100%) to reduce stress on the battery.

WARNING!

There is a risk of fire and burns if the battery is handled improperly.
DO NOT disassemble, crush, puncture, short external contacts, or dispose the battery pack in fire or water.

EU Importer: Unique Technology Europe B.V.
Kapitein Hatterasstraat 19, 5015 BB, Tilburg, the Netherlands

