













How to Calibrate EC

- 1) Press and hold **ENTER** for 3 seconds
- 2) **CAL** option will flash, press **ENTER**
- 3) Press   to select **MANUAL CAL**
- 4) Press 
- 5) Enter password:    
- 6) Release any water in the lines through hose bibb, unscrew sensor, place in 2.77 calibration solution and swirl vigorously
- 7) Wait for a stable EC to appear. If 2.77 appears, sensor is calibrated. If not:
Press  to select a digit
Press  or  to change a digit
Change to 2.7700, then press **ENTER**



HAND TIGHTEN ONLY!

TO GO BACK IN MENU PRESS
SIMULTANEOUSLY



VIEW THE FULL USER MANUAL AT:

.....
<https://www.rhythmcss.com/handbook>
Password: **afs2029**