





To join sofas, align alignment pins and fasten sofas using a 5/16-18 x 2-1/2" bolt with two large washers at each end.



Align the hook from the screen to the slot in the back of the sofa. You should feel it snap onto the pin located inside the sofa.



Align the bottom mounting bracket of the sofa, with the plate located on the bottom of the screen. Attach the screen to the sofa with two $1/4-20 \times 3/4$ " bolts.

